



Every part matters

EN

RS Pro DIN Rail Controller Concise Manual


1. INSTALLATION

Installation Guidance

- Installation should only be performed by technically competent personnel. Standards compliance shall not be impaired when fitting into the final installation. It is the responsibility of the installing engineer to ensure that the configuration is safe. Local regulations regarding the electrical installation & safety must be observed. Impairment of protection will occur if the product is used in a manner not specified by the manufacturer. Due to the low weight of this instrument there are no special lifting or carrying considerations. Designed to offer a minimum of Basic Insulation only. Ensure that supplementary insulation suitable for Installation Category II is achieved when fully installed. To avoid possible hazards, accessible conductive parts of the final installation should be protectively earthed in accordance with EN61010 for Class 1 equipment. Output wiring should be within a Protectively Earthed cabinet. Sensor sheaths should be bonded to protective earth or not be accessible. Live parts should not be accessible without the use of a tool. When fitted to the final installation, an IEC/CSA APPROVED disconnecting device should be used to disconnect both LINE and NEUTRAL conductors simultaneously. Do not position the equipment so that it is difficult to operate the disconnecting device. Ventilation slots must not be covered and adequate air circulation must be allowed. Use conductor sizes 30-12 AWG, minimum temp rating of cables to be 80c.




Bus Connector (optional) Mounting & Unmounting



Terminal Wiring

CAUTION: Check information label on housing for correct operating voltage before connecting supply to Power Inputs. Diagrams show all possible option combinations, check your exact product specification before connecting.



\* NEVER DIRECTLY CONNECT DEDICATED CONFIGURATION SOCKET TO A USB PORT.


2. FRONT PANEL

Front panel controls including Up/Down buttons, Select, and a display showing PV 25 °C and SP 37. Includes text: 'Display turns off after 5, 15 or 30 minutes without key presses.' and 'LEDs show respective output state: 1 2 3'.

Navigation & Editing

Press [Up] or [Down] keys to navigate between parameters or menu items. Press [Select] to highlight and edit a parameter value. Press [Select] or [Down] to change the parameter value, then press [Select] within 60 seconds to confirm change.

For example, changing the setpoint (SP).



Navigating to Setup Mode or Advance Configuration from Operator Mode:

- Setup Mode - press [Select] & [Down]
- Advanced Configuration - press [Select] & [Up]

Returning to Operator Mode:

Press [Select] & [Down] to move back one level. After 120 seconds without key presses the unit returns automatically to the first Operator Mode screen.

3. SETUP (& FIRST POWER UP)

Important Note: When powered up for the first time, or after a factory reset (default) the instrument enters Setup. The device remains in Setup, or will keep powering up back into Setup, until all parameters have been reviewed and the user exits Setup.

Some parameters may be hidden depending on configuration & hardware. Alternatively press [Select] & [Down] to enter Setup from Operator mode and [Select] & [Up] to exit.

Table with 3 columns: Setup Lock, Enter code & press [Select], Default 10

Parameter list table with columns: Parameter, Description, Default Value. Includes J, K, PT100, B, C, L, N, R, S, T Thermocouple and Linear dc options.

>Input Units °C or °F (hidden when a linear input is used) °C

>Input Decimal Place 0000 \* 000.0 \* 00.00 0.000

Scale Range max & min only visible when input is a linear type.

>Input Scale Range Maximum Maximum for application working range. 1000

>Input Scale Range Minimum Minimum for application working range. 0

>Input Digital I/P Action None Alarm Reset (clears latched alarms) Ctrl Enable/Disable (disables control) Ctrl Auto/Manual Pre-Tune Start/Stop Tune at SP Start/Stop

>Output 1 Usage Heat Cool Alarm 1 Alarm 2 Alm. 1or2 Loop Alarm

Control Loop Alarm time is 2x Integral (PID) or Loop Alarm Time (if mode is On.Off)

>Output 2 Usage Same options as Output 1 Usage Alarm 1

>Output 3 Usage Same options as Output 1 Usage Alarm 2

>Linear Out Usage Heat Cool PV Retx SP Retx

>Linear Out Type 0-10V 2-10V 0-20mA 4-20mA 0-5V 1-5V

Table with 3 columns: Parameter, Description, Default Value. Includes Linear Out Scale Range, Alarm 1 Value, Alarm 2 Value, Setpoint, Coms Unit Address, Coms Baud Rate, Coms Parity, and Control Automatic Tuning.

4. OPERATOR MODE

Table with 3 columns: Name, Details. Includes User Screen, Manual control, Transmitter view enabled, Alarm State, and Latch State.

Important: Visibility for parameters below must be set to Show in Operator sub-menu.

Table with 3 columns: Name, Details. Includes Alarm State and Latch State.

>Input Units To clear press [Select] then [Down] to select Yes. Press [Select] to accept. Screens show the Maximum & Minimum PV reached.

>Input Control Enable OFF - Control output(s) disabled. (Ignored when in manual mode). ON - Control output(s) enabled.

>Input Manual Control Enable OFF - Automatic control, PID or On-Off control available. ON - Manual control, Manual Power shown as P% xxx.

>Input Time On Remaining On Timer Visible when On Timer is active. See Ramp & Timers diagram.

>Input Delay Time Remaining Delay Timer Visible when Delay Timer is active. See Ramp & Timers diagram.

Warnings & Error Messages

Caution: Do not continue your process until any issues are resolved.

Table with 3 columns: Name, Details. Includes Pop up Alerts: Warnings and Confirmations, Alarm 1, and Pop up Alerts: Alarm 1, Alarm 2, Alarm 1 & 2, Starting Calibration, Calibration Ongoing, Calibration Fail, Control is Enabled, Tune Error messages, Tuning in progress, Setup not Completed & Offset in use (SP offset).

Table with 3 columns: Name, Details. Includes ALARM, LATCH, HIGH, LOW, OPEN, ERROR, TUNE, P%, Ramp, OFF, Control Delayed, and Tuning in progress.

Table with 3 columns: Tune Errors, Details. Includes tErr1 through tErr8 with corresponding error descriptions like 'PV within 5% of SP', 'Setpoint is ramping', 'Control is ON/OFF', etc.

5. SPECIFICATIONS

Important: Check your product code for exact hardware fitted.

PROCESS INPUT

Thermocouple Calibration: ±0.25% of full range, ±1LSD & ±1°C for Thermocouple CJC. BS4937, NBS125 & IEC584. PT100 Calibration: ±0.25% of full range, ±1LSD. BS1904 & DIN43760 (0.00385Ω/°C).

DC Calibration: ±0.25% of full range, ±1LSD.

Sampling Rate: 4 per second. Impedance: >1MΩ resistive, except dc mA (5Ω) and V (47kΩ)

Sensor Break Detection: Thermocouple, RTD, 4 to 20mA, 10 to 50mV, 2 to 10V and 1 to 5V ranges only. Control outputs turn off at sensor break.

DIGITAL INPUT (Isolated or Non-Isolated version)

Functions: Reset Alarm, Control Enable/Disable, Auto/Manual, Pre-Tune Start/Stop or Tune at SP Start/Stop.

Signal: Non-isolated - Open or Close only. Isolated - Open (2 to 24Vdc) or Closed (<0.8Vdc). Closed to Open transition = Reset, Enabled, Auto or Start.

OUTPUTS

Relay Contacts: Form C SPDT (Op 1) / Form A SPST relay (other), 2A @ 250Vac.

Relay Lifetime: >150,000 operations at rated voltage/current, resistive load.

SSR Driver Capability: SSR drive voltage >10V at 20mA

Output 3 option only: DC (Linear)

Types: 0 to 20mA, 4 to 20mA, 0 to 5V, 0 to 10V or 2 to 10V

Load Resistance: Current Output 500Ω max, Voltage Output 500Ω min.

Resolution: 8 bits in 250ms (10 bits in 1s typical, >10 bits in >1s typical).

RS485 SERIAL COMMUNICATIONS (Modbus RTU)

Data Rate: 1200, 2400, 4800, 9600, 19200 or 38400 bps.

OPERATING CONDITIONS

Usage: For indoor use only, DIN-rail mounted in suitable enclosure.

Ambient Temp: <95% humidity 0°C to 55°C (Operating), -10°C to 80°C (Storage).

Relative Humidity: 20% to 95% non-condensing.

Altitude: < 2000m

Power Supply: Mains power version - 100 to 240Vac ±10%, 50/60Hz, 9VA Low voltage version - 24Vac +10/-15% 50/60Hz 9VA or 24Vdc +10/-15% 5W.

ENVIRONMENTAL

Standards: CE, UL & cUL.

EMI: EN61326-1:2013, Table 2 & Class A.

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

Safety: UL61010-1 Edition 3, EN61010-1 Version 2010, Pollution Degree 2 & Installation Class 2.

Protection Rating: IP20.

PHYSICAL

Unit Size: Height - 99mm; Width - 22.5mm; Depth - 121mm

Ventilation: A space of 80mm must be allowed above & below each unit.

Weight: 0.20kg maximum

ISOLATION

Isolation matrix table with columns: PSU, Universal Input, Relay, SSR, Linear, RS485 Comms, Non-Isolated Digital Input, Isolated Digital Input, Configuration Port. Rows show isolation status for various components.

## 6. SAFETY & WARNING SYMBOLS



Risk of electric shock.



Caution, refer to the manual.



Alternating or direct current could be present.



Equipment protected through-out by double insulation.

## 7. ADVANCED CONFIGURATION

Advanced Configuration gives access to all possible parameters; however, the device hides parameters that are irrelevant to your exact product specification & configuration.

### Advanced Configuration Navigation

Enter by pressing **□** & **▽**. Press **△** or **▽** to navigate to the required menu, then press **□** to enter.

Press **□** & **△** to exit up 1 level. Depending upon which menu you enter it may be necessary to exit 2 or 3 levels for Operator Mode.

### Advanced Configuration menus

Advanced Lock	Enter code & press <b>□</b>	Default 20
Menus		
Menu	Description	
User	Includes Status, Control & Manual Mode enable/disable.	
Input	Configure the process input.	
User Calibration	Single or two-point calibration adjustments for the process input.	
Outputs	Configuration parameters for the outputs.	
Control	PID control tuning & configuration parameters.	
Setpoint & Timer	Setpoint & timer settings.	
Alarms	Alarm configuration.	
Communication	Modbus communications settings.	
Display	Lock codes and Factory Default.	
Operator Screens	Control what appears in Operator Mode.	
Information	View serial number & manufacturing details.	

### User menu

Parameter	Description	Default Value
Alarm State	Alarm active Alarm set, but not active Alarm set, but not active Alarm not set	n/a
Latch State	Output Latched Latch set but output not Latched Latch set but output not Latched Latch not set To clear press <b>□</b> then <b>△</b> to select <b>Yes</b> . Press <b>□</b> to accept.	n/a
Maximum PV	Maximum and Minimum PV recorded whilst powered up or since last reset. To clear press <b>□</b> then <b>△</b> to select <b>Yes</b> . Press <b>□</b> to accept.	n/a
Minimum PV	Same as Maximum PV.	n/a
Control Enable	<b>OFF</b> - Control output(s) disabled. (Ignored when in manual mode) SP replaced by <b>OFF</b> . <b>ON</b> - Control output(s) enabled. Setpoint visible in User screen.	ON
Manual Control Enable	<b>OFF</b> - Instrument in automatic control mode (PID or On-Off control). <b>ON</b> - Manual control ON. Power shown as <b>Pxxx %</b> in Operator mode, in place of SP.	OFF

### Input menu

Parameter	Description	Default Value
Input Type	See Input Type table in SETUP (& FIRST POWER UP).	K Thermocouple
Units	Displayed as °C or °F (Units are hidden when a linear input is used)	°C
Decimal Place	0000	0000
	000.0	
	00.00	
	0.000	Not for temperature.
Scale Range Maximum	Maximum for application working range	Max allowed for Input Type.
Scale Range Minimum	Minimum for application working range	Min allowed for Input Type.
Filter Time	OFF or 0.5 to 100.0 seconds in 0.5 increments	2.0
CJC Enable	<b>Enable</b> Enables the internal thermocouple CJC (Cold Junction Compensation). <b>Disable</b> Disables the internal CJC. External compensation must be provided for thermocouples.	Enable

Parameter	Description	Default Value
Digital I/P Action	None Alarm Reset (clears latched alarms) Ctrl Enable/Disable Ctrl Auto/Manual Pre-Tune Start/Stop Tune at SP Start/Stop (not available for heat/cool)	Ctrl Enable/Disable

### User Calibration menu

Single-point offset or two-point calibration adjustment for process input. Can be used together, if required.

Parameter	Description	Default Value
Offset	Shifts the input value up or down by a single offset amount across the entire range.	0
Low Point	Enter value at which the low point error was measured.	Lower Limit
Low Offset	Enter equal, but opposite offset value to the observed low point error.	0
High Point	Enter value at which the high point error was measured.	Upper Limit
High Offset	Enter an equal, but opposite offset value to the observed high point error.	0

### Outputs menu

Parameter	Description	Default Value
>Output 1		
Usage	Heat Cool Alarm 1 Alarm 2 Alm. 1or2 Loop Alarm	Heat
Control Loop Alarm is set as 2x Integral (PID) or Loop Alarm Time (On.Off control)		
Alarm Action	<b>Direct</b> - Output active when alarm triggers <b>Reverse</b> - Output active when alarm is not triggered	Direct
Latching	<b>Off</b> - Alarm doesn't latch <b>On</b> - Alarm latches & needs to be cleared	Off
LED Indicator	<b>Direct</b> - LED Indicator lit when output is active <b>Reverse</b> - LED Indicator lit when output is inactive	Direct

>Output 2		
Usage	Same options as Output 1 - Usage	Alarm 1
Alarm Action	Same options as Output 1 - Alarm Action	Direct
Latching	Same options as Output 1 - Alarm Latching	Off
LED Indicator	Same options as Output 1 - LED Indicator	Direct

>Output 3 or >Linear Outp		
Usage	3 <sup>rd</sup> output - either Relay/SSR driver (Output 3) or Linear.	Output 3: Alarm 2
>Output 3 Usage	Output 3 - same options as Output 1 - Usage	Output 3: Alarm 2
>Linear Outp Usage	Linea: PV Retransmit	Linea: PV Retransmit
>Output 3 Alarm Action	Same options as Output 1 - Alarm Action	Direct
>Output 3 Alarm Latching	Same options as Output 1 - Alarm Latching	Off
>Output 3 LED Indicator	Same options as Output 1 - LED Indicator	Direct

>Linear Outp Type		
Type	0-10V 2-10V 0-20mA 4-20mA 0-5V 1-5V	0-10V
>Linear Outp Scale Range Maximum	Display value for maximum output, -1999 to 9999	Input type Max
>Linear Outp Scale Range Minimum	Display value for minimum output, -1999 to 9999	Input type Min


Control menu		
PID control tuning & configuration & Loop Alarm. Hidden if no control outputs are set.		
Parameter	Description	Default Value
Proportion Heat Band	ON/OFF (0.0) or PID control in display units. 1 to 9999 - 0 decimal places	161
Proportion Cool Band	0.1 to 999.9 - 1 decimal place 0.01 to 99.99 - 2 decimal places 0.001 to 9.999 - 3 decimal places	161
Auto Reset (Integral)	0.01 to 99.59. and OFF (0.00) (minutes & seconds).	5.00

Parameter	Description	Default Value
Rate (Derivative)	0.01 to 99.59 or OFF (0.00) (minutes & seconds).	1.15
Overlap/Deadband	In display units, range -20 to +20% of Heat & Cool Proportional Band. 0 is Off.	0
Differential (On/Off)	Visible when using On/Off control. In display units centred about the setpoint. Range: 0.1% to 10.0% of input span	8
Loop Alarm Time	Visible when On/Off control & Loop Alarm assigned to an output. Sets time before the loop alarm triggers. (minutes & seconds)	99.59
Manual Rst (Bias)	Manual Reset 0 to 100% (-100% to 100% if heat/cool control)	25%
Heat Cycle Time	0.1 to 512.0 seconds	32.0
Cool Cycle Time		32.0
Output Interlock	Prevents simultaneous activation of both heat & cool outputs. On / Off Only set to On if Overlap/Deadband = 0.	Off
Heat Power Limit	% power upper limit 0 to 100%	100%
Cool Power Limit	% power upper limit 0 to 100%	100%
Power Up Action	<b>Last</b> - Powers up with control enable in the same state as on power off or power failure. <b>On</b> - Always powers up with control enabled.	Last
Automatic Tuning	Off Start Pre-Tune Start Tune at SP *	Off

\*Start Tune at SP not available for Heat & Cool process.

### Setpoint menu

Parameter	Description	Default Value
Enable Timer	<b>Enabled</b> Enables the Delay and On Timers. Applies at next power-up / control enable. <b>Disabled</b> Delay and On Timers ignored. (Setpoint ramping still functions.)	Disabled
Delayed Start Time	Time from power-up or control enable before control begins from 00.01 to 99.59 or OFF (0.00) (hours & minutes) If OFF control starts immediately.	OFF
Ramp Rate	Rate actual setpoint changes from current PV to target setpoint following power-up or control enable. From 0.001 to 9999 or OFF (10 000) (Units / hr). Any setpoint changes also follow this rate.	OFF
On Time	The time the target setpoint will be maintained once reached, from 00.01 to 99.59 or Off (00.00) (hours & minutes) Infinite (100.00) - control remains on indefinitely.	Infinite
Upper Limit	Used to limit the Maximum setpoint value.	Scale Range Maximum
Lower Limit	Used to limit Minimum setpoint value.	Scale Range Minimum
Offset	Offsets the setpoint. For use in multi-zone setpoint slave applications. Offset in use pop-up appears when SP is changed.	0



Ramp & Timers diagram – delay, ramp and timer

- From power up or control enable the unit delays process control until the Delay Timer expires (time set by Delayed Start Time).
- Setpoint ramps from the current PV to the target setpoint at Ramp Rate (Ramp indicates ramping). If Ramp Rate is OFF the active setpoint steps directly to target setpoint.
- When the active setpoint reaches the target setpoint, the On Timer counts down (time set by On Time).
- When the On Timer finishes the control switches off. If On Time is set to INF then the control stays on.

### Alarms menu

Parameter	Description	Default Value
>Alarm 1		
Type	None PV High PV Low Deviation Band	PV High

Parameter	Description	Default Value
Value	Range minimum to range maximum, or OFF (maximum +1). OFF disables alarm.	1373
Hysteresis	0 to full span.	1
>Alarm 2		
Type	Same options as Alarm 1	PV Low
Value		-240
Hysteresis		1
>Options		
Alarm Inhibit temporarily deactivates alarms at power-up & on change in setpoint.		
Alarm Inhibit	None Alarm 1 Alarm 2 Alarm 1 & 2	None
Alarm PV Notification	None Alarm 1 Alarm 2 Alarm 1 & 2	Alarm 1 & 2
Sensor Break Alarm	On - activates both alarms, if configured, when a sensor break is detected.	Off

### Communications menu

Modbus communications settings, only shown when RS485 option is fitted.

Parameter Name	Description	Default Value
Unit Address	Modbus address from 1 to 255	1
Baud Rate	Coms data rate in kbps 1200, 2400, 4800, 9600, 19200 & 38400.	9600
Parity	Parity checking: Odd, Even or None	None

### Display menu

Lock codes & Factory Defaults.

Parameter Name	Description	Default Value
Setup Unlock Code	View & adjust Setup lock code. From 1 to 9999 or Off for no lock code.	10
Advanced Unlock Code	View & adjust Advanced lock code. From 1 to 9999 or Off for no lock code.	20
Screen Timeout	Screensaver time 5, 15 or 30 mins.	5
Selected language	Display language, 2 available – English plus either German or French.	English
Transmitter	Transmitter view <b>Enable</b> hides the setpoint.  <b>Important:</b> The device still functions as a controller even though SP is hidden.  For transmitter function, <b>Linear Outp – Usage</b> must be <b>PV Retransmit</b> or <b>SP Retransmit</b> .	Disable
Reset to Defaults	Reset parameters back to factory defaults. To clear press <b>□</b> then <b>▽</b> to select <b>Yes</b> . Press <b>□</b> to accept.	

### Operator Screens menu

Controls what appears in Operator Mode.

Parameter Name	Description	Default Value
Control Enabled	Hide or Show parameters in Operator Mode.	Hide
Manual Ctrl Enabled		Hide
Alarm State		Hide
Latch State		Show
Maximum PV		Hide
Minimum PV		Hide
Remaining On Time		Hide
Remaining Delay Time	Hide	

### Information menu (Read-Only)

Parameter Name	Description
PRL	The hardware/software revision level.
DOM	Date of manufacture (mmyy).
FW Version	The firmware version number & code type.
FW Type	The firmware version number & code type.
Serial	Instrument serial number.
Out1 Out2 Out3	SSR (SSR driver) or Relay SSR (SSR driver) or Relay. None, SSR (SSR driver), Relay or Linear.
Comm DI	Comms option - Fitted or None. Digital Input options – Iso (isolated) or NonIs (non-isolated).