

### PRODUCTINFORMATION

Maximum Current (per Tin-Lead Contact)	PP Powerclaw 55 amps	<b>SB Powerclaw</b> 50 amps	<b>Locking Powerclaw</b> 55 amps
Maximum Voltage (AC or DC)	600 volts	600 volts	600 volts
Housing Material	Polycarbonate	Polycarbonate	Polycarbonate
Contact Material	Copper per ASTM-B-152	Copper per ASTM-B-152	Copper per ASTM-B-152
Contact Plating: Tin-Lead	.100 micro" 60/40 Pb-Sn over .050 micro" Ni	.100 micro" 60/40 Pb-Sn over .050 micro" Ni	.100 micro" 60/40 Pb-Sn over .050 micro" Ni
Contact Plating: Silver*	.100 micro Au over .050 micro" Ni	.100 micro Au over .050 micro" Ni	.100 micro Au over .050 micro'' Ni
Mating/Unmating Forces	7 lb. Average	15 lb. Average	7 lb. Average
Suggested Board Thickness	.150" max.	.150'' max.	.150" max.

<sup>\*</sup>Silver is a custom option; Tin-lead plating is standard.

# HIGH POWER PCB CONTACTS

Test Condition	Specification Tested to and Met:	
Mechanical		
Sine Vibration	MIL-STD-1344, Method 2005, Test Condition I.	
Mechanical Shock	MIL-STD-1344, Method 2004, Test Condition I.	
Mating Force	APP Specification, 7 lb average mating force.	
Durability	APP Specification, no base metal exposed after 50 cycles	
Electrical		
Temperature Rise at rated current	UL 1977	
Dielectric Voltage Withstand	MIL-STD-1344, Method 3001, Type 1.	
Contact Resistance	MIL-STD-1344, Method 3004, Type 1.	
Thermal		
Temperature Cycling	MIL-STD-1344, Method 1003, Test Condition A.	
Humidity	MIL-STD-1344, Method 3001, Type 1.	
Flammability		
PP-, LP-, SB-series	UL 94, 94VO.	

## PART NUMBER INFORMATION

PC - (Powerclaw)	(Color)	- X - (Plating)	— XX (Housing)
	BLK-Black	T-Tin	PP-Powerpole 75 amp
	RED-Red	S-Silver	LP-Locking Powerpole 75 amp
	BLU-Blue		SB-SB50 amp
	WHT-White		'
	GRY-Gray		
	GRN-Green		



Powerclaw Mounting Staples

PC Staple 1 = 1 pole mounting staple

PC Staple 2 = 2 pole mounting staple

#### **POWERCLAW FEATURES**

Quick disconnect avoids need for system maintenance or calibrated torquing

Tin-lead plated for easy soldering and minimal contact resistance at high current

Snap-On Interface ensures foolproof assembly and proper connection

Fully insulated plastic housing provides the user with a safe connection

**UL recognized and CSA** approved for certified workmanship and reliability

Meets UL hot-spark requirements so that equipment can be hot swapped


Mating connector accepts wire gauges from #10 to #6 for design flexibility


Multiple color-coding and keying provides design flexibility

Anti-static packaging meets electronics PCB requirements

Vacuum packaging prevents tarnishing of contacts during shelf life


Modular high "Power to the Board"





#### EMPERATURE


Temperature Rise at Constant Currents: Powerclaw™ Tested in Accordance with EIA 364-70, No enclosure, 25+/-5 deg. C. ambient (#8 AWG Foil on Board Side, #6 AWG conductor on wire side, Contact Cat. No. 5900)



Temperature Rise of Contact at exit from Housing Interface (No Air Flow over Test Loop)

Single Pole Powerpole	Multiple Pole Powerpole	SB501 fousing, Two Pole	UL/CSA Optimum Limit
•	<del></del>	<del></del>	—— <b>×</b> ——

#### G 7 G




"Powerclaw Packaging" (Orders will be shipped in silver, non-transparent, plastic bags.)

Powerclaw connectors (PP. Locking, SB) are packaged in ESD plastic and foam for easy assembly use compatible with the electronics market requirements. The packaging is vacuum sealed, which prevents any tarnishing or environmental reactions to occur on the contact. The vacuum pack is easily opened at assembly by puncturing the bag. Each bag will be labeled and bar-coded for

convenient assembly

count.




**PACKAGING QUANTITIES** 


Locking Powerclaw 20 per bag


20 per bag


PP Powerclaw


#### POWERCLAW SPECIFICATIONS











(3)

**(4)** 

(5)

(2)



# Anderson Power Products\* ANDERSON POWER PRODUCTS\*


USA

13 Pratts Junction Road Sterling, MA 01564 (Tel) 978-422-8101 (Fax) 978-422-8005

Europe

Rathealy Road, Fermoy Co. Cork Ireland

(Tel) 353-25-32277 (Fax) 353-25-32296



#### **GENERAL INSTALLATION INSTRUCTIONS**

- **1.** Install Powerclaw assembly onto circuit board and verify proper insertion of leads through the circuit board.
- Slide staple over Powerclaw or Locking Powerclaw or insert mounting screws into SB Powerclaw\* and insert into board.
- **3.** Fasten staple by bending the leads on the opposite side of the board. Fasten screws by use of proper nuts on opposite side of board.
- **4.** Verify that the edge of the Powerclaw contact touches the edge of the housing on the top face. This insures proper contact alignment in housing.
- **5.** Solder circuit board leads by wave or hand soldering. We suggest performing solder reflow operations prior to insertion and installation of Powerclaw connectors.
  - \* Screws not included in connector; suggested size 6-32UNC.