


DHTG

Rotary indexing table

FESTO

Operating instruction



8225400

8225400
2025-01f
[8225402]

Original instructions

Table of contents

1	Applicable documents.....	6
2	Safety.....	6
2.1	Safety instructions.....	6
2.2	Intended use.....	6
2.3	Foreseeable misuse.....	6
2.4	Training of qualified personnel.....	6
3	Additional information.....	6
4	Product overview.....	7
4.1	Product design.....	7
4.2	Function.....	7
5	Mounting.....	7
5.1	Fixing.....	7
5.2	Attachment of plate.....	8
6	Installation.....	9
6.1	Installation, pneumatic.....	9
6.1.1	Examples of connection for clockwise or anticlockwise rotation.....	9
6.1.2	Example of connection for pendulum operation.....	10
6.2	Installation, electrical.....	10
7	Commissioning.....	11
7.1	Clockwise or anticlockwise rotation.....	12
7.2	Pendulum operation.....	12
8	Operation.....	12
8.1	Adjusting rotational speed.....	12
8.2	Adjusting cushioning.....	13
9	Maintenance.....	13
9.1	Maintenance work.....	13
9.2	Replacing shock absorbers.....	13
9.3	Cleaning.....	14
9.4	Lubrication.....	14
10	Malfunctions.....	15
10.1	Fault clearance.....	15
11	Modification.....	16

12	Technical data.....	17
12.1	Technical data, general.....	17
12.2	Technical data, mechanical.....	18
12.3	Technical data, pneumatic.....	19
12.4	Characteristic curves.....	19

1 Applicable documents



All available documents for the product → www.festo.com/sp.

2 Safety

2.1 Safety instructions

- Only use the product in its original condition without unauthorised modifications.
- Observe the identifications on the product.
- Take into account the ambient conditions at the location of use.
- Store the product in a cool, dry environment protected from UV and corrosion. Keep storage times short.
- Before working on the product, switch off the compressed air supply and lock it to prevent it from being switched on again.

2.2 Intended use

The rotary indexing table rotates a payload and a defined rotation angle to a holding position.

2.3 Foreseeable misuse

Operation is prohibited in areas in the vicinity of machining, aggressive media, grinding dust or welding spatter.

2.4 Training of qualified personnel

Work on the product may only be carried out by qualified personnel who can evaluate the work and detect dangers. The qualified personnel have knowledge and experience in dealing with pneumatic drives and pneumatic axes.

3 Additional information

- Contact the regional Festo contact if you have technical problems
→ www.festo.com.
- Accessories and spare parts → www.festo.com/catalogue.

4 Product overview

4.1 Product design




Fig. 1: Product design

- | | |
|--|--|
| 1 One-way flow control valve | 6 Threaded hole for plate (6x) |
| 2 Adjusting screw for cushioning adjustment | 7 Mounting hole (4x) |
| 3 Retaining screw for table bearing | 8 Threaded hole for position sensing (4x) |
| 4 Pin hole for plate (2x) | 9 Pneumatic ports (A) and (B) |
| 5 Through-hole for energy through-feed | 10 Pneumatic ports (C) and (D) |

4.2 Function

The rotary indexing table is a double-acting semi-rotary drive based on the gear rack-pinion principle with positively guided interlock. Alternating pressurisation of the pneumatic ports moves two gear rack pistons back and forth. The pistons convert the linear motion to a rotary motion by a pinion.

After the rotation process, the positively guided interlock bolts are engaged to prevent rotation of the table top. The pinion is disengaged from the table top for the return stroke.

A second pair of pistons controls the engagement of the pinion in the table gearing and the interlock of the holding position. The integrated shock absorber brakes the rotary indexing table in the direction of rotation.

Overload protection

The rotary indexing tables DHTG-140 and DHTG-220 are also fitted with overload protection to prevent overload.

5 Mounting

5.1 Fixing



The retaining screws must be supplied by the customer. Use only retaining screws with a minimum strength class of 8.8.

- Requirements:
- Sufficient space for maintenance and renovation work.

Direct fastening from above




Fig. 2: Direct fastening from above

1. Insert the centring sleeves ZBH into the DHTG from below.
2. Position the DHTG on the mounting surface.
3. Screw in and tighten the retaining screws from above.

DHTG	-65	-90	-140	-220
Retaining screw	M4	M6		M8
Max. tightening torque [Nm]	2.9	9.9		24

Direct fastening from below




Fig. 3: Direct fastening from below

1. Insert the centring sleeves ZBH into the DHTG from below.
2. Position the DHTG on the mounting surface.
3. Screw in and tighten the retaining screws from below.

DHTG	-65	-90	-140	-220
Retaining screw	M5	M8		M10
Max. tightening torque [Nm]	5.9	24.9		47

5.2 Attachment of plate



The retaining screws must be supplied by the customer. Use only retaining screws with a minimum strength class of 8.8.

- Requirements:
- The DHTG is mounted at the assembly location.




Fig. 4: Attachment of plate

1. Place the plate at the correct position.
2. Screw in the retaining screws but do not tighten them yet.
3. Drive the centring pins through the plate into the DHTG.
4. Tighten the retaining screws.

DHTG	-65	-90	-140	-220
Retaining screw	M4		M6	M8
Max. tightening torque [Nm]	2.9		9.9	24

6 Installation

6.1 Installation, pneumatic

1. Use fittings, seals and suitable tubing from the Festo catalogue → 3 Additional information.
2. Screw the fittings into the corresponding pneumatic ports.

DHTG	-65	-90	-140	-220
Tightening torque [Nm]	1.5 ± 20 %		7 ± 20 %	

3. Insert suitable tubing into the fitting to the stop.
4. Seal pneumatic ports that are not required.

6.1.1 Examples of connection for clockwise or anticlockwise rotation




Fig. 5: Single circuit




Fig. 6: Extended circuit

6.1.2 Example of connection for pendulum operation




Fig. 7: Single circuit




Fig. 8: Extended circuit

6.2 Installation, electrical




Fig. 9: Proximity switch connection



The proximity switches must be screwed into the corresponding drilled holes depending on the direction of rotation.

Sensing	Direction of rotation	
	Clockwise rotation	Anticlockwise or pendulum operation
Rotary motion	W	U
Interlock	V	V
Piston end position	U	W

Tab. 1

1. Use the appropriate proximity switches from the Festo catalogue → 3 Additional information.
2. Screw the proximity switches into the corresponding drilled holes.

DHTG		-65	-90	-140	-220
Max. screw-in depth					
Thread (U) and (W)	[mm]	11.5		13.5	18.5
Thread (V)	[mm]	19.7	14	16	21

7 Commissioning



When exhausting the DHTG, the reset force of the shock absorber may move the rotating plate from the end position to an undefined position. Always pressurise the last pressurised pneumatic port before commissioning:

- Pneumatic port (B): clockwise or anticlockwise rotation
- Pneumatic port (C) or (D): pendulum operation



The compressed air is interrupted at the piston end position of the 5/2-way valve. The compressed air in the DHTG is trapped and the movement is stopped. The speed at which the DHTG comes to a standstill depends on the mass moment of inertia and the angular velocity. The table may move to its end position, but without additional driving torque. The table can be moved manually within a specific range.



The rotational speed is controlled internally by the one-way flow control valve for clockwise and anticlockwise rotation. The pendulum operation must be controlled externally by an additional one-way flow control valve in the pneumatic port → www.festo.com/catalogue.



The increased heat during operation reduces the viscosity of the shock absorber oil and the shock absorber can bottom out if the mass moment of inertia is too high.

- Reduce the mass moment of inertia.

Requirements:

- The DHTG is mounted.
 - The pneumatic and electrical installation is complete and tested.
1. Check the operating conditions and critical limits → 12.1 Technical data, general.
 2. Screw in the flow control screw completely.
 3. Unscrew the flow control screw one revolution.
 4. Switch on the compressed air supply and start the test run.

7.1 Clockwise or anticlockwise rotation

1. Pressurise the pneumatic port (A).
⇒ The rotary indexing table rotates to the right or left depending on whether the DHTG is mounted for clockwise or anticlockwise rotation → 11 Modification.
2. If necessary, adjust the rotational speed → 8.1 Adjusting rotational speed.
3. If necessary, adjust the cushioning → 8.2 Adjusting cushioning.
4. If necessary, readjust the proximity switches → 6.2 Installation, electrical

7.2 Pendulum operation

Clockwise rotation


1. Pressurise the pneumatic port (A).
⇒ The DHTG is unlocked.
2. Pressurise the pneumatic port (C).
⇒ The plate rotates clockwise.
3. Pressurise the pneumatic port (B).
⇒ The DHTG is locked.
4. Pressurise the pneumatic port (D).
⇒ The plate rotates anticlockwise.
5. If necessary, adjust the rotational speed → 8.1 Adjusting rotational speed.
6. If necessary, adjust the cushioning → 8.2 Adjusting cushioning.

Anticlockwise rotation

1. Pressurise the pneumatic port (A).
⇒ The DHTG is unlocked.
2. Pressurise the pneumatic port (D).
⇒ The plate rotates anticlockwise.
3. Pressurise the pneumatic port (B).
⇒ The DHTG is locked.
4. Pressurise the pneumatic port (C).
⇒ The plate rotates clockwise.
5. If necessary, adjust the rotational speed → 8.1 Adjusting rotational speed.
6. If necessary, adjust the cushioning → 8.2 Adjusting cushioning.

8 Operation

8.1 Adjusting rotational speed



1 One-way flow control valve

Fig. 10: Adjusting rotational speed

The rotational speed is adjusted by the one-way flow control valve.

- Set the desired rotational speed with the one-way flow control valve.
 - ⇒ Clockwise rotation: rotational speed slows.
 - ⇒ Anticlockwise rotation: rotational speed is faster.

8.2 Adjusting cushioning




Fig. 11: Adjusting cushioning

1. Loosen the clamping component one revolution.
2. Set the adjusting screw to the desired cushioning with an Allen key. Avoid a hard stop at the end positions. The overload protection must also not be triggered.
 - ⇒ Clockwise rotation: cushioning is increased.
 - ⇒ Anticlockwise rotation: cushioning is reduced.
3. Tighten the clamping component.

DHTG		-65	-90	-140	-220
Tightening torque	[Nm]	0.8 ± 20%		2.5 ± 20%	

9 Maintenance

9.1 Maintenance work

Check the shock absorbers every 2 million strokes:

- Oil leak
- Hard stops
- General Function

9.2 Replacing shock absorbers




Fig. 12: Replacing shock absorbers



Replace the shock absorber after 10 million load cycles at the latest.

Requirements:

- The power supply is switched off and locked to prevent unauthorised reactivation.
- The compressed air supply is switched off and locked to prevent unauthorised reactivation.
- The system is completely exhausted.

Removal

1. Unscrew the one-way flow control valve from the connecting plate.
2. Unscrew the retaining screws of the connecting plate and remove the connecting plate.
3. Remove the retaining ring on the shock absorber.
4. Replace the shock absorber.

Mounting

1. Insert the shock absorber.
2. Mount the retaining ring on the shock absorber.
3. Position the connecting plate correctly and screw in and tighten the retaining screws.

DHTG		-65	-90	-140	-220
Tightening torque	[Nm]	2.9 ± 20%		9.9 ± 20%	

4. Screw in the one-way flow control valve and tighten it.

DHTG		-65	-90	-140	-220
Tightening torque	[Nm]	1.5 ± 20%		5.5 ± 20%	

9.3 Cleaning

Regularly removing lubricant from the surfaces reduces the service life.

- Clean the outside of the product as required with a soft cloth.
Permissible cleaning agents:
 - Detergent, maximum +60 °C
 - Petroleum ether, free of aromatic compounds

9.4 Lubrication

General relubrication of the mechanical components is recommended every 5 million switching cycles.

After a conversion re-lubricate the following components with LUB-E1:

- Piston and piston chamber
- Seal
- Interlock
- Gear rack with pinion
- Table bearings
- Indexing disc

10 Malfunctions

10.1 Fault clearance

Malfunction	Cause	Remedy
The rotating plate does not rotate.	The overload protection is active.	– Pressurise pneumatic port B and rotate the rotating plate manually against the direction of rotation until it can no longer be moved. The overload protection and possibly the interlock audibly engage.
	An audible leakage.	– Contact the regional Festo contact if you have technical problems → www.festo.com .
	The one-way flow control valve is completely closed.	– Open the one-way flow control valve.
The rotating plate does not engage.	The end position has not been reached.	– Unscrew the shock absorber adjusting screw until the rotating plate engages.
	The overload protection is active.	– Pressurise pneumatic port B and rotate the rotating plate manually against the direction of rotation until it can no longer be moved. The overload protection and possibly the interlock audibly engage.
	The toothed disc and the pinion are aligned tooth to tooth.	– Contact the regional Festo contact if you have technical problems → www.festo.com .
Hard metallic impacts at the end position.	The adjusting screw for the shock absorber is unscrewed too far.	– Screw in the adjusting screw.
	The shock absorber is faulty.	– Replace the shock absorber.
Hard metallic impacts in the interlock.	The shock absorber adjusting screw was screwed in too far, e.g. when changing the direction of rotation.	– Unscrew the adjusting screw.
The plate position is incorrect.	The overload protection is incorrectly engaged by 180° (plate offset by 30°).	– Force the overload protection and turn until the overload protection engages again.

Tab. 2: Fault clearance

11 Modification



The DHTG can also be converted from clockwise rotation to anticlockwise rotation similar to the steps described below.

Requirements:

- The power supply is switched off and locked to prevent unauthorised reactivation.
- The compressed air supply is switched off and locked to prevent unauthorised reactivation.
- The system is completely exhausted.

Remove connecting plate




Fig. 13: Removal and mounting of connecting plate

- | | |
|---|------------------|
| 1 One-way flow control valve | 5 O-ring |
| 2 Retaining screw (5x) | 6 Distance piece |
| 3 Connecting plate | 7 Shock absorber |
| 4 Adjusting screw with clamping component | 8 Retaining ring |

1. Unscrew the clamping component one revolution.
2. Unscrew the adjusting screw a few revolutions.
3. Unscrew the one-way flow control valve from the connecting plate.
4. Unscrew the retaining screws of the connecting plate and remove the connecting plate.
5. Remove the retaining ring on the shock absorber.
6. Remove the shock absorber.
Not applicable for DHTG-...-2 and DHTG-...-3
7. Remove the distance piece.
8. Remove the O-ring.
For DHTG-65: remove the buffer.

Mounting connecting plate

1. Insert the shock absorber into the piston bore next to it.
2. Mount the retaining ring on the shock absorber.
3. Insert the O-ring.
For DHTG-65: insert the buffer.

4. Insert the distance piece.
Not applicable for DHTG-...-2 and DHTG-...-3
5. Position the connecting plate correctly and screw in and tighten the retaining screws.

DHTG	-65	-90	-140	-220
Tightening torque [Nm]	2.9 ± 20%		9.9 ± 20%	

6. Screw in the one-way flow control valve and tighten it.

DHTG	-65	-90	-140	-220
Tightening torque [Nm]	1.5 ± 20%		5.5 ± 20%	

Removing stop plate




Fig. 14: Removal and mounting of stop plate

1. Unscrew the retaining screws of the stop plate and remove the stop plate.
2. Unscrew both plug screws on the back of the stop plate.

Mounting stop plate

1. Screw both plug screws into the other drilled hole and tighten them. Tightening torque 0.5 Nm ± 20%.
⇒ Clockwise rotation: drilled hole R opened.
⇒ Anticlockwise rotation: drilled hole L opened.
2. Position the stop plate correctly, screw in the retaining screws and tighten them.

DHTG	-65	-90	-140	-220
Tightening torque [Nm]	1.5 ± 20%	2.9 ± 20%	5.9 ± 20%	

3. Set the desired cushioning → 8.2 Adjusting cushioning.

12 Technical data

12.1 Technical data, general

DHTG	
Certificates, declaration of conformity	➔ www.festo.com/sp
Mode of operation	Double-acting twin-piston drive
Mounting position	Any
Degree of protection	IP54
Cushioning	Adjustable shock absorber stroke, hard characteristic curve
Operating medium	Compressed air in accordance with ISO 8573-1:2010 [7:4:4]

DHTG	
Operating medium	Inert gases
Information on the operating medium	Lubricated operation possible, in which case lubricated operation will always be required
Ambient temperature [°C]	+5 ... +60
Storage temperature [°C]	-20 ... +80
Temperature of medium [°C]	-5 ... +60

Tab. 3: Technical data, general

12.2 Technical data, mechanical




Fig. 15: Technical data, mechanical

DHTG		-65	-90	-140	-220
Max. axial force (F)	[N]	1000	2000	4000	5000
Max. radial force (R)	[N]	2000	5000	6000	8000
Max. breakdown torque (M)	[Nm]	100	150	300	500
Max. tangential torque (T)	[Nm]	100	150	200	500
Parallelism of plates	[mm]	≤ 0.04			
Axial runout of plates	[mm]	≤ 0.02			
Concentricity of plates	[mm]	≤ 0.02			
Interchangeability	[mm]	< 0.2			
Repetition accuracy of swivel angle	[°]	≤ 0.03			
Max. inertia with open flow control valve	[kgm²]	0.015	0.03	0.3	2.5
Theoretical torque					
0.4 MPa	[Nm]	1.4	2.9	12.1	39.3
0.6 MPa	[Nm]	2.1	4.4	18.1	58.9
0.8 MPa	[Nm]	2.8	5.9	24.1	78.5
Maximum permissible frequency at 0.6 MPa					
DHTG-...-2	[1/sec]	3.4	1.9	—	—
DHTG-...-4	[1/sec]	4.7	3.1	1.8	1
DHTG-...-6	[1/sec]	5.5	4.3	2.4	1.3
DHTG-...-8	[1/sec]	7.7	5.6	3.1	1.8
DHTG-...-12	[1/sec]	10	5.8	3.1	2.3
DHTG-...-24	[1/sec]	14.2	6.6		3.5

Tab. 4: Technical data, mechanical

12.3 Technical data, pneumatic

DHTG		-65	-90	140	220
Operating pressure	[MPa]	0.4 ... 0.8			
	[bar]	4 ... 8			
	[psi]	58.02 ... 116.03			
Leakage at 0.6 MPa	[SLPM]	<2			
Pneumatic ports					
Pneumatic port (A)		M5		G 1/8	
Pneumatic port (B)		M5		G 1/8	
Pneumatic port (C)		M5		G 1/8	
Pneumatic port (D)		M5		G 1/8	

Tab. 5: Technical data, pneumatic

12.4 Characteristic curves

The following characteristic curves show the switching frequency (f) as a function of the mass moment of inertia (J).

DHTG-65




Fig. 16: DHTG-65

- | | | | |
|---|------------------|---|-------------------|
| 1 | 2-point indexing | 5 | 8-point indexing |
| 2 | 3-point indexing | 6 | 12-point indexing |
| 3 | 4-point indexing | 7 | 24-point indexing |
| 4 | 6-point indexing | | |

DHTG-90




Fig. 17: DHTG-90

- | | |
|--------------------|---------------------|
| 1 2-point indexing | 5 8-point indexing |
| 2 3-point indexing | 6 12-point indexing |
| 3 4-point indexing | 7 24-point indexing |
| 4 6-point indexing | |

DHTG-140




Fig. 18: DHTG-140

- | | |
|--------------------|---------------------|
| 1 2-point indexing | 5 8-point indexing |
| 2 3-point indexing | 6 12-point indexing |
| 3 4-point indexing | 7 24-point indexing |
| 4 6-point indexing | |

DHTG-220




Fig. 19: DHTG-220

- | | |
|--------------------|---------------------|
| 1 2-point indexing | 5 8-point indexing |
| 2 3-point indexing | 6 12-point indexing |
| 3 4-point indexing | 7 24-point indexing |
| 4 6-point indexing | |

The following characteristic curves show the maximum permissible cycle frequency (f) as a function of the mass moment of inertia (J).

DHTG-65




Fig. 20: DHTG-65

- | | |
|--------------------|---------------------|
| 1 2-point indexing | 5 8-point indexing |
| 2 3-point indexing | 6 12-point indexing |
| 3 4-point indexing | 7 24-point indexing |
| 4 6-point indexing | |

DHTG-90




Fig. 21: DHTG-90

- | | |
|--------------------|---------------------|
| 1 2-point indexing | 5 8-point indexing |
| 2 3-point indexing | 6 12-point indexing |
| 3 4-point indexing | 7 24-point indexing |
| 4 6-point indexing | |

DHTG-140




Fig. 22: DHTG-140

- | | |
|--------------------|---------------------|
| 1 3-point indexing | 4 8-point indexing |
| 2 4-point indexing | 5 12-point indexing |
| 3 6-point indexing | 6 24-point indexing |

DHTG-220




Fig. 23: DHTG-220

- | | |
|--------------------|---------------------|
| 1 3-point indexing | 4 8-point indexing |
| 2 4-point indexing | 5 12-point indexing |
| 3 6-point indexing | 6 24-point indexing |

Festo SE & Co. KG

Ruiter Straße 82

73734 Esslingen

Germany

Phone: +49 711 347-0

www.festo.com