

3. 配線

配線上の注意 **警告**

- 取付け、配線作業を行うときは、必ず電源を外部にて全相共遮断してから行ってください。
感電、製品損傷の恐れがあります。

配線上の注意 **注意**

- ネジ加工や配線工事を行うときに、切粉や電線屑を本製品やシーケンサなどの通風窓へ落とし込まないでください。
火災、故障、誤動作の原因となります。
- ノイズの影響により、シーケンサが誤動作する原因になることがあるので、次の項目を必ず守ってください。
 - 電源線やアナログ入出力線は、主回路線や高圧電線、負荷線との近接や束線を行わないでください。
ノイズやサージ誘導の影響を受けやすくなります。
100mm以上離して布線するようにしてください。
 - アナログ入出力線のシールドは、必ず信号受取り側で一点接地を行ってください。また、強電系とは共通接地しないでください。
- ヨーロッパ式端子台タイプへの配線は、次の注意事項に従い適切に行ってください。感電、故障、短絡、断線、誤動作、製品損傷の恐れがあります。
 - 電線の端末処理方法は、マニュアルに記載した寸法に従ってください。
 - 締付トルクは、マニュアルに記載したトルクに従ってください。
 - より線の端末は、“ヒゲ線”が出ないようによじってください。
 - 電線の端末は、ハンダメッキしないでください。
 - 規定サイズ以外の電線や規定本数を超える電線を接続しないでください。
 - 端子台や電線接続部分には、外力が直接加わらないように、電線を固定してください。
- 端子台タイプへの配線は、次の注意事項に従い適切に行ってください。感電、故障、短絡、断線、誤動作、製品損傷の恐れがあります。
 - 電線の端末処理方法は、シーケンサ本体マニュアルに記載した寸法に従ってください。
 - 締付トルクは、シーケンサ本体マニュアルに記載したトルクに従ってください。

3.1 使用ケーブルと端子締付トルク

3.1.1 ヨーロッパ式端子台


- 電線サイズ
 - 電源または熱電対切換え入力は、導体サイズがAWG22-20のものを使用してください。
 - 熱電対の配線は、熱電対のタイプに合った補償導線を使用してください。
→補償導線の詳細については、3.3節を参照
- 適合電線

形式	電線サイズ
電線1本	0.3~0.5mm ² (AWG22~20)
電線2本	0.3mm ² (AWG22) ×2本

- 端末処理
 - より線は被覆を剥ぎ芯線をよりそのまま接続し、単線は被覆を剥ぎそのまま接続してください。
 - または、絶縁スリーブ付棒端子を使用し接続してください。
<参考例>

メーカー	形名	圧着工具
フエニックス・コンタクト株式会社	AI 0.5-8WH	CRIMPFOX 6※1 (またはCRIMPFOX 6T-F※2)

- ※1 旧形名 CRIMPFOX ZA 3
- ※2 旧形名 CRIMPFOX UD 6



絶縁スリーブ付棒端子を使用する場合は、電線のシースの厚みによって、入れにくくなるので、外形図を参考に電線サイズを選定してください。
端子の締付トルクは0.22~0.25N・mとしてください。規定以上のトルクで端子ネジを締め付けしないでください。故障、誤動作の原因となります。

3.2 電源配線

電源配線については、下記マニュアルを参照してください。
→FX3s・FX3g・FX3gc・FX3u・FX3ucシリーズ
ユーザーズマニュアル[アナログ制御編]

3.3 熱電対の配線


→端子配列は、本マニュアルの1.2節を参照

熱電対の配線上の注意

- 熱電対のタイプ
 - 熱電対は、K型、J型2種類のタイプが使用できます。ただし、全ch(チャンネル)同じタイプの熱電対を使用してください。
 - 熱電対は、絶縁タイプを使用してください。
- 補償導線について
 - 熱電対との接続は、右記のタイプの補償導線をご使用ください。
 - 補償導線は、線抵抗10Ωに対して約0.12°C高めに表示します。その差を引いて使用してください。
 - 補償導線は長くなるとノイズなどの影響を受けやすくなるため、100m以下で使用されることをおすすめします。

熱電対	補償導線のタイプ
K型	KX, KCA, KCB, KCC
J型	JX

熱電対の配線例




L□+, L□-, ch□の□には、ch番号が入ります。

- ※1 J型熱電対を使用する場合は、“J-type”端子を短絡し、特殊補助リレー(K型、J型モード切換え)をONしてください。
特殊補助リレーの詳細については、下記マニュアルを参照してください。
→FX3s・FX3g・FX3gc・FX3u・FX3ucシリーズ
ユーザーズマニュアル[アナログ制御編]
- ※2 FX3s・FX3g・FX3uシーケンサのサービス電源(DC24V)を用いることもできます。

3.4 接地

- 接地は下記の項目を実施してください。
- 接地はD種接地を実施してください。(接地抵抗: 100Ω以下)
 - 接地はできるだけ、専用接地としてください。
専用接地がとれないときは、下図の“共用接地”としてください。
詳細は、接続する各シーケンサのユーザーズマニュアル[ハードウェア編]を参照してください。



- 接地線はAWG 20~22(0.3~0.5 mm²)の太さのものを使用してください。
- 接地点はできるだけこのシーケンサの近くとし、接地線の距離を短くしてください。

4. 仕様

立上げ・保守時の注意 **注意**

- 分解、改造はしないでください。
故障、誤動作、火災の原因となることがあります。
- 修理については、三菱電機システムサービス株式会社にお問い合わせください。
- 本品を落下させたり、強い衝撃を与えないでください。
破損の原因となります。

廃棄時の注意 **注意**

- 製品を廃棄するときは、産業廃棄物として扱ってください。

輸送・保管上の注意 **注意**

- 本品は精密機器なので輸送の間あらゆる衝撃をさけてください。
本品の故障の原因になります。
輸送後、本品の動作確認を行ってください。

4.1 対応シーケンサ

機種名	対応状況
FX3sシーケンサ	Ver. 1.00~(初品から)
FX3gシーケンサ	Ver. 1.00~(初品から)
FX3gcシーケンサ	Ver. 1.40~(初品から)
FX3uシーケンサ	Ver. 2.20~(初品から)
FX3ucシーケンサ	Ver. 1.30~(SER No. 48**** 2004年8月生産品以降)

バージョン番号は、D8001/D8101をモニタし、下3桁の値で知ることができます。

4.2 一般仕様

下記以外の一般仕様は、接続するシーケンサと同じです。
接続するシーケンサの一般仕様については、使用する各シーケンサのユーザーズマニュアル[ハードウェア編]を参照してください。


項目	仕様
耐電圧	AC500V 1分間
絶縁抵抗	DC500Vメガーにて5MΩ以上

4.3 電源仕様

項目	仕様
A/D変換回路 駆動電源	DC24V +20% -15% 45mA/DC24V 端子台にDC24V電源を接続し供給してください。
インタフェース 駆動電源	DC5V 15mA 基本ユニットのDC5V電源から内部給電します。

4.4 性能仕様

項目	仕様	
	摂氏(°C)	華氏(°F)
入力信号	熱電対 K型またはJ型 JIS C 1602-1995 ただし、全ch(チャンネル)同じタイプの熱電対を使用してください。	
定格温度範囲	K型 -100°C~-+1000°C	K型 -148°F~-+1832°F
	J型 -100°C~-+600°C	J型 -148°F~-+1112°F
デジタル出力	K型 -1000~+10000	K型 -1480~+18320
	J型 -1000~+6000	J型 -1480~+11120
分解能	K型 0.4°C	K型 0.72°F
	J型 0.3°C	J型 0.54°F
総合精度	±(0.5% フルスケール+1°C)	
A/D変換時間	<ul style="list-style-type: none"> FX3u/FX3ucシーケンサ: 200μs(データの更新は毎演算周期) FX3s/FX3g/FX3gcシーケンサ: 250μs(データの更新は毎演算周期) 	



本書によって、工業所有権その他の権利の実施に対する保証、または実施権を許諾するものではありません。
また本書の掲載内容の使用により起因する工業所有権上の諸問題については、当社は一切その責任を負うことができません。

保証について
当社の責に帰すことができない事由から生じた損害、当社製品の故障に起因するお客様での機会損失、過失利益、当社の予見の有無を問わず特別の事情から生じた損害、二次損害、事故補償、当社製品以外への損害およびその他の業務に対する保証については、当社は責任を負いかねます。

安全にお使いいただくために

- この製品は一般工業を対象とした汎用品として製作されたもので、人命にかかわるような状況下で使用される機器あるいはシステムに用いられることを目的として設計、製造されたものではありません。
- この製品を原子力用、電力用、航空宇宙用、医療用、乗用移動体用の機器あるいはシステムなどの特殊用途への適用をご検討の際には、当社の営業窓口までご照会ください。
- この製品は厳重品質体制の下に製造しておりますが、この製品の故障により重大な故障または損失の発生が予測される設備への適用に際しては、バックアップやフェールセーフ機能をシステム的に設置してください。

インターネットによる情報サービス「三菱電機FAサイト」

三菱電機FAサイト <http://www.MitsubishiElectric.co.jp/fa>
三菱電機FAサイトでは、製品や事例などの技術情報に加え、トレーニングスクール情報や各種お問い合わせ窓口をご提供しています。また、メンバー登録いただくマニュアルやCADデータ等のダウンロード、eラーニングなどの各種サービスをご利用いただけます。

三菱電機FA機器電話技術相談			
●電話技術相談窓口		※1 春季・夏季・年末年始の休日を除く	
対象機種	電話番号	月曜~金曜	受付時間※1
ME15C・IQ-F/FX GOT-F900	052-725-2271	9:00~19:00(金曜は17:00まで)	月曜~日曜・祝日 9:00~17:00

三菱電機株式会社

〒100-8310 東京都千代田区丸の内2-7-3(東京ビル)



JAPANESE

ENGLISH

三菱マイクロシーケンサ

FX3U-4AD-TC-ADP

ユーザズマニュアル

Table with manual number, revision, and date.

このたびは、三菱マイクロシーケンサ用FX3U-4AD-TC-ADP熱電対温度センサ...

本マニュアルは、本製品の各部名称、外形寸法、取付け、および仕様について述べたものです...

この印刷物は2015年4月発行です。なお、お断りなしに仕様を変更することがありますのでご了承ください。

© 2004 Mitsubishi Electric Corporation

安全上のご注意

(ご使用前に必ずお読みください)

このマニュアルでは、安全に関する注意事項のランクを警告、注意として区分してあります。

Warning and Attention icons with corresponding text.

なお、注意に記載した事項でも、状況によっては重大な結果に結びつく可能性があります。

関連マニュアルとマニュアルの入手方法

Table listing related manuals and their contents.

マニュアルの入手方法

- 1) 製本マニュアル(印刷物)の入手
2) 電子データ(PDFファイル)の入手

対応規格

FX3U-4AD-TC-ADPは、2005年6月生産品からEC指令(EMC指令)、UL規格(UL, cUL)に対応しています。

- 注意
・本製品は一般工業環境下で使用してください。
・EU域内販売責任者は下記のとおりです。

EU域内販売責任者: Mitsubishi Electric Europe B.V. Gothaer Str. 8, 40880 Ratingen, Germany

EMC指令に適合するための注意

- アナログ特殊アダプタは、ヨーロッパ規格に準拠・適合しています。ただし、計測や制御において、精度を要求する場合は、次の内容を実施されることをおすすめします。
・アナログ製品は、ノイズに敏感な製品のため、取扱い方法に注意してください。
・ケーブルは、シールド線を使用することをおすすめします。
・アナログ値(AD変換後の値)をプログラムで使用する場合は、平均値データを使用してください。

1. 製品概要


FX3U-4AD-TC-ADP熱電対温度センサ入力アナログ特殊アダプタ(以下TC-ADPと略称)は、K、J型熱電対温度センサを接続し温度を4ch測定するための特殊アダプタです。

1.1 同梱品の確認

下記製品および付属品が同梱されているか確認してください。

Table listing included items: Main body and User Manual.

1.2 各部名称と外形寸法・端子配列



特殊アダプタ接続用コネクタカバ-を取り外した状態
質量: 約0.1kg
外装色: マンセル0.086Y 7.64/0.81
DINレール幅: 35mm

- (1) DINレール取付け用溝(DINレール: DIN46277)
(2) ネームプレート
(3) 特殊アダプタ接続用フック
(4) 特殊アダプタの左側に特殊アダプタを接続する場合は、使用します。
(5) 直接取付け用穴(φ2.0φ4.5, 取付けネジ: M4メネジ)
(6) POWER LED(緑色)
(7) 端子台(ヨーロッパ式)
(8) 熱電対センサ入力、K/J型切換え入力およびDC24V電源を配線します。
(9) DINレール取付け用フック
(10) 特殊アダプタ接続用コネクタ
(11) 特殊アダプタの左側に通信特殊アダプタまたはアナログ特殊アダプタを接続するときに使用します。

2. 取付け

取付け/取外しの詳細は、使用する各シーケンサのユーザズマニュアル[ハードウェア編]を参照してください。

取付け上の注意

- 取付け、配線作業などを行うときは、必ず電源を外部にて全相共遮断してから行ってください。

取付け上の注意

- シーケンサ本体マニュアルに記載の一般仕様の環境で使用してください。
・ほこり、油煙、導電性ダスト、腐食性ガス(潮風、Cl2、H2S、SO2、NO2など)、可燃性ガスのある場所、高温、結露、風雨にさらされる場所、振動、衝撃がある場所で使用しないでください。
・感電、火災、誤動作、製品の損傷あるいは劣化の原因となることがあります。
・ネジ加工や配線作業を行うときに、切粉や電線屑を本製品やシーケンサなどの通風窓へ落とし込まないでください。
・火災、故障、誤動作の原因となります。
・製品の導電部には直接触れないでください。
・誤動作故障の原因となります。
・特殊アダプタは所定のコネクタに確実に装着してください。
・接触不良により誤動作の原因となることがあります。

2.1 シーケンサとの接続方法

シーケンサへの取付け方法を説明します。説明は、FX3Uシーケンサを例にしています。
その他のシーケンサについては、接続する各シーケンサのユーザズマニュアル[ハードウェア編]を参照してください。

手順

- 1) 電源をOFFにします。
2) 基本ユニットに機能拡張ボードを取付けてください。
3) 機能拡張ボードの特殊アダプタ接続用コネクタカバー(右図A)をはずします。
4) 基本ユニットの特殊アダプタ接続用フック(右図B)をスライドします。
5) 基本ユニットに特殊アダプタ(右図C)を右図のように接続します。
6) 基本ユニットの特殊アダプタ接続用フック(右図D)をスライドさせ、特殊アダプタ(右図E)を固定します。

接続上の注意

高速入出力特殊アダプタとそれ以外の特殊アダプタを組み合わせで使用する場合は、使用するすべての高速入出力特殊アダプタを取り付けた後に、それ以外の特殊アダプタを接続してください。

3. 配線

配線上的注意

- 取付け、配線作業を行うときは、必ず電源を外部にて全相共遮断してから行ってください。

配線上的注意

- ネジ加工や配線工事を行うときに、切粉や電線屑を本製品やシーケンサなどの通風窓へ落とし込まないでください。
・ノイズの影響により、シーケンサが誤動作する原因になることがあるので、次の項目を必ず守ってください。
1) 電源線やアナログ入出力線は、主回路線や高圧電線、負荷線との近接や束線を避けてください。
2) アナログ入出力線のシールドは、必ず信号受取側で一点接地を行ってください。
・ヨーロッパ式端子台タイプへの配線は、次の注意事項に従い適切に行ってください。
・端子台タイプへの配線は、次の注意事項に従い適切に行ってください。


3.3 熱電対の配線

→端子配列は、本マニュアルの1.2節を参照

熱電対の配線上的注意

- 熱電対のタイプ
・熱電対は、K型、J型の2種類のタイプが使用できます。ただし、全ch(チャンネル)同じタイプの熱電対を使用してください。
・補償導線について
熱電対との接続は、右記のタイプの補償導線をご使用ください。


熱電対の配線例



- ※1 J型熱電対を使用する場合は、J-type端子を短絡し、特殊補助リレー(K型、J型モード切換え)をONにしてください。
※2 FX3S・FX3G・FX3Uシーケンサのサービス電源(DC24V)を用いることもできます。

3.4 接地

- 接地は下記の項目を実施してください。
・接地はD種接地を実施してください。(接地抵抗: 100Ω以下)
・接地はできるだけ、専用接地としてください。
・専用接地が各々あるときは、下図の「共用接地」としてください。



4. 仕様

立上げ・保守時の注意

- 分解、改造はしないでください。
・本品を落下させたり、強い衝撃を与えないでください。
・絶縁方式
・断線時の注意

輸送・保管上の注意

- 本品は精密機器なので輸送の間あらゆる衝撃をさけてください。

4.1 対応シーケンサ

Table listing compatible PLC models and their corresponding versions.

4.2 一般仕様


下記以外の一般仕様は、接続するシーケンサと同じです。

4.3 電源仕様

Table listing power specifications: AC/DC conversion, drive power, and interface power.

4.4 性能仕様

Table listing performance specifications: Input signal, temperature range, digital output, resolution, and accuracy.



本書によって、工業所有権その他の権利の実施に対する保証、または実施権を許諾するものではありません。

保証について
この製品は一般工業を対象とした汎用品として製造されたもので、人命にかかわるような状況下で使用される機器あるいはシステムに用いられることを目的として設計、製造されたものではありません。

安全にお使いいただくために
この製品は一般工業を対象とした汎用品として製造されたもので、人命にかかわるような状況下で使用される機器あるいはシステムに用いられることを目的として設計、製造されたものではありません。

インターネットによる情報サービス「三菱電機FAサイト」
三菱電機FAサイト http://www.MitsubishiElectric.co.jp/fa

三菱電機FA機器電話技術相談
●電話技術相談 ※1 春季・夏季・年末年始の休日を除く

三菱電機株式会社
〒100-8310 東京都千代田区丸の内2-7-2 (東京ビル)



PROGRAMMABLE CONTROLLERS
MELSEC-F

FX3U-4AD-TC-ADP

USER'S MANUAL



Manual Number	JY997D14801
Revision	K
Date	April 2015

This manual describes the part names, dimensions, mounting, and specifications of the product. Before use, read this manual and the manuals of all relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions. Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration:
The company and product names described in this manual are registered trademarks or the trademarks of their respective companies.

Effective April 2015
Specifications are subject to change without notice.
© 2005 Mitsubishi Electric Corporation

Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

WARNING and **CAUTION**.

WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by **CAUTION** may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manuals

Manual name	Manual No.	Description
FX3S/FX3G/FX3GC/FX3U/ FX3UC Series User's Manual - Analog Control Edition	JY997D16701 MODEL CODE: 09R619	Describes specifications for analog control and programming method for FX3S/FX3G/FX3GC/ FX3U/ FX3UC Series PLC.
FX3S/FX3G/FX3GC/FX3U/ FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.
FX3S Series User's Manual - Hardware Edition	JY997D48601 MODEL CODE: 09R535	Explains FX3S Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3G Series User's Manual - Hardware Edition	JY997D31301 MODEL CODE: 09R521	Explains FX3G Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3GC Series User's Manual - Hardware Edition	JY997D45401 MODEL CODE: 09R533	Explains FX3GC Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains FX3UC Series PLC specifications for I/O, wiring, installation, and maintenance.

How to obtain manuals
For product manuals or documents, consult with the Mitsubishi Electric dealer from who you purchased your product.

Applicable standards

FX3U-4AD-TC-ADP units made in June, 2005 or later comply with the EC Directive (EMC Directive) and UL standards (UL, cUL). Further information can be found in the following manual.

- FX3s Series Hardware Manual (Manual No. JY997D48301)
- FX3g Series Hardware Manual (Manual No. JY997D46001)
- FX3gc Series Hardware Manual (Manual No. JY997D45201)
- FX3u Series Hardware Manual (Manual No. JY997D18801)
- FX3uc (D, DS, DSS) Series Hardware Manual (Manual No. JY997D28601)
- FX3uc-32MT-LT-2 Hardware Manual (Manual No. JY997D31601)

Regarding the standards that relate to the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Attention

- This product is designed for use in industrial applications.

Note

- Authorized Representative in the European Community:
Mitsubishi Electric Europe B.V.
Gothaer Str. 8, 40880 Ratingen, Germany

Caution for EC Directive

The analog special adapters have been found to be compliant to the European standards in the aforesaid manual and directive. However, for the very best performance from what are in fact delicate measuring and controlled output device Mitsubishi Electric would like to make the following points:
As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow those manufacturers installation requirements. Mitsubishi Electric recommend that shielded cables should be used. If NO other EMC protection is provided, then users may experience temporary loss or accuracy between ±10 % in very heavy industrial areas. However, Mitsubishi Electric suggest that if adequate EMC precautions are followed for the users complete control system, users should expect accuracy as specified in this manual.

- Sensitive analog cable should not be laid in the same trunking or cable conduit as high voltage cabling. Where possible users should run analog cables separately.
- Good cable shielding should be used. When terminating the shield at Earth - ensure that no earth loops are accidentally created.
- When reading analog values, EMC accuracy can be improved out by averaging the readings. This can be achieved either through functions on the analog special adapters or through a users program.

1. Outline


FX3U-4AD-TC-ADP (hereinafter called TC-ADP) is an analog special adapter for measuring temperature via four channels of connected Type K or Type J thermocouple thermometer.

1.1 Incorporated Items

Verify that the following product and items are included in the package:

Product	FX3U-4AD-TC-ADP K/J type thermocouple thermometer input special adapter
Accessories	User's manual (This manual)

1.2 External Dimensions, Part Names, and Terminal Layout



Weight: Approx. 0.1 kg (0.22 lbs)

- [1] DIN rail mounting groove (DIN rail: DIN46277)
- [2] Name plate
- [3] Special adapter slide lock:
Used to connect additional special adapters onto the left side of this special adapter.
- [4] Special adapters connector cover:
Remove this cover to connect additional special adapters to the left side.
- [5] Direct mounting hole: 2 holes of $\phi 4.5$ (0.18") (mounting screw: M4 screw)
Not used when connecting to FX3GC/FX3UC Series PLC.
- [6] POWER LED (green):
Lit while 24 V DC power is supplied properly to terminals '24+' and '24-'.
- [7] Terminal block (European type):
Connect thermocouple sensor input, Type K or J changeover input, and 24 V DC power supply.
- [8] Special adapter connector:
Used to connect this special adapter to PLC main unit or special adapter.
- [9] DIN rail mounting hook
- [10] Special adapter fixing hook
- [11] Special adapter connector:
Used to connect communication or analog special adapters to the left side of the TC-ADP.

2. Installation

For installation/uninstallation details, refer to the respective PLC User's manual Hardware Edition.

INSTALLATION PRECAUTIONS **WARNING**

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work.
Failure to do so may cause electric shock or damage to the product.

INSTALLATION PRECAUTIONS **CAUTION**


- Use the product within the generic environment specifications described in PLC main unit manual (Hardware Edition).
Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂, or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind.
If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits.
Failure to do so may cause fire, equipment failures or malfunctions.
- Do not touch the conductive parts of the product directly.
Doing so may cause device failures or malfunctions.
- Connect special adapter securely to their designated connectors.
Loose connections may cause malfunctions.

2.1 Connection to the PLC

This section describes the connection method to the PLC (FX3U Series PLC is used for the following example). For installation method to other PLCs, refer to the respective PLC User's manual Hardware Edition.

Procedure

- 1) Turn off the power.
Disconnect all the cables connected to the PLC main unit and special adapter, and demount the main unit and special adapter mounted on DIN rail or mounted directly using screws.
- 2) Install an expansion board to the main unit.
For the expansion board installation procedure, refer to the following manual:
→ FX3u Series User's Manual - Hardware Edition
- 3) Remove the special adapter connector cover on the expansion board (fig.A).
When connecting this product to another special adapter, please replace the 'expansion board' in the above description with a 'special adapter' and perform the procedure as indicated.
- 4) Slide the special adapter slide lock (fig.B) of the main unit.
When connecting this product to another special adapter, please replace the 'main unit' in the above description with a 'special adapter' and perform the procedure as indicated. (Please replace the following procedures similarly.)
- 5) Connect the special adapter (fig.C) to the main unit as shown on the right.
- 6) Slide back the special adapter slide lock (fig.B) of the main unit to fix the special adapter (fig.C).



Connection precautions

Connect all the high-speed I/O special adapters before connecting other special adapters when they are used in combination.
Do not connect a high-speed I/O special adapter on the left side of any special adapters other than other high-speed I/O special adapters.

3. Wiring

WARNING

Make sure to cut off all phases of the power supply externally before attempting installation or wiring work.
Failure to do so may cause electric shock or damage to the product.

CAUTION

When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits.
Failure to do so may cause fire, equipment failures or malfunctions.

Make sure to observe the following precautions in order to prevent malfunctions under the influence of noise:

- Do not bundle the power line or shield of the analog input/output cable together with or lay it close to the main circuit, high-voltage line, or load line.
Otherwise, noise disturbance and/or surge induction are likely to take place. As a guideline, lay the control line at least 100mm (3.94") or more away from the main circuit, high-voltage line, or load line.
- Ground the shield of the analog input/output cable at one point on the signal receiving side. However, do not use common grounding with heavy electrical systems.

Make sure to properly wire to the terminal block (European type) in accordance with the following precautions.

Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.

- The disposal size of the cable end should follow the dimensions described in the manual.
- Tightening torque should follow the specifications in the manual.
- Twist the end of strand wire and make sure that there are no loose wires.
- Do not solder-plate the electric wire ends.
- Do not connect more than the specified number of wires or electric wires of unspecified size.
- Affix the electric wires so that neither the terminal block nor the connected parts are directly stressed.

Make sure to properly wire the terminal block in accordance with the following precautions.

Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.

- The disposal size of the cable end should follow the dimensions described in the manual of the PLC main unit.
- Tightening torque should follow the specifications in the manual of the PLC main unit.

3.1 Applicable cable and terminal tightening torque

3.1.1 Type terminal block (European type)

- Wire size
 - The power supply wiring and the Type K/J changeover input wiring should use 22-20 AWG wire.
 - Thermocouple wiring should use the compensating lead wire suitable for the type of thermocouple.
→ For details of compensating lead wire, Refer to Section 3.3
- Applicable cable


Type	Wire size
Single-wire	0.3 mm ² to 0.5 mm ² (AWG22 to 20)
2-wire	2 pieces of 0.3 mm ² (AWG22)

- Termination of cable end
Strip the coating of strand wire and twist the cable core before connecting it, or strip the coating of single wire before connecting it.
An alternative connection is to use a ferrule with insulating sleeve.
<Reference>

Manufacturer	Model	Caulking tool
Phoenix Contact Co., Ltd.	AI 0.5-8WH	CRIMPFOX 6 ^{*1} (or CRIMPFOX 6T-F ^{*2})

*1 Old model name: CRIMPFOX ZA 3

*2 Old model name: CRIMPFOX UD 6



When using a stick terminal with insulating sleeve, choose a wire with proper cable sheath referring to the above outside dimensions, or otherwise, the wire cannot be inserted easily. The tightening torque must be 0.22 to 0.25 N·m. Do not tighten terminal screws exceeding the specified torque. Failure to do so may cause equipment failures or malfunctions.

3.2 Power Supply Wiring

For the power supply wiring, refer to the following manual.
→ FX3S/FX3G/FX3GC/FX3U/FX3UC Series User's Manual - Analog Control Edition

3.3 Selection of thermocouple


→ For the terminal configuration, refer to Section 1.2

Precautions on thermocouple wiring

- Thermocouple type
 - There are 2 types of thermocouples: Type K and Type J. Select the desired type. However, be sure to connect the same type of thermocouple to all the channels.
 - Use insulated thermocouple types.
- Compensating lead wire
 - To connect the thermocouple, use one of the right types of compensating lead wires. The compensating lead wire indicates the temperature value of approximately 0.12 °C higher than that of the wire resistor (10 Ω). Temperature value should be used in consideration of this point. If the compensating lead wire is very long, the wire may be easily affected by noise, etc. It is, therefore, recommended that the length of the compensating lead wire should be 100 m (328' 1") or less.

Thermocouple	Type of compensating lead wire
Type K	KX, KCA, KCB, KCC
Type J	JX

Example of thermocouple wiring




- When using the Type J thermocouple, short-circuit the 'Type J' terminals and turn the special auxiliary relay (Type K/J mode changeover) ON.
For details of auxiliary relays, refer to the following manual.
→ FX3S/FX3G/FX3GC/FX3U/FX3UC Series User's Manual - Analog Control Edition
- 24 V DC service power supply of the FX3S/FX3G/FX3U Series PLC can also be used.

3.4 Grounding

Grounding should be performed as stated below.

- The grounding resistance should be 100 Ω or less.
- Independent grounding should be performed for best results. When independent grounding is not performed, perform "shared grounding" of the following figure. For details, refer to the respective PLC User's manual Hardware Edition.



- The grounding wire size should be AWG 22-20 (0.3-0.5 mm²).
- The grounding point should be close to the PLC, and all grounding wire should be as short as possible.

4. Specifications

STARTUP AND MAINTENANCE PRECAUTIONS

CAUTION

- Do not disassemble or modify the PLC.
Doing so may cause fire, equipment failures, or malfunctions.
* For repair, contact your local Mitsubishi Electric representative.
- Do not drop the product or exert strong impact to it.
Doing so may cause damage.

DISPOSAL PRECAUTIONS

CAUTION

- Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device.

TRANSPORTATION AND STORAGE PRECAUTIONS

CAUTION

- The product is a precision instrument. During transportation, avoid any impacts.
Failure to do so may cause failures in the product. After transportation, verify the operations of the product.

4.1 Applicable PLC

Model name	Applicability
FX3S Series PLC	Ver. 1.00 or later (from first production)
FX3G Series PLC	Ver. 1.00 or later (from first production)
FX3GC Series PLC	Ver. 1.40 or later (from first production)
FX3U Series PLC	Ver. 2.20 or later (from first production)
FX3UC Series PLC	Ver. 1.30 or later (from the production manufactured in August, 2004 with SER No. 48****)

The version number can be checked by monitoring D8001/D8101 as the last three digits indicate it.

4.2 General Specifications

Items other than the following are equivalent to the those of the PLC main unit.
For general specifications, refer to the respective PLC User's manual Hardware Edition.

Item	Specification
Dielectric withstand voltage	500 V AC for one minute
Insulation resistance	5 MΩ or more by 500 V DC megger

Between all terminals and ground terminal of PLC main unit

4.3 Power Supply Specifications

Item	Specification
A/D conversion circuit driving power	24 V DC ±20 %/-15 %, 45 mA for 24 V DC Connect a 24 V DC power supply to the terminal block.
Interface driving power	5 V DC, 15 mA 5 V DC power is supplied from the internal power supply of main unit.

4.4 Performance Specifications

Item	Specifications			
	Centigrade (°C)	Fahrenheit (°F)		
Input signal	Thermocouple type K or J JIS C 1602-1995			
Rated temperature range	Type K	-100 °C to +1000 °C	Type K	-148 °F to +1832 °F
	Type J	-100 °C to +600 °C	Type J	-148 °F to +1112 °F
Digital output	Type K	-1000 to +10000	Type K	-1480 to +18320
	Type J	-1000 to +6000	Type J	-1480 to +11120
Resolution	Type K	0.4 °C	Type K	0.72 °F
	Type J	0.3 °C	Type J	0.54 °F
Total accuracy	±(0.5% full scale +1 °C)			
A/D conversion time	<ul style="list-style-type: none"> FX3U/FX3UC Series PLC: 200 μs (The data will be updated at every scan time of the PLC.) FX3S/FX3G/FX3GC Series PLC: 250 μs (The data will be updated at every scan time of the PLC.) 			
Input characteristics				
Insulation method	<ul style="list-style-type: none"> The photocoupler is adopted to insulate the analog input area from the PLC. The DC/DC converter is adopted to insulate the power supply line from the analog input area. A channels are not insulated from each other. 			
Occupied points	0 point (This number is not related to the maximum number of input/output points of the PLC.)			

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN



PROGRAMMABLE CONTROLLERS
MELSEC-F

Side A JAPANESE
Side B ENGLISH

FX3U-4AD-TC-ADP

USER'S MANUAL



Manual Number	JY997D14801
Revision	K
Date	April 2015

This manual describes the part names, dimensions, mounting, and specifications of the product. Before use, read this manual and the manuals of all relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions. Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration:
The company and product names described in this manual are registered trademarks or the trademarks of their respective companies.
Effective April 2015
Specifications are subject to change without notice.
© 2005 Mitsubishi Electric Corporation

Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

WARNING and CAUTION

WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by CAUTION may also cause severe injury. It is important to follow all precautions for personal safety.

Associated Manuals

Manual name	Manual No.	Description
FX3S/FX3G/FX3GC/FX3U/FX3UC Series User's Manual - Analog Control Edition	JY997D16701 MODEL CODE: 09R619	Describes specifications for analog control and programming method for FX3S/FX3G/FX3GC/ FX3U/ FX3UC Series PLC.
FX3S/FX3G/FX3GC/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions and devices.
FX3S Series User's Manual - Hardware Edition	JY997D48601 MODEL CODE: 09R535	Explains FX3S Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3G Series User's Manual - Hardware Edition	JY997D31301 MODEL CODE: 09R521	Explains FX3G Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3GC Series User's Manual - Hardware Edition	JY997D45401 MODEL CODE: 09R533	Explains FX3GC Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3U Series User's Manual - Hardware Edition	JY997D16501 MODEL CODE: 09R516	Explains FX3U Series PLC specifications for I/O, wiring, installation, and maintenance.
FX3UC Series User's Manual - Hardware Edition	JY997D28701 MODEL CODE: 09R519	Explains FX3UC Series PLC specifications for I/O, wiring, installation, and maintenance.

How to obtain manuals
For product manuals or documents, consult with the Mitsubishi Electric dealer from who you purchased your product.

3. Wiring

WIRING PRECAUTIONS **WARNING**

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

WIRING PRECAUTIONS **CAUTION**

- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Make sure to observe the following precautions in order to prevent malfunctions under the influence of noise:
 - Do not bundle the power line or shield of the analog input/output cable together with or lay it close to the main circuit, high-voltage line, or load line. Otherwise, noise disturbance and/or surge induction are likely to take place. As a guideline, lay the control line at least 100mm (3.94") or more away from the main circuit, high-voltage line, or load line.
 - Ground the shield of the analog input/output cable at one point on the signal receiving side. However, do not use common grounding with heavy electrical systems.
- Make sure to properly wire to the terminal block (European type) in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - The disposal size of the cable end should follow the dimensions described in the manual.
 - Tightening torque should follow the specifications in the manual.
 - Twist the end of strand wire and make sure that there are no loose wires.
 - Do not solder-plate the electric wire ends.
 - Do not connect more than the specified number of wires or electric wires of unspecified size.
 - Affix the electric wires so that neither the terminal block nor the connected parts are directly stressed.
- Make sure to properly wire the terminal block in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - The disposal size of the cable end should follow the dimensions described in the manual of the PLC main unit.
 - Tightening torque should follow the specifications in the manual of the PLC main unit.

3.1 Applicable cable and terminal tightening torque

3.1.1 Type terminal block (European type)

- Wire size
 - The power supply wiring and the Type K/J changeover input wiring should use 22-20 AWG wire.
 - Thermocouple wiring should use the compensating lead wire suitable for the type of thermocouple.


→ For details of compensating lead wire, Refer to Section 3.3

Type	Wire size
Single-wire	0.3 mm ² to 0.5 mm ² (AWG22 to 20)
2-wire	2 pieces of 0.3 mm ² (AWG22)

- Termination of cable end
Strip the coating of strand wire and twist the cable core before connecting it, or strip the coating of single wire before connecting it. An alternative connection is to use a ferrule with insulating sleeve.
-Reference>

Manufacturer	Model	Caulking tool
Phoenix Contact Co., Ltd.	AI 0.5-8WH	CRIMPFOX 6 ¹ (or CRIMPFOX 6T-F ²)

¹ Old model name: CRIMPFOX ZA 3
² Old model name: CRIMPFOX UD 6



When using a stick terminal with insulating sleeve, choose a wire with proper cable sheath referring to the above outside dimensions, or otherwise, the wire cannot be inserted easily. The tightening torque must be 0.22 to 0.25 N·m. Do not tighten terminal screws exceeding the specified torque. Failure to do so may cause equipment failures or malfunctions.

Applicable standards

FX3U-4AD-TC-ADP units made in June, 2005 or later comply with the EC Directive (EMC Directive) and UL standards (UL, cUL). Further information can be found in the following manual.

- FX3S Series Hardware Manual (Manual No. JY997D48301)
- FX3G Series Hardware Manual (Manual No. JY997D46001)
- FX3GC Series Hardware Manual (Manual No. JY997D45201)
- FX3U Series Hardware Manual (Manual No. JY997D18801)
- FX3UC (D, DS, DSS) Series Hardware Manual (Manual No. JY997D28601)
- FX3UC-32MT-LT-2 Hardware Manual (Manual No. JY997D31601)

Regarding the standards that relate to the main unit, please refer to either the FX series product catalog or consult with your nearest Mitsubishi product provider.

Attention

- This product is designed for use in industrial applications.

Note

- Authorized Representative in the European Community:
Mitsubishi Electric Europe B.V.
Gothaer Str. 8, 40880 Ratingen, Germany

Caution for EC Directive

The analog special adapters have been found to be compliant to the European standards in the aforesaid manual and directive. However, for the very best performance from what are in fact delicate measuring and controlled output device Mitsubishi Electric would like to make the following points:
As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow those manufacturers installation requirements. Mitsubishi Electric recommend that shielded cables should be used. If NO other EMC protection is provided, then users may experience temporary loss or accuracy between ±10 % in very heavy industrial areas. However, Mitsubishi Electric suggest that if adequate EMC precautions are followed for the users complete control system, users should expect accuracy as specified in this manual.

- Sensitive analog cable should not be laid in the same trunking or cable conduit as high voltage cabling. Where possible users should run analog cables separately.
- Good cable shielding should be used. When terminating the shield at Earth - ensure that no earth loops are accidentally created.
- When reading analog values, EMC accuracy can be improved out by averaging the readings. This can be achieved either through functions on the analog special adapters or through a users program.

1. Outline


FX3U-4AD-TC-ADP (hereinafter called TC-ADP) is an analog special adapter for measuring temperature via four channels of connected Type K or Type J thermocouple thermometer.

1.1 Incorporated Items

Verify that the following product and items are included in the package:

Product	FX3U-4AD-TC-ADP K/J type thermocouple thermometer input special adapter
Accessories	User's manual (This manual)

1.2 External Dimensions, Part Names, and Terminal Layout



- [1] DIN rail mounting groove (DIN rail: DIN46277)
- [2] Name plate
- [3] Special adapter slide lock: Used to connect additional special adapters onto the left side of this special adapter.
- [4] Special adapters connector cover: Remove this cover to connect additional special adapters to the left side. Direct mounting hole: 2 holes of φ4.5 (0.18") (mounting screw: M4 screw) Not used when connecting to FX3GC/FX3UC Series PLC.
- [5] POWER LED (green): Lit while 24 V DC power is supplied properly to terminals '24+' and '24-'.
- [6] Terminal block (European type): Connect thermocouple sensor input, Type K or J changeover input, and 24 V DC power supply.
- [8] Special adapter connector: Used to connect this special adapter to PLC main unit or special adapter.
- [9] DIN rail mounting hook
- [10] Special adapter fixing hook
- [11] Special adapter connector: Used to connect communication or analog special adapters to the left side of the TC-ADP.

2. Installation

For installation/uninstallation details, refer to the respective PLC User's manual Hardware Edition.

INSTALLATION PRECAUTIONS **WARNING**

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

INSTALLATION PRECAUTIONS **CAUTION**

- Use the product within the generic environment specifications described in PLC main unit manual (Hardware Edition). Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂, or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions.
- Connect special adapter securely to their designated connectors. Loose connections may cause malfunctions.

4. Specifications

STARTUP AND MAINTENANCE PRECAUTIONS **CAUTION**

- Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. * For repair, contact your local Mitsubishi Electric representative.
- Do not drop the product or exert strong impact to it. Doing so may cause damage.

DISPOSAL PRECAUTIONS **CAUTION**

- Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device.

TRANSPORTATION AND STORAGE PRECAUTIONS **CAUTION**

- The product is a precision instrument. During transportation, avoid any impacts. Failure to do so may cause failures in the product. After transportation, verify the operations of the product.

4.1 Applicable PLC

Model name	Applicability
FX3S Series PLC	Ver. 1.00 or later (from first production)
FX3G Series PLC	Ver. 1.00 or later (from first production)
FX3GC Series PLC	Ver. 1.40 or later (from first production)
FX3U Series PLC	Ver. 2.20 or later (from first production)
FX3UC Series PLC	Ver. 1.30 or later (from the production manufactured in August, 2004 with SER No. 48****)

The version number can be checked by monitoring D8001/D8101 as the last three digits indicate it.

4.2 General Specifications

Items other than the following are equivalent to the those of the PLC main unit. For general specifications, refer to the respective PLC User's manual Hardware Edition.

Item	Specification
Dielectric withstand voltage	500 V AC for one minute
Insulation resistance	5 MΩ or more by 500 V DC megger

4.3 Power Supply Specifications

Item	Specification
A/D conversion circuit driving power	24 V DC +20 %/-15 %, 45 mA for 24 V DC Connect a 24 V DC power supply to the terminal block.
Interface driving power	5 V DC, 15 mA 5 V DC power is supplied from the internal power supply of main unit.

2.1 Connection to the PLC

This section describes the connection method to the PLC (FX3U Series PLC is used for the following example). For installation method to other PLCs, refer to the respective PLC User's manual Hardware Edition.

Procedure

- Turn off the power.
Disconnect all the cables connected to the PLC main unit and special adapter, and demount the main unit and special adapter mounted on DIN rail or mounted directly using screws.
- Install an expansion board to the main unit.
For the expansion board installation procedure, refer to the following manual:
→ FX3U Series User's Manual - Hardware Edition
- Remove the special adapter connector cover on the expansion board (fig.A).
When connecting this product to another special adapter, please replace the 'expansion board' in the above description with a 'special adapter' and perform the procedure as indicated.
- Slide the special adapter slide lock (fig.B) of the main unit.
When connecting this product to another special adapter, please replace the 'main unit' in the above description with a 'special adapter' and perform the procedure as indicated. (Please replace the following procedures similarly.)
- Connect the special adapter (fig.C) to the main unit as shown on the right
- Slide back the special adapter slide lock (fig.B) of the main unit to fix the special adapter (fig.C).

Connection precautions

Connect all the high-speed I/O special adapters before connecting other special adapters when they are used in combination. **Do not connect a high-speed I/O special adapter on the left side of any special adapters other than other high-speed I/O special adapters.**

4.4 Performance Specifications

Item	Specifications	
	Centigrade (°C)	Fahrenheit (°F)
Input signal	Thermocouple type K or J JIS C 1602-1995	
Rated temperature range	Type K	-100 °C to +1000 °C -148 °F to +1832 °F
	Type J	-100 °C to +600 °C -148 °F to +1112 °F
Digital output	Type K	-1000 to +10000 -1480 to +18320
	Type J	-1000 to +6000 -1480 to +11120
Resolution	Type K	0.4 °C 0.72 °F
	Type J	0.3 °C 0.54 °F
Total accuracy	±(0.5 % full scale +1 °C)	
A/D conversion time	• FX3U/FX3UC Series PLC: 200 μs (The data will be updated at every scan time of the PLC.)	
	• FX3S/FX3G/FX3GC Series PLC: 250 μs (The data will be updated at every scan time of the PLC.)	
Input characteristics	Type K	
	Type J	
Insulation method	• The photocoupler is adopted to insulate the analog input area from the PLC.	
	• The DC/DC converter is adopted to insulate the power supply line from the analog input area.	
Occupied points	• A channels are not insulated from each other.	
	0 point (This number is not related to the maximum number of input/output points of the PLC.)	

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty
Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.