


# Operation Manual

## Smart-UPS<sup>®</sup> X-Series UPS

750 VA  
1000 VA  
1500 VA

120V  
230V



<b>Overview .....</b>	<b>1</b>
<b>About the UPS .....</b>	<b>1</b>
<b>Safety .....</b>	<b>1</b>
<b>Product Overview .....</b>	<b>1</b>
Front panel .....	1
Rear panel .....	1
<b>Specifications .....</b>	<b>2</b>
Operating Conditions .....	2
Environmental Specifications .....	2
<b>Installation .....</b>	<b>2</b>
UPS .....	2
Network Management Card .....	2
External Battery Pack .....	2
 <b>Operation .....</b>	 <b>3</b>
<b>Connect Equipment to the UPS .....</b>	<b>3</b>
Basic Connections .....	3
<b>Display Interface .....</b>	<b>4</b>
Overview .....	4
Using the display interface .....	4
Standard Menus .....	4
Advanced Menus .....	5
 <b>Configuration .....</b>	 <b>6</b>
<b>UPS Settings .....</b>	<b>6</b>
Start-up Settings .....	6
General Settings .....	6
<b>Controllable Outlet Groups .....</b>	<b>7</b>
Overview .....	7
Model-specific Controllable Outlet Groups .....	8
Using the Controllable Outlet Groups and UPS outlets .....	9
Customize the Controllable Outlet Groups and the UPS outlets ..	9
Network Management Card Settings .....	10

<b>Emergency Power Off .....</b>	<b>11</b>
EPO Overview .....	11
Normally open contacts .....	11
Normally closed contacts .....	11
 <b>Troubleshooting .....</b>	 <b>12</b>
 <b>Service and Support.....</b>	 <b>14</b>
Service .....	14
Transport the UPS .....	14
APC Worldwide Customer Support .....	14
 <b>Smart-UPS Factory Warranty .....</b>	 <b>15</b>
LIMITED WARRANTY .....	15

# Overview

## About the UPS

The APC® by Schneider Electric Smart-UPS® X-Series is a high performance Uninterruptible Power Supply (UPS). It provides protection for electronic equipment from utility power blackouts, brownouts, sags, and surges; small utility fluctuations and large disturbances. The UPS also provides battery backup power until utility power returns to safe levels or the batteries are fully discharged.

## Safety



**Read the Safety Guide included in the package before installing the UPS.**

Inspect the UPS upon receipt. Notify the carrier and dealer if there is damage.




Recycle the packaging

## Product Overview

### Front panel


- ❶ Battery
- ❷ Battery connector
- ❸ Display interface
- ❹ Bezel




### Rear panel

- ❶ Smart slot
- ❷ External battery pack connector
- ❸ Outlets
- ❹ EPO connector
- ❺ USB port
- ❻ Serial port
- ❼ TVSS ground screw
- ❽ UPS input
- ❾ Circuit breaker

120 V



230 V



# Specifications

## Operating Conditions


This unit is intended for indoor use only. Select a location sturdy enough to support the weight of the unit and External Battery Packs (XLBP).

Do not operate the UPS where there is excessive dust, or the temperature or humidity are outside the specified limits.

**This unit has front and rear air vents. Allow adequate space for proper ventilation.**

## Environmental Specifications

Environmental factors impact battery life. High temperatures, poor utility power, and frequent, short duration discharges will shorten battery life.




For additional specifications, see the APC Web site at [www.apc.com](http://www.apc.com).

<b>Temperature</b>	<b>Operating</b>	0° to 40° C (32° to 104° F)
	<b>Storage</b>	-15° to 45° C (5° to 113° F) charge UPS battery every six months
<b>Maximum Elevation</b>	<b>Operating</b>	3,000 m (10,000 ft)
	<b>Storage</b>	15,000 m (50,000 ft)
<b>Humidity</b>		0% to 95% relative humidity, non-condensing

# Installation

## UPS




For UPS installation information, see the Smart-UPS X-Series Quick-Start guide that is included with the UPS. The guide is also available on the enclosed CD and the APC Web site at [www.apc.com](http://www.apc.com).

## Network Management Card



For installation information, see the user manual provided with the Network Management Card (NMC). The user manual is also available on the APC Web site at [www.apc.com](http://www.apc.com).

## External Battery Pack



For installation information, see the Smart-UPS X-Series External Battery Pack Installation guide that is included with the external battery pack. The guide is also available on the enclosed CD and the APC Web site at [www.apc.com](http://www.apc.com).


# Operation

## Connect Equipment to the UPS




**Note:** The UPS will charge to 90% capacity in the first three hours of normal operation. **Do not expect full battery run capability during this initial charge period.**

1. Connect equipment to the outlets on the rear panel of the UPS. **Do not use extension cords, plug equipment directly into the UPS.**
2. Connect the UPS to the building utility power. **Connect the UPS to a two-pole, three-wire, grounded receptacle only.**
3. Press the ON/OFF button on the front panel of the UPS to apply power to the unit and all connected equipment.
4. To use the UPS as a master on/off switch, turn on all the equipment that is connected to the UPS.



See “Controllable Outlet Groups” on page 7 for information on how to use the Controllable Outlet Groups.



### Basic Connections



**Serial port:** Connect to a computer to use power management software.



**USB port:** Connect to a computer to use power management software.



**External Battery Pack connector:** Connect external battery packs to provide extended runtime during power outages. The UPS can support up to five external battery packs.




**TVSS Ground Screw:** The UPS features a Transient Voltage Surge-Suppression (TVSS) screw for connecting the ground lead on surge suppression devices such as a telephone and network line protectors. When connecting a grounding cable, disconnect the UPS from utility power.

# Display Interface

## Overview

- ❶ Online indicator
- ❷ UPS Output On/Off button
- ❸ On Battery indicator
- ❹ Fault indicator
- ❺ Replace Battery indicator
- ❻ Display screen
- ❼ UP/DOWN buttons
- ❽ ENTER button
- ❾ ESCAPE button



## Using the display interface

Use UP and DOWN to scroll through the main menu options. Press ENTER to view the sub-menus under each main menu option. Press ESCAPE to exit a sub-menu and return to a main menu.

## Standard Menus

The Standard menus are the most commonly used menus for the UPS.

Menu	General Functions
<b>Status</b>	View basic information about the UPS: <ul style="list-style-type: none"> <li>• Operating mode</li> <li>• Controllable Outlet state, On or Off</li> <li>• Efficiency of the UPS</li> <li>• Information about the load</li> <li>• Battery capacity</li> <li>• Estimated runtime</li> <li>• Input and output voltage and frequency</li> <li>• Information about the last transfer to battery power</li> <li>• Self-test results</li> </ul>
<b>Configuration</b>	Configure the settings for the UPS: <ul style="list-style-type: none"> <li>• Language</li> <li>• Local power quality: Good, Fair, Poor</li> <li>• Choose Standard or Advanced menus</li> <li>• LCD Display mode, Always On or Power-Saving</li> <li>• Audible alarms</li> <li>• Reset to Factory Defaults</li> </ul>
<b>Test &amp; Diags</b>	Use the Test & Diags menu to have the UPS perform a self-test.

<b>Menu</b>	<b>General Functions</b>
<b>About</b>	Display information about this unit: <ul style="list-style-type: none"> <li>• Unit model number</li> <li>• Serial number</li> <li>• Battery installation date</li> <li>• Suggested battery replacement date</li> <li>• Replacement Battery Cartridge model number</li> <li>• UPS firmware version</li> </ul>

## Advanced Menus

The Advanced menus provide additional options for the UPS and are available only if the display interface is configured to use the Advanced Menus.

<b>Menu</b>	<b>General Functions</b>
<b>Status</b>	View detailed information about the UPS: <ul style="list-style-type: none"> <li>• Energy meter</li> <li>• Number of external battery packs connected to the UPS</li> <li>• Load current</li> <li>• Status of the Controllable Outlet Groups</li> <li>• Battery voltage</li> </ul>
<b>Configuration</b>	Configure advanced settings for the UPS: <ul style="list-style-type: none"> <li>• UPS and Controllable Outlet group delays and settings</li> <li>• High and lower transfer points</li> <li>• Sensitivity settings</li> <li>• Date of last battery replacement</li> </ul>
<b>Control</b>	Control the UPS and Controllable Outlet Groups to turn on, turn off, or reboot
<b>Test &amp; Diags</b>	Perform a UPS alarm test or a runtime calibration test
<b>Log</b>	View the event log for information about any changes to the UPS and any faults
<b>About</b>	View information about the unit: <ul style="list-style-type: none"> <li>• Hardware version</li> <li>• Software version</li> <li>• NMC information (if applicable)</li> </ul>



# Configuration

---

## UPS Settings

### Start-up Settings

Configure these settings at initial start-up, using the display interface or APC PowerChute® software.



**Note:** During start-up, use the display interface to configure these settings. If nothing is selected, the unit will use the default settings.

Function	Factory Default	Options	Description
Language	English	<ul style="list-style-type: none"><li>• English</li><li>• French*</li><li>• German*</li><li>• Spanish*</li><li>• Italian*</li></ul>	The language for the display interface.  *Language options will vary by model.
Local power quality	Good	<ul style="list-style-type: none"><li>• Good</li><li>• Fair</li><li>• Poor</li></ul>	Select the quality of input utility power. <ul style="list-style-type: none"><li>• If Good is selected, the unit will go on battery power more often to provide the cleanest power supply to the connected equipment.</li><li>• If Poor is selected, the UPS will tolerate more fluctuations in power and will go on battery power less often.</li></ul> If unsure of the local power quality, select Good.
Menu Type	Standard	Standard or Advanced	The advanced menus include all parameters. The Standard menus display a limited set of menus and options.
Display Mode	Always On	Always On or Power Saving	The display may be always on or may be set to automatically turn on only when using the configuration buttons or if an event occurs.

### General Settings

Configure these settings at any time, using the display interface or APC PowerChute software.

Function	Factory Default	Options	Description
High transfer point	120 V: 140 VAC 230 V: 280 VAC	120 V: 140-150 VAC 230 V: 280-300 VAC	To avoid unnecessary battery usage, set the transfer point higher if the utility voltage is chronically high and the connected equipment is known to work under this condition. This setting may also be adjusted using the power quality setting.
Low Transfer Point	120 V: 75 VAC 230 V: 170 VAC	120 V: 75-85 VAC 230 V: 150-170 VAC	Set the transfer point lower if the utility voltage is chronically low and the connected equipment can tolerate this condition. This setting may also be adjusted using the power quality setting.

Function	Factory Default	Options	Description
<b>Nominal Output Voltage</b>	230 V: 230 VAC	230 V: 220, 230, 240 VAC	Set the nominal output voltage of the UPS on battery. This is available on 230V models only.
<b>Transfer Sensitivity</b>	High	High, Low, Medium	Specify how sensitive the UPS will be towards voltage changes.
<b>Low Battery Warning</b>	90 sec	0-300 sec	The UPS will emit an audible alarm when the remaining runtime has reached this level.
<b>Date of Last Battery Replacement</b>	Date set at factory	Reset this date when the battery module is replaced.	
<b>Audible Alarm</b>	On	On/Off	The UPS will mute all audible alarms if this is set to Off or when the display buttons are pressed.
<b>Battery Self-Test Interval Setting</b>	On start-up and every 14 days since the last test	<ul style="list-style-type: none"> <li>• Never</li> <li>• Start-up only</li> <li>• Frequency of test</li> </ul>	The interval at which the UPS will execute a self-test.
<b>Reset to Factory Default</b>	No	Yes/No	Restore the UPS factory default settings.

## Controllable Outlet Groups

### Overview

The rear panel of the UPS has multiple outlets, some are grouped into Controllable Outlet Groups, all others are the UPS outlets. All of these groups can be configured to turn off, turn on, shut down, and reboot connected equipment, independently of each other.

The Controllable Outlet Groups and the UPS outlets can be configured to react to power events in specific ways:

- Turn off: Disconnect from power immediately and restart only with a manual command
- Turn on: Connect to power immediately
- Shutdown: Disconnect power in sequence, and automatically reapply power in sequence when utility power becomes available
- Reboot: Shut down and restart

In addition, the Controllable Outlet Groups and the UPS outlets can also:

- Turn on or off in a specified sequence
- Shut down when various conditions occur





**Note:** If the Controllable Outlet Groups are not configured, all of the outlets on the unit will still provide battery back-up power.



## Model-specific Controllable Outlet Groups

① Controllable Outlet Group(s)    ② UPS outlets



750VA, 120 V and 230 V.



1000 VA, 120 V and 230 V.



1500 VA, 120 V and 230 V.



## Using the Controllable Outlet Groups and UPS outlets



The UPS outlets function as a master switch. They turn on first when power is applied, shut off last when there is a power outage and battery run-time has been exhausted.

The UPS outlets must be turned on for the Controllable Outlet Groups to turn on.

1. Connect critical equipment to the UPS outlets (except for 1500 VA models; then, connect all critical equipment to one Controllable Outlet Group.)
2. Connect peripheral equipment to the Controllable Outlet Groups.
  - Nonessential equipment that should shut off quickly in the event of a power outage to conserve battery runtime can be added to a short power-off delay
  - If equipment has dependent peripherals that must restart or shut down in a specific order, such as an ethernet switch that must restart before a connected server, connect the devices to separate groups
  - Equipment that needs to reboot independently from other equipment should be added to a separate group
3. Use the Configuration menus to configure how the Controllable Outlet Groups will react in the event of a power outage.

## Customize the Controllable Outlet Groups and the UPS outlets

Use the **Control** menus to change the Controllable Outlet Groups and the UPS outlet settings.

Function	Factory Default	Options	Description
<b>Name String</b> <b>Outlet Group</b>	Outlet Group 1	Edit these names using an external interface, such as the Network Management Card Web interface.	
<b>UPS Name String</b>	UPS Outlets		
<b>Turn On Delay</b>	0 sec	0-32767 sec	The amount of time the UPS or Controllable Outlet Group will wait between receiving the command to turn on and the actual startup.
<b>Turn Off Delay</b>	0 sec	0-32767 sec	The amount of time that the UPS or Controllable Outlet Group will wait between receiving the command to turn off and the actual shut down.
<b>Reboot Duration</b>	4 sec	0-32767 sec	The amount of time that the UPS or Controllable Outlet Group must remain off before it will restart.
<b>Minimum Return Time</b>	0 sec	0-32767 sec	The amount of battery runtime that must be available before the UPS or Controllable Outlet Group will turn on.
<b>Load Shed On Battery</b>	Disabled	<ul style="list-style-type: none"> <li>• Shutdown with Delay</li> <li>• Shutdown immediately</li> <li>• Turn off immediately</li> <li>• Turn off with delay</li> <li>• Disabled</li> </ul>	<p>When the unit switches to battery power, the UPS can disconnect power to the Controllable Outlet Groups to save runtime.</p> <p>Configure this delay time, use the LOAD SHED TIME WHEN ON BATTERY setting.</p>

<b>Function</b>	<b>Factory Default</b>	<b>Options</b>	<b>Description</b>
<b>Load Shed Time when On Battery</b>	Disabled	0-32767 sec	The amount of time the outlets will function on battery power before they will turn off.
<b>Load Shed On Runtime</b>	Disabled	<ul style="list-style-type: none"> <li>• Shutdown with delay</li> <li>• Shutdown immediately</li> <li>• Turn off immediately</li> <li>• Turn off with delay</li> <li>• Disabled</li> </ul>	<p>When the battery runtime falls below the specified value, the Controllable Outlet Group will turn off.</p> <p>Configure this time using the LOAD SHED RUNTIME REMAINING setting.</p>
<b>Load Shed On Runtime Remaining</b>	Disabled	0-32767 sec	When the remaining runtime reaches this level, the Controllable Outlet Group will turn off.
<b>Load Shed on Overload</b>	Disabled	<ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled</li> </ul>	(Applicable only for Controllable Outlet Groups, not the UPS outlets.) When enabled, the Controllable Outlet Group will turn off immediately in the event of a power outage and will have to be manually restarted.

## Network Management Card Settings

These settings are available only on units that have a Network Management Card (NMC) and are set in the factory. These settings can only be modified using an external interface, like the NMC web interface.

- NMC IP Address Mode
- NMC IP Address
- NMC Subnet Mask
- NMC Default Gateway

# Emergency Power Off

## EPO Overview


The Emergency Power Off (EPO) option is a safety feature that will immediately disconnect all connected equipment from utility power. The UPS will immediately shut down and will not switch to battery power.

The UPS must be manually re-started to re-apply power to connected equipment and to the UPS. Press ON/OFF on the front panel of the unit.

## Normally open contacts

1. If the EPO switch or relay contacts are normally open, insert the wires from the switch or contacts at pins 1 and 2 of the EPO terminal block. Use 16-28 AWG wire.
2. Secure the wires by tightening the screws.


Power will be disconnected to the UPS and attached loads if the contacts are closed.



## Normally closed contacts

1. If the EPO switch or relay contacts are normally closed, insert the wires from the switch or contacts at pins 2 and 3 of the EPO terminal block. Use 16-28 AWG wire.
2. Insert a wire jumper between pins 1 and 2. Secure the wires by tightening the three screws at position 1, 2, and 3.

Power will be disconnected to the UPS and attached loads if the contacts are opened.



**Note:** The power for operating the EPO circuit is sourced from pin 1. This is an isolated 24 V which can source only a few milliamperes.

If the normally closed (NC) EPO configuration is used, the EPO switch or relay should be rated for "dry" circuit applications, the rating should be for low voltage and low current applications. This normally implies the contacts are gold-plated.

**Adhere to all national and local electrical codes when wiring the EPO. Wiring must be performed by a qualified electrician.**

The EPO interface is a Safety Extra Low Voltage (SELV) circuit. Connect the EPO interface only to other SELV circuits. The EPO interface monitors circuits that have no determined voltage potential. SELV circuits are controlled by a switch or relay properly isolated from utility power. To avoid damage to the UPS, do not connect the EPO interface to any circuit other than a SELV circuit.

Use one of the following cable types to connect the UPS to the EPO switch.

- CL2: Class 2 cable for general use.
- CL2P: Plenum cable for use in ducts, plenums, and other spaces used for environmental air.
- CL2R: Riser cable for use in a vertical run in a floor-to-floor shaft.
- CLEX: Limited use cable for use in dwellings and for use in raceways.
- Installation in Canada: Use only CSA certified, type ELC, (extra-low voltage control cable).
- Installation in countries other than Canada and the USA: Use standard low-voltage cable in accordance with national and local regulations.

# Troubleshooting

---

<b>Problem and Possible Cause</b>	<b>Solution</b>
-----------------------------------	-----------------

---

## **The UPS will not turn on or there is no output**

---

The unit has not been turned on.	Press the ON button once to turn on the UPS.
The UPS is not connected to utility power.	Ensure that the power cable is securely connected to the unit and to the utility power supply.
The input circuit breaker has tripped.	Reduce the load to the UPS, disconnect nonessential equipment and reset the circuit breaker.
The unit shows very low or no input utility voltage.	Check the AC power supply to the UPS by plugging in a table lamp. If the light is very dim, check the utility voltage.
The battery connector plug is not securely connected.	Ensure that all battery connections are secure.
There is an internal UPS fault.	Do not attempt to use the UPS. Unplug the UPS and have it serviced immediately.

---

## **The UPS is operating on battery, while connected to input utility power**

---

The input circuit breaker has tripped.	Reduce the load to the UPS, disconnect nonessential equipment and reset the circuit breaker.
There is very high, very low, or distorted input line voltage.	Move the UPS to a different outlet on a different circuit. Test the input voltage with the utility voltage display. If acceptable to the connected equipment, reduce the UPS sensitivity.

---

## **UPS is emitting an audible beeping sound**

---

The UPS is in normal operation.	None. The UPS is protecting the connected equipment.
---------------------------------	--

---

## **UPS does not provide expected backup time**

---

The UPS battery is weak due to a recent outage or is near the end of its service life.	Charge the battery. Batteries require recharging after extended outages and wear out faster when put into service often or when operated at elevated temperatures. If the battery is near the end of its service life, consider replacing the battery even if the replace battery LED indicator is not yet illuminated.
The UPS is overloaded.	Check the UPS load display. Unplug unnecessary equipment, such as printers.

---

## **Display interface indicators flash sequentially**

---

The UPS has been shut down remotely through software or an optional accessory card.	None. The UPS will restart automatically when utility power returns.
---	--

---

## **All indicators are lit and the UPS emits a constant beeping sound**

---

Internal UPS fault.	The fault LED is illuminated and the unit displays a fault message. Do not attempt to use the UPS. Turn the UPS off and have it serviced immediately.
---------------------	---

---

<b>Problem and Possible Cause</b>	<b>Solution</b>
-----------------------------------	-----------------

---

**All indicators are illuminated and the UPS is plugged into a wall outlet**

---

The UPS has shut down and the battery has discharged from an extended outage.	None. The UPS will return to normal operation when the power is restored and the battery has a sufficient charge.
---	---

---

**The replace battery LED is illuminated**

---

The battery has a weak charge.	Allow the battery to recharge for at least four hours. Then, perform a self-test. If the problem persists after recharging, replace the battery.
--------------------------------	--

---

The replacement battery is not properly connected.	Ensure that the battery connector is securely connected.
--	--

---

**The display interface has a Site Wiring Fault message**

---

Wiring faults detected include missing ground, hot-neutral, polarity reversal, and overloaded neutral circuit.	If the UPS indicates a site wiring fault, have a qualified electrician inspect the building wiring. (Applicable for 120 V units only.)
--	--



# Service and Support

---

## Service

If the UPS requires service, do not return it to the dealer. Follow these steps:

1. Review the problems discussed in *Troubleshooting* in this manual to eliminate common problems.
2. If the problem persists, contact APC Customer Support through the APC Web site, **www.apc.com**.
  - a. Note the model number of the UPS, the serial number located on the rear side of the unit, and the date of purchase.
  - b. Call APC Customer Support and a technician will attempt to solve the problem over the phone. If this is not possible, the technician will issue a Returned Material Authorization Number (RMA#).
  - c. If the UPS is under warranty, repairs are free.
  - d. Procedures for servicing or returning products may vary internationally. Refer to the APC Web site for country specific instructions.
3. Pack the UPS in its original packaging. If this is not available, refer to **www.apc.com** for information about obtaining a new set.
  - a. Pack the UPS properly to avoid damage in transit. Never use foam beads for packaging. Damage sustained in transit is not covered under warranty.
  - b. **Always DISCONNECT THE BATTERY before shipping in compliance with U.S. Department of Transportation (DOT) and IATA regulations.** The battery may remain in the UPS.
4. Write the RMA# provided by Customer Support on the outside of the package.
5. Return the unit by insured, pre-paid carrier to the address given to you by Customer Support.

## Transport the UPS

1. Shut down and disconnect all equipment connected to the UPS.
2. Shut down and disconnect the UPS from utility power.
3. Disconnect the UPS from all internal and external batteries.
4. Follow the shipping instructions outlined in the *Service* section of this manual.

## APC Worldwide Customer Support

Customer support for this or any other APC product is available at no charge in any of the following ways:

- Visit the APC Web site to access documents in the APC Knowledge Base and to submit customer support requests.
  - **www.apc.com** (Corporate Headquarters)  
Connect to localized APC Web sites for specific countries, each of which provides customer support information.
  - **www.apc.com/support/**  
Global support searching APC Knowledge Base and using e-support.
- Contact the APC Customer Support Center by telephone or e-mail.
  - Local, country-specific centers: go to **www.apc.com/support/contact** for contact information.

For information on how to obtain local customer support, contact the APC representative or other distributors from whom you purchased your APC product.

# Smart-UPS Factory Warranty

---

## LIMITED WARRANTY

American Power Conversion (APC) warrants its Smart-UPS (Products) to be free from defects in materials and workmanship for a period of three (3) years, excluding the batteries, which are warranted for two (2) years from date of purchase. APC's obligation under this warranty is limited to repairing or replacing, at its own sole option, any such defective products. Repair or replacement of a defective Product or part thereof does not extend the original warranty period.

This warranty applies only to the original purchaser who must have properly registered the Product within 10 days of purchase. Products may be registered online at [warranty.apc.com](http://warranty.apc.com).

APC shall not be liable under this warranty if its testing and examination disclose that the alleged defect in the Product does not exist or that it was caused by end user's or any third person's misuse, negligence, improper installation, testing, operation or use of the Product contrary to APC's recommendations or specifications. Further, APC shall not be liable for defects resulting from: 1) unauthorized attempts to repair or modify the Product, 2) incorrect or inadequate electrical voltage or connection, 3) inappropriate on-site operation conditions, 4) Acts of God, 5) exposure to the elements, or 6) theft. In no event shall APC have any liability under this warranty for any Product where the serial number has been altered, defaced, or removed.

EXCEPT AS SET FORTH ABOVE, THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, APPLICABLE TO PRODUCTS SOLD, SERVICED OR FURNISHED UNDER THIS AGREEMENT OR IN CONNECTION HEREWITH.

APC DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTION AND FITNESS FOR A PARTICULAR PURPOSE.

APC EXPRESS WARRANTIES WILL NOT BE ENLARGED, DIMINISHED, OR AFFECTED BY AND NO OBLIGATION OR LIABILITY WILL ARISE OUT OF, APC'S RENDERING OF TECHNICAL OR OTHER ADVICE OR SERVICE IN CONNECTION WITH THE PRODUCTS.

THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES. THE WARRANTIES SET FORTH ABOVE CONSTITUTE APC'S SOLE LIABILITY AND PURCHASER'S EXCLUSIVE REMEDY FOR ANY BREACH OF SUCH WARRANTIES. APC'S WARRANTIES RUN ONLY TO ORIGINAL PURCHASER AND ARE NOT EXTENDED TO ANY THIRD PARTIES.

IN NO EVENT SHALL APC, ITS OFFICERS, DIRECTORS, AFFILIATES OR EMPLOYEES BE LIABLE FOR ANY FORM OF INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, ARISING OUT OF THE USE, SERVICE OR INSTALLATION, OF THE PRODUCTS, WHETHER SUCH DAMAGES ARISE IN CONTRACT OR TORT, IRRESPECTIVE OF FAULT, NEGLIGENCE OR STRICT LIABILITY OR WHETHER APC HAS BEEN ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES. SPECIFICALLY, APC IS NOT LIABLE FOR ANY COSTS, SUCH AS LOST PROFITS OR REVENUE (WHETHER DIRECT OR INDIRECT), LOSS OF EQUIPMENT, LOSS OF USE OF EQUIPMENT, LOSS OF SOFTWARE, LOSS OF DATA, COSTS OF SUBSTITUANTS, CLAIMS BY THIRD PARTIES, OR OTHERWISE.

NO SALESMAN, EMPLOYEE OR AGENT OF APC IS AUTHORIZED TO ADD TO OR VARY THE TERMS OF THIS WARRANTY.

NOTHING IN THIS LIMITED WARRANTY SHALL SEEK TO EXCLUDE OR LIMIT APC'S LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM ITS NEGLIGENCE OR ITS FRAUDULENT MISREPRESENTATION OR TO THE EXTENT THAT IT CANNOT BE EXCLUDED OR LIMITED BY APPLICABLE LAW.

To obtain service under warranty you must obtain a Returned Material Authorization (RMA) number from customer support. Customers with warranty claims issues may access the APC worldwide customer support network through the APC Web site: [support.apc.com](http://support.apc.com). Select your country from the country selection pull-down menu. Open the Support tab at the top of the web page to obtain contact information for customer support in your region. Products must be returned with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase.

**Harmonized Standards** EN60950-1; IEC60950-1; EN62040-1-1; EN55022; EN55024;  
IEC61000-3-2, 3-3, 4-2, 4-3, 4-4, 4-5, 4-6, 4-11

**Applicable Council Directives** 2006/95/EC; 2004/108/EC

**Type of Equipment** Uninterruptible Power Supply

**Model Numbers** SMX750I, SMX1000I, SMX1500RMI2U, SMX1500RMI2UNC

**Manufacturers**

American Power Conversion  
132 Fairgrounds Rd  
West Kingston, RI 02892  
USA

American Power Conversion  
2nd Street, PEZA  
Cavite Economic Zone  
Rosario, Cavite  
Philippines

APC (Suzhou) UPS Co., Ltd  
339 Suhong Zhong Lu  
Suzhou Industrial Park  
Suzhou Jiangsu 215021  
P.R. China

American Power Conversion  
Ballybritt Business Park  
Galway  
Ireland

American Power Conversion  
Lot 10, Block 16, Phase 4  
PEZA, Rosario, Cavite  
Philippines

APC Power Infrastructure Co., Ltd  
1678 Ji Xian Road, Tong An  
Xiamen 361100  
P.R. China

American Power Conversion  
Breaffy Rd, Castlebar  
Co Mayo  
Ireland

American Power Conversion  
Lot 3, Block 14, Phase 3  
PEZA, Rosario, Cavite  
Philippines

APC India Pvt Ltd  
187/3, Jigani Industrial Area  
Bangalore, Karnataka 562106  
India

APC Brazil LTDA  
Al. Xingu, 850, Barueri  
Alphaville/Sao Paulo 06455-030  
Brazil

**Importer** American Power Conversion (APC) Ballybritt Business Park Galway, Ireland

**Place** Galway, Ireland Gerry Daly, Managing Director, Europe  
01/February/2009



© 2009 APC by Schneider Electric. APC, the APC logo are owned by Schneider Electric Industries S.A.S., American Power Conversion Corporation, or their affiliated companies. All other trademarks are property of their respective owners.