## 296-2360 Earth Leakage Relay with Transformer



## **Connection & Test**

Check the Auxiliary Voltage on the Relay label and connect it as shown on one of the wiring diagrams adjacent (230V Phase and neutral shown) ensuring that the supply cables pass through the 35mm aperture in the relay.

When the auxiliary voltage is present the Green LED marked POWER will light.

Set the tripping Current as required: (0.03) = 30mA (0.1) = 100mA (0.3) = 300mA (0.5) = 500mA (1) = 1 Amp (3) = 3 Amps

Set the Time delay switch as required. 0.02, 0.1, 0.3, 0.5, 0.75 or 1 second.

Press the Test button to check that the tripping function operates. The Red LED marked with the Earth sign will light and the POWER LED will go out..

Press the Reset button to reset the relay.

Do not press the Test and Reset buttons together.

## **Technical**

Auxiliary Voltage: 230V AC Voltage Tolerance: + or - 20% Frequency: 50....60Hz

Tripping response: 0.03A (30mA) ....3A
Time delay: 0.02....1 second
Reset: Manual or Remote
Test: Local or Remote button

Relay contact: 6A, 250V AC Resistive load

4.5A, AC11, 250V AC 5A DC11 30V DC

Remote Meter (depending on Trip current)

0.03A 2.25 mV / mA 0.1A 0.68 mV / mA 0.3A 0.25 mV / mA 0.5A 0.15 mV / mA 1A 0.07 mV / mA 3A 0.025 mV / mA

Insulation: 1500V AC Mounting: DIN Rail or Screw

fixing

Enclosure: DIN Rail 6 module

Protection: IP41
Terminals: IP20
Weight: 0.41 Kg

Standards: IEC364; IEC755; UTE60 - 130;

VDE664; NFC61-141( Sect. 1)





