

The Tool is Used to Crimp:

AMPLI-BOND* Terminals, PLASTI-GRIP* Terminals, TERMINYL* Terminals and Splices, Pre-Insulated nylon Heavy Duty Terminals, Pre-Insulated AMPOWER* Terminals, and Sealed COPALUM* Terminals and Splices.

Figure 1

1. INTRODUCTION

This instruction sheet provides application, maintenance, and inspection procedures for Crimping Heads 58422-1 and 2161730-1 (part number 2161730-1 is a special version of part number 58422-1, with an extended stroke for terminating sealed COPALUM quick-termination connectors).

A typical crimping head is shown in Figure 1. The crimping heads accept interchangeable die sets for a variety of heavy-duty terminals and splices for large wire sizes - within Size 8 through 4/0 AWG range. Refer to instructions packaged with specific die sets for compatible products, wire ranges, strip dimensions, and application procedures.

The crimping heads are designed for two DYNA-CRIMP* tools: either Hydraulic Hand Pump 314979-1 (covered in customer manual 409-5860) or Hydraulic Power Unit 69120-[] (described in 409-1950). Read these instructions, and all applicable references, before inserting any die assemblies and crimping any terminals or splices.

NOTE



Dimensions on this sheet are in millimeters [with inches in brackets].

Reasons for reissue are provided in Section 8, REVISION SUMMARY.

2. DESCRIPTION

Main components of the crimping head are: a yoke which houses the stationary die and retains the terminal assembly for crimping, a removable latch pin which allows pivoting of the yoke on the pivot pin (typically required for splice terminations), a cylinder which contains the head's hydraulic chamber, a piston (ram) which holds and controls the moving die, and a quick connect/disconnect coupler (cylinder half) which mates with the coupler on hose or handle control to release or supply pressure.

DANGER



To avoid injury when using DYNA-CRIMP equipment, observe the following precautions:

- Do NOT modify the crimping equipment in any way.
- Use only dies, terminals, and wire specified for the head.
- Do NOT perform repairs other than those specified in the instructional material supplied with the equipment.

3. CRIMPING HEAD INSTALLATION

Each crimping head is shipped with a coating of lubricating oil to prevent rust and corrosion. Wipe the oil off before installing the crimping head on the power unit. Note that the crimping head is shipped without oil inside the cylinder. To install crimping head, proceed as follows.

DANGER



Make sure that hydraulic pressure to hose or handle control is released and that power supply is disconnected to electric power unit, if applicable.

1. Remove protective dust caps from both quick connect/disconnect couplers.
2. Hold hose or handle control vertically to prevent oil spillage. Attach hose or handle control to coupling section on head. Thread properly and tighten securely.

CAUTION



Oil flow must be unobstructed between power unit and crimping head. Make sure that all couplers are fully mated and tightened.

NOTE



If crimping head must be removed after being in production, pressure must be released in the hydraulic system before head is removed.
 - If using Hydraulic Power Unit 69120-[], DISCONNECT POWER UNIT FROM POWER SUPPLY.
 - If using Hydraulic Hand Pump 314979-1, depress the pressure release.




Figure 2

4. DIE INSERTION AND REMOVAL (Figure 2)

DANGER



Avoid personal injury. When using power unit, exercise caution to avoid accidentally depressing foot pedal or handle control when installing or changing dies.

Make sure that matched die set, terminal, and wire size are compatible. With crimping head properly installed, refer to die set instructions, and insert / change die set as follows:

1. Remove latch pin and open yoke on crimping head.
2. Loosen setscrew in yoke. Refer to die set instructions and insert stationary (upper) die which includes the nest area into well of yoke. Tighten setscrew.
3. Activate power unit to advance ram until setscrew is visible (about 12.7 mm [.50 in.]). Loosen setscrew.
4. Insert moving (lower) die, which serves as the indenter, into ram well, making sure that moving die is properly oriented to mate with stationary die. Tighten setscrew.
5. Close yoke and secure with latch pin.
6. Slowly close dies to ensure proper alignment.

7. Complete the cycle and return the ram to the DOWN position.

CAUTION



Always ensure that latch pin is fully inserted or damage may occur to yoke, dies, or latch pin.

5. CRIMPING PROCEDURE

DANGER



Avoid personal injury. When operating power unit, exercise caution while holding terminals, splices, or wire near crimping area.

The following crimping procedure provides general information. Refer to instructions packaged with individual die sets for specific products, wire sizes, strip dimensions, positioning of terminals and splices in the dies, and crimping procedures.

NOTE



Never operate the power unit without having a crimping head attached to the handle control or crimping head coupling.

1. Insert terminal or splice in the stationary (upper) die according to instructions packaged with the dies. Make sure the latch pin is secure before activating the power unit.
2. Slowly advance moving (lower) die with short, quick strokes until terminal or splice is secure.
3. Insert the stripped wire.
4. Cycle tool to complete crimp. Remove crimped terminal or splice.

NOTE



If the splice or terminal sticks in the die after crimping, apply a rocking action to remove it from the die.

6. INSPECTION / MAINTENANCE

DANGER



Make sure hydraulic pressure is released and power supply is disconnected before following inspection and maintenance procedures, unless otherwise specified in the procedure.

Each crimping head is assembled and inspected before shipment. TE Connectivity recommends that the crimping head be inspected immediately upon its arrival at your facility, and at regularly scheduled intervals, to ensure that the crimping head has not been damaged during handling. Frequency of inspection depends upon the following: care, amount of use, and handling of the head; type and size of products crimped; degree of operator skill; and environmental conditions.

6.1. Cleaning

Remove accumulations of dirt and grease on the crimping head, especially in areas where dies are installed and terminals are crimped. Clean the entire head frequently with a clean, lint-free cloth.

6.2. Visual Inspection

Refer to Figure 3 and proceed as follows:

1. With hydraulic pressure released, inspect the assembled head for nicks, scratches, and cracks. Inspect for cracks especially at the corners of the yoke and around the top of the cylinder.
2. Inspect pivot pin holes and latch pin holes for wear. Replace parts, as needed.
3. Activate power unit. Raise ram to UP position. Inspect flat and round surfaces of ram for galling (fretting or wear by friction), cracks, or oil leakage. Release pressure and make sure that ram retracts smoothly.
4. If head shows evidence of galling, cracks, oil leakage, or rough cycling, return the crimping head for repairs. (Refer to Section 7, REPLACEMENT AND REPAIR).




Figure 3

6.3. Crimping Head Check-Out Procedure

If the ram fails to return to the DOWN position after completion of a crimping cycle, the cause may be in the crimping head. To determine whether or not the trouble is in the crimping head, proceed as follows:

A. With Hydraulic Power Unit 69120-0

With power unit activated, press the pressure release button on the electrical control box. Or, if the unit has the “dump” feature, move the trigger to the “dump” position and hold for several seconds. This will release any pressure in the hydraulic system. If the ram returns to DOWN position, the trouble is NOT in the crimping head. If ram does not return, ensure that the coupler is fully engaged. If coupler is engaged and ram still does not go DOWN, return the crimping head for repairs.

B. With Hydraulic Hand Pump 314979-1

With power unit activated, turn the hold/return lever to the RETURN position. If the ram fails to return to the START or DOWN position, return the crimping head for repairs.

7. REPLACEMENT AND REPAIR

Customer-replaceable parts are listed in Figure 4. A complete inventory can be stocked and controlled to prevent lost time when replacement of parts is necessary. Order replacement parts through your TE representative, or call 1-800-526-5142, or send a facsimile of your purchase order to 1-717-986-7605, or write to:


CUSTOMER SERVICE (038-035)
 TYCO ELECTRONICS CORPORATION
 PO BOX 3608
 HARRISBURG PA 17105-3608

Tools may also be returned to TE for evaluation and repair. For tool repair service, contact a TE representative at 1-800-526-5136.

8. REVISION SUMMARY

Since the previous release of this document, the following changes were made:

- Added Crimping Head 2161730-1 to document.
- Corrected trademark references in Figure 1.
- Updated company name, logo, and format to corporate requirements.



REPLACEMENT PARTS FOR CRIMPING HEADS 58422-1 AND 2161730-1

ITEM	PART NUMBER	DESCRIPTION	QTY PER HEAD
1	311471-1	Coupler, Quick Connect / Disconnect	1
2	306209-8	Pin, Removable Latch	1
3	8-59558-5	Pin, Pivot	1
4	1-21045-1	Ring, Retaining	1
5	4-21012-0	Setscrew	3
6	4-23147-7	Spring, Compression	1
7	1-21919-6	Pin, Dowel	1

Figure 4