
Thermo-chiller *HRS Series* Maintenance Handbook



- | | |
|---|---|
| 1 Safety Instructions | 8 Fluorocarbons |
| 2 Thermo-chiller HRS Series | 9 Earthquake Resistance Strength Calculation:
Selection of Anchor Bolts |
| 3 Quick Manual and Check Sheets | 10 Customer Support Flow Chart for Use
in the Event of a Problem |
| 4 Maintenance | 11 Frequently Asked Questions (FAQ) |
| 5 Replacement Procedure for Mechanical Seal | Technical Data/Glossary of Terms |
| 6 Fluorocarbon Recovery Procedure | |
| 7 Replacement Procedure for Filling
Coolant Gas | |

To users of this handbook

This handbook is for use only by qualified refrigeration service technicians who hold valid local authorization. The procedures in this handbook require special skills and the use of special equipment and tools. The work required will be either extremely difficult or impossible for an un-authorized technician to perform.

Read the accompanying service manual in addition to this handbook, and be sure to fully understand the contents before performing any repair work. Also, prepare the product operation manual in advance.

Only a fully-qualified technician who understands the content of the operation manual and the procedures for this model, and who has sufficient knowledge of general machinery and equipment can perform the maintenance and repair of this product.

All work must be performed according to the procedures. However, SMC will not be held responsible for any problems incurred during the work.

It is strictly prohibited to copy, transfer or lend this handbook entirely or partially without prior permission from SMC.

Other caution

Follow any special safety instructions if there is any given for the working site.

Thermo-chiller *HRS Series* Maintenance Handbook

CONTENTS

1 Safety Instructions	1
Before Starting Maintenance on the Product	1
Reading the Handbook	1
Hazards	2
• Level of hazards	2
• Definition of “Serious injury” and “Light injury”	2
• Types of hazard labels	3
• Locations of hazard labels	4
Other Labels	5
• Product label	5
Safety Measures	5
• Safety instructions for use	5
Waste Disposal	6
• Disposal of refrigerant and compressor oil	6
• Disposal of product	6
Material Safety Data Sheet (SDS)	6
2 Thermo-chiller HRS Series	7
Features	7
How to Order/Specifications	
• Single-phase 100/115 VAC	15
• Single-phase 200 to 230 VAC	17
Cooling Capacity	19
Heating Capacity	21
Pump Capacity/Required Facility Water Flow Rate	23
Dimensions	24
Center of Gravity	27
Flow Chart	29
Electric Circuit Diagram	31
Construction	33
HRS012-A-10-□, TP (FEB. 2015) or earlier	33
HRS012-A-10-□, After TQ (MAR. 2015)	35
HRS012-W-10-□, TP (FEB. 2015) or earlier	37
HRS012-W-10-□, After TQ (MAR. 2015)	39
HRS018-A-10-□, TP (FEB. 2015) or earlier	41
HRS018-A-10-□, After TQ (MAR. 2015)	43
HRS018-W-10-□, TP (FEB. 2015) or earlier	45

HRS018-W□-10-□, After TQ (MAR. 2015)	47
HRS012-A□-20-□, TP (FEB. 2015) or earlier	49
HRS012-A□-20-□, After TQ (MAR. 2015)	51
HRS012-W□-20-□, TP (FEB. 2015) or earlier	53
HRS012-W□-20-□, After TQ (MAR. 2015)	55
HRS018-A□-20-□, TP (FEB. 2015) or earlier	57
HRS018-A□-20-□, After TQ (MAR. 2015)	59
HRS018-W□-20-□, TP (FEB. 2015) or earlier	61
HRS018-W□-20-□, After TQ (MAR. 2015)	63
HRS024-A□-20-□, TP (FEB. 2015) or earlier	65
HRS024-A□-20-□, After TQ (MAR. 2015)	67
HRS024-W□-20-□, TP (FEB. 2015) or earlier	69
HRS024-W□-20-□, After TQ (MAR. 2015)	71
HRS030-A□-20-□, TP (FEB. 2015) or earlier	73
HRS030-A□-20-□, After TQ (MAR. 2015)	75
HRS030-W□-20-□, TP (FEB. 2015) or earlier	77
HRS030-W□-20-□, After TQ (MAR. 2015)	79
HRS050-A□-20-□	81
HRS050-W□-20-□	83
HRS060-A□-20-□	85
HRS060-W□-20-□	87
Replacement Parts for Optional Accessories	89
Replacement Parts List	91
● Replacement parts for circulating fluid circuit and electrical circuit	91
● Replacement parts for refrigeration circuit and facility water circuit	95
● Other replacement parts	97
● Replacement parts for optional accessories	97
Illustration of Replacement Parts	99
● Dustproof filter	99
● Panel	99
● Temperature sensor	100
● Hose	100
● Pressure sensor (For circulating fluid)	101
● Level switch	101
● DC power supply	102
● Main board/Communication board/Power board/Display board/Fuse	103
● Pump	105
● Fan	106
● Tank	106
● Tank lid	107
● Valve for automatic water fill	107

● Power switch	108
● Inlet socket	108
● Compressor.....	108
● Condenser (For air-cooled type)	109
● Heat exchanger (For water-cooled type)	109
● Water regulating valve	110
● Filter dryer.....	110
● Electronic expansion valve, Electronic expansion valve coil	110
● Heat exchanger	111
● Pressure sensor (For refrigerant)	111
● Thermistor sensor.....	111
Parts Replacement Cycle.....	112
Product Warranty	113
I. Product Warranty	113
II. Special Instructions	114
△ Safety Instructions.....	115

3 Quick Manual and Check Sheets 116

Quick Manual	117
Read Before Using.....	117
Safety Instructions	117
1. Name of Parts and Accessories.....	117
2. Transportation, Transfer and Moving	117
3. Mounting and Installation	118
4. Piping	118
5. Filling of Circulating Fluid	118
6. Wiring of Power Supply	119
7. Start, Stop and Temperature Setting.....	119
8. How to Reset Alarms.....	120
9. Alarm Code List	120
Before Requesting Service	120
Piping Check Sheet	121
Inspection Monitor Screen Check Sheet	123

4 Maintenance 132

Alarms: Causes and Remedies (HRS012/018/024/030/050/060)	133
● Alarm Troubleshooting	133
① No screen display or alarm, but chiller won't start up.....	133
② Chiller starts up, but won't cool.....	133
③ Won't warm up (Low load, Cooling load).....	135
④ Circulating fluid, facility water, automatic water fill, etc., won't flow	136

⑤ Circulating fluid/Refrigerant leakage	136
⑥ Recommended replacement period of main functioning parts	137
⑦ Sensor disconnection and other part errors.....	137
⑧ Purity levels when using deionized water as the circulating fluid	137
Troubleshooting of Alarms	138
● AL01: Low level in tank	138
● AL02: High circulating fluid discharge temp. [For air-cooled type]	140
● AL02: High circulating fluid discharge temp. [For water-cooled type]	149
● AL03: Circulating fluid discharge temp. rise	158
● AL04: Circulating fluid discharge temp. drop	159
● AL05: High circulating fluid return temp.....	161
● AL06: High circulating fluid discharge pressure	163
● AL07: Abnormal pump operation	166
● AL08: Circulating fluid discharge pressure rise	171
● AL09: Circulating fluid discharge pressure drop.....	174
● AL10: High compressor intake temp.....	175
● AL11: Low compressor intake temp.	177
● AL12: Low super heat temperature.....	179
● AL13: High compressor discharge pressure [For air-cooled type]	184
● AL13: High compressor discharge pressure [For water-cooled type]	193
● AL15: Refrigerant circuit pressure (high pressure side) drop	200
● AL16: Refrigerant circuit pressure (low pressure side) rise	205
● AL17: Refrigerant circuit pressure (low pressure side) drop	209
● AL18: Compressor overload [For air-cooled type]	214
● AL18: Compressor overload [For water-cooled type]	219
● AL19: Communication error	224
● AL20: Memory error	224
● AL21: DC line fuse cut	225
● AL22: Circulating fluid discharge temp. sensor failure	225
● AL23: Circulating fluid return temp. sensor failure	227
● AL24: Compressor intake temp. sensor failure	229
● AL25: Circulating fluid discharge pressure sensor failure.....	232
● AL26: Compressor discharge pressure sensor failure.....	234
● AL27: Compressor intake pressure sensor failure	236
● AL28: Maintenance of pump	238
● AL29: Maintenance of fan motor [For air-cooled type].....	238
● AL30: Maintenance of compressor	238
● AL31: Contact input 1 signal detection	239
● AL32: Contact input 2 signal detection	239
● AL33: Water leakage	240
● AL34: Electric resistivity/conductivity rise	241

● AL35: Electric resistivity/conductivity drop	241
● AL36: Electric resistivity/conductivity sensor error	241
Troubleshooting of Errors without Alarm Generation	242
● The circulating fluid temperature does not go down	242
● The circulating fluid temperature does not go up	242
● The operation panel displays nothing	242
● Impossible to operate the thermo-chiller with the "RUN/STOP" key on the operation panel ...	244
● Lights on the operation panel or display(s) on the digital display does not operate ...	244
● The alarm buzzer does not sound	245
● Facility water does not flow (for water-cooled type)	245
● Automatic water fill does not operate (for Option J "Automatic water fill specification") ...	246
Replacement Parts Chart	249
Parts Replacement Procedure	250
Precautions for Whole Work	250
● Preparation for work	250
● Check after work	250
● Tools to be used	251
● Removal and mounting of the panel	253
● Discharge of the circulating fluid and facility water	255
Check After Work	259
● Starting the product	259
● Stopping the product	259
● Check items after starting	259
Replacement Procedure	260
● Replacement of temperature sensor (PT1)	260
● Replacement of temperature sensor (PT2)	262
● Replacement of pump (For standard pump)	264
● Replacement of high pressure pump	268
● Replacement of mechanical seal set	271
● Replacement of fan	275
● Replacement of level switch	279
● Replacement of pressure sensor	282
● Replacement of dustproof filter	284
● Replacement of front panel	286
● Replacement of tank	291
● Replacement of tank (For automatic water fill)	293
● Replacement of inlet socket	297
● Replacement of power switch	299
● Replacement of DC power supply	301
● Replacement of main board & communication board	304
● Replacement of power board	307

● Replacement of display board	309
● Replacement of hose	313
● Replacement of fuse	322
● Replacement of valve for automatic water fill	325
● Replacement of compressor	327
● Replacement of heat exchanger	346
● Replacement of air-cooled condenser	354
● Replacement of water-cooled condenser	366
● Replacement of water pressure regulating valve	374
● Replacement of filter dryer	380
● Replacement of electric expansion valve	392
● Replacement of refrigerant pressure sensor	401
5 Replacement Procedure for Mechanical Seal	409
Models with Mechanical Seal	409
● HRS012/018/024/030-A□-20-(M)T	409
● HRS012/018/024/030-W□-20-(M)T	409
● HRS050/060-A□-20-□(M)	410
● HRS050/060-W□-20-□(M)	410
Service Parts to Be Used	411
Tools to Be Used and Recommended Protective Equipment	412
Internal Construction of the Pump	415
Replacement Procedure	416
● Removal procedure	416
● Cleaning procedure	424
● Remounting procedure	427
● Inspection and precautions before use	434
6 Fluorocarbon Recovery Procedure	435
● Structure of recovery equipment	435
● Other tools to be prepared	437
● Connection with recovery cylinder and gauge manifold	438
● Connection of the power supply cable and float switch (safety device) cable	439
● Connection with thermo-chiller	439
● Preparation for recovery	440
● Starting the recovery process	441
● Finishing the recovery process	442
● Submission of certificate for fluorocarbon recovered	443
7 Replacement Procedure for Filling Coolant Gas	444
● Flow chart	444

● Required tools	445
● Procedure	447
● Submission of certificate for fluorocarbon filled	449
8 Fluorocarbons	450
● Types of fluorocarbons and regulations	450
● Reduction plan in accordance with the Montreal Protocol, Kyoto Protocol, and Paris Agreement	450
● The “Act on Rational Use and Proper Management of Fluorocarbons” was put into force in April 2015.	451
● Importing restrictions on Hydrofluorocarbons (HFCs) into the European Union (EU). EU F-Gas Regulation (517/2014)	455
● Handling of thermo-chillers that have become unnecessary	457
9 Earthquake Resistance Strength Calculation: Selection of Anchor Bolts	458
● Installation location and anticipated seismic force	458
● Anchor bolt (M8), Anti-quake bracket (HRS-TK001/002) specifications	460
● Force acting on anchor bolts	460
● Result of anchor bolt selection (Result of earthquake resistance strength calculation) ...	462
10 Customer Support Flow Chart for Use in the Event of a Problem	463
Customer support flow chart for when there is a problem with a product an end user in country B has purchased from a distributor in country A	463
11 Frequently Asked Questions (FAQ)	465
Technical Data/Glossary of Terms	468



Before starting maintenance on the product, be sure to carefully read and fully understand all the warnings and precautions described in this handbook.

■ Before Starting Maintenance on the Product

- This chapter describes safety related issues regarding the maintenance of the product.
- This product is a circulating fluid temperature controller. SMC shall not take any responsibility for any problems that may arise from using the product for other purposes.
- This product is for the indoor use and not available outdoor.
- This product is not designed for a clean room. It generates dust from the internal components such as pump and fan motor (for air-cooled type).
- This product operates at a high voltage and contains components which become very hot and rotate. If a component needs to be replaced or repaired, use extreme caution regarding electric shocks, burns, cuts, and entanglement.
- All personnel who work with or around the product and those involved in the maintenance, operation, or other work related to the product should carefully read and fully understand the safety related information in this handbook before starting any maintenance work.

■ Reading the Handbook

This handbook contains symbols to help identify important actions when performing maintenance.



This sign stands for actions that must be followed.



This sign stands for prohibited actions.

■ Hazards

● Level of hazards

The instructions given in this handbook aim to assure safe and correct operation of the unit and to prevent injury of operators or damage to the unit. These instructions are grouped into three categories, Danger, Warning and Caution, which indicate the level of hazard, damage and also the degree of emergency. All texts that contain safety critical matter and should be carefully observed.

DANGER, WARNING and CAUTION signs are in order according to seriousness (DANGER > WARNING > CAUTION).



DANGER

“DANGER”: Hazard that will cause serious personal injury or death during operation.



WARNING

“WARNING”: Hazard that may cause serious personal injury or death during operation.



CAUTION

“CAUTION”: Hazard that may cause minor personal injury.



CAUTION

“CAUTION without exclamation symbol”: Hazard that may cause damage or failure of the unit, facility, etc.

● Definition of “Serious injury” and “Light injury”

Serious injury: The injury that gives aftereffects including loss of eyesight, burnt, electrical shock, fracture, poisoning, etc. and requires long-term treatment or hospitalization.

Light injury: The injury that does not need long term treatment or hospitalization. (Others excluded from serious injury.)

● Types of hazard labels

The unit has various potential hazards and they are marked with warning labels. Be sure to read this section before starting any work on the unit.

Warning related to electricity

WARNING



This symbol stands for a possible risk of electric shock.

The product is operated at high voltage and contains uncovered live terminals inside.

- DO NOT operate the product without cover panels fitted.
- DO NOT work inside this product unless you have been trained to do so.

Warning related to high temperatures

WARNING



This symbol stands for a possible risk of hot surface and burns.

The product has surfaces that can reach high temperatures during operation. Even after the power is turned off, there can still be residual heat in the product.

- DO NOT operate the product without cover panels fitted.
- DO NOT start working inside the product until the temperature has decreased sufficiently.

Warning related to rotating objects

WARNING



This symbol stands for a possible risk of cutting fingers or hand, or entanglement by rotating fan (For air-cooled type).

The product contains a cooling fan that rotates during operation of the product.

The fan can start and stop intermittently and without warning.

- DO NOT operate the product without cover panels fitted.

Warning related to other general dangers

WARNING



This symbol stands for general danger.

Hazards Inside

Hot Surfaces Inside — See Hot Surface symbol

Rotating Fan Inside — See Rotating Fan symbol (For air-cooled type)

Pressurized System Inside — The product contains pressurized fluid systems.

- DO NOT operate the product without cover panels fitted.

● Locations of hazard labels

There are various warning labels on the product to show the potential hazards.





Fig. 1-1 Warning label position



* For air-cooled type

Fig. 1-2 Warning label position

Other Labels

Product label

Information about the product, such as Serial No. and Model No. can be found on the model label. This information is needed when contacting an SMC sales distributor.




Fig. 1-3 Position of product label

How to see the manufacturing code R O 001 (January 2013)

R			O			001
Year	Symbol	Remarks	Month	Symbol	Remarks	Serial no.
2013	R	Repeated from A to Z in alphabetical order	1	O	Repeated from O to Z in alphabetical order, with O for January and Z for December	—
2014	S		2	P		
2015	T		3	Q		
↓	↓		↓	↓		

Safety Measures

Safety instructions for use

⚠ WARNING



Follow the instructions below when using the product. Failure to follow the instructions may cause an accident and injury.

- Before starting maintenance of the product, be sure to lock out and tag out the breaker of the user's power supply.
- If operating the product during maintenance, be sure to inform all workers nearby.
- Use only the correct tools and procedure when installing or maintaining the product.
- Use the recommended personal protective equipment where specified to protect yourself from any hazards.

- Check all parts and screws are fitted correctly and securely after maintenance.
- Do not remove the panels except for the cases permitted in this handbook.
- Do not remove the panels during operation.

■ Waste Disposal

● Disposal of refrigerant and compressor oil

The product uses hydrofluorocarbon type refrigerant (HFC) and compressor oil. Comply with the laws and regulations in each country for the disposal of refrigerant and compressor oil. The type and quantity of refrigerant is described on the product label.

If these fluids need to be recovered, read and understand the instructions below carefully. If there is any unclear point, contact an SMC's sales distributor.

WARNING



- Only maintenance personnel or qualified people are allowed to open the cover panels of the product.
- Do not mix the compressor oil with domestic waste for disposal. Also, the disposal of the waste must only be conducted by specific facilities that are permitted for that purpose.

WARNING



- Comply with the laws and regulations in each country for the disposal of refrigerant and compressor oil.
- The release of refrigerant in to the atmosphere is banned by law. Recover it with specific equipment and dispose of it correctly.
- Only people who have sufficient knowledge and experience about the product and its accessories are allowed to recover the refrigerant and compressor oil.

● Disposal of product

The disposal of the product must be handled by a specialized industrial waste disposal agency in accordance with local laws and regulations.

■ Material Safety Data Sheet (SDS)

Maintenance personnel should check with the customer whether any chemical substances, such as antiseptic, have been added to the circulating fluid or facility water remaining in the product.

If any such substance has been added, ask the customer to submit the SDS of that substance, and start maintenance in accordance with the hazard and toxicity information described therein.

However, depending on the case, you may wish to ask the customer to wash the product beforehand. Please note that safety should always take priority.

2

Thermo-chiller *HRS Series*

Lightweight/Compact

Temperature stability $\pm 0.1^{\circ}\text{C}$



HRS050/HRS060



HRS012/018/024



HRS030



Same width for all models: 377 mm

Model	Size [mm]	Weight	Cooling capacity (60 Hz)	Set temperature range
HRS012	W 377 x H 615 x D 500	40 kg	1300 w	5 to 40°C
HRS018			1900 w	
HRS024			2400 w	
HRS030	W 377 x H 660 x D 500	47 kg	3200 w	
HRS050	W 377 x H 976 x D 592	69 kg	5100 w	
HRS060		73 kg	5900 w	

Compatible with power supplies in Europe, Asia, Oceania, North, Central, and South America

- Single-phase 100 VAC (50/60 Hz), 115 VAC (60 Hz)
- Single-phase 200 to 230 VAC (50/60 Hz)

With heating function

Heating method using discharged heat makes a heater unnecessary.

Convenient functions

Page 10

Timer operation function/Unit conversion function/Power failure auto-restart function/Anti-freezing operation function

Easy maintenance

Page 10

Tool-less maintenance of filter

Self diagnosis function and check display

Page 11

35 types of alarm codes

Communication function

Page 11


Equipped with serial communication (RS232C/RS485) and contact I/Os (2 inputs and 3 outputs) as standard.

Environmental friendly **R407C** **R410A** as refrigerant


Temperature stability $\pm 0.1^{\circ}\text{C}$ / Compact

The precision temperature control method by expansion valve and temperature sensor, realized high temperature stability of $\pm 0.1^{\circ}\text{C}$ and a small-size tank.

■ Air-cooled HRS□-A-□



■ Water-cooled HRS□-W-□



Refrigeration circuit

- The compressor compresses the refrigerant gas, and discharges the high temperature and high pressure refrigerant gas.
- In the case of air-cooled refrigeration, the high temperature and high pressure refrigerant gas is cooled down by an air-cooled condenser with the ventilation of the fan, and becomes a liquid. In the case of water-cooled refrigeration, the refrigerant gas is cooled by a water-cooled condenser with the facility water in the facility water circuit, and becomes a liquid.
- The liquefied high pressure refrigerant gas expands and its temperature lowers when it passes through expansion valve A and vaporizes by taking heat from the circulating fluid in the evaporator.
- The vaporized refrigerant gas is sucked into the compressor and compressed again.
- When heating the circulating fluid, the high pressure and high temperature refrigerant gas is bypassed into the evaporator by expansion valve B, to heat the circulating fluid.

Point The combination of precise control of **expansion valve A** for cooling, and **expansion valve B** for heating realized high temperature stability.

Circulating fluid circuit

- The circulating fluid discharged from the pump, is heated or cooled by the user's equipment and returns to the thermo-chiller.
- The circulating fluid is controlled to a set temperature by the refrigeration circuit, to be discharged to the user's equipment side again by the thermo-chiller.

Point Since the refrigeration circuit is controlled by the signal from **2 temperature sensors (for return and discharge)**, precise temperature control of the circulating fluid can be performed. Therefore, there is no necessity of absorbing the temperature difference in the circulating fluid with a large tank capacity, and realizes high temperature stability even with a **small-size tank**. Also, contributes to space-saving.


Facility water circuit

For water-cooled refrigeration HRS□-W-□

- The water-regulating valve opens and closes to keep the refrigerant gas pressure consistent. The facility water flow rate is controlled by the water-regulating valve.


Installation close to a wall is possible on both sides.

(HRS012/018/024 * Except option G)




Reduced-height double condenser structure (HRS030/060)




Current
Multiple air-cooled condensers are provided on the top and bottom.



HRS030
Achieved a maximum reduction in the height of the product while expanding the cooling capacity, by providing overlapped air-cooled condensers.



With heating function



* This is just an example diagram.

Simple operation

Step ① Press the **RUN/STOP** keys.

Step ② Adjust the temperature setting with the **▼ / ▲** keys.

Step ③ Press the **RUN/STOP** key to stop.
 Easy operation by these steps


Large digital display

The "large digital display" (7-segment and 4 digits) and "2 row display" provide a clearer view of the current value (PV) and set value (SV).



Power supply (24 VDC) available

Power can be supplied from the connector at the rear side of the HRS to external switches, etc.



Variations

Model	Cooling method	Cooling capacity [W] (50/60 Hz)	Single-phase 100 VAC (50/60 Hz) 115 VAC (50/60 Hz)	Single-phase 200 to 230 VAC (50/60 Hz)	Option	Optional accessories	International standards
HRS012	Air-cooled refrigeration Water-cooled refrigeration	1100/1300	●	●	<ul style="list-style-type: none"> With earth leakage breaker With automatic fluid fill function Applicable to deionized water piping High pressure pump mounted (* The HRS050/060 cannot be selected.) High temperature environment specification (* The HRS030/050/060 cannot be selected.) 	<ul style="list-style-type: none"> Anti-quake bracket Piping conversion fitting (For air-cooled, water-cooled and option) Concentration meter Bypass piping set Power supply cable DI filter set Electric resistance sensor set/ Electric resistance control set Electric conductivity sensor set/ Electric conductivity control set Particle filter set Drain pan set (With water leakage sensor) Connector cover Analog gateway unit Replacement type dustproof filter set Separately installed power transformer Filter for circulating fluid fill port 	 (UL Standards) Refer to pages 15 to 18 for details on applicable models.
HRS018		1500/1700	●	—			
HRS024		1700/1900	—	●			
HRS030		2100/2400	—	●			
HRS050		2600/3200	—	●			
HRS060		4700/5100	—	●			
HRS060		4900/5900	—	●			

* UL Standards: Applicable to only 60 Hz



Reduces the maintenance hours for the pump.

Adoption of the magnet pump*1


No external leakage of the circulating fluid because the sealless pump is used, and a periodic check of the pump leakage and replacement of the mechanical seal are not necessary.

*1 When the option, high pressure pump, is selected and for the HRS050/060, the mechanical seal pump is chosen.

Easy check of the circulating fluid level



With casters (Removable)




Shaped for easy supply of circulating fluid


The angled supply port facilitates the supply of circulating fluid.

Filter for circulating fluid fill port
 (Optional accessory on page 58)

* After supplying the circulating fluid, the tank lid can be closed with the filter mounted.



Supply is possible even when 2 products are stacked.





Tool-less inspection and cleaning of air-cooled condenser

Dustproof filter

Integrated with the grill of the front panel. Mounting and removal can be done easily.


Easy to clean dust and cutting chips, etc. stuck to the dustproof net by brush or air blow.

Easy to mount/ remove due to magnet type!




Replacement type dustproof filter set

Suitable for use in excessively dusty atmospheres. The disposable type filter saves time and effort of cleaning.



Particle filter set

Removes foreign matter in the circulating fluid. Effective to prevent foreign matter from entering the user's equipment and chiller.



- Prevents pump malfunction.
- Prevents lowering of the water-cooled condenser performance.



Protects the pump and condenser from foreign matter!!

Convenient functions (Refer to the Operation Manual for details.)


■ Timer operation function

Timer for ON and OFF can be set in units of 0.5 h up to 99.5 h.

Ex.) Can set to stop on Saturday and Sunday and restart on Monday morning.

Ex. SE.02 "ON timer"


Timer The time remaining can be checked.



■ Unit conversion function

Temperature and pressure units can be changed.

Orange indicator lights up.



■ Power failure auto-restart function

Automatic restart from stoppage due to power failure, etc. is possible without pressing the [STOP] key and remote operation.

■ Anti-freezing operation function

If the temperature approaches freezing point, e.g. in winter at night, the pump operates automatically and the heat generated by the pump warms the circulating fluid, preventing freezing.

■ Key-lock function

Can be set in advance to protect the set values from being changed by pressing keys by mistake.

■ Function to output a signal for completion of preparation

Notifies by communication when the temperature reaches the pre-set temperature range.

■ Independent operation of the pump

The pump can be operated independently while chiller is powered off. You can check piping leak and remove the air.

Self diagnosis function and check display


Display of 35 types of alarm codes For details, refer to page 120.

Operation is monitored all the time by the integrated sensor. Should any error occur, the self diagnosis result is displayed by the applicable alarm code from 35 types. This makes it easier to identify the cause of the alarm. Can be used before requesting service.

Changeable alarm set values

Setting item	Set value
Circulating fluid discharge temperature rise	5 to 48°C
Circulating fluid discharge temperature drop	1 to 39°C
Circulating fluid discharge pressure rise	0.05 to 0.75 MPa ^{*1}
Circulating fluid discharge pressure drop	0.05 to 0.18 MPa ^{*1}

^{*1} Set values vary depending on the model.




Alarm codes notify of checking times.

Notifies when to check the pump and fan motor. Helpful for facility maintenance.

^{*} The fan motor is not used in water-cooled refrigeration.


Ex. AL28 "Pump maintenance"



Check display

The internal temperature, pressure and operating time of the product are displayed.

Ex. drv. "Accumulated operating time"



Displayed item
Circulating fluid outlet temperature
Circulating fluid return temperature
Compressor gas temperature
Circulating fluid outlet pressure
Compressor gas discharge pressure
Compressor gas return pressure
Accumulated operating time
Accumulated operating time of pump
Accumulated operating time of fan motor ^{*1}
Accumulated operating time of compressor

^{*1} These are displayed only for air-cooled refrigeration.

Communication function


The serial communication (RS232C/RS485) and contact I/Os (2 inputs and 3 outputs) are equipped as standard.

Communication with the user's equipment and system construction are possible, depending on the application.

A 24 VDC output can be also provided, and is available for a flow switch (SMC's PF2W, etc.).


Ex. 1 Remote signal I/O through serial communication

The remote operation is enabled (to start and stop) through serial communication.



Ex. 3 Alarm and operation status (start, stop, etc.) signal output


The alarm and status generated in the product are assigned to 3 output signals based on their contents, and can be output.



- **Output setting example**
- Output 1: Temperature rise
- Output 2: Pressure rise
- Output 3: Operation status (start, stop, etc.)























Ex. 2 Remote operation signal input

One of the contact inputs is used for remote operation and the other is used for a flow switch to monitor the flow, and their warning outputs are taken in.



Power for flow switch (24 VDC) can be supplied from thermo-chiller.

Application Examples

	Heat source	Automotive	Light electrical appliance	Food	Machinery	Medical	Semiconductor
Arc welding machine 	Torch	●			●		
Resistance welding machine 	Tip	●	●		●		
Laser welding machine 	Oscillator	●	●		●		●
UV curing device 	Lamp	●	●	●		●	
X-ray instrument 			●			●	●
Electronic microscope 	Lens		●			●	●
Laser marker 	Oscillator	●	●	●		●	●
Ultra sonic wave inspection machine 		●	●		●		
Atomizing device/ Crushing equipment 	Blade			●			
Linear motor 	Motor	●			●		
Packaging machines (food products) 	Dies/ Welded portions			●			
Mold cooling 	Mold	●	●	●		●	
Temperature control of adhesive and paint material 	Paint material/ Welding materials	●	●	●			
Cooling of vacuum pump 	Pump	●					●
Shrink fit machine 	Workpiece	●			●		
Gas cylinder cabinet 							●
Concentrating equipment 	Test liquid			●		●	
Reagent cooling equipment 	Reagent			●		●	●
Cleaning machine (hydrocarbon-based) 	Cleaning tank	●	●		●		
Printing machine 	Roller		●	●	●		
Chamber electrode 	Electrode						●
High frequency induction heating equipment 	Power supply/ Heating coil	●			●		

Global Supply Network







SMC has a comprehensive network in the global market.

We now have a presence of more than 500 branch offices and distributors in 83 countries world wide such as Asia, Oceania, North/Central/South America, and Europe. With this global network, we are able to provide a global supply of our substantial range of products with the best service. We also provide full support to local factories, foreign manufacturing companies and Japanese companies in each country.




SMC Thermo-chiller Variations

Lots of variations are available in response to the users' requirements.

Series	Temperature stability [°C]	Set temperature range [°C]	Cooling capacity [kW]													Environment	International standards
			1.2	1.8	2.4	3	5	6	9	10	15	20	25	28			
 HRSE Basic type	±2.0	10 to 30	●	●	●										Indoor use	CE (Only 230 VAC type)	
 HRS Standard type	±0.1	5 to 40	●	●	●	●	●	●							Indoor use	CE UL (Only 60 Hz)	
 HRS090 Standard type	±0.5	5 to 35							●						Indoor use	CE (400 V as standard)	
 HRS100/150 Standard type	±1.0	5 to 35								●	●				Outdoor installation IPX4	CE (400 V as standard)	
 HRSH090 Inverter type	±0.1	5 to 40							●						Indoor use	CE (400 V as standard, 200 V as an option) UL (Only 200 V as an option)	
 HRSH Inverter type	±0.1	5 to 35								●	●	●	●	●	Outdoor installation IPX4	CE (400 V as standard, 200 V as an option) UL (Only 200 V as an option)	


Circulating Fluid/Facility Water Line Equipment



Flow Switch: Monitors the flow rate and temperature of the circulating fluid and facility water.

Refer to the [Web Catalog](#) for details.

3-Color Display Digital Flow Switch for Water **PF3W**
 Integrated with temperature sensor
 PVC Piping



3-Color Display Electromagnetic Type Digital Flow Switch **LFE**



Digital Flow Switch for Deionized Water and Chemical Liquids **PF2D**
4-Channel Flow Monitor **PF2□200**



Pressure Switch: Monitors pressure of the circulating fluid and facility water.

Refer to the [Web Catalog](#) for details.



2-Color Display High-Precision Digital Pressure Switch **ISE80**



Pressure Sensor for General Fluids **PSE56□**
Pressure Sensor Controller **PSE200,300**

Particle Filter



Fittings and Tubing

Refer to the [Web Catalog](#) for details.

S Coupler **KK**



S Coupler/Stainless Steel (Stainless Steel 304) **KKA**



Tubing **T□**



Metal One-touch Fittings **KQB2**



Stainless Steel 316 One-touch Fittings **KQG2**



Stainless Steel 316 Insert Fittings **KFG2**



Fluoropolymer Fittings **LQ**




Series	Material
T	Nylon
TU	Polyurethane
TH	FEP (Fluoropolymer)
TD	Modified PTFE (Soft fluoropolymer)
TL	Super PFA
TLM	PFA

Thermo-chiller Standard Type

Single-phase 100/115 VAC

HRS Series



How to Order

Air-cooled refrigeration

HRS 018 - A - 10 -

Cooling capacity*

012	Cooling capacity 1100/1300 W (50/60 Hz)
018	Cooling capacity 1500/1700 W (50/60 Hz)

* UL Standards: Applicable to only 60 Hz

Cooling method*

A	Air-cooled refrigeration
----------	--------------------------

Pipe thread type*

Nil	Rc
F	G (with PT-G conversion fitting set)
N	NPT (with PT-NPT conversion fitting set)

Power supply*1

Symbol	Power supply
10	Single-phase 100 VAC (50/60 Hz) 115 VAC (60 Hz)

*1 UL Standards: Applicable to only 60 Hz

Option

Symbol	Option
Nil	None
B	With earth leakage breaker
J	With automatic fluid fill function
M	Applicable to deionized water piping
T	High pressure pump mounted*1
W	SI unit only*2

• When multiple options are combined, indicate symbols in alphabetical order.

*1 • The cooling capacity will decrease by about 300 W from the value in the catalog.

• The pump has a mechanical seal in it and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF003, as a preventive measure.

*2 Unit selection function is not available in Japan due to new measurement law. If using this product within Japan, please select this option.
Fixed unit: MPa/°C

Specifications * There are different values from standard specifications. Refer to the Web Catalog for details.

Model		HRS012-A□-10	HRS018-A□-10
Cooling method		Air-cooled refrigeration	
Refrigerant		R407C (HFC)	
Refrigerant charge		kg	0.32
Control method		PID control	
Ambient temperature/Humidity/Altitude*1, 11		Temperature: 5 to 40°C, Humidity: 30 to 70%, Altitude: less than 3000 m	
Circulating fluid system	Circulating fluid*2	Tap water, 15% ethylene glycol aqueous solution*4	
	Set temperature range*1	5 to 40	
	Cooling capacity (50/60 Hz)*3	W	1100/1300
	Heating capacity (50/60 Hz)*3	W	360/450
	Temperature stability*5	°C	±0.1
	Pump	7 (0.13 MPa)/7 (0.18 MPa)	
	Rated flow (50/60 Hz)*6, 7	L/min	
	Maximum flow rate (50/60 Hz)	L/min	
	Maximum pump head (50/60 Hz)	m	
	Output	W	
Tank capacity		Approx. 5	
Port size		Rc1/2	
Fluid contact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC	
Electrical system	Power supply	Single-phase 100 VAC (50/60 Hz), 115 VAC (60 Hz) Allowable voltage range ±10%	
	Circuit protector	A	
	Applicable earth leakage breaker capacity*8	A	
	Rated operating current	A	
	Rated power consumption (50/60 Hz)*3	kVA	7.5/8.3
Noise level (50/60 Hz)*9		dB	
Accessories		Fitting (for drain outlet) 1 pc., Input/output signal connector 1 pc., Power supply connector 1 pc., Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1, Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by user.	
Weight*10		kg	

*1 It should have no condensation.

*2 If tap water is used, use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994 cooling water system - circulating type - make-up water).

*3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid rated flow, ④ Circulating fluid: Tap water
Refer to the cooling capacity graph on page 19 for details.

*4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.

*5 Outlet temperature when the circulating fluid flow is rated flow, and the circulating fluid outlet and return port are directly connected. Installation environment and the power supply are within specification range and stable.

*6 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*7 Required minimum flow rate for cooling capacity or maintaining the temperature stability. The specification of the cooling capacity and the temperature stability may not be satisfied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set (sold separately).)

*8 Purchase an earth leakage breaker with current sensitivity of 15 mA or 30 mA separately. (A product with an optional earth leakage breaker (option B) is also available. Refer to page 42.)

*9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids

*11 If the product is used at altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (Web Catalog) Item 14 * For altitude of 1000 m or higher."

How to Order

Water-cooled refrigeration

HRS 018 - W - 10 -

Cooling capacity*

012	Cooling capacity 1100/1300 W (50/60 Hz)
018	Cooling capacity 1500/1700 W (50/60 Hz)

* UL Standards: Applicable to only 60 Hz

Cooling method*

W	Water-cooled refrigeration
---	----------------------------

Pipe thread type*

Nil	Rc
F	G (with PT-G conversion fitting set)
N	NPT (with PT-NPT conversion fitting set)

Power supply**1

Symbol	Power supply
10	Single-phase 100 VAC (50/60 Hz) 115 VAC (60 Hz)

*1 UL Standards: Applicable to only 60 Hz

Option

Symbol	Option
Nil	None
B	With earth leakage breaker
J	With automatic fluid fill function
M	Applicable to deionized water piping
T	High pressure pump mounted*1
W	SI unit only*2

• When multiple options are combined, indicate symbols in alphabetical order.

*1 • The cooling capacity will decrease by about 300 W from the value in the catalog.

• The pump has a mechanical seal in it and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF003, as a preventive measure.

*2 Unit selection function is not available in Japan due to new measurement law. If using this product within Japan, please select this option. Fixed unit: MPa°C



Specifications * There are different values from standard specifications. Refer to the Web Catalog for details.

Model		HRS012-W□-10	HRS018-W□-10
Cooling method		Water-cooled refrigeration	
Refrigerant		R407C (HFC)	
Refrigerant charge		0.25	0.26
Control method		PID control	
Ambient temperature/Humidity/Altitude*1		Temperature: 5 to 40°C, Humidity: 30 to 70%, Altitude: less than 3000 m	
Circulating fluid system	Circulating fluid*2	Tap water, 15% ethylene glycol aqueous solution*4	
	Set temperature range*1	5 to 40	
	Cooling capacity (50/60 Hz)*3	1100/1300	1500/1700
	Heating capacity (50/60 Hz)*3	360/450	
	Temperature stability*5	±0.1	
	Rated flow (50/60 Hz)*6, 7	7 (0.13 MPa)/7 (0.18 MPa)	
	Maximum flow rate (50/60 Hz)	27/29	
	Maximum pump head (50/60 Hz)	14/19	
	Output	200	
	Tank capacity	Approx. 5	
Facility water system	Port size	Rc1/2	
	Fluid contact material	Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC	
	Temperature range	5 to 40	
	Pressure range	0.3 to 0.5	
	Required flow rate (50/60 Hz)*11	8	12
	Inlet-outlet pressure differential of facility water	0.3 or more	
Electrical system	Port size	Rc3/8	
	Fluid contact material	Stainless steel, Copper (Heat exchanger brazing), Bronze, Synthetic rubber	
	Power supply	Single-phase 100 VAC (50/60 Hz), 115 VAC (60 Hz) Allowable voltage range ±10%	
	Circuit protector	15	
	Applicable earth leakage breaker capacity*8	15	
Noise level (50/60 Hz)*9	Rated operating current	7.5/8.3	7.7/8.4
	Rated power consumption (50/60 Hz)*3	0.7/0.8	0.8/0.8
		58/55	
Accessories		Fitting (for drain outlet) 1 pc., Input/output signal connector 1 pc., Power supply connector 1 pc., Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1, Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by user.	
Weight*10		40	

*1 It should have no condensation.

*2 If tap water is used, use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994 cooling water system - circulating type - make-up water).

*3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid rated flow, ④ Circulating fluid: Tap water, ⑤ Facility water temperature: 25°C. Refer to the cooling capacity graph on page 19 for details.

*4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.

*5 Outlet temperature when the circulating fluid flow is rated flow, and the circulating fluid outlet and return port are directly connected. Installation environment and the power supply are within specification range and stable.

*6 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*7 Required minimum flow rate for cooling capacity or maintaining the temperature stability. The specification of the cooling capacity and the temperature stability may not be satisfied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set (sold separately).)

*8 Purchase an earth leakage breaker with current sensitivity of 15 mA or 30 mA separately. (A product with an optional earth leakage breaker (option B) is also available. Refer to the Web Catalog for details.)

*9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids

*11 Required flow rate when a load for the cooling capacity is applied at a circulating fluid temperature of 20°C, and circulating fluid rated flow and facility water temperature of 25°C.

Thermo-chiller Standard Type

Single-phase 200 to 230 VAC

HRS Series



RoHS



How to Order

Air-cooled refrigeration **HRS 018 - A - 20 -**

Cooling method

A Air-cooled refrigeration

Pipe thread type

Nil	Rc
F	G (with PT-G conversion fitting set)
N	NPT (with PT-NPT conversion fitting set)

Power supply*1

Symbol	Power supply
20	Single-phase 200 to 230 VAC (50/60 Hz)

*1 UL Standards: Applicable to only 60 Hz

Cooling capacity

012	Cooling capacity 1100/1300 W (50/60 Hz)
018	Cooling capacity 1700/1900 W (50/60 Hz)
024	Cooling capacity 2100/2400 W (50/60 Hz)
030	Cooling capacity 2600/3200 W (50/60 Hz)
050	Cooling capacity 4700/5100 W (50/60 Hz)
060	Cooling capacity 4900/5900 W (50/60 Hz)

* UL Standards: Applicable to only 60 Hz

The pump of 050 and 060 have a mechanical seal and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF004, as a preventive measure.

Option

Symbol	Option	Applicable model
Nil	None	
B	With earth leakage breaker	HRS012/018/024
J	With automatic fluid fill function	030/050/060
M	Applicable to deionized water piping	
T	High pressure pump mounted*1	HRS012/018/024/030
G	High temperature environment specification	HRS012/018/024
W	SI unit only*2	HRS012/018/024 030/050/060

• When multiple options are combined, indicate symbols in alphabetical order.

*1 The cooling capacity will decrease by about 300 W from the value in the catalog.

The pump has a mechanical seal in it and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF003, as a preventive measure.

*2 Unit selection function is not available in Japan due to new measurement law. If using this product within Japan, please select this option.
Fixed unit: MPa/°C

Specifications * There are different values from standard specifications. Refer to the Web Catalog for details.

Model		HRS012-A□-20	HRS018-A□-20	HRS024-A□-20	HRS030-A□-20	HRS050-A□-20	HRS060-A□-20	
Cooling method		Air-cooled refrigeration						
Refrigerant		R407C (HFC)				R410A (HFC)		
Refrigerant charge		kg	0.35	0.36	0.36	0.57	0.65	
Control method		PID control						
Ambient temperature/Humidity/Altitude*1, 12		Temperature: 5 to 40°C, High temperature environment specification (option): 5 to 45°C, Humidity: 30 to 70%, Altitude: less than 3000 m						
Circulating fluid system	Circulating fluid*2		Tap water, 15% ethylene glycol aqueous solution*4					
	Set temperature range*1		5 to 40					
	Cooling capacity (50/60 Hz)*3		W	1100/1300	1700/1900	2100/2400	2600/3200	4700/5100
	Heating capacity (50/60 Hz)*3		W		530/650		600/640	1100/1400
	Temperature stability*5		°C	±0.1				
	Pump	Rated flow (50/60 Hz)*6, 7	L/min	7 (0.13 MPa)/7 (0.18 MPa)			23 (0.24 MPa)/26 (0.32 MPa)	23 (0.21 MPa)/26 (0.28 MPa)
		Maximum flow rate (50/60 Hz)	L/min	27/29			34/40	31/42
		Maximum pump head (50/60 Hz)	m	14/19				50
		Output	W	200				550
	Tank capacity		L	Approx. 5				
Port size			Rc1/2					
Fluid contact material			Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC					
Electrical system	Power supply		Single-phase 200 to 230 VAC (50/60 Hz) Allowable voltage range ±10%					
	Circuit protector	A	10			20	30	
	Applicable earth leakage breaker capacity*8	A	10			20	30	
	Rated operating current	A	4.6/5.1	4.7/5.2	5.1/5.9	5.2/6.0	8/11	
	Rated power consumption (50/60 Hz)*3	kVA	0.9/1.0	0.9/1.0	1.0/1.2	1.0/1.2	1.7/2.2	
	Noise level (50/60 Hz)*9	dB	60/61			62/65	65/68	
	Accessories		Fitting (for drain outlet) 1 pc.*11, Input/output signal connector 1 pc., Power supply connector 1 pc.*11, Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1*11, Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by user.					
Weight*10		kg	43		47	69	73	

*1 It should have no condensation.

*2 If tap water is used, use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994 cooling water system - circulating type - make-up water).

*3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid rated flow, ④ Circulating fluid: Tap water

Refer to the cooling capacity graph on pages 19 and 20 for details.

*4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.

*5 Outlet temperature when the circulating fluid flow is rated flow, and the circulating fluid outlet and return port are directly connected. Installation environment and the power supply are within specification range and stable.

*6 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*7 Required minimum flow rate for cooling capacity or maintaining the temperature stability. The specification of the cooling capacity and the temperature stability may not be satisfied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set (sold separately).)

*8 Purchase an earth leakage breaker with current sensitivity of 30 mA separately. (A product with an optional earth leakage breaker (option B) is also available.)

*9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids

*11 It is not provided for the HRS050/060.

*12 If the product is used at altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (Web Catalog) Item 14 * For altitude of 1000 m or higher."

How to Order**Water-cooled refrigeration****HRS 018 - W - 20 -**

2

Thermo-chiller HRS Series

Cooling capacity*

012	Cooling capacity 1100/1300 W (50/60 Hz)
018	Cooling capacity 1700/1900 W (50/60 Hz)
024	Cooling capacity 2100/2400 W (50/60 Hz)
030	Cooling capacity 2600/3200 W (50/60 Hz)
050	Cooling capacity 4700/5100 W (50/60 Hz)
060	Cooling capacity 4900/5900 W (50/60 Hz)

* UL Standards: Applicable to only 60 Hz

The pump of 050 and 060 have a mechanical seal and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF004, as a preventive measure.

Cooling method*

W	Water-cooled refrigeration
----------	----------------------------

Pipe thread type*

Nil	Rc
F	G (with PT-G conversion fitting set)
N	NPT (with PT-NPT conversion fitting set)

Power supply1**

Symbol	Power supply
20	Single-phase 200 to 230 VAC (50/60 Hz)

*1 UL Standards: Applicable to only 60 Hz

Option

Symbol	Option	Applicable model
Nil	None	
B	With earth leakage breaker	HRS012/018/024
J	With automatic fluid fill function	030/050/060
M	Applicable to deionized water piping	
T	High pressure pump mounted*1	HRS012/018/024/030
W	SI unit only*2	HRS012/018/024/030/050/060

*When multiple options are combined, indicate symbols in alphabetical order.

*1 The cooling capacity will decrease by about 300 W from the value in the catalog.

The pump has a mechanical seal in it and leakage could occur depending on circulating fluid quality. We recommend you to use Particle Filter Kit, HRS-PF003, as a preventive measure.

*2 Unit selection function is not available in Japan due to new measurement law. If using this product within Japan, please select this option.

Fixed unit: MPa/°C

Specifications * There are different values from standard specifications. Refer to the **Web Catalog** for details.

Model	HRS012-W-20	HRS018-W-20	HRS024-W-20	HRS030-W-20	HRS050-W-20	HRS060-W-20
Cooling method	Water-cooled refrigeration					
Refrigerant	R407C (HFC)					
Refrigerant charge	kg	0.3	0.31	0.31	0.5	0.65
Control method	PID control					
Ambient temperature/Humidity/Altitude*1	Temperature: 5 to 40°C, Humidity: 30 to 70%, Altitude: less than 3000 m					
Circulating fluid*2	Tap water, 15% ethylene glycol aqueous solution*4					
Set temperature range*1	5 to 40					
Cooling capacity (50/60 Hz)*3	W	1100/1300	1700/1900	2100/2400	2600/3200	4700/5100
Heating capacity (50/60 Hz)*3	W		530/650		400/600	1000/1300
Temperature stability*5	°C	±0.1				
Rated flow (50/60 Hz)*6,7	L/min	7 (0.13 MPa)/7 (0.18 MPa)				
Maximum flow rate (50/60 Hz)	L/min	27/29				
Maximum pump head (50/60 Hz)	m	14/19				
Output	W	200				
Tank capacity	L	Approx. 5				
Port size		Rc1/2				
Fluid contact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Alumina ceramic, Carbon, PP, PE, POM, FKM, EPDM, PVC				
Temperature range	°C	5 to 40				
Pressure range	MPa	0.3 to 0.5				
Required flow rate (50/60 Hz)*11	L/min	8	12	14	15	16
Inlet-outlet pressure differential of facility water	MPa	0.3 or more				
Port size		Rc3/8				
Fluid contact material		Stainless steel, Copper (Heat exchanger brazing), Bronze, Synthetic rubber				
Power supply		Single-phase 200 to 230 VAC (50/60 Hz)				
Circuit protector	A	10				
Applicable earth leakage breaker capacity*8	A	10				
Rated operating current	A	4.6/5.1	4.7/5.2	5.1/5.9	5.2/6.0	7.6/10
Rated power consumption (50/60 Hz)*3	kVA	0.9/1.0	0.9/1.0	1.0/1.2	1.0/1.2	1.5/2.0
Noise level (50/60 Hz)*9	dB	60/61				
Accessories		Fitting (for drain outlet) 1 pc.*12, Input/output signal connector 1 pc., Power supply connector 1 pc.*12, Operation Manual (for installation/operation) 1, Quick Manual (with a clear case) 1*12, Alarm code list sticker 1, Ferrite core (for communication) 1 pc., Power supply cable: Option (sold separately) to be ordered or prepared by user.				
Weight*10	kg	43		46		67

*1 It should have no condensation.

*2 If tap water is used, use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994 cooling water system - circulating type - make-up water).

*3 ① Ambient temperature: 25°C, ② Circulating fluid temperature: 20°C, ③ Circulating fluid rated flow, ④ Circulating fluid: Tap water, ⑤ Facility water temperature: 25°C. Refer to the cooling capacity graph on pages 19 and 20 for details.

*4 Use a 15% ethylene glycol aqueous solution if operating in a place where the circulating fluid temperature is 10°C or less.

*5 Outlet temperature when the circulating fluid flow is rated flow, and the circulating fluid outlet and return port are directly connected. Installation environment and the power supply are within specification range and stable.

*6 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*7 Required minimum flow rate for cooling capacity or maintaining the temperature stability. The specification of the cooling capacity and the temperature stability may not be satisfied if the flow rate is lower than the rated flow. (In such a case, use a bypass piping set (sold separately).)

*8 Purchase an earth leakage breaker with current sensitivity of 30 mA separately. (A product with an optional earth leakage breaker (option B) is also available.)

*9 Front: 1 m, height: 1 m, stable with no load, Other conditions → See *3.

*10 Weight in the dry state without circulating fluids

*11 Required flow rate when a load for the cooling capacity is applied at a circulating fluid temperature of 20°C, and circulating fluid rated flow and facility water temperature of 25°C.



*12 It is not provided for the HRS050/060.

* If the product is used at altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (**Web Catalog**) Item 14 * For altitude of 1000 m or higher."
* For models with high pressure pump mounted (-T), the cooling capacity will decrease by about 300 W from each graph.

Cooling Capacity



HRS012-A-10, HRS012-W-10 (Single-phase 100/115 VAC) (50 Hz)

(60 Hz)





HRS018-A-10, HRS018-W-10 (Single-phase 100/115 VAC) (50 Hz)

(60 Hz)





HRS012-A-20, HRS012-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)



HRS018-A-20, HRS018-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)





- * If the product is used at altitude of 1000 m or higher, refer to "Operating Environment/Storage Environment" (Web Catalog) Item 14 * For altitude of 1000 m or higher."
- * For models with high pressure pump mounted (-T), the cooling capacity will decrease by about 300 W from each graph.

Cooling Capacity



HRS024-A-20, HRS024-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)





HRS030-A-20, HRS030-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)





HRS050-A-20, HRS050-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)




HRS060-A-20, HRS060-W-20 (Single-phase 200 to 230 VAC) (50 Hz)

(60 Hz)




Heating Capacity


HRS⁰¹²₀₁₈-A-W-10 (Single-phase 100/115 VAC) (50 Hz)




(60 Hz)




HRS⁰¹²₀₁₈-A-W-20 (Single-phase 200 to 230 VAC) (50 Hz)




(60 Hz)




HRS030-A-20 (Single-phase 200 to 230 VAC) (50 Hz)




(60 Hz)




HRS030-W-20 (Single-phase 200 to 230 VAC) (50 Hz)





(60 Hz)





Heating Capacity

HRS050-A-20 (Single-phase 200 to 230 VAC) (50 Hz)




(60 Hz)


HRS050-W-20 (Single-phase 200 to 230 VAC) (50 Hz)



(60 Hz)


HRS060-A-20 (Single-phase 200 to 230 VAC) (50 Hz)


(60 Hz)



HRS060-W-20 (Single-phase 200 to 230 VAC) (50 Hz)


(60 Hz)




Pump Capacity


HRS⁰¹²₀₁₈-A_W-10 (Single-phase 100/115 VAC)




HRS⁰¹²₀₁₈-A_W-20 (Single-phase 200 to 230 VAC)




HRS030-A_W-20 (Single-phase 200 to 230 VAC)



HRS050-A_W-20 (Single-phase 200 to 230 VAC)




HRS060-A_W-20 (Single-phase 200 to 230 VAC)



Required Facility Water Flow Rate


HRS012-W-¹⁰₂₀, HRS018-W-¹⁰₂₀, HRS024-W-20
HRS030-W-20, HRS050-W-20, HRS060-W-20



⚠ Caution

Mechanical Seal Pump


The pump used for the thermo-chiller HRS050/060 series uses a mechanical seal with the fixed ring and rotary ring used for the shaft seal part. If foreign matter enter the gap between the seals, this may cause a trouble such as leakage from the seal part or pump lock. Therefore, it is strongly recommended to install the particle filter in the return piping of the chiller.



* This is the facility water flow rate at the circulating fluid rated flow and the cooling capacity listed in the "Cooling Capacity" specifications.


Dimensions

HRS012/018/024



*1 The power supply cable is not provided. (The power supply connector is provided.)
 *2 The conversion fitting (R3/8 male thread) is provided.


HRS030-A-20



*1 The power supply cable is not provided. (The power supply connector is provided.)
 *2 The conversion fitting (R3/8 male thread) is provided.

Dimensions


HRS030-W-20



*1 The power supply cable is not provided. (The power supply connector is provided.)


*2 The conversion fitting (R3/8 male thread) is provided.

HRS050/060-A




Dimensions


HRS050/060-W



Center of Gravity
HRS012/018-A-10




HRS012/018-W-10




Center of Gravity

HRS012/018/024-A-20

2
Thermo-chiller HRS Series




HRS012/018/024-W-20




Flow Chart

HRS012/018/024/030-A-10/20




HRS012/018/024/030-W-10/20




Flow Chart

HRS050/060-A-20




HRS050/060-W-20



Electric Circuit Diagram

HRS0□□-□□-□□





Circuit Symbol	Part Name	Circuit Symbol	Part Name
[L1]	AC Inlet With Noise Filter	[PCB1]	Main Board
[CB]	Circuit Breaker	[PCB2]	Communication Board
	Earth Leakage Breaker*1	[PCB3]	AC Power Board
[DCPS]	DC24V Power Supply	[PCB4]	Display Board
[L2 ~ 5]	Ferrite Core	[PM]	Pump
[PS1 ~ 3]	Pressure Sensor		High-Pressure Pump*3
[EV1, 2]	Electric Expansion Valve	[FAN]	Fan Motor
[PT1, 2]	Temperature Sensor	[CM]	Compressor
[T1]	Thermistor Sensor	[C1]	Running Capacitor for FAN
[LS]	Tank Level Switch	[C2]	Running Capacitor for CM
[SVAF1]*2	Solenoid Valve for Auto Filling	[C3]*3	Running Capacitor for PM*3


*1 Option B

*2 Option J

*3 Option T

Construction

Applicable models, Ser. No.: HRS012-A-10-□, TP (FEB. 2015) or earlier



Construction










No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
48	Fan (for 100V)With bracket	HRS-S0023	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
58	Main Board (for HRS012-A-10)	HRS-S0033	●
74	Main Board (for HRS012-A-10-T)	HRS-S0282	○ (For option T)
86	Main Board (for HRS012-A-10-MT)	HRS-S0283	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-A-10-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
48	Fan (for 100V)With bracket	HRS-S0023	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
58	Main Board (for HRS012-A-10)	HRS-S0033	●
74	Main Board (for HRS012-A-10-T)	HRS-S0282	○ (For option T)
86	Main Board (for HRS012-A-10-MT)	HRS-S0283	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-W-10-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
59	Main Board (for HRS012-W-10)	HRS-S0034	●
75	Main Board (for HRS012-W-10-T)	HRS-S0284	○ (For option T)
87	Main Board (for HRS012-W-10-MT)	HRS-S0285	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-W-10-□, After TQ (MAR. 2015)



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
59	Main Board (for HRS012-W-10)	HRS-S0034	●
75	Main Board (for HRS012-W-10-T)	HRS-S0284	○ (For option T)
87	Main Board (for HRS012-W-10-MT)	HRS-S0285	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-A-10-□, TP (FEB. 2015) or earlier



Construction






No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
48	Fan (for 100V)With bracket	HRS-S0023	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
60	Main Board (for HRS018-A-10)	HRS-S0035	●
76	Main Board (for HRS018-A-10-T)	HRS-S0286	○ (For option T)
88	Main Board (for HRS018-A-10-MT)	HRS-S0287	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-A-10-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
48	Fan (for 100V)With bracket	HRS-S0023	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
60	Main Board (for HRS018-A-10)	HRS-S0035	●
76	Main Board (for HRS018-A-10-T)	HRS-S0286	○ (For option T)
88	Main Board (for HRS018-A-10-MT)	HRS-S0287	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-W-10-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
61	Main Board (for HRS018-W-10)	HRS-S0036	●
77	Main Board (for HRS018-W-10-T)	HRS-S0288	○ (For option T)
89	Main Board (for HRS018-W-10-MT)	HRS-S0289	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-W-10-□, After TQ (MAR. 2015)



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
32	Power switch (For 15A)	HRS-S0070	●
33	Inlet socket	HRS-S0021	●
34	Pump (for 100V)	HRS-S0022	●
38	High head pump (For 100V type option T)	HRS-S0265	○ (For option T)
41	High head pump (For 100V type option MT)	HRS-S0266	○ (For option MT)
45	Mechanical seal Kit (For 100V type option T)	HRS-S0390	○ (For option T)
46	Mechanical seal Kit (For 100V type option MT)	HRS-S0412	○ (For option MT)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
61	Main Board (for HRS018-W-10)	HRS-S0036	●
77	Main Board (for HRS018-W-10-T)	HRS-S0288	○ (For option T)
89	Main Board (for HRS018-W-10-MT)	HRS-S0289	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
115	Compressor (for 100V type)	HRS-S0409	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
164	Base	HRS-S0061	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.





Construction

Applicable models, Ser. No.: HRS012-A□-20-□, TP (FEB. 2015) or earlier



For options other than G

For options G



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
62	Main Board (for HRS012-A-20)	HRS-S0037	●
78	Main Board (for HRS012-A-20-T)	HRS-S0038	○ (For option T)
90	Main Board (for HRS012-A-20-MT)	HRS-S0039	○ (For option MT)
98	Main Board (for HRS012-A-20-G)	HRS-S0078	○ (For option G)
101	Main Board (for HRS012-A-20-GT)	HRS-S0079	○ (For option GT)
104	Main Board (for HRS012-A-20-GMT)	HRS-S0080	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-A□-20-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
62	Main Board (for HRS012-A-20)	HRS-S0037	●
78	Main Board (for HRS012-A-20-T)	HRS-S0038	○ (For option T)
90	Main Board (for HRS012-A-20-MT)	HRS-S0039	○ (For option MT)
98	Main Board (for HRS012-A-20-G)	HRS-S0078	○ (For option G)
101	Main Board (for HRS012-A-20-GT)	HRS-S0079	○ (For option GT)
104	Main Board (for HRS012-A-20-GMT)	HRS-S0080	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-W□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRG-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
63	Main Board (for HRS012-W-20)	HRS-S0040	●
79	Main Board (for HRS012-W-20-T)	HRS-S0041	○ (For option T)
91	Main Board (for HRS012-W-20-MT)	HRS-S0042	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS012-W□-20-□, After TQ (MAR. 2015)



Construction



No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Pawer board	HRS-S0019	●
31	Pawer switch	HRS-S0020	●
32	Pawer switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
63	Main Board (for HRS012-W-20)	HRS-S0040	●
79	Main Board (for HRS012-W-20-T)	HRS-S0041	○ (For option T)
91	Main Board (for HRS012-W-20-MT)	HRS-S0042	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
122	Heat exchanger (Condenser)	HRS-S0133	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-A□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
64	Main Board (for HRS018-A-20)	HRS-S0043	●
80	Main Board (for HRS018-A-20-T)	HRS-S0044	○ (For option T)
92	Main Board (for HRS018-A-20-MT)	HRS-S0045	○ (For option MT)
99	Main Board (for HRS018-A-20-G)	HRS-S0081	○ (For option G)
102	Main Board (for HRS018-A-20-GT)	HRS-S0082	○ (For option GT)
105	Main Board (for HRS018-A-20-GMT)	HRS-S0083	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-A□-20-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
64	Main Board (for HRS018-A-20)	HRS-S0043	●
80	Main Board (for HRS018-A-20-T)	HRS-S0044	○ (For option T)
92	Main Board (for HRS018-A-20-MT)	HRS-S0045	○ (For option MT)
99	Main Board (for HRS018-A-20-G)	HRS-S0081	○ (For option G)
102	Main Board (for HRS018-A-20-GT)	HRS-S0082	○ (For option GT)
105	Main Board (for HRS018-A-20-GMT)	HRS-S0083	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-W□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRG-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
65	Main Board (for HRS018-W-20)	HRS-S0046	●
81	Main Board (for HRS018-W-20-T)	HRS-S0047	○ (For option T)
93	Main Board (for HRS018-W-20-MT)	HRS-S0048	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS018-W□-20-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Pawer board	HRS-S0019	●
31	Pawer switch	HRS-S0020	●
32	Pawer switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
65	Main Board (for HRS018-W-20)	HRS-S0046	●
81	Main Board (for HRS018-W-20-T)	HRS-S0047	○ (For option T)
93	Main Board (for HRS018-W-20-MT)	HRS-S0048	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS024-A□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
66	Main Board (for HRS024-A-20)	HRS-S0049	●
82	Main Board (for HRS024-A-20-T)	HRS-S0050	○ (For option T)
94	Main Board (for HRS024-A-20-MT)	HRS-S0051	○ (For option MT)
100	Main Board (for HRS024-A-20-G)	HRS-S0084	○ (For option G)
103	Main Board (for HRS024-A-20-GT)	HRS-S0085	○ (For option GT)
106	Main Board (for HRS024-A-20-GMT)	HRS-S0086	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS024-A□-20-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
5	Right Side Panel (For option G)	HRS-S0075	○ (For option G)
9	Left Side Panel	HRS-S0004	●
10	Left Side Panel (For option G)	HRS-S0076	○ (For option G)
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
49	Fan (for 200V type)	HRS-S0067	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
66	Main Board (for HRS024-A-20)	HRS-S0049	●
82	Main Board (for HRS024-A-20-T)	HRS-S0050	○ (For option T)
94	Main Board (for HRS024-A-20-MT)	HRS-S0051	○ (For option MT)
100	Main Board (for HRS024-A-20-G)	HRS-S0084	○ (For option G)
103	Main Board (for HRS024-A-20-GT)	HRS-S0085	○ (For option GT)
106	Main Board (for HRS024-A-20-GMT)	HRS-S0086	○ (For option GMT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
161	Condenser bracket	HRS-S0015	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS024-W□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRG-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
67	Main Board (for HRS024-W-20)	HRS-S0052	●
83	Main Board (for HRS024-W-20-T)	HRS-S0053	○ (For option T)
95	Main Board (for HRS024-W-20-MT)	HRS-S0054	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS024-W□-20-□, After TQ (MAR. 2015)



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
4	Right Side Panel	HRS-S0003	●
9	Left Side Panel	HRS-S0004	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
16	Hose (For standard pump)	HRS-S0008	●
20	Hose (For option T)	HRS-S0077	○ (For option T)
22	Hose (For option MT)	HRS-S0069	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
35	Pump (for 200V type)	HRS-S0066	●
39	High head pump (For option T)	HRS-S0062	○ (For option T)
42	High head pump (For option MT)	HRS-S0063	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
67	Main Board (for HRS024-W-20)	HRS-S0052	●
83	Main Board (for HRS024-W-20-T)	HRS-S0053	○ (For option T)
95	Main Board (for HRS024-W-20-MT)	HRS-S0054	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
136	Heat exchanger	HRS-S0030	●
139	Heat exchanger (For option M)	HRS-S0413	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
145	Thermistor sensor	HRS-S0057	●
150	Caster (4Pcs.)	HRS-S0059	●
152	Packaging Materials set	HRS-S0060	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
162	Thermal insulator for heat exchanger	HRS-S0031	●
163	Thermal insulator for copper pipe	HRS-S0032	●
164	Base	HRS-S0061	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS030-A□-20-□, TP (FEB. 2015) or earlier



Construction


No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
5	Right Side Panel (For option G)	HRS-S0075	●
10	Left Side Panel (For option G)	HRS-S0076	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
17	Hose (For standard pump)	HRS-S0302	●
21	Hose (For option T)	HRS-S0303	○ (For option T)
23	Hose (For option MT)	HRS-S0304	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
36	Pump (for 200V)	HRS-S0361	●
40	High head pump (For option T)	HRS-S0299	○ (For option T)
43	High head pump (For option MT)	HRS-S0300	○ (For option MT)
47	Mechanical seal Kit	HRG-S0211	○ (For option T)
50	Fan	HRS-S0301	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
68	Main Board	HRS-S0290	●
84	Main Board (for HRS030-A-20-T)	HRS-S0291	○ (For option T)
96	Main Board (for HRS030-A-20-MT)	HRS-S0292	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
117	Compressor (for 200V type)	HRS-S0423	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
137	Heat exchanger Assy	HRS-S0380	●
140	Heat exchanger Assy (For option M)	HRS-S0414	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
153	Packaging Materials set	HRS-S0391	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
163	Thermal insulator for copper pipe	HRS-S0032	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS030-A□-20-□, After TQ (MAR. 2015)



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
5	Right Side Panel (For option G)	HRS-S0075	●
10	Left Side Panel (For option G)	HRS-S0076	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
17	Hose (For standard pump)	HRS-S0302	●
21	Hose (For option T)	HRS-S0303	○ (For option T)
23	Hose (For option MT)	HRS-S0304	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
36	Pump (for 200V)	HRS-S0361	●
40	High head pump (For option T)	HRS-S0299	○ (For option T)
43	High head pump (For option MT)	HRS-S0300	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
50	Fan	HRS-S0301	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
68	Main Board	HRS-S0290	●
84	Main Board (for HRS030-A-20-T)	HRS-S0291	○ (For option T)
96	Main Board (for HRS030-A-20-MT)	HRS-S0292	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
117	Compressor (for 200V type)	HRS-S0423	●
119	Condenser (For air-cooled type)	HRS-S0381	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
137	Heat exchanger Assy	HRS-S0380	●
140	Heat exchanger Assy (For option M)	HRS-S0414	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
146	Thermistor sensor	HRS-S0338	●
150	Caster (4Pcs.)	HRS-S0059	●
153	Packaging Materials set	HRS-S0391	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
163	Thermal insulator for copper pipe	HRS-S0032	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS030-W□-20-□, TP (FEB. 2015) or earlier



Construction












No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
5	Right Side Panel (For option G)	HRS-S0075	●
10	Left Side Panel (For option G)	HRS-S0076	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
17	Hose (For standard pump)	HRS-S0302	●
21	Hose (For option T)	HRS-S0303	○ (For option T)
23	Hose (For option MT)	HRS-S0304	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
36	Pump (for 200V)	HRS-S0361	●
40	High head pump (For option T)	HRS-S0299	○ (For option T)
43	High head pump (For option MT)	HRS-S0300	○ (For option MT)
47	Mechanical seal Kit	HRG-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
69	Main Board	HRS-S0293	●
85	Main Board (for HRS030-W-20-T)	HRS-S0294	○ (For option T)
97	Main Board (for HRS030-W-20-MT)	HRS-S0295	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
137	Heat exchanger Assy	HRS-S0380	●
140	Heat exchanger Assy (For option M)	HRS-S0414	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
150	Caster (4Pcs.)	HRS-S0059	●
153	Packaging Materials set	HRS-S0391	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
163	Thermal insulator for copper pipe	HRS-S0032	●

Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".
It is used by setting the program.

Construction

Applicable models, Ser. No.: HRS030-W□-20-□, After TQ (MAR. 2015)



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
2	Upper Panel	HRS-S0002	●
5	Right Side Panel (For option G)	HRS-S0075	●
10	Left Side Panel (For option G)	HRS-S0076	●
13	Front panel	HRS-S0519	●
15	Temperature sensor	HRS-S0007	●
17	Hose (For standard pump)	HRS-S0302	●
21	Hose (For option T)	HRS-S0303	○ (For option T)
23	Hose (For option MT)	HRS-S0304	○ (For option MT)
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
26	DC power supply	HRS-S0016	●
28	Display board	HRS-S0520	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
31	Power switch	HRS-S0020	●
32	Power switch (For 15A)	HRS-S0070	○ (For option T)
33	Inlet socket	HRS-S0021	●
36	Pump (for 200V)	HRS-S0361	●
40	High head pump (For option T)	HRS-S0299	○ (For option T)
43	High head pump (For option MT)	HRS-S0300	○ (For option MT)
47	Mechanical seal Kit	HRS-S0211	○ (For option T)
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
56	Main Board (for HRS012/018/024)	HRS-S0134	●/○ Note 2.
69	Main Board	HRS-S0293	●
85	Main Board (for HRS030-W-20-T)	HRS-S0294	○ (For option T)
97	Main Board (for HRS030-W-20-MT)	HRS-S0295	○ (For option MT)
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
111	Earth leakage breaker (For option B)	HRS-S0393	○ (For option B)
114	Earth leakage breaker (For option B or BT)	HRS-S0394	○ (For option B or BT)
116	Compressor (for 200V type)	HRS-S0068	●
123	Heat exchanger (Condenser)	HRS-S0384	●
125	Water regulating valve	HRS-S0385	●
127	Filter drier	HRS-S0387	●
129	Electronic Expansion Valve (For heating)	HRS-S0028	●
131	Electronic Expansion Valve (For cooling)	HRS-S0029	●
133	Electronic Expansion Valve Coil (For heating)	HRS-S0009	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
137	Heat exchanger Assy	HRS-S0380	●
140	Heat exchanger Assy (For option M)	HRS-S0414	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
143	Pressure sensor (For high or low pressure)	HRS-S0013	●
146	Thermistor sensor	HRS-S0338	●
150	Caster (4Pcs.)	HRS-S0059	●
153	Packaging Materials set	HRS-S0391	●
155	Power supply connector omission prevention fittings	HRS-S0074	●
156	Drain Fitting	HRS-S0102	●
157	Sequence I/O command signal connector	HRS-S0103	●
158	Power supply connector	HRS-S0104	●
159	Ferrite core	HRS-S0105	●
160	Drain Plug set	HRS-S0132	●
163	Thermal insulator for copper pipe	HRS-S0032	●


Note 1 Excerpt number from the total list of P91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models: HRS050-A□-20-□



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
3	Upper Panel	HRS-S0092	●
6	Right Side Panel (For air cooling)	HRS-S0093	●
11	Left Side Panel (For air cooling)	HRS-S0095	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
18	Hose (For standard pump)	HRS-S0097	●
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
27	DC power supply	HRS-S0087	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
37	Pump	HRS-S0088	●
44	Pump (For option M)	HRS-S0089	○ (For option M)
47	Mechanical seal Kit	HRG-S0211	●
51	Fan	HRS-S0099	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
57	Main Board (HRS050)	HRS-S0135	●/○ Note 2.
70	Main Board	HRS-S0090	●
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
108	Relay (For Compressor)	HRS-S0392	●
109	Circuit breaker	HRS-S0395	●
112	Earth leakage breaker (For option B)	HRS-S0348	○ (For option B)
118	Compressor	HRS-S0337	●
120	Condenser (For air-cooled type)	HRS-S0382	●
128	Filter drier	HRZ-S0227	●
130	Electronic Expansion Valve (For heating)	HRS-S0340	●
132	Electronic Expansion Valve (For cooling)	HRS-S0341	●
134	Electronic Expansion Valve Coil (For heating)	HRS-S0386	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
138	Heat exchanger	HRS-S0184	●
141	Heat exchanger (For option M)	HRS-S0415	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
144	Pressure sensor (For high pressure)	HRS-S0183	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
151	Caster (4Pcs.)(for HRS050)	HRS-S0098	●
154	Packaging Materials set	HRS-S0151	●
157	Sequence I/O command signal connector	HRS-S0103	●
159	Ferrite core	HRS-S0105	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models: HRS050-W□-20-□



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
3	Upper Panel	HRS-S0092	●
8	Right Side Panel (For water-cooled)	HRS-S0094	●
12	Left Side Panel (For water-cooled)	HRS-S0096	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
18	Hose (For standard pump)	HRS-S0097	●
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
27	DC power supply	HRS-S0087	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
37	Pump	HRS-S0088	●
44	Pump (For option M)	HRS-S0089	○ (For option M)
47	Mechanical seal Kit	HRG-S0211	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
57	Main Board (HRS050)	HRS-S0135	●/○ Note 2.
71	Main Board	HRS-S0091	●
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option T)
108	Relay (For Compressor)	HRS-S0392	●
109	Circuit breaker	HRS-S0395	●
112	Earth leakage breaker (For option B)	HRS-S0348	○ (For option B)
118	Compressor	HRS-S0337	●
124	Heat exchanger (Condenser)	HRS-S0152	●
126	Water regulating valve	HRS-S0388	●
128	Filter drier	HRZ-S0227	●
130	Electronic Expansion Valve (For heating)	HRS-S0340	●
132	Electronic Expansion Valve (For cooling)	HRS-S0341	●
134	Electronic Expansion Valve Coil (For heating)	HRS-S0386	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
138	Heat exchanger	HRS-S0184	●
141	Heat exchanger (For option M)	HRS-S0415	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
144	Pressure sensor (For high pressure)	HRS-S0183	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
151	Caster (4Pcs.)(for HRS050)	HRS-S0098	●
154	Packaging Materials set	HRS-S0151	●
157	Sequence I/O command signal connector	HRS-S0103	●
159	Ferrite core	HRS-S0105	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models: HRS060-A□-20-□



Construction

No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
1	Dustproof filter	HRS-S0001	●
3	Upper Panel	HRS-S0092	●
7	Right Side Panel (For air cooling)	HRS-S0298	●
11	Left Side Panel (For air cooling)	HRS-S0095	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
19	Hose (For standard pump)	HRS-S0362	●
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
27	DC power supply	HRS-S0087	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
37	Pump	HRS-S0088	●
44	Pump (For option M)	HRS-S0089	○ (For option M)
47	Mechanical seal Kit	HRG-S0211	●
51	Fan	HRS-S0099	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
57	Main Board (HRS050)	HRS-S0135	●/○ Note 2.
72	Main Board	HRS-S0296	●
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
108	Relay (For Compressor)	HRS-S0392	●
110	Circuit breaker	HRS-S0396	●
113	Earth leakage breaker (For option B)	HRS-S0397	○ (For option B)
118	Compressor	HRS-S0337	●
121	Condenser (For air-cooled type)	HRS-S0383	●
128	Filter drier	HRZ-S0227	●
130	Electronic Expansion Valve (For heating)	HRS-S0340	●
132	Electronic Expansion Valve (For cooling)	HRS-S0341	●
134	Electronic Expansion Valve Coil (For heating)	HRS-S0386	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
138	Heat exchanger	HRS-S0184	●
141	Heat exchanger (For option M)	HRS-S0415	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
144	Pressure sensor (For high pressure)	HRS-S0183	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
151	Caster (4Pcs.)(for HRS050)	HRS-S0098	●
154	Packaging Materials set	HRS-S0151	●
157	Sequence I/O command signal connector	HRS-S0103	●
159	Ferrite core	HRS-S0105	●


Note 1. Excerpt number from the total list of P.91 to 98

Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.

Construction

Applicable models: HRS060-W□-20-□



Construction





No. Note 1.	Names of parts	Parts number	●: For standard type ○: For option type
(1)	Dustproof filter	HRS-S0001	●
3	Upper Panel	HRS-S0092	●
8	Right Side Panel (For water-cooled)	HRS-S0094	●
12	Left Side Panel (For water-cooled)	HRS-S0096	●
13	Front panel B	HRS-S0005	●
14	Front panel A	HRS-S0006	●
15	Temperature sensor	HRS-S0007	●
18	Hose (For standard pump)	HRS-S0097	●
24	Pressure sensor (For circulating fluid)	HRS-S0011	●
25	Level switch	HRS-S0014	●
27	DC power supply	HRS-S0087	●
28	Display board	HRS-S0017	●
29	Communication board	HRS-S0018	●
30	Power board	HRS-S0019	●
37	Pump	HRS-S0088	●
44	Pump (For option M)	HRS-S0089	○ (For option M)
47	Mechanical seal Kit	HRG-S0211	●
52	Fuse (5Pcs.)	HRS-S0024	●
53	Tank	HRS-S0025	●
54	Tank (For automatic water-fill)	HRS-S0072	○ (For option J)
55	Tank lid	HRS-S0026	●
57	Main Board (HRS050)	HRS-S0135	●/○ Note 1.
73	Main Board	HRS-S0297	●
107	Solenoid Valve (For automatic water-fill)	HRS-S0071	○ (For option J)
108	Relay (For Compressor)	HRS-S0392	●
109	Circuit breaker	HRS-S0395	●
112	Earth leakage breaker (For option B)	HRS-S0348	○ (For option B)
118	Compressor	HRS-S0337	●
124	Heat exchanger (Condenser)	HRS-S0152	●
126	Water regulating valve	HRS-S0388	●
128	Filter drier	HRZ-S0227	●
130	Electronic Expansion Valve (For heating)	HRS-S0340	●
132	Electronic Expansion Valve (For cooling)	HRS-S0341	●
134	Electronic Expansion Valve Coil (For heating)	HRS-S0386	●
135	Electronic Expansion Valve Coil (For cooling)	HRS-S0010	●
138	Heat exchanger	HRS-S0184	●
141	Heat exchanger (For option M)	HRS-S0415	○ (For option M)
142	Pressure sensor (For high pressure)	HRS-S0012	●
144	Pressure sensor (For high pressure)	HRS-S0183	●
146	Thermistor sensor	HRS-S0338	●
149	Label (For Operation display)	HRS-S0058	●
151	Caster (4Pcs.)(for HRS050)	HRS-S0098	●
154	Packaging Materials set	HRS-S0151	●
157	Sequence I/O command signal connector	HRS-S0103	●
159	Ferrite core	HRS-S0105	●

Note 1. Excerpt number from the total list of P.91 to 98




Note 2. These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○".

It is used by setting the program.








Replacement Parts for Optional Accessories

Divergence piping		Particle filter bracket, P.P.Depth Element	
HRS-DP001	HRS-DP002	HRS-PF001	HRS-PF002
			
Water leakage detector (For drain pan set)		DI Sensor	
HRS-WL001	HRS-WL002	HRS-DI001	HRS-DI004
			

Replacement Parts for Optional Accessories

DI Sensor for control		Electrical conductivity Sensor	Electrical conductivity Sensor for control
HRS-DI003	HRS-DI005	HRS-DI008	HRS-DI009
			


Construction (Accessories included in the package)

-  Operation manual (Japanese/English)^{*1}
166  Quick manual (Japanese/English)
167  Alarm code list sticker
158  Power supply connector (Female)
157  Contact input/output communication connector
156  Fitting (For drain outlet)
159  Ferrite core (For contact input/output communication)



For N and F types^{*2}

- For circulating fluid connection port: 1/2 x 2
- For facility water connection port: 3/8 x 2 (For water-cooled refrigeration)
- For automatic water fill connection: 3/8 x 1, 3/4 x 1 (For option J)



*1 Please download via our website.

*2 Refer to the **Web Catalog** for details on the optional accessories HRS-EP□□□

Replacement Parts List

● Replacement parts for circulating fluid circuit and electrical circuit

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	Unit
			HRS-S□□□ HRZ-S□□□ HRG-S□□□			
1	■*1	Dustproof filter	HRS-S0001	0.5	1	pcs.
2		Upper Panel	HRS-S0002	1.0	1	pcs.
3		Upper Panel	HRS-S0092	1.0	1	pcs.
4		Right Side Panel	HRS-S0003	1.6	1	pcs.
5		Right Side Panel (For option G)	HRS-S0075	1.6	1	pcs.
6		Right Side Panel (For air cooling)	HRS-S0093	3.0	1	pcs.
7		Right Side Panel (For air cooling)	HRS-S0298	3.0	1	pcs.
8		Right Side Panel (For water-cooled)	HRS-S0094	3.0	1	pcs.
9		Left Side Panel	HRS-S0004	1.6	1	pcs.
10		Left Side Panel (For option G)	HRS-S0076	1.6	1	pcs.
11		Left Side Panel (For air cooling)	HRS-S0095	3.0	1	pcs.
12		Left Side Panel (For water-cooled)	HRS-S0096	3.0	1	pcs.
13		Front panel B (-S/N TP)	HRS-S0005	0.2	1	pcs.
		Front panel (S/N TQ-)	HRS-S0519		1	pcs.
14		Front panel A (-S/N TP) (Integration to No.13)(S/N TQ-)	HRS-S0006	0.2	1	pcs.
15	■	Temperature sensor	HRS-S0007	0.1	1	ass'y
16		Hose (For standard pump)	HRS-S0008	0.6	1	kit
17		Hose (For standard pump)	HRS-S0302	0.8	1	kit
18		Hose (For standard pump)	HRS-S0097	1.0	1	kit
19		Hose (For standard pump)	HRS-S0362	1.0	1	kit
20		Hose (For option T)	HRS-S0077	0.6	1	kit
21		Hose (For option T)	HRS-S0303	0.6	1	kit
22		Hose (For option MT)	HRS-S0069	0.6	1	kit
23		Hose (For option MT)	HRS-S0304	0.6	1	kit
24	■	Pressure sensor (For circulating fluid)	HRS-S0011	0.1	1	pcs.
25	■	Level switch	HRS-S0014	0.1	1	pcs.
26	■	DC power supply	HRS-S0016	0.2	1	pcs.
27	■	DC power supply	HRS-S0087	0.23	1	pcs.
28	■	Display board (-S/N TP)	HRS-S0017	0.2	1	ass'y
		Display board (S/N TQ-)	HRS-S0520		1	ass'y
29	■	Communication board	HRS-S0018	0.1	1	pcs.
30	■	Power board	HRS-S0019	0.2	1	pcs.
31		Power switch	HRS-S0020	0.037	1	pcs.
32		Power switch (For 15A)	HRS-S0070	0.037	1	pcs.
33		Inlet socket	HRS-S0021	0.044	1	kit
34		Pump (for 100V)	HRS-S0022	7.0	1	ass'y
35	■	Pump (for 200V type)	HRS-S0066	7.0	1	ass'y
36	■	Pump (for 200V)	HRS-S0361		1	ass'y
37	■	Pump	HRS-S0088	12.0	1	ass'y
38	□*4	High head pump (For 100V type option T)	HRS-S0265	12.0	1	ass'y
39	■	High head pump (For option T)	HRS-S0062	12.0	1	ass'y
40	■	High head pump (For option T)	HRS-S0299	12.0	1	ass'y
41		High head pump (For 100V type option MT)	HRS-S0266	12.0	1	ass'y
42		High head pump (For option MT)	HRS-S0063	12.0	1	ass'y
43		High head pump (For option MT)	HRS-S0300	12.0	1	ass'y
44		Pump (For option M)	HRS-S0089	12.0	1	ass'y
45	□	Mechanical seal Kit (For 100V type option T)	HRS-S0390		1	kit
46	□	Mechanical seal Kit (For 100V type option MT)	HRS-S0412		1	kit
47	■	Mechanical seal Kit	HRG-S0211	0.018	1	kit
48	□	Fan (for 100V) With bracket	HRS-S0023	1.7	1	ass'y
49	■	Fan (for 200V type)	HRS-S0067	1.7	1	ass'y
50	■	Fan	HRS-S0301	3.1	1	ass'y
51	■	Fan	HRS-S0099	3.1	1	ass'y
52	■	Fuse (5Pcs.)	HRS-S0024	0.0005	5	pcs.
53	■	Tank	HRS-S0025	0.8	1	ass'y
54	■	Tank (For automatic water-fill)	HRS-S0072	0.8	1	ass'y
55	■	Tank lid	HRS-S0026	0.1	1	pcs.

*1 These are recommended stock for replacement parts that are marked "■".

*2 These are replacement parts of the standard specification used in HRS that are marked "●".

*3 These are replacement parts of the option specification used in HRS that are marked "□".

*4 These are recommended stock for replacement parts of 100 VAC specifications that are marked "□".

	Applicable models of HRS															
	HRS□□□-□-10				HRS□□□-□-20											
	012-A	012-W	018-A	018-W	012-A	012-W	018-A	018-W	024-A	024-W	030-A	030-W	050-A	050-W	060-A	060-W
	●*2		●		●		●		●		●		●		●	
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●		●	●	●	●	●		●				●
					○*3		○		○		●	●				
													●		●	●
	●	●	●	●	●	●	●	●	●	●		●				
					○		○		○		●	●			●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
											●	●		●	●	●
	○	○	○	○	○	○	○	○	○	○	○	○			●	
	○	○	○	○	○	○	○	○	○	○		○				
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○
	●	●	●	●	●	●	●	●	●	●	●	●				
					●	●	●	●	●	●		●		●	●	●
	○	○	○	○							●	●				
	○	○	○	○	○	○	○	○	○	○		○				
	○	○	○	○	○	○	○	○	○	○		○				
											○	○				
	○	○	○	○									○	○	○	○
	○	○	○	○	○	○	○	○	○	○	○	○	●	●	●	●
	●		●		●		●		●		●					
													●	●	●	●
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

*5 These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○". It is used by setting the program.

*6 These are the parts that are not included with HRS that are marked "(●)". But there is no problem to use.

*7 These are replacement parts used to optional accessories that are marked "▲".

Replacement Parts List

● Replacement parts for circulating fluid circuit and electrical circuit (Continues)

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	Unit
			HRS-□□□□ HRZ-□□□□ HRG-□□□□			
56	■	Main Board (for HRS012/018/024)	HRS-S0134	0.13	1	pcs.
57	■	Main Board (HRS050)	HRS-S0135	0.13	1	pcs.
58		Main Board (for HRS012-A-10)	HRS-S0033	0.13	1	pcs.
59		Main Board (for HRS012-W-10)	HRS-S0034	0.13	1	pcs.
60		Main Board (for HRS018-A-10)	HRS-S0035	0.13	1	pcs.
61		Main Board (for HRS018-W-10)	HRS-S0036	0.13	1	pcs.
62		Main Board (for HRS012-A-20)	HRS-S0037	0.13	1	pcs.
63		Main Board (for HRS012-W-20)	HRS-S0040	0.13	1	pcs.
64		Main Board (for HRS018-A-20)	HRS-S0043	0.13	1	pcs.
65		Main Board (for HRS018-W-20)	HRS-S0046	0.13	1	pcs.
66		Main Board (for HRS024-A-20)	HRS-S0049	0.13	1	pcs.
67		Main Board (for HRS024-W-20)	HRS-S0052	0.13	1	pcs.
68		Main Board	HRS-S0290	0.13	1	pcs.
69		Main Board	HRS-S0293	0.13	1	pcs.
70		Main Board	HRS-S0090	0.13	1	pcs.
71		Main Board	HRS-S0091	0.13	1	pcs.
72		Main Board	HRS-S0296	0.13	1	pcs.
73		Main Board	HRS-S0297	0.13	1	pcs.
74		Main Board (for HRS012-A-10-T)	HRS-S0282	0.13	1	pcs.
75		Main Board (for HRS012-W-10-T)	HRS-S0284	0.13	1	pcs.
76		Main Board (for HRS018-A-10-T)	HRS-S0286	0.13	1	pcs.
77		Main Board (for HRS018-W-10-T)	HRS-S0288	0.13	1	pcs.
78		Main Board (for HRS012-A-20-T)	HRS-S0038	0.13	1	pcs.
79		Main Board (for HRS012-W-20-T)	HRS-S0041	0.13	1	pcs.
80		Main Board (for HRS018-A-20-T)	HRS-S0044	0.13	1	pcs.
81		Main Board (for HRS018-W-20-T)	HRS-S0047	0.13	1	pcs.
82		Main Board (for HRS024-A-20-T)	HRS-S0050	0.13	1	pcs.
83		Main Board (for HRS024-W-20-T)	HRS-S0053	0.13	1	pcs.
84		Main Board (for HRS030-A-20-T)	HRS-S0291	0.13	1	pcs.
85		Main Board (for HRS030-W-20-T)	HRS-S0294	0.13	1	pcs.
86		Main Board (for HRS012-A-10-MT)	HRS-S0283	0.13	1	pcs.
87		Main Board (for HRS012-W-10-MT)	HRS-S0285	0.13	1	pcs.
88		Main Board (for HRS018-A-10-MT)	HRS-S0287	0.13	1	pcs.
89		Main Board (for HRS018-W-10-MT)	HRS-S0289	0.13	1	pcs.
90		Main Board (for HRS012-A-20-MT)	HRS-S0039	0.13	1	pcs.
91		Main Board (for HRS012-W-20-MT)	HRS-S0042	0.13	1	pcs.
92		Main Board (for HRS018-A-20-MT)	HRS-S0045	0.13	1	pcs.
93		Main Board (for HRS018-W-20-MT)	HRS-S0048	0.13	1	pcs.
94		Main Board (for HRS024-A-20-MT)	HRS-S0051	0.13	1	pcs.
95		Main Board (for HRS024-W-20-MT)	HRS-S0054	0.13	1	pcs.
96		Main Board (for HRS030-A-20-MT)	HRS-S0292	0.13	1	pcs.
97		Main Board (for HRS030-W-20-MT)	HRS-S0295	0.13	1	pcs.
98		Main Board (for HRS012-A-20-G)	HRS-S0078	0.13	1	pcs.
99		Main Board (for HRS018-A-20-G)	HRS-S0081	0.13	1	pcs.
100		Main Board (for HRS024-A-20-G)	HRS-S0084	0.13	1	pcs.
101		Main Board (for HRS012-A-20-GT)	HRS-S0079	0.13	1	pcs.
102		Main Board (for HRS018-A-20-GT)	HRS-S0082	0.13	1	pcs.
103		Main Board (for HRS024-A-20-GT)	HRS-S0085	0.13	1	pcs.
104		Main Board (for HRS012-A-20-GMT)	HRS-S0080	0.13	1	pcs.
105		Main Board (for HRS018-A-20-GMT)	HRS-S0083	0.13	1	pcs.
106		Main Board (for HRS024-A-20-GMT)	HRS-S0086	0.13	1	pcs.
107	■	Solenoid Valve (For automatic water-fill)	HRS-S0071	0.3	1	ass'y
108		Relay (For Compressor)	HRS-S0392	0.09	1	pcs.
109		Circuit breaker	HRS-S0395	0.2	1	pcs.
110		Circuit breaker	HRS-S0396	0.2	1	pcs.

*1 These are recommended stock for replacement parts that are marked "■".

*2 These are replacement parts of the standard specification used in HRS that are marked "●".

*3 These are replacement parts of the option specification used in HRS that are marked "○".

*4 These are recommended stock for replacement parts of 100 VAC specifications that are marked "□".

[illegible]

*6 These are the parts that are not included with HRS that are marked “(●)”. But there is no problem to use.
*7 These are replacement parts used to optional accessories that are marked “▲”.

Replacement Parts List

● Replacement parts for circulating fluid circuit and electrical circuit (Continues)

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	Unit
			HRS-□□□□ HRZ-□□□□ HRG-□□□□			
111		Earth leakage breaker (For option B)	HRS-S0393	0.2	1	pcs.
112		Earth leakage breaker (For option B)	HRS-S0348	0.2	1	pcs.
113		Earth leakage breaker (For option B)	HRS-S0397	0.2	1	pcs.
114		Earth leakage breaker (For option B or BT)	HRS-S0394	0.2	1	pcs.

● Replacement parts for refrigeration circuit and facility water circuit

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	Unit
			HRS-□□□□ HRZ-□□□□ HRG-□□□□			
115	□	Compressor (for 100V type)	HRS-S0409		1	kit
116	■	Compressor (for 200V type)	HRS-S0068	12.0	1	kit
117	■	Compressor (for 200V type)	HRS-S0423	12.0	1	kit
118	■	Compressor	HRS-S0337	17.0	1	kit
119	■	Condenser (For air-cooled type)	HRS-S0381		1	ass'y
120	■	Condenser (For air-cooled type)	HRS-S0382		1	ass'y
121	■	Condenser (For air-cooled type)	HRS-S0383		1	kit
122		Heat exchanger (Condenser)	HRS-S0133	1.0	1	ass'y
123		Heat exchanger (Condenser)	HRS-S0384	1.0	1	ass'y
124		Heat exchanger (Condenser)	HRS-S0152	1.0	1	ass'y
125		Water regulating valve	HRS-S0385	0.8	1	ass'y
126		Water regulating valve	HRS-S0388	0.9	1	ass'y
127		Filter drier	HRS-S0387		1	pcs.
128		Filter drier	HRZ-S0227		1	pcs.
129	■	Electronic Expansion Valve (For heating)	HRS-S0028	0.30	1	kit
130	■	Electronic Expansion Valve (For heating)	HRS-S0340	0.21	1	kit
131	■	Electronic Expansion Valve (For cooling)	HRS-S0029	0.30	1	kit
132	■	Electronic Expansion Valve (For cooling)	HRS-S0341	0.23	1	kit
133		Electronic Expansion Valve Coil (For heating)	HRS-S0009	0.20	1	ass'y
134		Electronic Expansion Valve Coil (For heating)	HRS-S0386	0.20	1	ass'y
135		Electronic Expansion Valve Coil (For cooling)	HRS-S0010	0.20	1	ass'y
136		Heat exchanger	HRS-S0030	1.0	1	ass'y
137		Heat exchanger Assy	HRS-S0380	1.0	1	ass'y
138		Heat exchanger	HRS-S0184	1.0	1	ass'y
139		Heat exchanger (For option M)	HRS-S0413	4.0	1	ass'y
140		Heat exchanger Assy (For option M)	HRS-S0414	5.0	1	ass'y
141		Heat exchanger (For option M)	HRS-S0415	5.0	1	ass'y
142	■	Pressure sensor (For high pressure)	HRS-S0012	0.08	1	pcs.
143	■	Pressure sensor (For high or low pressure)	HRS-S0013	0.08	1	pcs.
144	■	Pressure sensor (For high pressure)	HRS-S0183	0.08	1	pcs.
145		Thermistor sensor	HRS-S0057	0.05	1	kit
146		Thermistor sensor	HRS-S0338	0.05	1	kit
—	■	(Charging weight of refrigerant)	R407C			
—	■	(Charging weight of refrigerant)	R410A			

*1 These are recommended stock for replacement parts that are marked "■".

*2 These are replacement parts of the standard specification used in HRS that are marked "●".

*3 These are replacement parts of the option specification used in HRS that are marked "□".

*4 These are recommended stock for replacement parts of 100 VAC specifications that are marked "□".

Applicable models of HRS															
HRS□□□-□-10				HRS□□□-□-20											
012-A	012-W	018-A	018-W	012-A	012-W	018-A	018-W	024-A	024-W	030-A	030-W	050-A	050-W	060-A	060-W
				○	○	○	○	○	○	○	○				
												○	○		○
○	○	○	○	○	○	○	○	○	○	○	○				

Applicable models of HRS															
HRS□□□-□-10				HRS□□□-□-20											
012-A	012-W	018-A	018-W	012-A	012-W	018-A	018-W	024-A	024-W	030-A	030-W	050-A	050-W	060-A	060-W
●	●	●	●		●	●	●	●	●		●				
				●	●	●	●	●	●		●				
●		●		●		●		●		●		●	●	●	●
	●		●		●		●		●			●		●	
											●				
	●		●		●		●		●		●		●		●
●	●	●	●	●	●	●	●	●	●	●	●		●	●	●
●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
○	○	○	○	○	○	○	○	○	○			●	●	●	●
●	●	●	●	●	●	●	●	●	●	●	●	○	○	○	○
●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
●	●	●	●	●	●	●	●	●	●			●	●	●	●
0.315 to 0.325 kg	0.250 to 0.260 kg	0.315 to 0.325 kg	0.250 to 0.260 kg	0.345 to 0.360 kg	0.295 to 0.305 kg	0.345 to 0.360 kg	0.295 to 0.305 kg	0.345 to 0.360 kg	0.295 to 0.305 kg	0.550 to 0.580 kg	0.480 to 0.510 kg				
												0.640 to 0.670 kg	0.640 to 0.670 kg	0.830 to 0.860 kg	0.720 to 0.750 kg

*5 These are replacement parts of the standard specification or option specification used in HRS that are marked "●/○". It is used by setting the program.

*6 These are the parts that are not included with HRS that are marked "(●)". But there is no problem to use.

*7 These are replacement parts used to optional accessories that are marked "▲".

Replacement Parts List

● Other replacement parts

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	
			HRS-□□□□ HRZ-□□□□ HRG-□□□□		Unit	
147	■	Extraction tool (J.S.T.)	HRS-S0055	0.010	1	pcs.
148	■	Extraction tool (molex)	HRS-S0056	0.005	1	pcs.
149	■	Label (For Operation display)	HRS-S0058	0.010	1	pcs.
		(Integration to No.13)(S/N TQ~)				
150	■	Caster (4Pcs.)	HRS-S0059	0.24	4	pcs.
151	■	Caster (4Pcs.)(for HRS050)	HRS-S0098	0.24	4	pcs.
152	■	Packaging Materials set	HRS-S0060	20.0	1-5	kit
153	■	Packaging Materials set	HRS-S0391	20.0	1-5	kit
154	■	Packaging Materials set	HRS-S0151	27.0	1	kit
155	■	Power supply connector omission prevention fittings	HRS-S0074	0.005	1	kit
156	■	Drain Fitting	HRS-S0102	0.1	1	pcs.
157	■	Sequence I/O command signal connector	HRS-S0103	0.01	1	pcs.
158	■	Power supply connector	HRS-S0104	0.04	1	kit
159	■	Ferrite core	HRS-S0105	0.03	1	pcs.
160	■	Drain Plug set	HRS-S0132	0.03	1	kit
161		Condenser bracket	HRS-S0015	1.0	1	kit
162		Thermal insulator for heat exchanger	HRS-S0031	0.0	1	kit
163		Thermal insulator for copper pipe	HRS-S0032	0.1	1	kit
164		Base	HRS-S0061	2.6	1	pcs.
165		PT Thread Adaptor Set	HRS-S0073	0.3	1	pcs.
166		Quick manual	HRS-S0106	0.03	1	vol.
167		Alarm cord list label	HRS-S0107	0.01	1	pcs.
168		Accessory set	HRS-S0108	0.90	1	kit
169		Accessory set	HRS-S0109	0.80	1	kit

● Replacement parts for optional accessories

No.	Recommended stock parts	Names of parts	Parts number	Weight [kg]	Packaged qty	
			HRS-□□ HRZ-□□ HRG-□□		Unit	
170		Divergence piping	HRS-S0100	0.3	1	ass'y
171	■	Particle filter bracket	HRS-S0244	0.35	1	kit
172	■	P.P.Depth Element (5 μmm)	EJ202S-005X11	0.083	1	pcs.
173	■	P.P.Depth Element (5 μmm)	EJ302S-005X11	0.083	1	pcs.
174		P.P.Depth Element (75 μmm)	EJ202S-075X11	0.165	1	pcs.
175		P.P.Depth Element (75 μmm)	EJ302S-075X11	0.165	1	pcs.
176	■	Water leakage detector (For drain pan set)	HRS-S0215	0.06	1	ass'y
177		DI Sensor	HRS-S0419		1	ass'y
178		DI Sensor for control	HRS-S0420		1	ass'y
179		Electrical conductivity Sensor	HRS-S0424		1	ass'y
180		Electrical conductivity Sensor for control	HRS-S0425		1	ass'y

*1 These are recommended stock for replacement parts that are marked "■".

*2 These are replacement parts of the standard specification used in HRS that are marked "●".

*3 These are replacement parts of the option specification used in HRS that are marked "○".

*4 These are recommended stock for replacement parts of 100 VAC specifications that are marked "□".

Thermo-chiller HRS Series

Thermo-chiller HRS Series

Thermo-chiller HRS Series


Thermo-chiller HRS Series

Thermo-chiller HRS Series

Thermo-chiller HRS Series

Illustration of Replacement Parts

● **Dustproof filter**



● **Panel**






Illustration of Replacement Parts

2

● **Temperature sensor**





● **Hose**



Thermo-chiller HRS Series

Illustration of Replacement Parts

● Pressure sensor (For circulating fluid)



● Level switch





Illustration of Replacement Parts

● **DC power supply**





Illustration of Replacement Parts

- Main board / Communication board / Power board / Display board / Fuse




Illustration of Replacement Parts

- Main board / Communication board / Power board / Display board / Fuse




Illustration of Replacement Parts

● Pump





Illustration of Replacement Parts

2

Thermo-chiller HRS Series

● **Fan**



● **Tank**






Illustration of Replacement Parts

● Tank lid



● Valve for automatic water fill







Illustration of Replacement Parts

● **Power switch**



● **Inlet socket**



● **Compressor**








Illustration of Replacement Parts

● **Condenser (For air-cooled type)**



● **Heat exchanger (For water-cooled type)**






Illustration of Replacement Parts

● **Water regulating valve**



● **Filter drier**



● **Electronic expansion valve, Electronic expansion valve coil**










Illustration of Replacement Parts


● **Heat exchanger**



● **Pressure sensor (For refrigerant)**



● **Thermistor sensor**



Parts Replacement Cycle

We recommend that you replace the parts according to the cycle specified in the table below so that you can extend the service life of your thermo-chiller.

Description		No. <small>(note)</small>	Reason for recommendation	Replacement cycle
Pump mechanical seal (For option T: High pressure pump)		45 to 47	Wear of the mechanical seal will lead to an increase in the leakage rate. (The mechanical seal may need to be replaced when the leakage rate exceeds 3 cc per hour.)	6000 to 8000 hours (Normally 1 year)
Solenoid valve for automatic water fill (For option J: With automatic water fill function)		107	Deterioration of the diaphragm will lead to a decrease in the opening and closing performance of the valve.	24 months
Circulating pump		34 to 44	Wear of the bearing will lead to a decrease in the circulating fluid flow rate.	36 months
Cooling fan (For air-cooled type)		48 to 51	Wear of the bearing will lead to a decrease in heat radiation efficiency.	
Electronic expansion valve		129 to 132	Deterioration of the device will lead to a decrease in temperature control performance.	
Seal, O-ring		—	Deterioration will lead to a decrease in seal performance.	
Dustproof filter		1	Clogging will lead to a decrease in air vent performance.	
Compressor		115 to 118	Wear of the bearing or compressed section (sliding section) will lead to a decrease in cooling capacity.	
Parts for refrigerant circuit	Heat exchanger assembly	136 to 141	Deterioration of the device will lead to a decrease in temperature control performance.	
	Condenser (Air-cooled)	119 to 121		
	Condenser (Water-cooled)	122 to 124		
	Filter drier	127, 128		
	Water regulating valve	125, 126		
Electrical boards	Display board	28	Failure to replace the parts will lead to a decrease in display function and/or operability. Deterioration of the board or mounted components will lead to a decrease in function.	
	Main board	56 to 106		
	Communication board	29		
	Power board	30		
	DC power supply	26, 27		
Electrical components	Earth leakage breaker (For option B or BT)	109 to 114	Wear or fixation of the sliding section will lead to a decrease in operating function. Deterioration of the condenser will lead to a decrease in control power supply function.	
Sensors	Temperature sensor	15	Deterioration will lead to a decrease in function.	
	Pressure sensor (For circulating fluid)	24		
	Pressure sensor (For high pressure)	142, 144		
	Pressure sensor (For low pressure)	143		
	Level switch	25		
	Thermistor sensor	145, 146		
Parts for circulating fluid circuits	Hose	16 to 23	Deterioration will lead to a decrease in function.	
Other	Fuse	52	When replacement is required based on the inspection results	
	Upper panel	2, 3		
	Right side panel	4 to 8		
	Left side panel	9 to 12		
	Front panel	13, 14		
	Tank	53, 54		
	Tank lid	55		
	Electronic expansion valve coil	133 to 135		
	Caster (4 pcs.)	150, 151		
	Drain fitting	156		
	Drain plug set	160		
	Power supply connector	158		
	Sequence I/O command signal connector	157		
	Quick manual	166		
	Alarm cord list label	167		
	Accessory set	168, 169		

Note) Numbers correspond to those in the replacement parts list on pages 91 to 98

Product Warranty

I. Product Warranty

1. Period

The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.

The warranty period of service parts (replacement parts) is 0.5 years after replacement.

2. Scope

For any failure reported within the warranty period which is clearly our responsibility, replacement parts will be provided. In that case, removed parts shall become the property of SMC.

Any damage incurred by the failure is not our responsibility.

3. Content

1. We guarantee that the product will operate normally if it is installed under maintenance and control in accordance with the Operation Manual, and operated under the conditions specified in the catalog or contracted separately.
2. We guarantee that the product does not have any defects in components, materials or assembly.
3. We guarantee that the product complies with the outline dimensions provided.
4. The following situations are out of scope of this warranty.
 - (1) The product was incorrectly installed or connected with other equipment.
 - (2) The product was under insufficient maintenance and control or incorrectly handled.
 - (3) The product was operated outside of the specifications.
 - (4) The product was modified or altered in construction.
 - (5) The failure was a secondary failure of the product caused by the failure of equipment connected to the product.
 - (6) The failure was caused by a natural disaster such as an earthquake, typhoon, or flood, or by an accident or fire.
 - (7) The failure was caused by operation different from that shown in the Operation Manual or outside of the specifications.
 - (8) The checks and maintenance specified (daily checks and periodic inspection) were not performed.
 - (9) The failure was caused by the use of circulating fluid or facility water other than those specified.
 - (10) The failure occurred naturally over time (such as discoloration of a painted or plated face).
 - (11) Sensory phenomena that are considered no effect on the functions (such as noise, vibration).
 - (12) The failure was due to the "Installation Environment" specified in the Operation Manual.
 - (13) The failure was caused by the customer disregarding **"6. Request to customers"**.

4. Disclaimer

The following are not covered by this warranty.

- (1) Expenses for daily checks and periodic inspection
- (2) Expenses for repairs performed by other companies
- (3) Expenses for transfer, installation and removal of the product
- (4) Expenses for replacement of parts other than those in this product, or for the supply of liquids
- (5) Inconvenience and loss due to product failure (such as telephone bills, compensation for workplace closure, and commercial losses).
- (6) Expenses and compensation not covered in **"2. Scope"**.

Product Warranty

5. Agreement

If there is any doubt about anything specified in “**2. Scope**” and “**3. Content**”, it shall be resolved by agreement between the customer and SMC.

6. Request to customers

Proper use and maintenance are essential to assure safe use of this product. Be sure to satisfy the following preconditions. Please note that we may refuse to carry out warranted repair if these preconditions have been disregarded.

- (1) Use the product following the instructions for handling described in the Operation Manual.
- (2) Perform checks and maintenance (daily checks and periodic inspection) specified in the Operation Manual and Maintenance Manual.
- (3) Record the check and maintenance results on the daily check sheet attached to the Operation Manual and Maintenance Manual.

7. Request for Warranted Repair

For warranted repair, please contact the supplier you purchased this product from. Warranted repair shall be on a request basis.

Repair shall be provided free of charge in accordance with the warranty period, preconditions and terms defined above. Therefore, a fee will be charged for any repairs if a failure is detected after the end of the warranty period.

II. Special Instructions


Instructions before the use of this unit


- (1) This unit is designed to be installed and operated in an industrial environment and used with a production facility.
- (2) This manual is intended to show the independent specifications of this unit.
In order to prevent unexpected failure, read and understand the contents of this manual and Operation Manual carefully and perform sufficient evaluation under the various possible operating conditions with your system connected before operating this unit.
- (3) This product is for indoor use. It cannot be used outdoors.
- (4) Clean room specifications are not applied to this unit. The pump and ventilating fan installed in this unit generate dust particles.
- (5) If this unit is used in a system where there is a high risk of damage to human life and equipment, or in an application which needs particular consideration of safety, operate this unit with safety margins added to rated values, performance etc., and take appropriate safety measures such as fail-safe measures.
- (6) The construction of this unit is not suitable for suspension. When loading off the packaged unit or lifting this unit, it is necessary to use a forklift. Additionally, it is not acceptable to mount heavy objects onto this unit or stack two or more units.
- (7) This unit is used to supply circulating fluid to the customer's system using an installed pump. Do not install any pump or other devices on your system to forcibly return the circulating fluid to this unit.


Product Warranty

Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of “**Caution**,” “**Warning**” or “**Danger**.” They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

 **Caution:** **Caution** indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

 **Warning:** **Warning** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

 **Danger :** **Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power – General rules relating to systems.
ISO 4413: Hydraulic fluid power – General rules relating to systems.
IEC 60204-1: Safety of machinery – Electrical equipment of machines.
(Part 1: General requirements)
ISO 10218-1: Manipulating industrial robots – Safety.
etc.

Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.
If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.
If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following “Limited warranty and Disclaimer” and “Compliance Requirements”.

Read and accept them before using the product.

Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2)
Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

*2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Safety Instructions

Be sure to read the “Handling Precautions for SMC Products” (M-E03-3) and “Operation Manual” before use.

■ Quick Manual	p. 117
Read before using	p. 117
Safety Instructions	p. 117
1. Name of Parts and Accessories	p. 117
2. Transportation, Transfer and Moving	p. 117
3. Mounting and Installation	p. 118
4. Piping	p. 118
5. Filling of Circulating Fluid	p. 118
6. Wiring of Power Supply	p. 119
7. Start, Stop and Temperature Setting	p. 119
8. How to Reset Alarms	p. 120
9. Alarm Code List	p. 120
Before Requesting Service	p. 120
■ Piping Check Sheet	p. 121
■ Inspection Monitor Screen Check Sheet	p. 123

Quick Manual




Read before using




Thank you for purchasing SMC's thermo-chiller (hereinafter referred to as the "product"). This "Quick Manual" (hereinafter referred to as this "manual") briefly explains the procedures to start and stop the product and reset its alarms. Read this manual as well as the Operation Manual attached before using.

Safety Instructions

- Read and understand Safety Instructions carefully for proper use.
- In these instructions, warning indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury. Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury. Make sure to follow every instruction since they are important for safety.
- The symbols used in this manual have the following meanings.

	Don'ts		Dos
--	--------	---	-----

 Warning	
	<ul style="list-style-type: none"> ● Do not service machinery/equipment or attempt to remove the product until safety is confirmed. In particular, before restarting the product, ensure that safety measures are taken.
	<ul style="list-style-type: none"> ● The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. ● Only personnel with appropriate training should operate machinery and equipment. ● The product can be dangerous when handled incorrectly. ● The piping, wiring, operation and maintenance of machines or equipment using this product must be performed by an operator who is appropriately trained and experienced. ● When the product is installed on equipment in conjunction with atomic energy, railways, air navigation, space, vehicles, medical treatment, or equipment in contact with food and beverages, or used for applications which could have negative effects on people, property, or animals requiring special safety analysis, give consideration to safety measures and contact SMC beforehand.

 Caution	
	<ul style="list-style-type: none"> ● Do not use the product outdoors. If the product is subjected to rain or water splash it may cause electrical shock, fire or failure. ● Do not use the product in an area of high temperature and humidity which cannot be exhausted, or where it is exposed to corrosive substances. Cooling failure can result. ● Do not handle the power supply connector and switch with wet hands. Electrical shock can result.
	<ul style="list-style-type: none"> ● Read the catalog and Operation Manual carefully. Keep to the specified procedures and within specified ranges. ● This product is heavy (over 40kg). When transferring the product with casters or handles, pay attention to slopes on the route and the risk of dropping the product. ● Select piping applicable to the operating pressure range. Otherwise, it can cause fluid leakage or rupture. ● Use fresh water or ethylene glycol aqueous solution (concentration of 15% or less) as the circulating fluid. ● For the precautions for handling the circulating fluid, get the Material Safety Data Sheet from the manufacturer and read it.


1. Name of Parts and Accessories

- Check the enclosed accessories with the delivered thermo-chiller.

Accessories		
1	Quick manual (this manual)	1 (with a clear cover)
2	Alarm code list label	1
3	Operation Manual	1
4	Power supply connector	1
5	Sequence I/O command signal connector*	1
6	Fitting (for drain port)*	1
7	Ferrite core*	1


*These accessories are not explained in this manual. For details, read the Operation Manual attached.

- The names of parts used in this manual are as follows.




*Water-cooled refrigeration type HRS□□□-W

(Operation display panel)



2. Transportation, Transfer and Moving


- 1) Be sure to unlock the caster (only at the front wheel). There is no lock function with the rear casters.
- 2) Push the left and right panels with the handle and move.
- 3) Use corners when pushing the front or rear panel. Pushing at the center can deform the panel.




No	Description	Function
1	Digital display (7-segment, 4 digits)	PV Displays the temperature and pressure of the circulating fluid and alarm codes.
		SV Displays the discharge temperature of the circulating fluid and the set values of other menus.
2	[°C] [°F] lamp	Equipped with a unit conversion function. Displays the unit of display temperature (default setting °C).
3	[MPa] [PSI] lamp	Equipped with a unit conversion function. Displays the unit of display pressure (default setting MPa).
4	[REMOTE] lamp*	Enables the remote operation (start and stop) by communication. Lights up during remote operation.
5	[RUN] lamp	Lights up when the product is started and in operation. Goes off when the product is stopped. Flashes during stand-by for stop or anti-freezing function, or independent operation of the pump.
6	[ALARM] lamp	Flashes with buzzer when alarm occurs.
7	[L] lamp	Lights up when the surface of the level indicator falls below the LOW level.

3. Mounting and Installation

- 1) Select a flat place applicable to the weight of the product for moving.
- 2) Install the product so that there are no obstacles in the work space for setting up and servicing, or blocking the radiation at the inlet and outlet of ventilation.



- 3) After moving, lock the caster at the front wheel again.
- 4) Fix the product to the floor or base using the anti-quake bracket (prepared separately).




*The Anchor bolts are not attached. To be prepared by the user.

No	Description	Function
8	[⌚] lamp*	Lights up while the run timer or stop timer function is working.
9	[⌚] lamp*	Lights up when the product is in automatic operation.
10	[RUN/STOP] key	Makes the product start or stop.
11	[MENU] key*	Shifts the main menu (display screen of temperature) and secret menu (entry of set values and monitor screen).
12	[SEL] key*	Changes the item in menu and enters the set value.
13	[▼] key	Decreases the set value.
14	[▲] key	Increases the set value.
15	[PUMP] key	Keep the [MENU] and [RUN/STOP] keys pressed down simultaneously. The pump starts running independently to make the product ready for start-up (release the air).
16	[RESET] key	Keep the [▼] and [▲] keys pressed down simultaneously. This will stop the alarm buzzer and reset the [ALARM] lamp.

*These lamps and keys are not used in this manual.
For details, read the Operation Manual attached.


4. Piping

- 1) Connect the circulating fluid return port with the user's machine outlet.
- 2) Connect the circulating fluid discharge port with the user's machine inlet.




<Water-cooled refrigeration type HRS□□-W>

- 1) Connect the facility water inlet with the user's water source outlet.
- 2) Connect the facility water outlet with the user's water source inlet.



5. Filling of Circulating Fluid

- 1) Check the drain port is plugged or closed by the valve to prevent the supplied circulating fluid from draining out.
- 2) Turn the lid for the circulating fluid fill port counterclockwise to open, and fill the circulating fluid up to "H" of the level indicator scale.
- 3) After filling to the specified level, turn the lid clockwise to close.



6. Wiring of Power Supply

Warning

● The electrical facilities should be installed and wired in accordance with local laws and regulations of each country and by the person who has knowledge and experience.

● Check the power supply. Operation with voltages, capacities, frequencies and cable sizes other than those specified can cause heat, fire and electrical shock.

● Wire with an applicable cable size and terminal.

Caution

● Use an individual socket or earth leakage breaker.

● Be sure to provide grounding. Incomplete grounding can cause failure and electrical shock.


Preliminary preparation for wiring.

- 1) Prepare the cable and individual socket or earth leakage breaker shown in the table below.
- 2) Strip the sheath from both ends of the cable.
- 3) Disassemble the power supply connector (supplied as an accessory) and mount one end of the cable to the L, N and E terminals and reassemble the power supply connector.
- 4) Connect the other end of the cable to a plug or crimped terminal that is connectable to the secondary side of the earth leakage breaker.

HRS model	Power supply voltage	Rated voltage [V]	Rated current [A]	Sensitivity of leak current [mA]	Cable qty. x size
HRS012-□□-10 HRS018-□□-10	1-phase 100V AC (50/60 Hz) 1-phase 115 V AC (60 Hz)	Recommended earth leakage breaker			3 cores x 14AWG (3 cores x 2.0 mm²) *including ground
		100 200 Sharing	15	15 or 30	
		Recommended plug			
125	15	—			
HRS012-□□-20 HRS018-□□-20 HRS024-□□-20 HRS030-□□-20	1-phase 200-230V AC (50/60 Hz)	Recommended earth leakage breaker			
HRS0□□-□□-20-□□ (If option [high head pump] is used.)		10	30		
		200, 230	15	30	

Wiring of power supply

- 1) Insert the power supply connector to the power cable hole.
- 2) Connect the plug or crimped terminal to the individual grounded socket or the secondary side of the earth leakage breaker and grounding.
- 3) Turn on the breaker, etc. of the facility power supply and energize the product.




7. Start, Stop and Temperature Setting

Preliminary preparation for start-up.

Supply of power

- 1) Turn on the power switch.

⇒The initial screen (HELLO) will be displayed for approx. 8 seconds on the operation panel, and changed to the display of the circulating fluid discharge temperature (main menu).




Air release

- 1) Press the [PUMP] key ([RUN/STOP] key and [MENU] key simultaneously). The [RUN] lamp flashes and only the pump continues to operation. This operation allows the discharge of the circulating fluid, and enables checking leakage from the piping and air release.
- 2) At this time, the fluid level can lower and cause the alarm "AL01; Low tank level", which will lead to the stop of the product.
- 3) In that case, check that there is no leakage from the user's piping, fill the circulating fluid as specified in "5.Filling of Circulating Fluid" and take necessary actions in "8.How to Reset Alarms".
- 4) Repeat steps 1) to 3) until the alarm ("AL01; Low tank level") is no longer generated.

Temperature setting

- 1) Press the [▼] and [▲] keys to change the SV to the required value.




(e.g.) "Set value of circulating fluid discharge temperature" 20.0°C (Default value)

Start of the product

- 1) Keep the [RUN/STOP] key pressed for approx. 2 seconds.


⇒The [RUN] lamp lights up (in green) and the product starts running.
The circulating discharge temperature (PV) is controlled to the set temperature (SV).



Stop of the product

- 1) Keep the [RUN/STOP] key pressed for approx. 2 seconds.

⇒The [RUN] lamp flashes (in green) and continues the operation until the product is ready to stop. After approx. 10 seconds, the [RUN] lamp goes off and the product stops.




8. How to Reset Alarms

⚠ Caution

1) Should some error occur, the [ALARM] lamp flashes (in red) and the buzzer sounds to inform the user of the error. Also, the alarm code will be displayed on the operation panel so that the cause can be checked on "9. Alarm Code List".

Flash



(Ex.)
"AL01"
"Low level in tank"

- Before resetting the alarm, read the "Cause and Remedy" of "9. Alarm Code List" and eliminate the cause explained there. Otherwise, the same alarm may be repeated.
- As accessories, the clear cover (for this manual) and alarm code list label are enclosed. Stick the label to the panel to check the content of alarm codes.

● Reset of alarm

- 1) Press the [RESET] key (▼) and [▲] keys simultaneously.
→The buzzer and then [ALARM] lamp (red) go off.



Before requesting service

Should some error occur, the user will be informed by the alarm (for warning). Check the cause and restart the product after eliminating it. If the same alarm is repeated frequently, or multiple alarms occur at the same time, which is obviously abnormal compared to the past performance of the product, contact the retailer or SMC sales representative where you purchased the product.

SMC Corporation

Address: 4-14-1 Sotokanda, Chiyoda-ku, Tokyo 101-0021, Japan

TEL: +81 3 5207 8249 FAX: +81 3 5298 5362

URL: <http://www.smcworld.com>

This manual is subject to change without prior notice.

9. Alarm Code List

Alarm code	Description	Operation	Cause/Remedy (Press the reset key after eliminating the cause.)
AL01	Low level in tank	Stop ^{*1}	The fluid level has fallen below the level indicator. Fill the circulating fluid.
AL02	High circulating fluid discharge temp.	Stop	· Reduce the ambient temperature or heat load. · Wait until the temperature decreases.
AL03	Circulating fluid discharge temp. rise	Continued ^{*1}	Check the ambient temperature condition and the temperature of supplied circulating fluid.
AL04	Circulating fluid discharge temp. drop	Continued ^{*1}	· Check the circulating fluid flows. · Check the heat load are within the specified range.
AL05	High circulating fluid return temp.	Stop	Check the user's piping for bends, squash and foreign matters.
AL06	High circulating fluid discharge pressure	Stop	Restart and check the pump is operating.
AL07	Abnormal pump operation	Stop	Check the user's piping for bends, squash and foreign matters.
AL08	Circulating fluid discharge pressure rise	Continued ^{*1}	Restart and check the pump is operating.
AL09	Circulating fluid discharge pressure drop	Continued ^{*1}	Check the temperature of the circulating fluid returning to the product.
AL10	High compressor intake temp.	Stop	· Check the circulating fluid flows. · Check the circulating fluid in the evaporator has not frozen.
AL11	Low compressor intake temp.	Stop	Reduce the ambient temperature or heat load.
AL12	Low super heat temperature	Stop	Check the ambient temperature is within the specified range.
AL13	High compressor discharge pressure	Stop	Reduce the ambient temperature or heat load.
AL15	Refrigerant circuit pressure (high pressure side) drop	Stop	Check the ambient temperature is within the specified range.
AL16	Refrigerant circuit pressure (low pressure side) rise	Stop	Reduce the ambient temperature or heat load.
AL17	Refrigerant circuit pressure (low pressure side) drop	Stop	Check the circulating fluid flows.
AL18	Compressor overload	Stop	Leave for 10 minutes and restart, and check the compressor is operating.
AL19 ^{*2}	Communication error ^{*2}	Continued ^{*1}	The request message from the host computer has not arrived. Send it again.
AL20	Memory error	Stop	Written data is different from read data. Ask for the service of RAM.
AL21	DC line fuse cut	Stop ^{*1}	Ask for the service of the fuse of the DC circuit.
AL22	Circulating fluid discharge temp. sensor failure	Stop	The temperature sensor is short-circuited or opened.
AL23	Circulating fluid return temp. sensor failure	Stop	Ask for the service of the temperature sensor.
AL24	Compressor intake temp. sensor failure	Stop	The pressure sensor is short-circuited or opened.
AL25	Circulating fluid discharge pressure sensor failure	Stop	Ask for the service of the pressure sensor.
AL26	Compressor discharge pressure sensor failure	Stop	
AL27	Compressor intake pressure sensor failure	Stop	
AL28	Maintenance of pump	Continued	The timing of a periodical check is informed.
AL29 ^{*3}	Maintenance of fan motor ^{*3}	Continued	Recommended to ask for the check and service of the pump, fan motor and compressor.
AL30	Maintenance of compressor	Continued	
AL31 ^{*2}	Contact input1 Signal detection	Stop ^{*1}	Contact input is detected.
AL32 ^{*2}	Contact input2 Signal detection	Stop ^{*1}	

*1 "Stop" or "Continued" are default setting. The user can changed to "Continued" and "Stop". For details, read the Operation Manual attached.

*2 "AL19, AL31, AL32" is disabled in the default setting. When this function needs to be enabled, refer to the Operation Manual attached.


*3 HRS□□□-A-□□ (Air-cooled refrigeration type).

*4 Refer to the "Operation Manual" (separate sheet) for other alarms.

Piping Check Sheet

Please enter an "○" for Yes and "×" for No.

Be sure to check the items with a "*" for trouble during a trial run.



Item to be cooled
(Ex.: Welding robot)

Valve

Air release valve

Thermometer

Filter

Thermometer

Flow meter

Insulating material

Flow direction

Flow switch

Drain valve

[Overall system & Heat load]

How many years has it been used? (Yrs. Mos.)

☐ * External load (heat generation of the item to be cooled) is known.

☐ * Minimum flow rate is achieved.

☐ * There are no leaks.

☐ * Cooling is performed without overheating.

[Relief valve (Bypass piping)]

☐ Set pressure is correct (does not exceed pressure resistance of the item to be cooled).

[Item to be cooled]

☐ There are no leaks.

☐ Wetted parts are not rusty.

☐ Does not change shape or break due to the pressure.

☐ There is no presence of droplets, the adhesion of liquid, etc.

☐ Grease is not adhered to the wetted parts.

[Operating/Storage environment]

☐ * Environment is suitable according to the "Specific Product Precautions*".

(*: Refer to the "Operation Manual" on the SMC website.)

[Circulating fluid, Facility water]

☐ * Liquid to be used is appropriate for the thermo-chiller (specifications).

☐ Replaced periodically to maintain cleanliness.

☐ * Does not contain additive agents.

☐ * Not foamy.

☐ Does not freeze (in the wintertime).

[Piping, Hose]

☐ Air is not trapped.

☐ An air vent (normally closed) is provided at the top.

☐ A drain valve (normally closed) is provided at the bottom.

☐ No condensation or freezing.

☐ Not bent or crushed.

[Valve, Bypass piping]

☐ Flow direction is correct.

☐ Aperture of the diaphragm (open/close) is appropriate.

[Thermo-chiller, Peripheral equipment]

☐ Liquid level in the tank is appropriate.

☐ Power is supplied at a stable voltage.

☐ Dustproof filter is not dirty or clogged.

☐ Leaks from the pump (mechanical seal) are within the permissible level.

☐ Bypass piping is provided to achieve the minimum flow rate.

☐ A check valve or solenoid valve is provided at the outlet port to prevent back flow.

☐ A solenoid valve is provided at the return port to prevent the liquid from spilling.

☐ Installation space (maintenance space) is sufficient.

☐ Numerical values on the inspection monitor screen are correct. (Refer to page 123.)

☐ Alarm codes are checked (noted) if alarms are generated.

☐ (For the -T, HRS050/060) A particle filter is provided.

[Regulator, Pressure gauge]

- ☐ * Flow direction (IN-OUT) is correct.
- ☐ * Pressure can be set.
- ☐ * Set pressure (85% or less of the primary pressure) is correct.
- ☐ * Bonnet seal is not loose.
- ☐ * There are no external leaks.
- ☐ * Pressure gauge does not show unusual deflection.

[Filter, Flow meter, Thermometer]


- ☐ No impurities in element
- ☐ Flow rate required for the item to be cooled is achieved.
- ☐ * Flow rate and temperature have validity.
(Heat generation of item to be cooled [kw]
= 70 x Flow rate [L/min] x Difference in
temperature [°C])

[Power supply]

- ☐ Electrical circuits are not overloaded.
- ☐ A power supply exclusively for the chiller is provided.
- ☐ Power supply capacity (circuit breaker size) is correct.
- ☐ Voltage is correct.
- ☐ No presence of short circuits.

[Circulating fluid circuit, Power supply]

Single-phase 100, 115 VAC
or 200-230 VAC



[Facility water circuit]

[Facility water]

- ☐ There is a difference in temperatures between the inlet and the outlet.
- ☐ Flow is not shut off.
- ☐ Covered with heat insulator and not dangerous even if touched.
- ☐ No presence of dust, foreign material, or corrosion.
- ☐ No presence of water hammer.
- ☐ No problems found in the circulating fluid or facility water.

- The “Inspection Monitor Screen Check Sheet” and the “Piping Check Sheet” provide the items to be checked on the spot in the event of an alarm.

When you make a request for servicing, please submit the check sheets with all alarm codes that have been generated.

Inspection Monitor Screen Check Sheet

Please enter an “○” for Yes and “×” for No.

Be sure to check the items with a “*” for trouble during a trial run.

List of inspection monitor menu check items

Display	Item	Contents	Value
t 1.	Circulating fluid outlet temperature	Displays the temperature of the circulating fluid outlet. This temperature does not take offset into consideration.	
t 2.	Circulating fluid return port temperature	Displays the temperature of the circulating fluid return.	
t 3.	Compressor inlet temperature	Displays the temperature of the inlet of the compressor.	
P 1.	Circulating fluid outlet pressure	Displays the circulating fluid outlet pressure at the outlet.	
P h.	Pressure of the higher pressure side of the refrigerant circuit	Displays the pressure of higher pressure side of the refrigerant circuit.	
P L.	Pressure of the lower pressure side of the refrigerant circuit	Displays the pressure of lower pressure side of the refrigerant circuit.	
d 1.	Electric resistivity/conductivity	Displays the electric resistivity/conductivity.	
P U n P	Accumulated operation time of the pump	Displays the accumulated operation time of the pump.	
F A n n	Accumulated operation time of the fan motor	Displays the accumulated operation time of the fan motor. (For air-cooled type)	
C E F.	Accumulated operation time of the compressor	Displays the accumulated operation time of the compressor.	
d r u.	Accumulated operation time	Displays the accumulated operation time.	

Check of the circulating fluid outlet temperature

1. Press and hold the [MENU] key for approx. 2 sec.

The temperature of the circulating fluid outlet “t 1.” is displayed on the digital display.



Displays the temperature of the circulating fluid at the outlet from which the fluid is fed to the customer's device. This temperature does not take temperature offset into consideration




- * Circulating fluid outlet temperature t1. is 1 [°C] or higher, AL02 [High circulating fluid discharge temperature] is not generated, and the temperature is controlled to the preset temperature (= SV + Offset).

Check of the circulating fluid inlet temperature

2. Press the [SEL] key once.

The temperature of the circulating fluid return is displayed on the digital display.



Displays the temperature of the circulating fluid returning from the customer's device.


CHECK!

- ☐ * Circulating fluid inlet temperature t_2 is equal to or higher than t_1 . [°C], AL05 [High circulating fluid return temperature (60°C)] is not generated, and there is an allowance for cooling capacity relative to the heat generation of the item to be cooled.

[Refer to "Heat generation of the item to be cooled" below.]

Heat generation of the item to be cooled

1. Plot the circulating fluid outlet pressure P1. on the pump capacity diagram, and read off the circulating fluid flow rate.



2. Calculate the heat generation of the item to be cooled.

$$\text{Heat generation of item to be cooled [kW]} = 70 \times \text{Circulating fluid flow rate [L/min]} \times (t_2 - t_1) / 1000 \text{ [W/kW]}$$

– Circulating fluid outlet temperature t_1 . [°C]

At this point,


70: Multiplier [J·min/(L·K·s)] (= Density of water [kg/L] × Specific heat [J/(kg·K)] / 60 [s/min])

66 for the case of 15% ethylene glycol aqueous solution

Check of the compressor inlet temperature

3. Press the [SEL] key once.

The compressor inlet temperature is displayed on the digital display.



Displays the compressor inlet temperature.



- ☐ The compressor inlet temperature t3. is -15 to 60 [$^{\circ}\text{C}$], and AL12 [Low superheat temperature] is not generated.

Check of the circulating fluid outlet pressure

4. Press the [SEL] key once.

The circulating fluid outlet pressure is displayed on the digital display.



The pressure of the circulating fluid outlet from which the fluid is sent to the customer's device is displayed.



- ☐ Circulating fluid outlet pressure P1. is 0.05 [MPa] or higher, and AL06 [High circulating fluid discharge pressure] is not generated.

Check of the pressure of the higher pressure side of the refrigerant circuit

5. Press the [SEL] key once.

The pressure of the higher pressure side of the refrigerant circuit is displayed on the digital display.



Displays the pressure of the higher pressure side of the refrigerant circuit.



- ☐ Pressure of the higher pressure side of the refrigerant circuit Ph. during operation is 0.1 [MPa] or more, and AL13 [High compressor discharge pressure] is not generated.
In addition, the calculated temperature ^{Note 2)} of the pressure of the higher pressure side of the refrigerant circuit Ph. during stoppage ^{Note 1)} exceeds the ambient temperature.


Note 1) Leave the compressor off for 24 hours to sufficiently cool it down to the ambient temperature.

Note 2) Refer to "Calculated temperature of the pressure of the higher pressure side of the refrigerant circuit Ph. (the pressure of the lower pressure side of the refrigerant circuit PL.)" on page 126 for details.


Refrigerant leakage

1. If the calculated temperature of the pressure of the higher pressure side of the refrigerant circuit Ph. during stoppage is equal to or lower than the ambient temperature, the refrigerant may be leaking. Have a specialist (an engineer possessing a Class 1 or Class 2 Refrigerant Freon Handling License) check the details.

[HRS012/018/024/030]



[HRS050/060]




Calculated temperature of the pressure of the higher pressure side of the refrigerant circuit Ph.
(the pressure of the lower pressure side of the refrigerant circuit PL.)

Check of the pressure of the lower pressure side of the refrigerant circuit

6. Press the [SEL] key once.

The pressure of the lower pressure side of the refrigerant circuit is displayed on the digital display.



Displays the pressure of the lower pressure side of the refrigerant circuit.

CHECK!

- ☐ Pressure of the lower pressure side of the refrigerant circuit PL. during operation is at least 0.2 ^{Note 3)} or 0.4 ^{Note 4)} [MPa], and AL16 [Refrigerant circuit pressure (lower pressure side) rise]] is not generated.

Note 3) Refer to “Calculated temperature of the pressure of the higher pressure side of the refrigerant circuit Ph. (the pressure of the lower pressure side of the refrigerant circuit PL.)” for the HRS012/018/024/030 on page 126 for details.

Note 4) Refer to “Calculated temperature of the pressure of the higher pressure side of the refrigerant circuit Ph. (the pressure of the lower pressure side of the refrigerant circuit PL.)” for the HRS050/060 on page 126 for details.

Check of the electric resistivity/conductivity

7. Press the [SEL] key once.

The electric resistivity/conductivity is displayed on the digital display.



- * This function is available for customers who have purchased the electric resistivity/conductivity sensor set which is a separately sold accessory. Refer to the Operation Manual attached to these optional accessories for details.

CHECK!

- ☐ Electric resistivity dl. is within the control range of 0.2 to 4.5 [MΩ] or 5 to 45 [μS], and neither AL34 [Electric resistivity/conductivity rise] nor AL35 [Electric resistivity/conductivity drop] are generated.

Check of the accumulated operation time of the pump

8. Press the [SEL] key once.

The accumulated operation time of the pump is displayed on the digital display.



Displays the accumulated operation time of the pump. Refer to the table below for the display.

List of time display

Cumulative time	Indicated value
0h to 999h	0 h to 9 9 9 h
1,000h to 99,999h	1 h h to 9 9 h h
100,000h	Return to 0 h

[For products other than the HRS012/018/024/030-T options (magnetic pump mounted)]

AL28 Pump maintenance alarm is generated when the accumulated operation time of the pump reaches 20,000 hours (2 0 h h) or more.

[For the HRS012/018/024/030-T options (high-pressure pump) and the HRS050/060 standard products]

AL28 Pump maintenance alarm is generated when the accumulated operation time of the pump reaches 8,000 hours (8 h h) or more.



- ☐ Accumulated operating time of the pump PunP has not reached 20,000 [h] ^{Note 5)} or 8,000 [h] ^{Note 6)}, and AL28 [Maintenance of pump] is not generated.

Note 5) For products other than the HRS012/018/024/030-T options (magnetic pump mounted)

Note 6) For the HRS012/018/024/030-T options (high-pressure pump) and the HRS050/060 standard products

Check of the accumulated operation time of the fan motor

9. Press the [SEL] key once.

The accumulated operation time of the fan motor is displayed on the digital display.



Displays the accumulated operation time of the fan motor. "List of time display" above for the display.

AL29 Fan motor maintenance alarm is generated when the accumulated operation time of the fan motor reaches 20,000 hours (2 0 h h) or more. For details, refer to Chapter 7 Alarm indication and trouble shooting.

Water-cooled refrigerated type does not have the fan motor. The accumulated time of the digital display shows " - - - - ".

Also, AL29 fan motor maintenance alarm is not generated.



- ☐ Accumulated operation time of the fan motor FRn.n has not reached 20,000 [h] ^{Note 7)}, and AL29 [Maintenance of fan motor] is not generated.

Note 7) For air-cooled type only

Check of the accumulated operation time of the compressor

10. Press the [SEL] key once.

The accumulated operation time of the compressor is displayed on the digital display.



Displays the accumulated operation time of the compressor. For the display, refer to “List of time display” on page 128.

AL30 Compressor maintenance alarm is generated when the accumulated operation time of the compressor reaches 50,000 hours (50 000 h) or more. For details, refer to page 137.

CHECK!

- ☐ Accumulated operation time of the fan compressor rEF. has not reached 50,000 [h], and AL30 [Maintenance of compressor] is not generated.

Check of the accumulated operation time

11. Press the [SEL] key once.

The accumulated operation time is displayed on the digital display.



Displays the accumulated operation time. For the display, refer to “List of time display” on page 128.

CHECK!

- ☐ The accumulated operation time has not reached 6,000 to 8,000 [h] ^{Note 8)} (Inspection time of mechanical seal), 20,000 [h] (Inspection time of pump and fan motor) ^{Note 9)}, or 50,000 [h] (Inspection time of compressor).

Note 8) For the HRS012/018/024/030-T options and the HRS050/060 standard products (high-pressure pump)

Note 9) For air-cooled type only

Completing the Inspection Monitor Screen Check Sheet (Question sheet)

12. Put a “O” or “x” in the check boxes of items 1 to 11 of the “Inspection Monitor Screen Check Sheet” on page 130. When inquiring about a problem occurring at a customer’s premises, please complete this check sheet to report the problem accurately, and contact your local sales representative or a service company.

Caution

If the “Inspection Monitor Screen Check Sheet” (question sheet) is not available, the service company will conduct their own checks instead.

In such cases, a certain period of time will be required before we can start repairing.

Inspection Monitor Screen Check Sheet (Question Sheet)

Please enter an "○" for Yes and "×" for No.

Be sure to check the items with a "*" for trouble during a trial run.

- ☐ * Circulating fluid outlet temperature t1. is 1 [°C] or higher, AL02 [High circulating fluid discharge temperature] is not generated, and the temperature is controlled to the preset temperature (= SV + Offset).
- ☐ * Circulating fluid inlet temperature t2. is equal to or higher than t1. [°C], AL05 [High circulating fluid return temperature (60°C)] is not generated, and there is an allowance for cooling capacity relative to the heat generation of the item to be cooled.
- ☐ The compressor inlet temperature t3. is -15 to 60 [°C], and AL12 [Low superheat temperature] is not generated.
- ☐ Circulating fluid outlet pressure P1. is 0.05 [MPa] or higher, and AL06 [High circulating fluid discharge pressure] is not generated.
- ☐ Pressure of the higher pressure side of the refrigerant circuit Ph. during operation is 0.1 [MPa] or more, and AL13 [High compressor discharge pressure] is not generated. In addition, the calculated temperature ^{Note 2)} of the pressure of the higher pressure side of the refrigerant circuit Ph. during stoppage ^{Note 1)} exceeds the ambient temperature.
- ☐ Pressure of the lower pressure side of the refrigerant circuit PL. during operation is at least 0.2 ^{Note 3)} or 0.4 ^{Note 4)} [MPa], and AL16 [Refrigerant circuit pressure (lower pressure side) rise] is not generated.
- ☐ Electric resistivity dl. is within the control range of 0.2 to 4.5 [MΩ] or 5 to 45 [μS], and neither AL34 [Electric resistivity/conductivity rise] nor AL35 [Electric resistivity/conductivity drop] are generated.
- ☐ Accumulated operating time of the pump PunP has not reached 20,000 [h] ^{Note 5)} or 8,000 [h] ^{Note 6)}, and AL28 [Maintenance of pump] is not generated.
- ☐ Accumulated operation time of the fan motor FRn.n has not reached 20,000 [h] ^{Note 7)}, and AL29 [Maintenance of fan motor] is not generated.
- ☐ Accumulated operation time of the fan compressor rEF. has not reached 50,000 [h], and AL30 [Maintenance of compressor] is not generated.
- ☐ The accumulated operation time has not reached 6,000 to 8,000 [h] ^{Note 8)} (Inspection time of mechanical seal), 20,000 [h] (Inspection time of pump and fan motor) ^{Note 9)}, or 50,000 [h] (Inspection time of compressor).

Other (Must be filled in)

Specifically describe the details of the problem and emergency measures taken.

■ Alarms: Causes and Remedies (HRS012/018/024/030/050/060)	p. 133
■ Troubleshooting of Alarms	p. 138
■ Troubleshooting of Errors without Alarm Generation	p. 242
■ Replacement Parts Chart	p. 249
■ Parts Replacement Procedure	p. 250
■ Check After Work	p. 259
■ Replacement Procedure	p. 260

■ Alarms: Causes and Remedies (HRS012/018/024/030/050/060)

When you've received requests from customers for product servicing due to the frequent generation of the same alarm or multiple alarms, refer to 1. Alarm Troubleshooting below and Troubleshooting on pages 138 to 248 in order to remedy the problem.

1. Alarm Troubleshooting

After taking note of all the alarm codes that are being generated, refer to Table 4-1 and follow the instructions to remedy each specific problem.

Table 4-1

Conditions	Remedy for specific problem
① No screen display or alarm, but chiller won't start up	p. 133
② Chiller starts up, but won't cool (Overload)	p. 133, 134
③ Won't warm up (Low load, Cooling load)	p. 135
④ Circulating fluid, facility water, automatic water fill, etc., won't flow	p. 136
⑤ Circulating fluid/Refrigerant leakage	p. 136
⑥ Recommended replacement period of main functioning parts	p. 137
⑦ Sensor disconnection and other part errors	p. 137
⑧ Purity levels when using deionized water as the circulating fluid	p. 137

① No screen display or alarm, but chiller won't start up

Phenomenon		Cause	Remedy
Alarm code	Description		
— (Note)	The operation panel displays nothing even the power supply switch is turned ON.	Power source not supplying power Poor display board connection Power board error Display board error	Supply the correct power. Securely insert the connector [CN1]. Replace the power board. Replace the display board.
—	Impossible to operate with the "RUN/STOP" key on the operation panel	Communication settings are set. ((REMOTE) light is ON.) Display board error	Set to local mode. Replace the display board.
—	Lights on the operation panel or display(s) on the digital display does not show anything.	Display board error	Replace the display board.
—	The alarm buzzer does not sound.	Is "AS.01" in the alarm setting menu "OFF"? Display board error	Turn "AS.01" ON. Replace the display board.

Note) Problem with alarm symbol not being displayed

② Chiller starts up, but won't cool (Overload)

Phenomenon		Cause	Remedy
Alarm code	Description		
AL02	High circulating fluid discharge temp.	Temperature sensor error (with simultaneous AL22 generation)	Replace the temperature sensor.
		Ambient temperature exceeds the specification range (High ambient temperature)	Reduce the ambient temperature by ventilation, air conditioning, etc.
		External load exceeds the specification range (Object to be cooled is generating too much heat for the chiller to handle)	Reduce the amount of heat generated by the object to be cooled, or install a larger chiller.
		Insufficient ventilation space	Secure sufficient ventilation space.
		[For air-cooled type] Dirty dustproof filter	Clean or replace the dustproof filter.
			Replace facility water.
		[For water-cooled type] Dirty facility water	Clean the facility water circuit.
			Replace the water-cooled condenser.
			Replace the water regulating valve.
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	Replace the main board.
		Main board error	
		Flow rate of the circulating fluid is less than 5 L/min.	Install bypass piping and open the valve. Replace the pump.
		Dirty circulating fluid	Replace circulating fluid.
			Clean the circulating fluid circuit.
		Refrigerant leakage	Repair or replace the part of the refrigerant circuit where leakage is present. Please contact your nearest agency.
		Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
		Pressure sensor (for high pressure) error	Replace the pressure sensor (for high pressure). Please contact your nearest agency.
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure). Please contact your nearest agency.
		Other	Please contact an SMC's sales distributor.

② Chiller starts up, but won't cool (No refrigeration) (Continued)

Phenomenon		Cause	Remedy
Alarm code	Description		
AL03	Circulating fluid discharge temp. rise	Problems occur immediately after operation start or stop	Refer to "Setting of temperature alarm monitoring method and alarm generation timing" in the operation manual and review.
		Heat load fluctuation	Same as above
		Problem with the external piping (system)	Remedy the problem with the external piping (system).
		Other (Same as AL02)	Remedy AL02.
AL05	High circulating fluid return temp.	Temperature sensor error (with simultaneous AL23 generation)	Replace the temperature sensor.
		External load exceeds the specification range (Object to be cooled is generating too much heat for the chiller to handle)	Reduce the amount of heat generated by the object to be cooled, or install a larger chiller.
		Problems occur immediately after operation start or stop	Use bypass piping, etc., to reduce the circulating fluid return temperature to 60°C or below.
		Heat load fluctuation	Remedy the problem with the external piping (system).
		Problem with the external piping (system)	Replace the main board.
		Main board error	Check the troubleshooting section for the remedy for the alarm being generated.
		Other alarms are being generated.	Remedy AL02.
		The circulating fluid discharge temperature is above 45°C.	Please contact an SMC's sales distributor.
		Other	Replace the thermistor (T1).
		Compressor intake temp. sensor (T1) failure (with simultaneous AL24 generation)	Replace the temperature sensor.
AL10	High compressor intake temp.	Temperature sensor error (with simultaneous AL05 generation)	Remedy AL02.
		The circulating fluid discharge temperature is above 45°C.	Reduce the amount of heat generated by the object to be cooled, or install a larger chiller.
		External load exceeds the specification range (Object to be cooled is generating too much heat for the chiller to handle)	Remedy the problem with the external piping (system).
		Problem with the external piping (system)	Replace the pump.
		Flow rate of the circulating fluid is less than 5 L/min.	Install a bypass piping.
		Main board error	Replace the main board.
		Electronic expansion valve error	Replace the electronic expansion valve.
			Please contact your nearest agency.
		Ambient temperature exceeds the specification range (High ambient temperature)	Reduce the ambient temperature by ventilation, air conditioning, etc.
		External load exceeds the specification range (Object to be cooled is generating too much heat for the chiller to handle)	Reduce the amount of heat generated by the object to be cooled, or install a larger chiller.
AL13	High compressor discharge pressure	Insufficient ventilation space	Secure sufficient ventilation space.
		[For air-cooled type] Dirty dustproof filter	Clean or replace the dustproof filter.
			Replace facility water.
		[For water-cooled type] Dirty facility water	Clean the facility water circuit.
			Replace the water-cooled condenser.
			Replace the water regulating valve.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Fan motor error	Replace the fan motor.
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	
		Main board error	Replace the main board.
		Power board error	Replace the power board.
			Replace the pump.
		Flow rate of the circulating fluid is less than 5 L/min.	Install a bypass piping.
			Replace the pressure sensor (for high pressure).
		Pressure sensor (for high pressure) error	Please contact your nearest agency.
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure).
AL16	Refrigerant circuit pressure (low pressure side) rise	Electronic expansion valve error	Please contact your nearest agency.
			Replace the electronic expansion valve.
			Please contact your nearest agency.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Problem in external environment	Improve the external environment (operating environment).
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	
AL18	Compressor overload	Main board error	Replace the main board.
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure).
			Please contact your nearest agency.
		Electronic expansion valve error	Replace the electronic expansion valve.
			Please contact your nearest agency.
		Other	Please contact an SMC's sales distributor.
AL18	Compressor overload	Power supply failure	Use an appropriate power supply.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Ambient temperature exceeds the specification range (High ambient temperature)	Reduce the ambient temperature by ventilation, air conditioning, etc.
		External load exceeds the specification range (Object to be cooled is generating too much heat for the chiller to handle)	Reduce the amount of heat generated by the object to be cooled, or install a larger chiller.
		Insufficient ventilation space	Secure sufficient ventilation space.
		[For air-cooled type] Dirty dustproof filter	Clean or replace the dustproof filter.
		[For water-cooled type] Dirty facility water	Supply clean facility water.
		[For water-cooled type] Facility water does not flow.	Please contact an SMC's sales distributor.
			Replace the water-cooled condenser.
			Replace the water regulating valve.
		Main board error	Replace the main board.
		Power board error	Replace the power board.
AL18	Compressor overload	Compressor error	Replace the compressor.
		Other	Please contact an SMC's sales distributor.

③ Won't warm up (Low load, Cooling load)

Phenomenon		Cause	Remedy
Alarm code	Description		
AL04	Circulating fluid discharge temp. drop	Temperature sensor error (with simultaneous AL22 generation)	Replace the temperature sensor.
		Problems occur immediately after operation start or stop	Refer to "Setting of temperature alarm monitoring method and alarm generation timing" in the operation manual and review.
		Heat load fluctuation	Same as above
		Cooling load exceeds the heating capacity (Heat generated by the object to be cooled is a negative cooling load)	Use within the heating capacity or refrain from using exclusively for heating.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Main board error	Replace the main board.
		Flow rate of the circulating fluid is less than 5 L/min.	Replace the pump. Install a bypass piping.
		Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
		Other	Please contact an SMC's sales distributor.
AL11	Low compressor intake temp.	Compressor intake temp. sensor (T1) failure (with simultaneous AL24 generation)	Replace the thermistor (T1).
		Temperature sensor error (with simultaneous AL04 generation)	Replace the temperature sensor.
		Cooling load exceeds the heating capacity (Heat generated by the object to be cooled is a negative cooling load)	Use within the heating capacity or refrain from using exclusively for heating.
		Flow rate of the circulating fluid is less than 5 L/min.	Replace the pump. Install a bypass piping.
		Main board error	Replace the main board.
		Dirty circulating fluid	Replace circulating fluid. Clean the circulating fluid circuit.
			Replace the heat exchanger (evaporator). Please contact your nearest agency.
		Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
		Other	Please contact an SMC's sales distributor.
AL12	Low super heat temperature	Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Flow rate of the circulating fluid is less than 5 L/min.	Replace the pump. Install a bypass piping.
		Dirty circulating fluid	Replace circulating fluid. Clean the circulating fluid circuit.
			Replace the heat exchanger (evaporator). Please contact your nearest agency.
		Compressor intake temp. sensor (T1) failure (with simultaneous AL24 generation)	Replace the thermistor (T1).
		Pressure sensor (for high pressure) error	Replace the pressure sensor (for high pressure). Please contact your nearest agency.
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure). Please contact your nearest agency.
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	Replace the main board.
		Main board error	
AL17	Refrigerant circuit pressure (low pressure side) drop	Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Problem in external environment	Improve the external environment (operating environment).
		Flow rate of the circulating fluid is less than 5 L/min.	Replace the pump. Install a bypass piping.
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	Replace the main board.
		Main board error	
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure). Please contact your nearest agency.
		Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
		Other	Please contact an SMC's sales distributor.

④ Circulating fluid, facility water, automatic water fill, etc., won't flow

Phenomenon		Cause	Remedy
Alarm code	Description		
AL06	High circulating fluid discharge pressure	Pressure sensor (for circulating fluid) error (with simultaneous AL25 generation)	Replace the pressure sensor (for circulating fluid).
		Problem with the external piping (system)	Remedy the problem with the external piping (system). Install a bypass piping.
		Clogging in the heat exchanger	Replace the heat exchanger (evaporator). Please contact your nearest agency.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Main board error	Replace the main board.
AL07	Abnormal pump operation	Pressure sensor (for circulating fluid) error (with simultaneous AL25 generation)	Replace the pressure sensor (for circulating fluid).
		Ethylene glycol is too highly concentrated.	Replace with a 15% ethylene glycol aqueous solution.
		Power voltage error	Use an appropriate power supply.
		Pump error	Replace the pump.
		Main board error	Replace the main board.
AL08	Circulating fluid discharge pressure rise	Power board error	Replace the power board.
		AL06 is simultaneously being generated.	Check the troubleshooting section for the remedy for the alarm being generated (AL06).
		Pressure sensor (for circulating fluid) error (with simultaneous AL25 generation)	Replace the pressure sensor (for circulating fluid).
		Problem with the external piping (system)	Remedy the problem with the external piping (system). Install a bypass piping.
		This alarm set value is close to the external piping resistance.	Review the alarm set value.
		Clogging in the heat exchanger	Replace the heat exchanger (evaporator). Please contact your nearest agency.
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
AL09	Circulating fluid discharge pressure drop	Main board error	Replace the main board.
		Pressure sensor (for circulating fluid) error (with simultaneous AL25 generation)	Replace the pressure sensor (for circulating fluid).
		Pump error (with simultaneous AL07 generation)	Replace the pump.
(AL17)	(Refrigerant circuit pressure (low pressure side) drop)	Problem with the external piping (system)	Remedy the problem with the external piping (system).
		Other alarms are being generated.	Check the troubleshooting section for the remedy for the alarm being generated.
		Problem in external environment	Improve the external environment (operating environment).
		Flow rate of the circulating fluid is less than 5 L/min.	Replace the pump. Install a bypass piping.
		Power not being supplied to the pressure sensor (for high pressure, for low pressure)	Replace the main board.
		Main board error	Replace the main board.
		Pressure sensor (for low pressure) error	Replace the pressure sensor (for low pressure). Please contact your nearest agency.
		Electronic expansion valve error	Replace the electronic expansion valve. Please contact your nearest agency.
—	[For water-cooled type] Facility water does not flow.	Other	Please contact an SMC's sales distributor.
		Doesn't flow when the thermo-chiller is stopped	Start the thermo-chiller or install bypass piping for the facility water circuit.
—	[For option J] Automatic water fill does not operate.	Power is not being supplied.	Supply power.
		The tank fluid level is above "L."	Running normally, even if water is not being supplied. Start supply of water at "L" or below.
		Main board error	Replace the main board.
		Clogged automatic water fill opening	Replace the main board.
		Solenoid valve (used for automatic water fill) error	Replace the solenoid valve for automatic water-fill.

⑤ Circulating fluid/Refrigerant leakage

Phenomenon		Cause	Remedy
Alarm code	Description		
AL01	Low level in tank	Declining liquid level of the level gauge	Supplement circulating fluid.
		Chiller internal circulating fluid leakage	Repair leakage points.
		External piping leakage	Repair external piping.
		Mechanical seal leakage	Replace the mechanical seal or pump.
		Poor level switch connection	Securely insert the main board connector [CN3].
		Level switch error	Replace the level switch.
		Main board error	Replace the main board.
AL15	Refrigerant circuit pressure (high pressure side) drop	Pressure sensor (for high pressure) error (with simultaneous AL26 generation)	Replace the pressure sensor (for high pressure). Please contact your nearest agency.
		Refrigerant leakage	Repair or replace the part of the refrigerant circuit where leakage is present. Please contact your nearest agency.
		Main board error	Replace the main board.
AL33	Water leakage	[When used with the HRS-WL001 accessory (Sold separately)] Poor water leakage sensor connection	Securely insert the water leakage sensor connector.
		Liquid is adhered to the bottom of the water leakage sensor.	Repair water leakage points.
		Water leakage sensor error	Replace the water leakage sensor.

⑥ Recommended replacement period of main functioning parts

Phenomenon		Cause	Remedy
Alarm code	Description		
AL28	Maintenance of pump	Recommended circulating fluid pump replacement period	Replace the circulating fluid pump.
AL29	Maintenance of fan motor	[For air-cooled type] Recommended fan motor replacement period	Replace the fan motor.
AL30	Maintenance of compressor	Recommended compressor replacement period	Replace the compressor.
— (Note)	[For -T (High pressure pump), HRS050/060] The accumulated operating time (dru.) has reached between 6,000 and 8,000 hours.	Recommended mechanical seal replacement period	Replace the mechanical seal.

Note) Problem with alarm symbol not being displayed

⑦ Sensor disconnection and other part errors

Phenomenon		Cause	Remedy
Alarm code	Description		
AL19	Communication error	Change the value set at the time of shipment from the factory. Main board error Communication board error	Check Chapter 6 Communication alarm function in the operation manual's communication function volume. Replace the main board. Replace the communication board.
AL20	Memory error	Main board error Other	Replace the main board. Please contact an SMC's sales distributor.
AL21	DC line fuse cut	Fuse meltdown due to short-circuit protection function	Replace the fuse.
AL22	Circulating fluid discharge temp. sensor failure	Poor circulating fluid discharge temp. sensor (P1) connection Main board error Temperature sensor (PT1) error	Securely insert the main board connector [PT1]. Replace the main board. Replace the temperature sensor (PT1).
AL23	Circulating fluid return temp. sensor failure	Poor circulating fluid return temp. sensor (PT2) connection Main board error Temperature sensor (PT2) error	Securely insert the main board connector [PT2]. Replace the main board. Replace the temperature sensor (PT2).
AL24	Compressor intake temp. sensor failure	Poor compressor intake temp. sensor (T1) connection Main board error Thermistor (T1) error	Securely insert pins 7 and 19 of the main board connector [CN4]. Replace the main board. Replace the thermistor (T1).
AL25	Circulating fluid discharge pressure sensor failure	Poor circulating fluid discharge pressure sensor (P1) connection Power is not being supplied to the pressure sensor (P1). Main board error Pressure sensor P1 (for circulating fluid) error	Securely insert pins 8, 20, and 21 of the main board connector [CN4]. Replace the main board. Replace the pressure sensor P1 (for circulating fluid).
AL26	Compressor discharge pressure sensor failure	Poor pressure sensor (for high pressure) connection Power is not being supplied to the pressure sensor (for high pressure). Main board error Pressure sensor (for high pressure) error	Securely insert pins 10, 11, and 22 of the main board connector [CN4]. Replace the main board. Replace the pressure sensor (for high pressure).
AL27	Compressor intake pressure sensor failure	Poor pressure sensor (for low pressure) connection Power is not being supplied to the pressure sensor (for low pressure). Main board error Pressure sensor (for low pressure) error	Securely insert pins 12, 23, and 24 of the main board connector [CN4]. Replace the main board. Replace the pressure sensor (for low pressure).
AL31	Contact input 1 signal detection	Contact input 1 signal was input.	Check the sensor connected to contact input 1 signal.
AL32	Contact input 2 signal detection	Contact input 2 signal was input.	Check the sensor connected to contact input 2 signal.

⑧ Purity levels when using deionized water as the circulating fluid

Phenomenon		Cause	Remedy
Alarm code	Description		
AL34	Electric resistivity/conductivity rise	[When used with the HRS-DI accessory (Sold separately)] The purity level of the circulating fluid is above the set value. Electric resistivity sensor or electric conductivity sensor error	Replace the DI filter set (HRS-DP). Replace the electric resistivity sensor or electric conductivity sensor
AL35	Electric resistivity/conductivity drop	[When used with the HRS-DI accessory (Sold separately)] The purity level of the circulating fluid is below the set value. Electric resistivity sensor or electric conductivity sensor error	Replace the DI filter set (HRS-DP). Replace the electric resistivity sensor or electric conductivity sensor
AL36	Electric resistivity/conductivity sensor error	[When used with the HRS-DI accessory (Sold separately)] The purity level of the circulating fluid is below the set value. Electric resistivity sensor or electric conductivity sensor error	Replace the DI filter set (HRS-DP). Replace the electric resistivity sensor or electric conductivity sensor

Troubleshooting of alarms


AL01: Low level in tank

<Detection method> The level switch in the tank operates to detect the alarm.



4

Maintenance



1. Check the connection

Securely connect the connectors to [CN3] of the main board.
Pins of [LS1] must be securely inserted to the connectors. There must not be any incorrect insertion of the pins and defective crimping.





Fig. 4-1 Level switch connection check

2. Check conditions of the float and contact point

Remove the connectors [CN3]. Move the float of the level switch inside the tank.

Check that it is electrically conducted between the pin numbers 2 and 13 in the state shown below:

- When the float is in the lower position: Not electrically conducted between the contact points 2 and 13.
- When the float is in the upper position: Electrically conducted between the contact points 2 and 13.






Fig. 4-2 Operation of the level switch

AL02: High circulating fluid discharge temp. [For air-cooled type]

<Detection method> This alarm goes off when the temperature sensor for the circulating fluid (for discharge) detects 60°C or more.





1. Ambient temperature is out of the specification range.

Ambient temperature is higher than 40°C (45°C for Option G “High ambient temperature specification”).

2. External load is out of the specification range.

Cooling capacity varies depending on the ambient temperature, set circulating fluid temperature, and power supply frequency. Please refer to the “Cooling capacity” graph shown on pages 19 and 20.

3. Enough ventilation space has not been secured.

- The Thermo-Chiller is installed too close to a wall.
- There are other equipment close to the Thermo-Chiller.
- Hot ventilated air from other equipment enters the Thermo-Chiller.
- The Thermo-Chiller is operating in an enclosed space.
(e.g. In a room without ventilation or air conditioner)

4. The dustproof filter is too dusty.

Dustproof filter on the front side of the Thermo-Chiller or the fin of the air-cooled condenser inside is contaminated.




Fig. 4-3 An air-cooled condenser and a dustproof filter

5. Check the circulating fluid temperature sensor (PT1).

Two circulating fluid temperature sensors are used; one is for the outlet port (PT1) and one for the return port (PT2). Compare the temperatures sensed by the temperature sensors under the conditions shown below to judge if the values provided by the temperature sensors are correct or not:

- (1) Connect a shorter pipe directly from the circulating fluid outlet port to the return port of the Thermo-Chiller with a valve mounted to the outlet port. (Mount a valve to the outlet port to make it possible to adjust the flow rate roughly.)
- (2) Operate the Thermo-Chiller and stabilize the temperature.
- (3) Check the temperature shown for “t1: Circulating fluid outlet temperature” and “t2: Circulating fluid return temperature” in the “Check Monitor Menu”.

If the temperature is within the range of $t1 = t2 \pm 2^\circ\text{C}$, operation of the circulating fluid temperature sensor (PT1) is normal.

6. Check the circulating fluid temperature sensor (PT1) after it is replaced.

Replace the circulating fluid temperature sensor (PT1). (See “Replacement of temperature sensor (PT1)” on page 260.) After replacing, check that all the check items shown in “5. Check the circulating fluid temperature sensor (PT1)” are correctly followed.

7. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

8. Install a flow meter, and check the flow rate of the circulating fluid.

Install a flow meter. Refer to the “Pump capacity” graph on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

9. Circulating fluid is contaminated.

Contamination contained in the circulating fluid adheres to the heat exchanger (evaporator), and it decreases the heat exchanger performance.

Open the cap of the tank, and check visually the contamination (e.g. deformation, foreign matter, abnormal smell) of the circulating fluid inside the tank.

When the visual check finds contamination in the circulating fluid, check the influence of the contamination to the heat exchanger by following the instructions shown below.

- (1) Connect the circulating fluid outlet directly to the fluid return port with a valve mounted to the outlet port with a shorter piping to make it possible to operate the system at flow rate of circulating fluid at 7 L/min.

(For Option T, adjust the flow rate so that the circulating fluid discharge pressure will be approximately 0.4 MPa.)

- (2) Set the circulating fluid temperature to 20°C, and operate the Thermo-Chiller.
- (3) Check the temperature shown for “t2: Circulating fluid return temperature” and “t3: Compressor inlet temperature” in the “Check Monitor Menu”.
- (4) Displayed temperature will be as shown below in accordance with level of contamination of the heat exchanger.

<With no contamination with the heat exchanger>

“t3: Suction temperature of the compressor” ≥ “t2: Circulating fluid return temperature” –5°C

<With contamination with the heat exchanger>

“t3: Suction temperature of the compressor” < “t2: Circulating fluid return temperature” –5°C

e.g. (Normal) t2: 21.5, t3: 23.8, (Abnormal) t2: 21.5, t3: 15.5

10. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and one for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for “Ph: Refrigerant circuit pressure on the high pressure side” and “PL: Refrigerant circuit pressure on the low pressure side” in the “Check Monitor Menu”.
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

11. Check for refrigerant leakage.

Refrigerant leakage reduces the cooling capacity. To check for refrigerant leakage, it is necessary to make the refrigerant circuit temperature same as the ambient temperature. Stop the Thermo-Chiller operation, and leave it not operating for 24 hours.

Take the following instructions to check for refrigerant leakage after leaving not operating.

- (1) Measure the ambient temperature (room temperature).
- (2) Check the pressure shown for “Ph: Refrigerant circuit pressure on the high pressure side” in the “Check Monitor Menu” of the Thermo-Chiller.
- (3) If the measured point is lower than the values shown in the graph in “Fig. 4-4: Ambient temperature and refrigerant circuit pressure”, it means there is refrigerant leakage caused.




Fig. 4-4 Ambient temperature and refrigerant circuit pressure

12. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

13. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for high pressure)>

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the "CN4" connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-5 Check of input to the refrigerant circuit pressure sensor

14. Check the display of the refrigerant circuit pressure sensor (for high pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “Ph: Refrigerant circuit pressure on the high pressure side” value is within the range (the shaded part) in Fig. 4-6. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-6 Ambient temperature and refrigerant circuit pressure

15. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-6. If the cross point is within the range, it means that the pressure sensor is operating correctly.

16. Check the analogue output of the refrigerant circuit pressure sensor (for high pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 11 and the pin number 10 is in the same relationship shown in Fig. 4-8. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-7 Check of the refrigerant circuit pressure sensor (for high pressure) output




Fig. 4-8 Refrigerant circuit pressure sensor (for high pressure) analogue output

17. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-10. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-9 Check of the refrigerant circuit pressure sensor (for low pressure) output






Fig. 4-10 Refrigerant circuit pressure sensor (for low pressure) analogue output

AL02: High circulating fluid discharge temp. [For water-cooled type]

<Detection method> This alarm goes off when the temperature sensor for the circulating fluid (for discharge) detects 60°C or more.





1. Check the facility water system.

Check that the facility water system capability satisfies the required facility water flow rate that is specified on page 23.

2. Facility water is contaminated.

Check that the facility water is clean (without any foreign matter or discolouration).

3. Incorrect flow rate of the facility water.

Install a flow meter and check that the facility water system satisfies the required facility water flow rate that is specified on page 23.

* Facility water does not flow when the Thermo-Chiller is not operating. Check the facility water flow rate while the external load is being applied to the Thermo-Chiller or the circulating fluid temperature is being decreased.

4. Water-cooled condenser is contaminated.

Contamination given to the water-cooled condenser reduces cooling capacity. Check the water-cooled condenser for contamination by following the instructions shown below:

- (1) Remove the pipings connected to the inlet and outlet of the facility water.
- (2) Remove the upper panel and the right panel.
- (3) Remove the plug of the water-cooled condenser, and check inside the water-cooled condenser for contamination.




Fig. 4-11 The port for visual check for contamination inside the water-cooled condenser

5. External load is out of the specification range.

Cooling capacity varies depending on the facility water temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the "Cooling capacity" graph on pages 19 and 20.

6. Check the circulating fluid temperature sensor (PT1).

Two circulating fluid temperature sensors are used; one is for the outlet port (PT1) and one for the return port (PT2). Compare the temperatures sensed by the temperature sensors under the conditions shown below to judge if the values provided by the temperature sensors are correct or not:

- (1) Connect a shorter pipe directly from the circulating fluid outlet port to the return port of the Thermo-Chiller with a valve mounted to the outlet port. (Mount a valve to the outlet port to make it possible to adjust the flow rate roughly.)
- (2) Operate the Thermo-Chiller and stabilize the temperature.
- (3) Check the temperature shown for “t1: Circulating fluid outlet temperature” and “t2: Circulating fluid return temperature” in the “Check Monitor Menu”.

If the temperature is within the range of $t1 = t2 \pm 2^{\circ}\text{C}$, operation of the circulating fluid temperature sensor (PT1) is normal.

7. Check the circulating fluid temperature sensor (PT1) after it is replaced.

Replace the circulating fluid temperature sensor (PT1). (See “Replacement of the temperature sensor (PT1)” on page 260.) After replacing, check that all the check items shown in “6. Check the circulating fluid temperature sensor (PT1)” are correctly followed.

8. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

9. Check the pump performance.

Install a flow meter. Refer to the “Pump capacity” graph” on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

10. Circulating fluid is contaminated.

Contamination contained in the circulating fluid adheres to the heat exchanger (evaporator), and it decreases the heat exchanger performance.

Open the cap of the tank, and check visually the contamination (e.g. deformation, foreign matter, abnormal smell) of the circulating fluid inside the tank.

When the visual checks find contamination in the circulating fluid, check the influence of the contamination to the heat exchanger following the instructions shown below.

- (1) Connect the circulating fluid outlet directly to the fluid return port with a valve mounted to the outlet port with a shorter piping to make it possible to operate the system at flow rate of circulating fluid at 7 L/min. (For Option T, adjust the flow rate so that the circulating fluid discharge pressure will be approximately 0.4 MPa.)
- (2) Set the circulating fluid temperature to 20°C , and operate the Thermo-Chiller.
- (3) Check the temperature shown for “t2: Circulating fluid return temperature” and “t3: Compressor inlet temperature” in the “Check Monitor Menu”.
- (4) Displayed temperature will be as shown below in accordance with level of contamination of the heat exchanger.

<With no contamination with the heat exchanger>

“t3: Suction temperature of the compressor” \geq “t2: Circulating fluid return temperature” -5°C

<With contamination with the heat exchanger>

“t3: Suction temperature of the compressor” $<$ “t2: Circulating fluid return temperature” -5°C

e.g. (Normal) t2: 21.5 , t3: 23.8 , (Abnormal) t2: 21.5 , t3: 15.5

11. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for “Ph: Refrigerant circuit pressure on the high pressure side” and “PL: Refrigerant circuit pressure on the low pressure side” in the “Check Monitor Menu”.
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

12. Check for refrigerant leakage.

Refrigerant leakage reduces the cooling capacity. To check for refrigerant leakage, it is necessary to make the refrigerant circuit temperature same as the ambient temperature. Remove the facility water piping, stop the Thermo-Chiller operation, and leave it not operating for 24 hours.

Take the following instructions to check for refrigerant leakage after leaving not operating.

- (1) Measure the ambient temperature (room temperature).
- (2) Check the pressure shown for “Ph: Refrigerant circuit pressure on the high pressure side” in the “Check Monitor Menu” of the Thermo-Chiller.
- (3) If the measured point is lower than the values shown in the graph in “Fig. 4-12: Ambient temperature and refrigerant circuit pressure”, it means there is refrigerant leakage caused.




Fig. 4-12 Ambient temperature and refrigerant circuit pressure

13. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch of the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

14. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for high pressure)>

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the "CN4" connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-13 Check of input to the refrigerant circuit pressure sensor

15. Check the display of the refrigerant circuit pressure sensor (for high pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “Ph: Refrigerant circuit pressure on the high pressure side” value is within the range (the shaded part) in Fig. 4-14. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-14 Ambient temperature and refrigerant circuit pressure

16. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-14. If the cross point is within the range, it means that the pressure sensor is operating correctly.

17. Check the analogue output of the refrigerant circuit pressure sensor (for high pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 11 and the pin number 10 is in the same relationship shown in Fig. 4-16. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-15 Check of the refrigerant circuit pressure sensor (for high pressure) output




Fig. 4-16 Refrigerant circuit pressure sensor (for high pressure) analogue output

18. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-18. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-17 Check of the refrigerant circuit pressure sensor (for low pressure) output





Fig. 4-18: Refrigerant circuit pressure sensor (for low pressure) analogue output

AL03: Circulating fluid discharge temp. rise

<Detection method> This alarm goes off when the temperature sensor for the circulating fluid (for discharge) detects 45°C or more (can be changed).




1. Check the external piping.

Check if the external piping is in the conditions shown below:

- (1) The system has a circuit that high temperature circulating fluid returns to the Thermo-Chiller at once due to an operation of the valve or the switching valve in the external piping.
- (2) The system has a circuit that the circulating fluid that has been heated by a waste heat of the workpiece that is cooled returns to the Thermo-Chiller at once when the Thermo-Chiller starts operation.

AL04: Circulating fluid discharge temp. drop

<Detection method> This alarm goes off when the temperature sensor for the circulating fluid (for discharge) detects 1°C or less (can be changed).



1. Cooling load that is larger than the heating capacity is being applied to the Thermo-Chiller.

Please refer to the "Heating capacity" graph on pages 21 and 22.

2. Check the circulating fluid temperature sensor (PT1).

Two circulating fluid temperature sensors are used; one is for the outlet port (PT1) and the other is for the return port (PT2). Compare the temperatures sensed by the temperature sensors under the conditions shown below to judge if the values provided by the temperature sensors are correct or not:

- (1) Connect a shorter pipe directly from the circulating fluid outlet port to the return port of the Thermo-Chiller with a valve mounted to the outlet port. (Mount a valve to the outlet port to make it possible to adjust the flow rate roughly.)
- (2) Operate the Thermo-Chiller and stabilize the temperature.
- (3) Check the temperature shown for "t1: Circulating fluid outlet temperature" and "t2: Circulating fluid return temperature" in the "Check Monitor Menu".

If the temperature is within the range of $t1 = t2 \pm 2^{\circ}\text{C}$, operation of the circulating fluid temperature sensor (PT1) is normal.

3. Check the circulating fluid temperature sensor (PT1) after it is replaced.

Replace the circulating fluid temperature sensor (PT1). (See "Replacement of the temperature sensor (PT1)" on page 260.) After replacing, check that all the check items shown in "2. Check the circulating fluid temperature sensor (PT1)" are correctly followed.

4. Check flow rate of the circulating fluid is not less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

5. Check the pump performance.


Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

6. Check after stopping power supply for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

AL05: High circulating fluid return temp.

<Detection method> This alarm goes off when the temperature sensor for the circulating fluid (for fluid return) detects 60°C or more.



1. External load is out of the specification range.

Cooling capacity varies depending on the ambient temperature, facility water temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the "Cooling capacity" graph on pages 19 and 20.

2. The alarm goes off right after the Thermo-Chiller starts.

Check if the the Thermo-Chiller has a circuit that the circulating fluid that has been heated to 60°C or more by a waste heat of the workpiece that is cooled returns to the Thermo-Chiller at once when the Thermo-Chiller starts operation.

3. Check the external piping.

Check if the Thermo-Chiller has a circuit that high temperature circulating fluid returns to the Thermo-Chiller at once due to an operation of the valve or the switching valve in the external piping.

4. Check the circulating fluid temperature sensor (PT2).

Two circulating fluid temperature sensors are used; one is for the outlet port (PT1) and the other is for the return port (PT2). Compare the temperatures sensed by the temperature sensors under the conditions shown below to judge if the values provided by the temperature sensors are correct or not:

- (1) Connect a shorter pipe directly from the circulating fluid outlet port to the return port of the Thermo-Chiller with a valve mounted to the outlet port. (Mount a valve to the outlet port to make it possible to adjust the flow rate roughly.)
- (2) Operate the Thermo-Chiller and stabilize the temperature.
- (3) Check the temperature shown for "t1: Circulating fluid outlet temperature" and "t2: Circulating fluid return temperature" in the "Check Monitor Menu".

If the temperature is within the range of $t2 = t1 \pm 2^{\circ}\text{C}$, operation of the circulating fluid temperature sensor (PT2) is normal.


5. Check the circulating fluid temperature sensor (PT2) after it is replaced.

Replace the circulating fluid temperature sensor (PT2). (See "Replacement of the temperature sensor (PT2)" on page 262 for the replacement procedure.) After replacing, check that all the check items shown in "4. Check the circulating fluid temperature sensor (PT2)" are correctly followed.

AL06: High circulating fluid discharge pressure

<Detection method> This alarm goes off when the pressures detected by the circulating fluid pressure sensor (for discharge) reach the following values.

- Standard pump: The alarm will not be generated.
- Option T (High pressure pump): 0.70 MPa
- Option MT (High pressure pump for pure water): 0.60 MPa



1. Check the external piping.

Check if the external piping is in the conditions shown below:

- (1) The external piping has close bending, curves at a sharp angle or clogging.
- (2) A valve or a switching valve is mounted in the middle of the external piping, and it closes the piping temporarily.
- (3) A filter (strainer) for circulating fluid is used, and the filter is clogged.

2. Check the operating time of the Thermo-Chiller.

Operate the Thermo-Chiller as a single unit.

Connect an external piping of an I.D. of approximately 15 mm and a length of 2 meters or less) and a valve that is capable of roughly regulating pressure to the Thermo-Chiller.

Start operating the Thermo-Chiller with the valve fully open.

- (1) Check that "AL06: High circulating fluid discharge pressure" will not be generated with the valve fully open.
- (2) Display the circulating fluid discharge pressure "P1" on the operation panel, and gradually close the valve while the Thermo-Chiller is operating.

Check that "AL06: High circulating fluid discharge pressure" is generated when the circulating fluid discharge pressure "P1" reaches the pressures shown below:

- Option T: 0.7 MPa
- Option MT: 0.6 MPa

3. Check for any clogging in the heat exchanger.

Check for clogging in the heat exchanger (evaporator) due to contamination contained in the circulating fluid adheres to the heat exchanger.

Operate the Thermo-Chiller as a single unit.

- (1) Connect an external piping of an I.D. of approximately 15 mm and a length of 2 meters or less) and a valve that is capable of roughly regulating pressure to the Thermo-Chiller.
- (2) Do not connect the piping to the circulating fluid return port that is usually connected to it. Open the cap of the water fill port and inset the piping to the water fill port (to stop the circulating fluid entering the heat exchanger).

Operate the Thermo-Chiller to confirm that the "AL06: High circulating fluid discharge pressure" goes off. If it does not, it will cause clogging in the heat exchanger.




Fig. 4-19 Piping example

4. AL25 goes off when the circulating fluid pressure sensor connector is disconnected.

Confirm that “AL25: Circulating fluid discharge pressure sensor failure” goes off when the connector “PS1” of the circulating fluid pressure sensor (for discharge) is pulled out.




Fig. 4-20 Circulating fluid pressure sensor

5. Check the circulating fluid pressure sensor after it is replaced.

Replace the circulating fluid pressure sensor (for discharge). (See “Replacement of pressure sensor” on page 282.)

After replacing the sensor, operate the Thermo-Chiller and confirm that the alarm does not go off again.


AL07: Abnormal pump operation

<Detection method> This alarm goes off when the pressures detected by the circulating fluid pressure sensor (for discharge) is 0.05 MPa or less.



4

Maintenance



1. Check the power supply voltage.

Check that the power supply voltage is within the specified range. Check the power supply voltage that is supplied to the connector of the power supply cable to be connected to Thermo-Chiller with a tester.

Thermo-Chiller model: HRS□-□-10/20-□

↑
Power supply specification

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)

2. Check the pump rotation manually.

Check if the impeller of the high pressure pump has been locked by making a manual rotation. Remove the seal on the back of the motor. Insert a flat blade driver to rotate the motor shaft and check if the impeller rotates smoothly. If it does not rotate smoothly, there are some problems such as lodging of foreign matter at the pump part.




Fig. 4-21 Rotate the pump manually

3. Check the pump performance.

Operate the Thermo-Chiller as a single unit.

Install a pressure gauge (measurable range: approx. 0 to 1 MPa), a valve (with approximate flow adjustability), and a flow meter (measurable range: approx. 0 to 30 L/min) to the Thermo-Chiller.

Make an isolated operation of the pump (by pressing the “RUN/STOP” key and “MENU” key simultaneously) to check the pump performance.

Based on the measurement results of the flow meter and the pressure gauge installed, check if the pump performance satisfies the values shown in the “Pump performance” graph on page 23.




Fig. 4-22 Piping example

4. A small amount of circulating fluid flows.

Check that circulating fluid, even for a small amount, flows through the pump (that the pump can be rotated) when the pump makes an isolated operation (by pressing “RUN/STOP” key and “MENU” key simultaneously) with the piping conditions provided in section “3. Check the pump performance”.

5. Check the main board.

Check that the main board outputs signals.

Disconnect the connector “CN1” on the power board.

Perform settings of the tester to make it possible to measure 24 VDC.

Contact the negative side probe to the connector pin number 6 on the cable side of the “CN1” that has been removed, and contact the positive side probe to the pin number 8.

Check the voltage between the cable side connectors number 6 and number 8 while making an isolated operation of the pump (by pressing the “RUN/STOP” key and “MENU” key simultaneously).

<Normal> Between pin numbers 6 and 8: 24 VDC




Fig. 4-23 Check the pump signal output

6. Check the power board.

Check that the power is being supplied to the pump.

Disconnect the connector “CN3” of the power board to which the pump cable is connected.

Check if power supply voltage is being supplied to the “CN3” connector (Pin No. 1 and No.2) of the power board with a tester while the pump makes an isolated operation (by pressing “RUN/STOP” key and “MENU” key simultaneously).

[Power supply voltage to be supplied]

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), or 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)




Fig. 4-24 Check the pump input

7. Check the circulating fluid pressure sensor.

Install a pressure gauge, valve, and flow meter to the Thermo-Chiller in the same way as in step “3. Check the pump performance”. Compare the circulating fluid discharge pressure of the Thermo-Chiller with the value measured by the pressure gauge in the following procedure.

- (1) Display the circulating fluid discharge pressure “P1” on the Operation Panel of the Thermo-Chiller.
- (2) Perform an isolated operation of the pump (by pressing “RUN/STOP” key and “MENU” key simultaneously) to check if the value measured by the pressure gauge and the value displayed by the Thermo-Chiller are within the range provided below. If they are, the circulating fluid pressure sensor is operating correctly.

Pressure “P1” displayed by the Thermo-Chiller = Pressure measured by the pressure gauge \pm 0.07 MPa

8. Check the circulating fluid pressure sensor after it is replaced.


Replace the circulating fluid pressure sensor (for discharge). (See “Replacement of pressure sensor” on page 282.)

After replacing the sensor, operate the Thermo-Chiller and confirm that the alarm does not go off again.

AL08: Circulating fluid discharge pressure rise

<Detection method> This alarm goes off when the pressures detected by the circulating fluid pressure sensor (for discharge) reach the following values (change in the values acceptable).

- Standard pump: 0.30 MPa
- Option T (High pressure pump): 0.70 MPa
- Option MT (High pressure pump for pure water): 0.60 MPa



1. Check the external piping.

Check if the external piping is in the conditions shown below:

- (1) The external piping has close bending, curves at a sharp angle or clogging.
- (2) A valve or a switching valve is mounted in the middle of the external piping, and it closes the piping temporarily.
- (3) A filter (strainer) for circulating fluid is used, and the filter is clogged. Filtration rating has been changed.

2. Check for any clogging in the heat exchanger.

Check for clogging in the heat exchanger (evaporator) due to contamination contained in the circulating fluid adheres to the heat exchanger.

Operate the Thermo-Chiller as a single unit.

Install a pressure gauge (measurable range: approx. 0 to 1 MPa), a valve (with approximate flow adjustability), and a flow meter (measurable range: approx. 0 to 30 L/min) to the Thermo-Chiller.

Make an isolated operation of the pump (by pressing the “RUN/STOP” key and “MENU” key simultaneously) to measure the circulating fluid flow rate and the circulating fluid return pressure.

From the measurement results, if the circulating fluid return pressure is higher than the pressure at the return port in the “Pump capacity” graph shown in the Operation Manual, it means that there is a clogging in the heat exchanger.




Fig. 4-25 Piping example

3. AL25 goes off when the circulating fluid pressure sensor connector is disconnected.

Confirm that “AL25: Circulating fluid discharge pressure sensor failure” goes off when the connector “PS1” of the circulating fluid pressure sensor (for discharge) is pulled out.




Fig. 4-26 Circulating fluid pressure sensor


4. Check the circulating fluid pressure sensor after it is replaced.

Replace the circulating fluid pressure sensor (for discharge). (See “Replacement of pressure sensor” on page 282.)

After replacing the sensor, operate the Thermo-Chiller and confirm that the alarm does not go off again.

AL09: Circulating fluid discharge pressure drop

<Detection method> This alarm goes off when the pressures detected by the circulating fluid pressure sensor (for discharge) is 0.05 MPa or less (change in the values acceptable).




1. Check the external piping.

Check if the external piping is in the conditions shown below:

- (1) Valve opening has been changed.
- (2) A valve or a switching valve is mounted to the external piping, and they reduce the piping resistance temporarily.
- (3) A filter (strainer) for circulating fluid is used, and the filter element has been replaced with new one. A filter element has been forgotten to be mounted. Filtration rating has been changed.

AL10: High compressor intake temp.

<Detection method> This alarm goes off when the compressor intake temperature sensor detects 60°C or more.



1. External load is out of the specification range.

Cooling capacity varies depending on the ambient temperature, facility water temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the "Cooling capacity" graph on pages 19 and 20.

2. Check the external piping.

Check if the external piping is in the conditions shown below:

- (1) The system has a circuit that high temperature circulating fluid returns to the Thermo-Chiller at once due to an operation of the valve or the switching valve in the external piping.
- (2) The system has a circuit that the circulating fluid (60°C or more) that has been heated by a waste heat of the workpiece that is cooled returns to the Thermo-Chiller at once when the Thermo-Chiller starts operation.

3. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

4. Check the pump performance.

Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

5. Check the compressor intake temp. sensor.

Check for any difference between the actual compressor intake temperature and the temperature detected by the compressor intake temperature sensor by following the instructions shown below:

- (1) Stop the Thermo-Chiller and leave it not operating for 24 hours to make the temperature of the temperature sensor itself be the same as the ambient temperature.
- (2) Check the temperature shown for "t1: Circulating fluid discharge temperature" and "t3: Compressor inlet temperature" in the "Check Monitor Menu" of the Thermo-Chiller.
- (3) If $t3 = t1 \pm 3 \text{ }^{\circ}\text{C}$, it means that the compressor intake temperature sensor is operating correctly.

6. Check the compressor intake temp. sensor after replacement.


Replace the compressor intake temperature sensor with a new one. (See document No. HRX-MM-Q016 for replacement instructions) After replacing, check that all the check items shown in "5. Check the compressor intake temperature sensor." are correctly followed.

7. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch of the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

AL11: Low compressor intake temp.

<Detection method> This alarm goes off when the compressor intake temperature sensor detects -15°C or less.



1. Cooling load that is larger than the heating capacity is being applied to the Thermo-Chiller.

Please refer to the "Heating capacity" graph on pages 21 and 22.

2. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

3. Check the pump performance.

Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

4. Check the compressor intake temp. sensor.

Check for any difference between the actual compressor intake temperature and the temperature detected by the compressor intake temperature sensor by following the instructions shown below:

- (1) Stop the Thermo-Chiller and leave it not operating for 24 hours to make the temperature of the temperature sensor itself be the same as the ambient temperature.
- (2) Check the temperature shown for "t1: Circulating fluid discharge temperature" and "t3: Compressor inlet temperature" in the "Check Monitor Menu" of the Thermo-Chiller.
- (3) If $t3 = t1 \pm 3^{\circ}\text{C}$, it means that the compressor intake temperature sensor is operating correctly.

5. Check the compressor intake temp. sensor after replacement.

Replace the compressor intake temperature sensor with a new one. (See document No. HRX-MM-Q016 for replacement instructions) After replacing, check that all the check items shown in "4. Check the compressor intake temperature sensor." are correctly followed.

6. Circulating fluid is contaminated.

Contamination contained in the circulating fluid adheres to the heat exchanger (evaporator), and it decreases the heat exchanger performance.

Open the cap of the tank, and check visually the contamination (e.g. deformation, foreign matter, abnormal smell) of the circulating fluid inside the tank.

When the visual check finds contamination in the circulating fluid, check the influence of the contamination to the heat exchanger by following the instructions shown below.

- (1) Connect the circulating fluid outlet directly to the fluid return port with a valve mounted to the outlet port with a shorter piping to make it possible to operate the system at flow rate of circulating fluid at 7 L/min. (For Option T, adjust the flow rate so that the circulating fluid discharge pressure will be approximately 0.4 MPa.)
- (2) Set the circulating fluid temperature to 20°C , and operate the Thermo-Chiller.
- (3) Check the temperature shown for "t2: Circulating fluid return temperature" and "t3: Compressor inlet temperature" in the "Check Monitor Menu".
- (4) Displayed temperature will be as shown below in accordance with level of contamination of the heat exchanger.

<With no contamination with the heat exchanger>

"t3: Suction temperature of the compressor" \geq "t2: Circulating fluid return temperature" -5°C

<With contamination with the heat exchanger>

"t3: Suction temperature of the compressor" $<$ "t2: Circulating fluid return temperature" -5°C


e.g. (Normal) t2: 21.5 , t3: 23.8 , (Abnormal) t2: 21.5 , t3: 15.5

7. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch of the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

AL12: Low super heat temperature

<Detection method> This alarm goes off when the compressor intake temperature sensor detects the value that is lower than the converted temperature by the refrigerant circuit pressure sensor (for low pressure).



1. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

2. Check the pump performance.

Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

3. Circulating fluid is contaminated.

Contamination contained in the circulating fluid adheres to the heat exchanger (evaporator), and it decreases the heat exchanger performance.

Open the cap of the tank, and check visually the contamination (e.g. deformation, foreign matter, abnormal smell) of the circulating fluid inside the tank.

When the visual check finds contamination in the circulating fluid, check the influence of the contamination to the heat exchanger by following the instructions shown below.

- (1) Connect the circulating fluid outlet directly to the fluid return port with a valve mounted to the outlet port with a shorter piping to make it possible to operate the system at flow rate of circulating fluid at 7 L/min.
(For Option T, adjust the flow rate so that the circulating fluid discharge pressure will be approximately 0.4 MPa.)
- (2) Set the circulating fluid temperature to 20°C, and operate the Thermo-Chiller.
- (3) Check the temperature shown for "t2: Circulating fluid return temperature" and "t3: Compressor inlet temperature" in the "Check Monitor Menu".
- (4) Displayed temperature will be as shown below in accordance with level of contamination of the heat exchanger.
 - <With no contamination with the heat exchanger>
 - "t3: Suction temperature of the compressor" \geq "t2: Circulating fluid return temperature" -5°C
 - <With contamination with the heat exchanger>
 - "t3: Suction temperature of the compressor" $<$ "t2: Circulating fluid return temperature" -5°C

e.g. (Normal) t2: 21.5, t3: 23.8, (Abnormal) t2: 21.5, t3: 15.5

4. Check the compressor intake temp. sensor.

Check for any difference between the actual compressor intake temperature and the temperature detected by the compressor intake temperature sensor by following the instructions shown below:

- (1) Stop the Thermo-Chiller and leave it not operating for 24 hours to make the temperature of the temperature sensor itself be the same as the ambient temperature.
- (2) Check the temperature shown for "t1: Circulating fluid discharge temperature" and "t3: Compressor inlet temperature" in the "Check Monitor Menu" of the Thermo-Chiller.
- (3) If $t3 = t1 \pm 3^{\circ}\text{C}$, it means that the compressor intake temperature sensor is operating correctly.

5. Check the compressor intake temp. sensor after replacement.

Replace the compressor intake temperature sensor with a new one. (See document No. HRX-MM-Q016 for replacement instructions) After replacing, check that all the check items shown in "4. Check the compressor intake temperature sensor." are correctly followed.

6. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for "Ph: Refrigerant circuit pressure on the high pressure side" and "PL: Refrigerant circuit pressure on the low pressure side" in the "Check Monitor Menu".
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($\text{Ph} = \text{PL} \pm 0.1$), it means that the pressure sensors are operating correctly.

7. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-27 Check of the refrigerant circuit pressure sensor (for low pressure) input

8. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check "PL: Refrigerant circuit pressure on the low pressure side" value in the "Check Monitor Menu".
- (4) Check if the value at the cross point of the ambient temperature and the "PL: Refrigerant circuit pressure on the low pressure side" value is within the range (the shaded part) in Fig. 4-28. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-28 Ambient temperature and refrigerant circuit pressure

9. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

10. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-30. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-29 Check of the refrigerant circuit pressure sensor (for low pressure) output






Fig. 4-30 Refrigerant circuit pressure sensor (for low pressure) analogue output

AL13: High compressor discharge pressure [For air-cooled type]

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for high pressure) is 2.6 MPa (Option G: 2.8 MPa) or more.





1. Ambient temperature is out of the specification range.

Ambient temperature is higher than 40°C (45°C for Option G “High ambient temperature specification”).

2. External load is out of the specification range.

Cooling capacity varies depending on the ambient temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the “Cooling capacity” graph on pages 19 and 20.

3. Enough ventilation space has not been secured.

- The Thermo-Chiller is installed too close to a wall.
- There is other equipment close to the Thermo-Chiller.
- Hot ventilated air from other equipment enters the Thermo-Chiller.
- The Thermo-Chiller is operating in an enclosed space.
(e.g. In a room without ventilation or air conditioner)

4. The dustproof filter is too dusty.

Dustproof filter on the front side of the Thermo-Chiller or the fin of the air-cooled condenser inside is contaminated.




Fig. 4-31 An air-cooled condenser and a dustproof filter

5. Check the rotation of the fan.

Check visually that the fan rotates right after starting the Thermo-Chiller operation from the stopped state.

(Depending on the installation environment, the fan may stop rotating for few seconds after starting the product operation, which is normal. If the fan does not rotate after starting the operation, this is not normal.)




Fig. 4-32 Fan position

6. Check the power board.

Check that the power is being supplied to the fan motor.

Disconnect the connector “CN4” of the power board to which the fan/compressor cable is connected.

Operate the Thermo-Chiller (by pressing “RUN/STOP” key), and check if power supply voltage is supplied to the pins number 1 to number 3 of the “CN4” connector on the power board with a tester. In this test, if voltage supply is confirmed only for a couple of seconds after the Thermo-Chiller is started, it is normal.

Depending on the installation environment, power supply voltage may stop (or the voltage may drop to approximately 10 VAC) in some seconds after starting the product operation, which is normal. If the power supply voltage is not confirmed at the start operation, it is judged not to be normal.

[Power supply voltage to be supplied]

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), or 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)




Fig. 4-33 Confirm the fan input

7. Check the power board after replacement.

Replace the power board. (See “Replacement of power board” on page 307.)

After replacing the power board, confirm that all the items specified in step 6 have been checked.

8. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

9. Check the pump performance.

Install a flow meter. Refer to the “Pump capacity” graph” on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

10. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for the high pressure and one for the low pressure, are used for the refrigerant circuit.

The following instructions are to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for “Ph: Refrigerant circuit pressure on the high pressure side” and “PL: Refrigerant circuit pressure on the low pressure side” in the “Check Monitor Menu”.
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

11. After stopping power supply, check for the same alarm goes off when the chiller is re-started.

After stopping power supply (by turning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off when the Thermo-Chiller is restarted.

12. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for high pressure)>

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the "CN4" connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-34 Check of the refrigerant circuit pressure sensor input

13. Check the display of the refrigerant circuit pressure sensor (for high pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “Ph: Refrigerant circuit pressure on the high pressure side” value is within the range (the shaded part) in Fig. 4-35. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-35 Ambient temperature and refrigerant circuit pressure

14. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-35. If the cross point is within the range, it means that the pressure sensor is operating correctly.

15. Check the analogue output of the refrigerant circuit pressure sensor (for high pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 11 and the pin number 10 is in the same relationship shown in Fig. 4-37. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-36 Check of the refrigerant circuit pressure sensor (for high pressure) output




Fig. 4-37 Refrigerant circuit pressure sensor (for high pressure) analogue output

16. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-39. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-38 Check of the refrigerant circuit pressure sensor (for low pressure) output






Fig. 4-39 Refrigerant circuit pressure sensor (for low pressure) analogue output

AL13: High compressor discharge pressure [For water-cooled type]

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for high pressure) is 2.6 MPa or more.





1. Check the facility water system.

Check that the facility water system satisfies the required facility water flow rate that is specified on page 23.

2. Facility water is contaminated.

Check that the facility water is clean (without any foreign matter or discolouration).

3. Incorrect flow rate of the facility water.

Install a flow meter and check that the facility water system satisfies the required facility water flow rate that is specified on page 23.

* Facility water does not flow when the Thermo-Chiller is not operating. Check the facility water flow rate while the external load is being applied to the Thermo-Chiller or the circulating fluid temperature is being decreased.

4. Water-cooled condenser is contaminated.

Contamination given to the water-cooled condenser reduces cooling capacity. Check the water-cooled condenser for contamination by following the instructions shown below:

- (1) Remove the pipings connected to the inlet and outlet of the facility water.
- (2) Remove the upper panel and the right panel.
- (3) Remove the plug of the water-cooled condenser, and check inside the water-cooled condenser for contamination.




Fig. 4-40 The port for visual check for contamination inside the water-cooled condenser

5. External load is out of the specification range.

Cooling capacity varies depending on the facility water temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the "Cooling capacity" graph on pages 19 and 20.

6. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

7. Check the pump performance.

Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

8. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for "Ph: Refrigerant circuit pressure on the high pressure side" and "PL: Refrigerant circuit pressure on the low pressure side" in the "Check Monitor Menu".
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

9. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

10. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for high pressure)>

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the "CN4" connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-41 Check of the refrigerant circuit pressure sensor input

11. Check the display of the refrigerant circuit pressure sensor (for high pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “Ph: Refrigerant circuit pressure on the high pressure side” value is within the range (the shaded part) in Fig. 4-42. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-42 Ambient temperature and refrigerant circuit pressure

12. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-42. If the cross point is within the range, it means that the pressure sensor is operating correctly.

13. Check the analogue output of the refrigerant circuit pressure sensor (for high pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 11 and the pin number 10 is in the same relationship shown in Fig. 4-44. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-43 Check of the refrigerant circuit pressure sensor (for high pressure) output




Fig. 4-44 Refrigerant circuit pressure sensor (for high pressure) analogue output

14. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-46. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-45 Check of the refrigerant circuit pressure sensor (for low pressure) output





Fig. 4-46 Refrigerant circuit pressure sensor (for low pressure) analogue output

AL15: Refrigerant circuit pressure (high pressure side) drop

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for high pressure) is 0.1 MPa or less.



1. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for “Ph: Refrigerant circuit pressure on the high pressure side” and “PL: Refrigerant circuit pressure on the low pressure side” in the “Check Monitor Menu”.
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

2. Check for refrigerant leakage.

Refrigerant leakage reduces the cooling capacity. To check for refrigerant leakage, it is necessary to make the refrigerant circuit temperature same as the ambient temperature. Stop the Thermo-Chiller operation, and leave it not operating for 24 hours.

Take the following instructions to check for refrigerant leakage after leaving not operating.

- (1) Measure the ambient temperature (room temperature).
- (2) Check the pressure shown for “Ph: Refrigerant circuit pressure on the high pressure side” in the “Check Monitor Menu” of the Thermo-Chiller.
- (3) If the measured point is lower than the values shown in the graph in “Fig. 4-47: Ambient temperature and refrigerant circuit pressure”, it means there is refrigerant leakage caused.




Fig. 4-47 Ambient temperature and refrigerant circuit pressure

3. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for high pressure)>

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the "CN4" connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V




Fig. 4-48 Check of the refrigerant circuit pressure sensor (for high pressure) input

4. Check the display of the refrigerant circuit pressure sensor (for high pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “Ph: Refrigerant circuit pressure on the high pressure side” value is within the range (the shaded part) in Fig. 4-49. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-49 Ambient temperature and refrigerant circuit pressure

5. Check the analogue output of the refrigerant circuit pressure sensor (for high pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “Ph: Refrigerant circuit pressure on the high pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 11 and the pin number 10 is in the same relationship shown in Fig. 4-51. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-50 Check of the refrigerant circuit pressure sensor (for high pressure) output






Fig. 4-51 Refrigerant circuit pressure sensor (for high pressure) analogue output

AL16: Refrigerant circuit pressure (low pressure side) rise

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for low pressure) is 0.8 MPa (Option G: 0.85 MPa) or more.



1. Check the surrounding environment.

Check if the surrounding environment is in the conditions shown below:

- (1) Flow rate fluctuates due to a valve and a switching valve in the external piping. (Heat load is fluctuating.)
- (2) Heat that is larger than the cooling capacity is transiently being applied to the Thermo-Chiller.

2. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for "Ph: Refrigerant circuit pressure on the high pressure side" and "PL: Refrigerant circuit pressure on the low pressure side" in the "Check Monitor Menu".
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

3. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

4. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC \pm 1 V




Fig. 4-52 Check of the refrigerant circuit pressure sensor (for low pressure) input

5. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-53. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-53 Ambient temperature and refrigerant circuit pressure

6. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-55. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-54 Check of the refrigerant circuit pressure sensor (for low pressure) output






Fig. 4-55 Refrigerant circuit pressure sensor (for low pressure) analogue output

AL17: Refrigerant circuit pressure (low pressure side) drop

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for low pressure) is 0.2 MPa or less.



1. Check the surrounding environment.

Check if the surrounding environment is in the conditions shown below:

- (1) Flow rate fluctuates due to a valve and a switching valve in the external piping. (Heat load is fluctuating.)
- (2) The system has a circuit that low temperature circulating fluid returns to the Thermo-Chiller at once.

2. Flow rate of the circulating fluid is less than 5 L/min.

Install a flow meter, and check the flow rate of the circulating fluid.

3. Check the pump performance.

Install a flow meter. Refer to the "Pump capacity" graph" on page 23 and check that the pump capacity is suitable for the circulating fluid outlet pressure and the circulating fluid flow rate.

4. Check the pressure sensor in the refrigerant circuit.

Two pressure sensors, one for high pressure and the other for low pressure, are used for the refrigerant circuit. Take the following instructions to check for any abnormality with the pressure sensors:

- (1) Stop the Thermo-Chiller operation.
- (2) Check the temperature shown for "Ph: Refrigerant circuit pressure on the high pressure side" and "PL: Refrigerant circuit pressure on the low pressure side" in the "Check Monitor Menu".
- (3) If the pressure value shown by each sensor is ± 0.1 MPa ($Ph = PL \pm 0.1$), it means that the pressure sensors are operating correctly.

5. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

6. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor.

Check voltage by contacting the probe of the tester directly to the connector external surface with the "CN4" connector of the main board being inserted.

<Refrigerant circuit pressure sensor (for low pressure)>

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the "CN4" connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V




Fig. 4-56 Check of the refrigerant circuit pressure sensor (for low pressure) input

7. Check the display of the refrigerant circuit pressure sensor (for low pressure).

Compare the refrigerant circuit pressure and the ambient temperature with those shown in the graph to check the displayed value of the refrigerant circuit pressure sensor.

Follow the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours to make the ambient temperature and the temperature inside the Thermo-Chiller the same.
- (2) Check the ambient temperature.
- (3) Check “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (4) Check if the value at the cross point of the ambient temperature and the “PL: Refrigerant circuit pressure on the low pressure side” value is within the range (the shaded part) in Fig. 4-57. If the cross point is within the range, it means that the pressure sensor is operating correctly.




Fig. 4-57 Ambient temperature and refrigerant circuit pressure

8. Check the analogue output of the refrigerant circuit pressure sensor (for low pressure).

Find out if the main board is operating correctly.

Follow the instructions shown below:

- (1) Check the “PL: Refrigerant circuit pressure on the low pressure side” value in the “Check Monitor Menu”.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the same relationship shown in Fig. 4-59. (Accuracy: $\pm 5\%$)
- (5) If the voltage is in the same relationship as the graph shows, it means that the main board is operating correctly.




Fig. 4-58 Check of the refrigerant circuit pressure sensor (for low pressure) output





Fig. 4-59 Refrigerant circuit pressure sensor (for low pressure) analogue output


AL18: Compressor overload [For air-cooled type]

<Detection method> This alarm goes off when the difference between the pressure detected by the refrigerant circuit pressure sensor for high pressure and the pressure detected by the refrigerant circuit pressure sensor for low pressure is 0.1 MPa or less.



4

Maintenance



1. Check of power supply

Check if the power supply is correct.

- (1) Check if the power supply is within the specified range. Measure the power supply voltage that is connected to the connector of the power supply cable to be connected to the Thermo-Chiller with a tester, and check if the power supply voltage is within the specification range.

Thermo-Chiller model: HRS□-□-10/20-□

Power supply specification

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)

- (2) Check that there is no temporary voltage drop or instantaneous power supply stop caused with the power supply.

2. Check the compressor operation.

Leave the Thermo-Chiller in an operation stop state for 2 hours or more (to decrease the temperature of the compressor body).

After starting Thermo-Chiller operation, judge if the compressor is operating with the compressor operating noise and the vibration of the compressor.

(When checking vibration, use a screwdriver to touch the compressor body. Do not touch the compressor body directly with hand as it becomes hot while it is operating.)

3. Ambient temperature is out of the specification range.

Ambient temperature is higher than 40°C (45°C for Option G “High ambient temperature specification”).

4. External load is out of the specification range.

Cooling capacity varies depending on the ambient temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the “Cooling capacity” graph on pages 19 and 20.

5. Enough ventilation space has not been secured.

- The Thermo-Chiller is installed too close to a wall.
- There is other equipment close to the Thermo-Chiller.
- Hot ventilated air from other equipment enters the Thermo-Chiller.
- The Thermo-Chiller is operating in a enclosed space.

(e.g. In a room without ventilation or air conditioner)

6. The dustproof filter is too dusty.

Dustproof filter on the front side of the Thermo-Chiller or the fin of the air-cooled condenser inside is contaminated.




Fig. 4-60 An air-cooled condenser and a dustproof filter

7. Check the main board.

Check that the main board outputs signals.

Disconnect the connector "CN1" on the power board.

Perform settings of the tester to make it possible to measure 24 VDC.

Contact the negative side probe to the connector pin number 7 on the cable side of the "CN1" that has been removed, and contact the positive side probe to the pin number 8.

Operate the Thermo-Chiller (by pressing "RUN/STOP" key), and check the voltage between the cable connectors number 7 and number 8.

<Normal> Between pin numbers 7 and 8: 24 VDC




Fig. 4-61 Check the compressor signal output

8. Check the power board.

Check that the power is being supplied to the compressor.

Disconnect the connector "CN4" of the power board to which the fan/compressor cable is connected.

Operate the Thermo-Chiller (by pressing "RUN/STOP" key), and check if power supply voltage is supplied to the pins number 2 to number 4 of the "CN4" connector on the power board with a tester.

[Power supply voltage to be supplied]

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), or 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)




Fig. 4-62 Check the compressor input

9. Check the compressor.

Perform the checks after leaving the Thermo-Chiller not operating for 2 hours or more (after the compressor body temperature has decreased enough).

Disconnect the connector "CN4" of the power board to which the fan/compressor cable is connected.

Check the electricity continuity between the cable connector pin number 2 and the pin number 4 with a tester.

<Normal> Electric continuity between the cable connector pin number 2 and the pin number 4: Yes





Fig. 4-63 Check the compressor

AL18: Compressor overload [For water-cooled type]

<Detection method> This alarm goes off when the difference between the pressure detected by the refrigerant circuit pressure sensor for high pressure and the pressure detected by the refrigerant circuit pressure sensor for low pressure is 0.1 MPa or less.



1. Check of power supply

Check if the power supply is correct.

- (1) Check if the power supply is within the specified range. Measure the power supply voltage that is connected to the connector of the power supply cable to be connected to the Thermo-Chiller with a tester, and check if the power supply voltage is within the specification range.

Thermo-Chiller model: HRS□-□-10/20-□

↑
Power supply specification

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)

- (2) Check that there is no temporary voltage drop or instantaneous power supply stop caused with the power supply.

2. Check the compressor operation.

Leave the Thermo-Chiller in an operation stop state for 2 hours or more (to decrease the temperature of the compressor body).

After starting Thermo-Chiller operation, judge if the compressor is operating with the compressor operating noise and the vibration of the compressor.

(When checking vibration, use a screwdriver to touch the compressor body. Do not touch the compressor body directly with hand as it becomes hot while it is operating.)

3. Check the facility water system.

Check that the facility water system capability satisfies the required facility water flow rate that is specified on page 23.

4. External load is out of the specification range.

Cooling capacity varies depending on the facility water temperature, set circulating fluid temperature, and power supply frequency.

Please refer to the "Cooling capacity" graph on pages 19 and 20.

5. Facility water is contaminated.

Check that the facility water is clean (without any foreign matter or discolouration).

6. Incorrect flow rate of the facility water.

Install a flow meter and check that the facility water system satisfies the required facility water flow rate that is specified on page 23.

* Facility water does not flow when the Thermo-Chiller is not operating. Check the facility water flow rate while the external load is being applied to the Thermo-Chiller or the circulating fluid temperature is being decreased.

7. Water-cooled condenser is contaminated.

Contamination given to the water-cooled condenser reduces cooling capacity. Check the water-cooled condenser for contamination by following the instructions shown below:

- (1) Remove the pipings connected to the inlet and outlet of the facility water.
- (2) Remove the upper panel and the right panel.
- (3) Remove the plug of the water-cooled condenser, and check inside the water-cooled condenser for contamination.




Fig. 4-64 The port for visual check for contamination inside the water-cooled condenser

8. Check the main board.

Check that the main board outputs signals.

Disconnect the connector "CN1" on the power board.

Perform settings of the tester to make it possible to measure 24 VDC.

Contact the negative side probe to the connector pin number 7 on the cable side of the "CN1" that has been removed, and contact the positive side probe to the pin number 8.

Operate the Thermo-Chiller (by pressing "RUN/STOP" key), and check the voltage between the cable connectors number 7 and number 8.

<Normal> Between pin numbers 7 and 8: 24 VDC




Fig. 4-65 Check the compressor signal output

9. Check the power board.

Check that the power is being supplied to the compressor.

Disconnect the connector "CN4" of the power board to which the fan/compressor cable is connected.

Operate the Thermo-Chiller (by pressing "RUN/STOP" key), and check if power supply voltage is supplied to the pins number 2 to number 4 of the "CN4" connector on the power board with a tester.

[Power supply voltage to be supplied]

- -10 (100 V spec.): Single phase 100 VAC (50/60 Hz), or 115 VAC (60 Hz)
- -20 (200 V spec.): Single phase 200 VAC to 230 VAC (50/60 Hz)




Fig. 4-66 Check the compressor input

10. Check the compressor.

Perform the checks after leaving the Thermo-Chiller not operating for 2 hours or more (after the compressor body temperature has decreased enough).

Disconnect the connector "CN4" of the power board to which the fan/compressor cable is connected.

Check the electricity continuity between the cable connector pin number 2 and the pin number 4 with a tester.

<Normal> Electric continuity between the cable connector pin number 2 and the pin number 4: Yes





Fig. 4-67 Check the compressor

AL19: Communication error

<Detection method> This alarm goes off when no request messages have been received from the host computer for a specific period of time.



4

Maintenance


1. Check the main board after replacement.

Replace the main board with a new one. (See “Replacement of main board & communication board” on page 304.)

After replacement, check if the alarm goes off again.

AL20: Memory error

<Detection method> This alarm goes off when the written data to the CPU and the read data do not match.




1. After stopping power supply, check for the same alarm goes off again when the chiller is re-started.

After stopping power supply (by tuning off the power supply switch on the Thermo-Chiller), check if the same alarm goes off again when the Thermo-Chiller is restarted.

AL21: DC line fuse cut

<Detection method> This alarm goes off when the fuse in the DC circuit of the contact I/O communication connector blows.





[Remarks]

- It is necessary to replace the fuse to reset the alarm.
- When AL21 is generated the Thermo-Chiller is stop as default setting. Although DC circuit cannot be used (the alarm cannot be reset), it is possible to continue the Thermo-Chiller operation even when the AL21 is being generated by changing setting of the "AS.15" in the Alarm Setting Menu. (Refer to the section "Alarm Customizing Function" in Operation Manual for details.)

AL22: Circulating fluid discharge temp. sensor failure

<Detection method> This alarm goes off when the circulating fluid temperature sensor (for discharge) detects temperature that is outside of -80 to 120°C range.



1. Check the connection

Check the circulating fluid temperature sensor (for discharge) "PT1" that is connected to the main board for the items shown below:

- (1) The connector is securely connected.
- (2) The pins are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-68 Check for the correct connection of PT1



2. "AL23" goes off when the cables that are connected to PT1 and PT2 are exchanged and connected.

Perform checking with the Thermo-Chiller not operating. Check if "AL22" is reset and "AL23" is generated by taking the following instructions:

- (1) Exchange the inserting position of the connector "PT1" for circulating fluid temperature sensor (for discharge) and the connector "PT2" for circulating fluid temperature sensor (for return).
- (2) Reset the alarm.
- (3) Check if the cables inserting position exchange resets "AL22" and generates "AL23".

AL23: Circulating fluid return temp. sensor failure

<Detection method> This alarm goes off when the circulating fluid temperature sensor (for return) detects temperature that is outside of -80 to 120°C range.



1. Check the connection

Check the circulating fluid temperature sensor (for return) “PT2” that is connected to the main board for the items shown below:

- (1) The connector is securely connected.
- (2) The pins are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-69 Check for the correct connection of PT2


2. “AL22” goes off when the cables that are connected to PT1 and PT2 are exchanged and connected.

Perform checking with the Thermo-Chiller not operating. Check if “AL23” is reset and “AL22” is generated by taking the following instructions:

- (1) Exchange the inserting position of the connector “PT1” for circulating fluid temperature sensor (for discharge) and the connector “PT2” for circulating fluid temperature sensor (for return).
- (2) Reset the alarm.
- (3) Check if the cables inserting position exchange resets “AL23” and generates “AL22”.

AL24: Compressor intake temp. sensor failure

<Detection method> This alarm goes off when the compressor intake temperature sensor detects temperature that is outside of -40 to 70°C range.



1. Check the connection

Check the compressor intake temperature sensor "T1" (thermistor sensor) that is connected to the connector "CN4", pin numbers from 7 to 19, of the main board for the check points shown below:

- (1) The connector "CN4" is securely connected.
- (2) The pins of the compressor intake temperature sensor "T1" (with black lead wire) are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-70 Check the connection of the compressor intake temperature sensor

2. Check the compressor intake temperature sensor.

Disconnect the connector "CN4" of the main board. Check the resistance of the pins number 7 to 19 (compressor intake temperature sensor) of the remove cable side connector by following the instructions shown below:

- (1) Leave the Thermo-Chiller not operating for 24 hours. (Make the temperature of the refrigerant circuit the same as the ambient temperature.)
- (2) Measure the ambient temperature.
- (3) Disconnect the connector "CN4" of the main board, and measure the resistance between the pin number 7 and the pin number 19 to which the compressor intake temperature sensor is connected with a tester.
- (4) Check that the resistance and the ambient temperature detected by the tester almost match the resistances and ambient temperatures shown in Table 4-2 Resistances detected by thermistor sensor (Reference) on page 231. If there is a difference of $\pm 5^{\circ}\text{C}$ or more in the temperatures, it is judged to be abnormal.

(AL24 is generated when the temperature reaches -40°C or less (resistance: $43.34\text{ k}\Omega$ or more) or 70°C or more ($0.4895\text{ k}\Omega$ or less). When the resistance is $43.34\text{ k}\Omega$ or more or $0.4895\text{ k}\Omega$ or less, the sensor is judged to have failure.)





Fig. 4-71 Check the resistance of the compressor intake temperature sensor

Table 4-2 Thermistor sensor resistance (Reference)

Temperature °C	Criterion kΩ	Temperature °C	Criterion kΩ	Temperature °C	Criterion kΩ
-40.0	43.34	0.0	6.000	40.0	1.274
-39.0	40.98	1.0	5.746	41.0	1.231
-38.0	38.76	2.0	5.503	42.0	1.190
-37.0	36.68	3.0	5.273	43.0	1.150
-36.0	34.72	4.0	5.053	44.0	1.111
-35.0	32.87	5.0	4.844	45.0	1.075
-34.0	31.14	6.0	4.645	46.0	1.039
-33.0	29.51	7.0	4.455	47.0	1.005
-32.0	27.97	8.0	4.273	48.0	0.9724
-31.0	26.53	9.0	4.100	49.0	0.9409
-30.0	25.17	10.0	3.935	50.0	0.9106
-29.0	23.88	11.0	3.778	51.0	0.8814
-28.0	22.67	12.0	3.628	52.0	0.8532
-27.0	21.53	13.0	3.485	53.0	0.8261
-26.0	20.45	14.0	3.348	54.0	0.8000
-25.0	19.43	15.0	3.217	55.0	0.7749
-24.0	18.47	16.0	3.092	56.0	0.7507
-23.0	17.57	17.0	2.972	57.0	0.7273
-22.0	16.71	18.0	2.858	58.0	0.7048
-21.0	15.90	19.0	2.749	59.0	0.6832
-20.0	15.13	20.0	2.644	60.0	0.6622
-19.0	14.41	21.0	2.545	61.0	0.6421
-18.0	13.72	22.0	2.449	62.0	0.6226
-17.0	13.07	23.0	2.358	63.0	0.6038
-16.0	12.46	24.0	2.270	64.0	0.5857
-15.0	11.88	25.0	2.186	65.0	0.5683
-14.0	11.33	26.0	2.106	66.0	0.5514
-13.0	10.80	27.0	2.029	67.0	0.5351
-12.0	10.31	28.0	1.955	68.0	0.5194
-11.0	9.838	29.0	1.885	69.0	0.5042
-10.0	9.392	30.0	1.817	70.0	0.4895
-9.0	8.969	31.0	1.752		
-8.0	8.568	32.0	1.690		
-7.0	8.187	33.0	1.630		
-6.0	7.825	34.0	1.573		
-5.0	7.481	35.0	1.518		
-4.0	7.154	36.0	1.465		
-3.0	6.844	37.0	1.414		
-2.0	6.548	38.0	1.366		
-1.0	6.267	39.0	1.319		
0.0	6.000	40.0	1.274		

AL25: Circulating fluid discharge pressure sensor failure

<Detection method> This alarm goes off when the pressure detected by the circulating fluid pressure sensor (for discharge) is out of -0.33 to 1.5 MPa range.



1. Check the connection

Check the circulating fluid pressure sensor (for discharge) that is connected to the connector “CN4”, pin numbers 8, 20, and 21 of the main board for the check points shown below:

- (1) The connector “CN4” is securely connected.
- (2) Pin numbers 8, 20, and 21 of the circulating fluid pressure sensor (for discharge) “PS1” are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-72 Check the connection of the circulating fluid pressure sensor

2. Check the input to the circulating fluid pressure sensor.

Check that the power is supplied to the circulating fluid pressure sensor (for discharge).

Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.

Contact the positive probe to the pin number 21 and contact the negative probe to the pin number 20 of the “CN4” connector.

<Normal> Pin number 21 - Pin number 20: Voltage should be 24 VDC.

3. Check the output of the circulating fluid pressure sensor.

Find which has a problem, the circulating fluid pressure sensor (for discharge) or the main board.



Follow the instructions shown below:

- (1) Perform checking with the Thermo-Chiller not operating.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 8 and contact the negative probe to the pin number 20 of the “CN4” connector.
- (4) Check that the voltage between the pin number 8 and the pin number 20 is in the range shown below:

<Normal> Between pin numbers 8 and 20: 1 VDC +/- 0.2 V

AL26: Compressor discharge pressure sensor failure

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for high pressure) is out of the -0.33 to 3.0 MPa range.



1. Check the connection

Check the refrigerant circuit pressure sensor (for high pressure) that is connected to the connector “CN4”, pin numbers 10, 11, and 22 of the main board for the check points shown below:

- (1) The connector “CN4” is securely connected.
- (2) Pin numbers 10, 11, and 22 of the refrigerant circuit pressure sensor (for high pressure) “PS2” are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-73 Check connection of the refrigerant circuit pressure sensor (for high pressure)

2. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor (high pressure).

Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.

Contact the positive probe to the pin number 22 and contact the negative probe to the pin number 10 of the “CN4” connector.

<Normal> Pin number 22 - Pin number 10: Voltage should be 5 VDC +/- 1 V

3. Check the output of the refrigerant circuit pressure sensor.

Find which has a problem, the refrigerant circuit pressure sensor (for high pressure) or the main board.


Follow the instructions shown below:

- (1) Perform checking with the Thermo-Chiller not operating.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 11 and contact the negative probe to the pin number 10 of the “CN4” connector.
- (4) Check that the voltage between the pin number 10 and the pin number 11 is in the range shown below:

<Normal> Between pin numbers 10 and 11: 0.5 to 4.5 VDC +/- 0.2 V

AL27: Compressor intake pressure sensor failure

<Detection method> This alarm goes off when the pressure detected by the refrigerant circuit pressure sensor (for low pressure) is out of the -0.20 to 3.0 MPa range.



1. Check the connection.

Check the refrigerant circuit pressure sensor (for low pressure) that is connected to the connector “CN4”, pin numbers 12, 23, and 24 of the main board for the check points shown below:

- (1) The connector “CN4” is securely connected.
- (2) Pin numbers 12, 23, and 24 of the refrigerant circuit pressure sensor (for low pressure) “PS3” are securely inserted and there is no defective crimping. Check for the correct connection by lightly pulling the cable.




Fig. 4-74 Check connection of the refrigerant circuit pressure sensor (for low pressure)

2. Check for an input to the pressure sensor in the refrigerant circuit.

Check that the power is supplied to the refrigerant circuit pressure sensor (low pressure).

Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.

Contact the positive probe to the pin number 24 and contact the negative probe to the pin number 12 of the “CN4” connector.

<Normal> Pin number 24 - Pin number 12: Voltage should be 5 VDC +/- 1 V

3. Check the output of the refrigerant circuit pressure sensor.

Find which has a problem, the refrigerant circuit pressure sensor (for low pressure) or the main board.


Follow the instructions shown below:

- (1) Perform checking with the Thermo-Chiller not operating.
- (2) Check voltage by contacting the probe of the tester directly to the connector external surface with the “CN4” connector of the main board being inserted.
- (3) Contact the positive probe to the pin number 23 and contact the negative probe to the pin number 12 of the “CN4” connector.
- (4) Check that the voltage between the pin number 23 and the pin number 12 is in the range shown below:

<Normal> Between pin numbers 23 and 12: 0.5 to 4.5 VDC +/- 0.2 V

AL28: Maintenance of pump

<Detection method> This alarm goes off when the accumulated operating time of the pump reaches 8,000 hours or 20,000 hours.



1. For HRS012/018/024/030-A/W-□□-T, HRS050/060-A/W-□□

This alarm is generated every 8,000 hours of accumulated operating time. Be sure to check for leakage around the pump (mechanical seal). However, even in the absence of leakage, the mechanical seal should be replaced as a preventive measure.


The mechanical seal can be replaced up to 2 times. After the accumulated operating time has reached 20,000 hours, the pump itself will need to be replaced.

2. For HRS012/018/024/030-A/W-□□-□ (Other than high pressure pump specification)

This alarm is generated every 20,000 hours of accumulated operating time. Be sure to check for pump errors. However, even in the absence of errors, the pump should be replaced as a preventive measure.


AL29: Maintenance of fan motor [For air-cooled type]

<Detection method> This alarm goes off when the accumulated operating time of the fan motor reaches 20,000 hours.




AL30: Maintenance of compressor

<Detection method> This alarm goes off when the accumulated operating time of the compressor reaches 50,000 hours.




AL31: Contact input1 signal detection

<Detection method> This alarm goes off when a contact input is detected.




AL32: Contact input 2 signal detection

<Detection method> This alarm goes off when a contact input is detected.



AL33: Water leakage

<Detection method> This alarm goes off when the water leakage sensor detects water leakage.



1. Liquid remains on the bottom surface of the water detecting sensor.

There is a leakage sensing part on the bottom surface of the water leakage sensor, and if liquid contacts there, the water leakage sensor operates. Check if there is any liquid sticking to it.

2. Check the water leakage sensor.


Check the operation of the water leakage sensor following the instructions shown below:

- (1) If any liquid adheres on the bottom surface (the sensing part) of the water leakage sensor, wipe it off with waste cloth, etc.
- (2) Check that the indicator of the water leakage sensor turns green.
- (3) Reset the alarm of the Thermo-Chiller and confirm that AL33 is reset.
- (4) Put some water onto the bottom surface of the water leakage sensor to check if AL33 is generated.
- (5) If AL33 is generated when the procedures 1 to 4 are taken, the water leakage sensor is judged to be operating normally.

If the indicator does not turn ON or the indicator light does not change from red, the water leakage sensor operation is judged to be abnormal.


AL34: Electric resistivity/conductivity rise

<Detection method> This alarm goes off when the value detected by the electric resistivity sensor or the electric conductivity sensor exceeds the set value.




AL35: Electric resistivity/conductivity drop

<Detection method> This alarm goes off when the value detected by the electric resistivity sensor or the electric conductivity sensor is lower than the set value.




AL36: Electric resistivity/conductivity sensor error

<Detection method> This alarm goes off when the value detected by the electric resistivity sensor is out of -0.6 to $5.6 \text{ M}\Omega$ range.
The value detected by the electric resistivity sensor is out of -6.2 to $56.2 \text{ M}\Omega$ range.




■ Troubleshooting of errors without alarm generation


● The circulating fluid temperature does not go down



● The circulating fluid temperature does not go up



● The operation panel displays nothing



1. Check the connection.

Check that the connector "CN1" of the display board is connected.




Fig. 4-75 Check connection of the display board

2. Check the DC power supply.

Follow the instructions shown below to check that 24 VDC is being output from the DC power supply.

- (1) With the DC power supply connector "CN2" connected, directly contact the probe of the tester with the pins from outside of the connectors.
- (2) Contact the negative probe to the pin number 1 and contact the positive probe to the pin number 3 of the "CN2" connector, and measure the DC voltage output.
<Normal> 24 VDC is being output.





Fig. 4-76 Check the DC power supply output

● Impossible to operate the Thermo-Chiller with the “RUN/STOP” key on the operation panel



1. “REMOTE” light is ON.

Check if the “REMOTE” light on the operation panel is ON. If it is ON, the Thermo-Chiller is in the remote operation mode.






Fig. 4-77 Check the “REMOTE” light


● Lights on the operation panel or display(s) on the digital display does not operate





● The alarm buzzer does not sound



● Facility water does not flow (for water-cooled type)



● Automatic water fill does not operate (for Option J “Automatic water fill specification”)



4

Maintenance

1. No power supply.

The solenoid valve for automatic water-fill opens when the power supply switch of the Thermo-Chiller is ON. Check that the power is being supplied to the Thermo-Chiller.

2. The water level in the tank is at the “L” level or lower.

Water is filled automatically when the water level in the tank is at “L” level or lower.

3. Check output of the main board.

Check if the power is supplied from the main board to the solenoid valve for automatic water-fill.

- (1) Check it with the water level in the tank at “L” level or lower (the water level that generates “AL01: Low level in tank”).
- (2) With the connector “CN4” of the main board connected, directly contact the probe of the tester with the pins from outside of the connectors.
- (3) Contact the negative probe to the pin number 1 and contact the positive probe to the pin number 13 of the “CN4” connector, and measure the DC voltage output.
<Normal> 24 VDC is being output.




Fig. 4-78 Check the input of the solenoid valve for automatic water-fill

4. Orifice of the automatic water-fill port is clogged.

There is an orifice at the automatic water-fill port. Check that there is no clogging with foreign matter, etc.




Fig. 4-79 Check the orifice for automatic water-fill port

Replacement Parts Chart

An error occurring in one of the corresponding parts is the cause of the generation of the alarm. After checking the piping check sheet on pages 121 and 122, if there doesn't appear to be any problems with the operating environment, conditions, applications, etc., proceed to inspecting the corresponding parts and consider replacement if needed.

Note1) No.		Circulating fluid circuit/Electrical circuit parts															Refrigerant circuit parts									
		1	25	34 to 44	45 to 47	48 to 51	Note2) —	15	15	24	176	177 to 180	56 to 106	30	29	52	115 to 118	119 to 121	122 to 124	125 to 126	136 to 141	143	142 to 144	129 to 132	145 to 146	
Alarm code	Cooling method	Dustproof filter	Level switch	Pump/High pressure pump	Mechanical seal	Fan motor	Bypass piping	Circulating fluid temperature sensor (PT1)	Circulating fluid temperature sensor (PT2)	Circulating fluid discharge pressure sensor	Water leakage sensor	Electric resistivity/conductivity sensor	Main board	Power board	Communication board	Fuse	Compressor	Air-cooled condenser	Water-cooled condenser	Water regulating valve	Heat exchanger	Refrigerant circuit pressure sensor (for low pressure)	Refrigerant circuit pressure sensor (for high pressure)	Electronic expansion valve	Compressor intake temperature sensor (T1)	
AL01	Common		●	●	●								●													
AL02	Air-cooled	Note3) ●		●			●	●					●					●			●	●	●	●		
	Water-cooled			●			●	●					●					●	●	●	●	●	●	●		
AL03	Common	●		●			●						●					●	●	●	●	●	●	●		
AL04	Common			●			●	●					●						●	●	●	●	●	●		
AL05	Common			●			●		●				●											●		
AL06	Common						●			●			●								●					
AL07	Common			●						●	●		●	●												
AL08	Common						●			●			●								●					
AL09	Common			●						●			●													
AL10	Common	●		●			●		●				●					●	●	●	●	●	●	●	●	
AL11	Common			●			●	●					●								●	●	●	●	●	
AL12	Common			●			●						●								●	●	●	●	●	
AL13	Air-cooled	●		●		●	●						●	●				●		●		●	●	●	●	
	Water-cooled			●			●						●	●					●			●	●	●	●	
AL15	Common												●										●	●	●	
AL16	Common												●													
AL17	Common			●			●						●									●	●	●	●	
AL18	Air-cooled	●											●	●				●	●							
	Water-cooled												●	●					●	●						
AL19	Common												●		●											
AL20	Common												●													
AL21	Common												●			●										
AL22	Common							●					●										●	●	●	
AL23	Common								●				●													
AL24	Common												●													
AL25	Common									●			●													
AL26	Common												●										●	●	●	
AL27	Common												●									●				
AL28	Common			●	Note4)																					
AL29	Air-cooled				●	●																				
AL30	Common					●																				
AL31	Common														●											
AL32	Common														●											
AL33	Common										●															
AL34	Common											●														
AL35	Common											●														
AL36	Common											●														

Note 1) Each number corresponds to a number on the replacement parts list on pages 91 to 98.

Note 2) The bypass piping part number is HRS-BP001.

Note 3) The ● mark indicates the part error which is the cause of the generation of the alarm.

Note 4) For HRS012/018/024/030-T (High pressure pump) and HRS050/060

■ Parts Replacement Procedure

Precautions for Whole Work

WARNING



The panel must not be removed or mounted during the operation of the product. While the product is in operation, some parts will get hot or cold and a high voltage power supply will be applied, so there is a risk of burns (or frostbite) and electric shock to the operator.

WARNING



After the product is stopped, there is still a danger of getting burnt (or frostbitten) due to residual heat. Do not start work until the product reaches normal temperature.

WARNING



Unless otherwise specified, be sure to shut off the breaker of the facility power supply (the user's machine power supply).

CAUTION



When the panel is removed or mounted, be sure to wear protective shoes and gloves to prevent injury with the edge of the panel.

● Preparation for work

Remove the panel which covers the part to be replaced and drain the circulating fluid if necessary.

















● Check after work

After the work is completed, check the product can operate normally.

● Tools to be used

Prepare all tools before starting work.








Tools for repairing circulating fluid circuit/electrical circuit

Description	Icon	Content
Spanner/Wrench		Flat size: 9 mm
		Flat size: 8 mm
		Flat size: 10 mm
		Flat size: 17 mm
		Flat size: 21 mm
		Flat size: 24 mm
Drain pan		Height: Max. 100 mm
Nippers		—
Pliers		—
Cross recessed screwdriver (*1)		Total length: Max. 200 mm
		—
flat blade screwdriver (*1)		—
Long-nose plier		—
Hexagon wrench		Flat size: 2 mm
		Flat size: 5 mm
Silicone sealant		Recommended: HRG-S0214 Drying time: 2 hours

(*1) Screwdriver with magnetic tip.

- The following tools are required to perform repair work on the refrigerant circuit.

Tools for repairing refrigerant circuit

No.	Description	Photo	Remarks
1	Charge valve		
2	Refrigerant gauge manifold Charge hose		
3	Vacuum pump		
4	Leak detector Refrigerant gas (R407C)		
5	Scale		
6	Set of brazing tools Refrigerant recovery cylinder		
7	Refrigerant gas collector Charge hose		

● Removal and the mounting of the panel

■ Removal

⚠ CAUTION




Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

HRS□□□-A/W-□



1. Remove the upper panel. (Screw x 2)
2. Remove the side panel. (Screw x each right and left 6)
3. Remove the tank lid.
4. Remove the front panel. (Screw x 3)
 - * Pull out the connector from the display board to remove the front panel.
 After removing the tank lid, remove the O-ring at the side of the fluid inlet with a pair of tweezers.




Removal of panels



HRS050/060-A/W-□



1. Remove the upper panel. (Screw x 6)
2. Remove the side panels after removing the dustproof filter on the top. (Screw x 8 on each side)
* Refer to page 285 for the procedure of removal of the dustproof filter.
3. Remove the tank lid.
4. Remove the front panel. (Screw x 3)
* Pull out the connector from the display board to remove the front panel.
After removing the tank lid, remove the O-ring at the side of the fluid inlet with a pair of tweezers.



Removal of panels

■ Mounting

Panel attachment is performed in inverse order of its removal.



● Discharge of the circulating fluid and facility water

HRS□□□-A/W-□

The following parts requires to discharge the circulating fluid. Follow the procedure below.
Discharge the circulating fluid before the replacement.

Service parts which requires the discharge of the circulating fluid


Description	Part number
Temperature sensor	HRS-S0007
Hose (For standard pump) (For HRS012/018/024)	HRS-S0008
Hose (For standard pump) (For HRS030)	HRS-S0302
Hose (For high pressure pump MT) (For HRS012/018/024)	HRS-S0069
Hose (For high pressure pump MT) (For HRS030)	HRS-S0304
Hose (For high pressure pump T) (For HRS012/018/024)	HRS-S0077
Hose (For high pressure pump T) (For HRS030)	HRS-S0303
Level switch	HRS-S0014
Pump (For 100 V type)	HRS-S0022
Pump (For 200 V type)	HRS-S0066
Pump (For HRS030)	HRS-S0361
High pressure pump (For 100 V type option T)	HRS-S0265
High pressure pump (For 100 V type option MT)	HRS-S0266
High pressure pump (For 200 V type option T) (For HRS012/018/024)	HRS-S0062
High pressure pump (For 200 V type option T) (For HRS030)	HRS-S0299
High pressure pump (For 200 V type option MT) (For HRS012/018/024)	HRS-S0063
High pressure pump (For 200 V type option MT) (For HRS030)	HRS-S0300
Mechanical seal set (For 100 V type option T) (For HRS012/018)	HRS-S0390
Mechanical seal set (For 100 V type option MT) (For HRS012/018)	HRS-S0412
Mechanical seal set (For 200 V type option T, MT)	HRS-S0211
Tank	HRS-S0025
Tank (For automatic water fill)	HRS-S0072
Valve for automatic water fill	HRS-S0071

WARNING



- Stop the customer device and release the residual pressure before discharging the circulating fluid.
- Before discharging the facility water, in case of water-cooled refrigerated type, stop the equipment for the facility water, or stop the facility water circuit to release the residual pressure.

1. Place a container underneath the drain outlet. (The capacity of the container should be approx. 10 L)




Drain the circulating fluid and facility water

2. Remove the tank lid.
3. Remove the drain plug on the drain port on the piping to discharge the fluid.
An O-ring is used for the drain plug. Take care not to damage the O-ring.

4. Confirm that a sufficient amount of the circulating fluid has been drained from the user's machine and piping, and apply air purge from the circulating fluid return port.
5. After discharging the circulating fluid in the tank, refit the drain plug, clip and close the tank lid.

<For the water-cooled refrigeration chiller, drain the facility water according to the procedures from 6 to 8.>

6. Remove the piping of the outlet of the facility water.
7. Remove the dustproof filter to remove the plug. Refer to page 284 for the procedure of removal.




Removal of plug

⚠ CAUTION



Just removing the facility water piping does not discharge the facility water completely. Remove the plug to discharge the facility water.


8. After ensuring that the facility water is completely discharged, apply the sealant tape to the plugs which are removed during step 7 for mounting. Mount the dustproof filter after mounting them. Refer to page 284 for how to mount.
9. Refer to the figure below. Plug to the piping of the product to mount the plug to the piping of the product.



Plug to the piping of the product

■ Option T [High pressure pump]

The ball valve is the drain port. Open the ball valve to discharge the circulating fluid in the same way as procedure 1 to 9. Close the ball valve after discharging the circulating fluid.



Drain the circulating fluid and facility water from the product for option T [High pressure pump]


HRS050/060-A/W-□

The following parts requires to discharge the circulating fluid. Follow the procedure below. Discharge the circulating fluid before the replacement.

Service parts which requires the discharge of the circulating fluid

Description	Part number
Temperature sensor	HRS-S0007
Hose	HRS-S0097
Hose (For HRS060 air-cooled type)	HRS-S0362
Level switch	HRS-S0014
Pump	HRS-S0088
Pump (For option M)	HRS-S0089
Tank	HRS-S0025
Tank (For automatic water fill)	HRS-S0072
Valve for automatic water fill	HRS-S0071
Mechanical seal set	HRG-S0211


1. Place a container underneath the drain outlet. (The capacity of the container should be approx. 10 L)



Drain the circulating fluid and facility water

2. Remove the tank lid.
3. Open the ball valves at the drain port and drain the fluid.

4. Confirm that a sufficient amount of the circulating fluid has been drained from the user's machine and piping, and apply air purge from the circulating fluid return port.
 5. After the circulating fluid finishes has drained from the tank, close the ball valve at the drain port and put the tank lid back.
- <For the water-cooled refrigeration chiller, drain the facility water according to the procedures from 6 to 8.>**
6. Remove the piping of the outlet of the facility water.
 7. Remove the dustproof filter to remove the plug. Refer to page 285 for the procedure of removal.




Removal of the plug

⚠ CAUTION



Just removing the facility water piping does not discharge the facility water completely. Remove the plug to discharge the facility water.

8. After ensuring that the facility water is completely discharged, apply the sealant tape to the plugs which are removed during step 7 for mounting.
Mount the dustproof filter after mounting them. Refer to page 285 for how to mount.
9. Refer to the figure below. Plug to the piping of the product to mount the plug to the piping of the product.



Plug to the piping of the product


Check After Work

After the work is completed, check the product can operate normally.

Starting the product

Press the [RUN/STOP] key on the operation panel.


- The [RUN] lamp lights up (in green) and the product starts running.
- The circulating discharge temperature (PV) is controlled to the set temperature (SV).



Starting the product

Stopping the product

1. Press the [RUN/STOP] key on the operation panel.
 - The [RUN] lamp on the operation panel flashes green at 1 second intervals, and continues operation to prepare to stop.
 - After approx. 15 seconds, the [RUN] lamp goes off and the product stops.



Stopping the product

Check items after starting

Check the following items after starting the product.

⚠ WARNING



When an Alarm is seen, press the [STOP] key and then turn off the power supply switch to stop the product, and turn off the breaker of the user's power supply to isolate the product.

- There is no leakage from piping.
- There is no drain of circulating fluid from the drain port.
- The circulating fluid pressure is within the specified range.
- The tank level is within the specified range.

■ Replacement Procedure

● Replacement of temperature sensor (PT1)

HRS□□□-A/W-□



Part number of service parts (Temperature sensor)

Description	Part number
Temperature sensor	HRS-S0007

⚠ WARNING




Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

⚠ CAUTION


- When the temperature sensor is removed or mounted, it is turned using a spanner/wrench. At that time, be careful not to twist its cable. Otherwise, it can break.
- The product must not be operated until the liquid gasket is completely hardened. Otherwise, it can cause fluid leakage.

■ Removal

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. Remove the connector (PT1) from the main board.
4. Remove the temperature sensor (PT1).



Removal of temperature sensor (PT1)



Removal of temperature sensor (PT1)

■ Mounting

1. Apply the liquid gasket to the threads of the temperature sensor and mount the temperature sensor using a spanner/wrench.

Tips

Do not apply the liquid gasket to the first thread. Otherwise, the liquid gasket will spread to the circulating circuit and cause the product to fail. To prevent dust from getting caught in the threads, check there is no dust stuck to the threads before the screw is mounted.

2. Put through the electric wire from the grommet to the inside of the electric equipment.
3. Mount the connector (PT1) of the temperature sensor.
4. Mount the upper panel and the right panel in reversed order of removal. (Fixing screw x 8)



● Replacement of temperature sensor (PT2)

HRS□□□-A/W-□



Part number of service parts (Temperature sensor)

Description	Part number
Temperature sensor	HRS-S0007

⚠ WARNING




Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

⚠ CAUTION


- When the temperature sensor is removed or mounted, it is turned using a spanner/wrench. At that time, be careful not to twist its cable. Otherwise, it can break.
- The product must not be operated until the liquid gasket is completely hardened. Otherwise, it can cause fluid leakage.

■ Removal

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring the removal and the mounting of the panel.
3. Remove the connector (PT2) from the main board.
4. Remove the temperature sensor (PT2).



Removal of temperature sensor (PT2)



Removal of temperature sensor (PT2)

■ Mounting

1. Apply the liquid gasket to the threads of the temperature sensor and mount the temperature sensor using a spanner/wrench.

Tips

Do not apply the liquid gasket to the first thread. Otherwise, the liquid gasket will spread to the circulating circuit and cause the product to fail. To prevent dust from getting caught in the threads, check there is no dust stuck to the threads before the screw is mounted.

2. Put through the electric wire from the grommet to the inside of the electric equipment.
3. Mount the connector (PT2) of the temperature sensor.
4. Mount the upper panel and the left panel in reversed order of removal. (Fixing screw x 8)



● Replacement of pump (For standard pump)

■ Removal

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.


HRS□□□-A/W-□



Part number of service parts (Pump (For standard type))

Description	Part number
Pump (For 100 V type)	HRS-S0022
Pump (For 200 V type)	HRS-S0066
Pump (For HRS030)	HRS-S0361

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. Remove the support panel. (Screw x 4)
4. Remove the connector of the pump cable from the power board.
* For the HRS030, cut the cable tie of the pump cable fixed to the fan motor bracket.
5. Place the drain pan beneath fitting A. Remove fitting A to discharge water in the pump.
6. Remove the clip mounted to fitting B to remove fitting B.
7. Remove bolts to remove the pump. (Bolt x 4)
8. Remove the ground cable (G4) attached to the pump. (Screw x 1)



Removal of pump




HRS050/060-A/W-20-□



Part number of service parts (Pump)

Description	Part number
Pump	HRS-S0088
Pump (For option M)	HRS-S0089

1. Discharge the circulating fluid referring to the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring to the removal and the mounting of the panel.
3. Remove the band. (3 locations)
4. Remove the connector of the pump cable from the power board.
5. Remove the cable from the condenser.
6. Remove the ground cable (G3) attached to the pump. (Screw x 1)
7. Remove the hose attached to the pump. (3 pcs.)
8. Remove the condenser. (Screw x 1)
9. Remove the pump. (Screw x 4)




Removal of pump

■ Mounting

HRS□□□-A/W-□

1. Mount O-ring to the pump. (2 O-rings)
* Size is different. (Refer to the figure below.)



Mount the O-ring

2. Connect the ground cable (G4).
* There are two washers inside. Hold the ground cable between them to fix it to the pump.



3. Insert the pump to the notch of the base. Hand tighten the screw to the end. When the position is fixed, tighten with a screwdriver. (Bolt x 2)



4. Mount fitting to two locations.
* Apply grease.
5. Put the pump connector through the grommet from the bottom in order to connect to the power board.
* For the HRS030, fix the pump cable on the fan motor bracket with a cable tie to prevent the pump cable from touching the fan.

6. Mount the support panel. (Screw x 4)



(2 pcs. of the left side)



(2 pcs. of the drain port)

7. Mount the upper panel and the right panel in reversed order of removal.

HRS050/060-A/W-20-□

1. Mount the pump. (Screw x 4)




2. Mount the hose. (2 pcs.)

Tightening torque of hose between pump and circulating fluid outlet:




3. Connect the ground cable (G3). (Screw x 1)
4. Mount cable to the condenser.



Mount the condenser

5. Mount the cap and bracket to the condenser, and it mount the electrical equipment panel. (Screw x 1)



Mount the condenser

6. Mount pump cable to the power board.
7. Mount the band. (3 locations)
8. Mount the upper panel and the right panel in reversed order of removal.

● Replacement of high pressure pump

■ Removal

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.


HRS□□□-A/W-10-T



Part number of service parts (High pressure pump)

Description	Part number
High pressure pump (For 100 V type option T)	HRS-S0265
High pressure pump (For 100 V type option MT)	HRS-S0266

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. Remove the support panel. (Screw x 2)
4. Remove the connector of the pump cable from the power board.
5. Remove the ground cable (G4) attached to the pump. (Screw x 1)
6. Remove the hose attached to the pump. (2 pcs.)
7. Remove the pump. (Screw x 4)



Removal of high pressure pump


HRS□□□-A/W-20-T



Part number of service parts (High pressure pump)

Description	Part number
High pressure pump (For 200 V type option T) (HRS012/018/024)	HRS-S0062
High pressure pump (For 200 V type option T) (HRS030)	HRS-S0299
High pressure pump (For 200 V type option MT) (HRS012/018/024)	HRS-S0063
High pressure pump (For 200 V type option MT) (HRS030)	HRS-S0300

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. Remove the support panel. (Screw x 2)
4. Remove the connector of the pump cable from the power board.
5. Remove the cable from the condenser.
6. Remove the ground cable (G4) attached to the pump. (Screw x 1)
* For the HRS030, cut the cable tie of the pump cable fixed to the fan motor bracket.
7. Remove the hose attached to the pump. (2 pcs.)
8. Remove the condenser. (Screw x 1)
9. Remove the pump. (Screw x 4)



Removal of high pressure pump

■ Mounting

HRS□□□-A/W-10-T

1. Mount the pump. (Screw x 4)



2. Mount the hose. (2 pcs.)

Tightening torque of hose between high pressure pump and circulating fluid outlet:



3. Connect the ground cable (G4). (Screw x 1)

4. Mount pump cable to the power board.


5. Mount the support panel. (Screw x 2)



6. Mount the upper panel and the right panel in reversed order of removal.

HRS□□□-A/W-20-T

1. Mount the cap and bracket to the condenser, and it mount the electrical equipment panel. (Screw x 1)



Mount the condenser

2. Mount the pump. (Screw x 4)



3. Mount the hose. (2 pcs.)

Tightening torque of hose between high pressure pump and circulating fluid outlet:



4. Connect the ground cable (G4). (Screw x 1)

5. Mount cable to the condenser.

6. Mount pump cable to the power board.

* For the HRS030, fix the pump cable on the fan motor bracket with a cable tie to prevent the pump cable from touching the fan.

7. Mount the support panel. (Screw x 2)



8. Mount the upper panel and the right panel in reversed order of removal.

● Replacement of mechanical seal set

WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.



HRS0□□-A/W-10- (M) T (For high pressure pump 100 V type)

Part number of service parts (Mechanical seal set)

Description	Part number
Mechanical seal set [For 100 V type option T]	HRS-S0390
Mechanical seal set [For 100 V type option MT]	HRS-S0412

HRS□□□-A/W-20- (M) T (For high pressure pump 200 V type) HRS050/060-A/W-20- (M)

Part number of service parts (Mechanical seal set)

Description	Part number
Mechanical seal set [For 200 V type option T, MT]	HRG-S0211

O-ring size

These service parts include three of O-rings.

Please use A for HRS012/018/024/030 series (Only the high pressure pump).


O-ring size

Chiller model	O-ring type	Remarks
HRS012/018/024/030 series	A	Only the high pressure pump (Option T)
HRS050/060 series	B	—
HRG010 series	C	—

* For details, refer to page 409.

Internal construction of pump


The internal construction of the pump is as follows.



Internal construction of pump

■ Removal

1. Remove the high pressure pump referring the replacement of high pressure pump
2. Before disassembling the pump, place a "check mark" on the body, cover, and the motor.



3. Remove the body. (Hexagon socket head bolt x 3)
Place the drain pan under the body and drain water from the pump.
4. Remove the impeller and spring.

Tips

There is a danger of parts popping out. If the impeller gets stuck and cannot be removed, screw two screws of M6 x 50 mm or larger into the two thread holes of the impeller to pull out the impeller.


5. Remove the mechanical seal, O-ring and cover all in one.

Tips


If the cover cannot be removed, insert the blade of the spanner/wrench between the cover and motor and bring it up.

6. Remove the deflector rubber.

HRS012/018/024



HRS050/060



Removal of mechanical seal set

■ Mounting

1. Mount the deflector rubber to the motor shaft.
2. Mount the O-ring and mechanical seals (2 pcs.) onto the cover and onto the motor shaft.

Tips

Push the mechanical seal to the end.
The mounting direction of the cover is specified. Pay attention to the direction.
Align "check marks." (See How to Removal 2.)

3. Mount the spring and impeller onto the motor shaft. (Set screw x 2)

Tips



The direction of the spring is determined by the key of the impeller.

4. Mount the body onto the motor. (Hexagon socket head bolt x 3)
5. Remove the tape on the back of the motor. Insert the flat blade driver to rotate the motor shaft and check if the impeller rotates smoothly. Re-tape after checking. (Refer to the rotation verification of impeller below.)

Tips

The motor shaft does not rotate smoothly when the impeller comes into contact with the body or cover. Remove the body, and adjust the impeller.

6. Mount the high pressure pump referring the replacement of high pressure pump.



Rotation verification of impeller

● Replacement of fan

■ Removal

WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

HRS012/018/024-A□-□



Part number of service parts (Fan)


Description	Part number
Fan (For 100 V type)	HRS-S0023
Fan (For 200 V type) (HRS012/018/024)	HRS-S0067
Fan (For 200 V type) (HRS030)	HRS-S0301

1. Remove the upper panel and the panels on both sides referring the removal and the mounting of the panel.
2. Remove the fan motor pin from the connector of the compressor cable. (2 pcs.)

Tips

Use VLJ-20 of J.S.T. Mfg. Co., Ltd for removing pins.
Our part no. : HRS-S0055

3. Remove the ground wire (G5). (Screw x 1)
4. Remove the condenser. (Screw x 1)
5. Remove the fan. (Screw x 4)
 - * For the HRS030, cut the cable ties of the pump cable (1 place) and the compressor cable (5 places) fixed to the fan motor bracket.



Removal of fan

HRS050/060-A-20-□



Part number of service parts (Fan)


Description	Part number
Fan	HRS-S0099

1. Remove the upper panel and the panels on both sides referring to the removal and the mounting of the panel.
2. Remove the band. (3 locations)
3. Remove the fan motor pin from the connector of the compressor cable. (2 pcs.)
Insert the fan motor cable into the compressor cable connector.
(Fan ①: No. 1 and No. 3; Fan ②: No. 2 and No. 4)

Tips

Use VLJ-20 of J.S.T. Mfg. Co., Ltd for removing pins.
Our part no.: HRS-S0055

4. Remove the ground wire (Fan ①: G4, Fan ②: G5) mounted on the fan to be replaced. (Screw x 1)
5. Remove the condenser. (Screw x 1)
6. Remove the fan. (Screw x 4)



Removal of fan

■ Mounting

HRS012/018/024-A□-□

1. Mount the fan. (Screw x 4)



2. Mount the condenser. Then, mount the fan motor cable. (Screw x 1)
Connect the pink cable to the left, black cable to the right.



3. Insert the fan motor cable to the compressor cable connector.



Black: No. 1 Blue: No. 3
* BK is black, BL is blue.

4. Mount the ground wire (G5). (Screw x 1)



* For the HRS030, fix the pump cable (1 place) and the compressor cable (5 places) to the fan motor bracket with cable ties.

5. Mount the upper panel and the panels on both sides in reversed order of removal.

HRS050/060-A-20-□


1. Mount the fan. (Screw x 4)



2. Mount the condenser. Then, mount the fan motor cable. (Screw x 1)
Connect the pink cable to the left, black cable to the right.



3. Insert the fan motor cable to the compressor cable connector.



4. Mount the ground wire (Fan ①: G4, Fan ②: G5). (Screw x 1)



5. Mount the upper panel and the panels on both sides in reversed order of removal.

● Replacement of level switch

■ Removal

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

HRS012/018/024-A/W-□



Part number of service parts (Level switch)


Description	Part number
Level switch	HRS-S0014

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring the removal and the mounting of the panel.
3. Remove the level switch pin [LS1] (two red lines) from the main board.

Tips

Use "57031-6000" of MOLEX for removing.
Our part no.: HRS-S0056

4. Remove the nut with a spanner/wrench.
5. Remove the lid of the tank and take out the level switch from the tank.



Removal of level switch

HRS050/060-A/W-20-□



Part number of service parts (Level switch)


Description	Part number
Level switch	HRS-S0014

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring the removal and the mounting of the panel.
3. Remove the level switch pin [LS1] (two red lines) from the main board.

Tips

Use "57031-6000" of MOLEX for removing.
Our part no.: HRS-S0056

4. Remove the nut with a spanner/wrench.
5. Remove the lid of the tank and take out the level switch from the tank.




Removal of level switch

■ Mounting

HRS012/018/024-□□-□□

HRS050/060-□□-□□

1. Mount the marking tie at approx. 40 ±5 mm away from the cable end.
2. Remove the nut of the level switch.
3. Mount the nut after mounting the level switch to the tank. (Nut x 1)




Mount of level switch

Tips

The marking part of the level switch faces upward.

4. Put the level switch cable [LS1] (2 pcs.) through the grommet. Insert the pin to the connector. (No. 2 & No. 13)



Location to mount the connector

Tips

It does not matter which connector [LS1] is mounted to which socket.

5. Mount the upper panel and the side panel on the left in reversed order of removal.
6. Mount the lid of the tank.

● Replacement of pressure sensor

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024-□□-□□


HRS050/060-□□-□□




Part number of service parts (Pressure sensor)

Description	Part number
Pressure sensor (For circulating fluid)	HRS-S0011

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the connector of the pressure sensor cable (PS1) from the pressure sensor.
3. Remove the pressure sensor.



Removal of pressure sensor



Removal of pressure sensor

■ Mounting

HRS012/018/024/030-□□-□□

HRS050/060-□□-□□

1. Apply a liquid gasket to the threads of the pressure sensor and mount it.
2. Mount the connector of the pressure sensor cable (PS1) to the pressure sensor.
3. Mount the upper panel and the side panel on the right in reversed order of removal.

● Replacement of dustproof filter

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-□□-□□

HRS050/060-□□-□□




Part number of service parts (Dustproof filter)


Description	Part number
Dustproof filter	HRS-S0001

1. Pull out the lower part of the side surface of the dustproof filter.
2. When the magnet comes off, pull the dustproof filter downwards to remove. Care should be taken not to deform or scratch the air-cooled condenser.


1



2



Removal of dustproof filter



Removal of dustproof filter

■ Mounting

HRS012/018/024/030-□□-□□

HRS050/060-□□-□□

1. Mount the dustproof filter in reversed order of removal.

● Replacement of front panel

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-□



Part number of service parts (Front panel)

From production in March 2015 (After serial No. TQ***)

Description	Part number
Front panel	HRS-S0519

Until production in February 2015 (Serial No. TP*** or earlier)

Description	Part number
Front panel A	HRS-S0006
Front panel B	HRS-S0005


* For serial No., refer to Product label in the Operation Manual.

From production in March 2015 (After serial No. TQ***)

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the display board.

Tips


Push the claws A at the back of the front panel with both thumbs to open the front panel. Pull the display board with fingers to remove the display board.



Removal of front panel


Until production in February 2015 (Serial No. TP*** or earlier)

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the front panel A. (Screw x 4)



Removal of front panel A

3. Remove the front panel B. (Screw x 4)



Removal of front panel B

HRS050/060-A/W-20-□□-□□




Part number of service parts (Front panel A)

Description	Part number
Front panel A	HRS-S0006

Part number of service parts (Front panel B)


Description	Part number
Front panel B	HRS-S0005

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the front panel A. (Screw x 4)



Removal of front panel A

3. Remove the front panel B. (Screw x 4)



Removal of front panel B

■ Mounting


HRS012/018/024/030-A/W-□

From production in March 2015 (After serial No. TQ***)

1. Mount the display board.

Tips

Align with the 4 guides at the back of the front panel, set the end of the display board to the 2 claws B. Pull the display board forward while pushing the 2 claws A out with both thumbs until the claws click.



Mounting of front panel

2. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

Until production in February 2015 (Serial No. TP*** or earlier)

1. Mount the front panel B. (Screw x 4)

Tips

Mount front panel B aligning with holes at the center.

2. Mount the front panel A. (Screw x 4)

Tips

Mount front panel A aligning with holes at the center.

3. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

HRS050/060-A/W-20-□

1. Mount the front panel B. (Screw x 4)

Tips

Mount front panel B aligning with holes at the center.

2. Mount the front panel A. (Screw x 4)

Tips

Mount front panel A aligning with holes at the center.

3. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

● Replacement of tank

WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-□

HRS050/060-A/W-20-□



Part number of service parts (Tank)





Description	Part number
Tank	HRS-S0025

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
3. Remove the hose clamp and remove hose A and hose B.
4. Remove the level switch pin [LS1] (two red lines) from the main board.

Tips

Use "57031-6000" of MOLEX for removing.
Our part no.: HRS-S0056

5. Remove the tank.



Removal of tank

HRS012/018/024/030-A/W-J (With automatic water fill function)
HRS050/060-A/W-20-J



Part number of service parts (Tank (For automatic water fill))



Description	Part number
Tank (For automatic water fill)	HRS-S0072

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
3. Remove the hose clamp and remove hoses. (4 pcs.)
4. Remove the level switch pin [LS1] (two red lines) from the main board.

Tips

Use "57031-6000" of MOLEX for removing.
Our part no.: HRS-S0056

5. Remove the tank.




Removal of tank (With automatic water fill function)

■ Mounting

HRS012/018/024/030-A/W-□


HRS050/060-A/W-20-□

1. Install the tank.
2. Assemble the fitting mounted to the tank and hose A.



Hose A attaching

3. Mount the hose B.
4. Put the level switch cable [LS1] (2 pcs.) through the grommet. Insert the pin to the connector. (No. 2 & No. 13)



Location to mount the connector


Tips

It does not matter which connector [LS1] is mounted to which socket.

5. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.
6. Mount the tank lid.


HRS012/018/024/030-A/W-□□-J (With automatic water fill function) HRS050/060-A/W-20-J

1. Install the tank.
2. Mount the hoses and fitting to the tank. (4 pcs.)



Hoses attaching

3. Put the level switch cable [LS1] (2 pcs.) through the grommet. Insert the pin to the connector. (No. 2 & No. 13)



Location to mount the connector

Tips

It does not matter which connector [LS1] is mounted to which socket.

4. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.
5. Mount the tank lid.

● Replacement of inlet socket

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal


HRS012/018/024/030-A/W-□



Part number of service parts (Inlet socket)

Description	Part number
Inlet socket	HRS-S0021

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the connector. (7 locations)
3. Remove the plate. (Screw x 4)
4. Remove the inlet socket. (Screw x 2)




Removal of inlet socket

■ Mounting

HRS012/018/024/030-A/W-□

1. Mount the inlet socket. (Screw x 2)
* Be careful of the mounting direction.




Mounting direction in inlet socket

2. Mount the plate. (Screw x 4)



3. Insert wiring to terminal A-A', B-B', [G1] to terminal C, [LOAD] to terminal D.



Entry of connector

4. Mount the upper panel and the side panel on the right in reversed order of removal.

● Replacement of power switch

WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal


HRS012/018/024/030-A/W-□



Part number of service parts (Power switch)

Description	Part number	Applicable models
Power switch (For 10 A type)	HRS-S0020	· For 200 V type (Except high pressure pump)
Power switch (For 15 A type)	HRS-S0070	· For 100 V type · For high pressure pump 200 V type

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the connector. (7 locations)
3. Remove the plate. (Screw x 4)
4. Remove the power switch.




Removal of power switch

■ Mounting

HRS012/018/024/030-A/W-□

1. Mount the power switch.
* Be careful of the mounting direction.




Mounting direction in power switch

2. Mount the plate. (Screw x 4)



3. Insert wiring to terminal A-A', B-B', [G1] to terminal C, [LOAD] to terminal D.



Entry of connector

4. Mount the upper panel and the side panel on the right in reversed order of removal.

● Replacement of DC power supply

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS□□□-A/W-□



Part number of service parts (DC power supply)

Description	Part number
DC power supply	HRS-S0016





HRS050/060-A/W-20-□



Part number of service parts (DC power supply)

Description	Part number
DC power supply	HRS-S0087

1. Remove the upper panel, the side panel on the right and the front panel referring the removal and the mounting of the panel.
2. Remove the connector of DC power supply. (2 locations)
3. Hold the spacer (4 locations) to remove DC power supply.



Removal of DC power supply

■ Mounting

HRS012/018/024/030-A/W-□

HRS050/060-A/W-□

1. Mount the DC power supply. (Spacer x 4)
2. Mount the connector (2 locations).
3. Mount the upper panel, the side panel on the right and the front panel in reversed order of removal.

● Replacement of main board & communication board

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-□



Part number of service parts (Main board and communication board)

Description	Part number	Applicable models	Remarks
Main board*	HRS-S0033	HRS012-A-10	—
	HRS-S0282	HRS012-A-10-T	—
	HRS-S0283	HRS012-A-10-MT	—
	HRS-S0034	HRS012-W-10	—
	HRS-S0284	HRS012-W-10-T	—
	HRS-S0285	HRS012-W-10-MT	—
	HRS-S0035	HRS018-A-10	—
	HRS-S0286	HRS018-A-10-T	—
	HRS-S0287	HRS018-A-10-MT	—
	HRS-S0036	HRS018-W-10	—
	HRS-S0288	HRS018-W-10-T	—
	HRS-S0289	HRS018-W-10-MT	—
	HRS-S0037	HRS012-A-20	—
	HRS-S0078	HRS012-A-20-G	—
	HRS-S0038	HRS012-A-20-T	—
	HRS-S0079	HRS012-A-20-GT	—
	HRS-S0039	HRS012-A-20-MT	—
	HRS-S0080	HRS012-A-20-GMT	—
	HRS-S0040	HRS012-W-20	—
	HRS-S0041	HRS012-W-20-T	—
	HRS-S0042	HRS012-W-20-MT	—
	HRS-S0043	HRS018-A-20	—
	HRS-S0081	HRS018-A-20-G	—
	HRS-S0044	HRS018-A-20-T	—
	HRS-S0082	HRS018-A-20-GT	—
	HRS-S0045	HRS018-A-20-MT	—
	HRS-S0083	HRS018-A-20-GMT	—
	HRS-S0046	HRS018-W-20	—
	HRS-S0047	HRS018-W-20-T	—
	HRS-S0048	HRS018-W-20-MT	—
	HRS-S0049	HRS024-A-20	—
	HRS-S0084	HRS024-A-20-G	—
	HRS-S0050	HRS024-A-20-T	—
	HRS-S0085	HRS024-A-20-GT	—
	HRS-S0051	HRS024-A-20-MT	—
	HRS-S0086	HRS024-A-20-GMT	—
	HRS-S0052	HRS024-W-20	—
	HRS-S0053	HRS024-W-20-T	—
	HRS-S0054	HRS024-W-20-MT	—
	HRS-S0290	HRS030-A-20	—
	HRS-S0291	HRS030-A-20-T	—
	HRS-S0292	HRS030-A-20-MT	—
	HRS-S0293	HRS030-W-20	—
	HRS-S0294	HRS030-W-20-T	—
	HRS-S0295	HRS030-W-20-MT	—
	HRS-S0134	HRS012,018,024/030 series	Be sure to perform an initial setting of the main board.
Communication board	HRS-S0018	—	—

* The main board has to be selected either one of options listed. HRS-S0033 to HRS-S0054 and HRS-S0078 to HRS-S0086 and HRS-S0282 to HRS-S0295 are preset their initial setting. HRS-S0134 is universal part so it needs initial setting after replace the board.

HRS050/060-A/W-20-□




Part number of service parts (Main board and communication board)


Description	Part number	Applicable models	Remarks
Main board*	HRS-S0090	HRS050-A-20	—
	HRS-S0091	HRS050-W-20	—
	HRS-S0296	HRS060-A-20	
	HRS-S0297	HRS060-W-20	
	HRS-S0135	HRS050/060 series	Be sure to perform an initial setting of the main board.
Communication board	HRS-S0018	—	—

* The main board has to be selected either one of options listed. HRS-S0090 and HRS-S0091, S0296, S0297 are preset their initial setting. HRS-S0135 is universal part so it needs initial setting after replace the board.

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the connector of main board and communication board. (7 locations)
3. Remove the screw (2 locations) of communication board.
4. Hold the spacer (6 locations) to remove main board and communication board. (Refer to the figure on page 302.)
5. Remove the communication board from main board.



Removal of main board & communication board



Removal of main board & communication board

■ Mounting

HRS012/018/024/030-A/W-□

HRS050/060-A/W-20-□

1. Insert the main board to the communication board.
2. Mount the main board and communication board. (Spacer x 6)
3. Mount the screw of communication board. (2 locations)



4. Mount the connector of the main board and the communication board. (7 locations)
5. Mount the upper panel and the side panel on the right in reversed order of removal.
* When replacing the main control board, HRS-S0134, be sure to perform an initial setting of the main board. Please refer to the initial setting procedure attached to the service parts.

● Replacement of power board

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-□



HRS050/060-A/W-20-□




Part number of service parts (Power board)

Description	Part number
Power board	HRS-S0019

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the connector of power board. (5 locations)
3. Remove the power board. (Screw x 2)





■ Mounting

HRS012/018/024/030-A/W-□

HRS050/060-A/W-20-□

1. Mount the power board. (Screw x 2)



2. Mount the connector of power board. (5 locations)
3. Mount the upper panel and the side panel on the right in reversed order of removal.

● Replacement of display board

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS□□□-A/W-□



Part number of service parts (Display board)

From production in March 2015 (After serial No. TQ***)

Description	Part number
Display board	HRS-S0520

Until production in February 2015 (Serial No. TP*** or earlier)

Description	Part number
Display board	HRS-S0017


* For serial No., refer to Product label in the Operation Manual.

From production in March 2015 (After serial No. TQ***)

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the display board.

Tips


Push the claws A at the back of the front panel with both thumbs to open the front panel. Pull the display board with fingers to remove the display board.



Removal of display board

Until production in February 2015 (Serial No. TP*** or earlier)

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the display board. (Screw x 2)



Removal of display board


HRS050/060-A/W-20-□



Part number of service parts (Display board)

Description	Part number
Display board	HRS-S0017

1. Remove the upper panel, the panels on both sides and the front panel referring the removal and the mounting of the panel.
2. Remove the display board. (Screw x 2)



Removal of display board

■ Mounting


HRS012/018/024/030-A/W-□

From production in March 2015 (After serial No. TQ***)

1. Mount the display board.

Tips

Align with the 4 guides at the back of the front panel, set the end of the display board to the 2 claws B. Pull the display board forward while pushing the 2 claws A out with both thumbs until the claws click.



Mount the display board

2. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

Until production in February 2015 (Serial No. TP*** or earlier)

1. Mount the display board. (Screw x 4)



Tips

Mount the display board using the notch.

2. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

HRS050/060-A/W-20-□

1. Mount the display board. (Screw x 4)

**Tips**

Mount the display board using the notch.

2. Mount the upper panel, the panels on both sides and the front panel in reversed order of removal.

● Replacement of hose

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-□




Part number of service parts (Hose)

Description	Part number
Hose	HRS-S0008
Hose (For HRS030)	HRS-S0302
Hose (For high pressure pump MT)	HRS-S0069
Hose (For high pressure pump MT) (For HRS030)	HRS-S0304
Hose (For high pressure pump T)	HRS-S0077
Hose (For high pressure pump T) (For HRS030)	HRS-S0303

● Between tank-pump


1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the panels on both sides referring the removal and the mounting of the panel.
3. Remove the hose clamp and remove the hose.
 - * For the HRS030, cut the cable tie which fixes the hose between the pump and circulating fluid outlet port.



Removal of hose (Between tank-pump)

● Between tank-heat exchanger


1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring the removal and the mounting of the panel.
3. Remove the hose clamp on the tank side. (2 locations)
4. Remove the tank.
5. Remove the hose clamp on the heat exchanger side and remove the hose.



Removal of plastic hose (Between tank-heat exchanger)

● Between pump-circulating fluid outlet

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. Remove the hose clamp and remove hose.
 - * For the HRS030, cut the cable tie which fixes the hose between the pump and tank.




Removal of plastic hose (Between pump-circulating fluid outlet)

High pressure pump

● Between tank-pump


1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the panels on both sides referring the removal and the mounting of the panel.
3. Remove the hose clamp and remove hose.
 * For the HRS030-A, cut the cable tie which fixes the hose between the pump and circulating fluid outlet port.



Removal of plastic hose (Between tank-pump)

● Between tank-heat exchanger


4. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
5. Remove the upper panel and the side panel on the left referring the removal and the mounting of the panel.
6. Remove the hose clamp on the tank side. (2 locations)
7. Remove the tank.
8. Remove the hose clamp on the heat exchanger side and remove the hose.



Removal of plastic hose (Between tank-heat exchanger)

● Between pump-circulating fluid outlet

1. Discharge the circulating fluid referring the discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
3. The hose fitting is loosened and remove the hose.
 - * For the HRS030-A, cut the cable tie which fixes the hose between the tank and pump.
 - * For the HRS030-W, cut the cable tie fixed on the electrical panel.



Removal of plastic hose (Between pump-circulating fluid outlet)

HRS050/060-A/W-20-□




Part number of service parts (Hose)

Description	Part number
Hose	HRS-S0097
Hose (For HRS060)	HRS-S0362

● Between tank-pump


1. Discharge the circulating fluid referring to discharge of the circulating fluid and facility water.
2. Remove the upper panel and the panels on both sides referring to removal and the mounting of the panel.
3. Remove the hose clamp and remove the hose.



Removal of hose (Between tank-pump)

● Between tank-union tee


1. Discharge the circulating fluid referring to discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring to removal and the mounting of the panel.
3. Remove the hose clamp on the tank side. (2 locations)
4. Remove the tank.
5. Remove the hose clamp on the union tee side and remove the hose.



Removal of hose (Between tank-union tee)

● Between heat exchanger-union tee


1. Discharge the circulating fluid referring to discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the left referring to removal and the mounting of the panel.
3. Remove the hose clamp and remove hose.



Removal of plastic hose (Between heat exchanger-union tee)

● Between pump-circulating fluid outlet


1. Discharge the circulating fluid referring to discharge of the circulating fluid and facility water.
2. Remove the upper panel and the side panel on the right referring to removal and the mounting of the panel.
3. The hose fitting is loosened and remove the hose.



Removal of hose (Between pump-circulating fluid outlet)

● Between pump-union tee

1. Discharge the circulating fluid referring to discharge of the circulating fluid and facility water.
2. Remove the upper panel and the panels on both sides referring to removal and the mounting of the panel.
3. Remove the hose clamp and remove hose.



Removal of plastic hose (Between pump-union tee)

■ Mounting

HRS012/018/024/030-A/W-□

⚠ CAUTION

Check the hose is not twisted after connecting.

■ Mounting (Between tank-pump)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
* For the HRS030, fix the hose between the pump and circulating fluid outlet port with a cable tie to prevent the hose between the tank and pump from touching the fan motor bracket.
3. Mount the upper panel and the panels on both sides in reversed order of removal.

■ Mounting (Between tank-heat exchanger)

1. Mount the hose on the tank using the hose clamp.
2. Install the tank.
3. Mount the hose on the heat exchanger.
4. Hold the hose with the hose clamp. (3 locations)
5. Mount the upper panel and the side panel on the left in reversed order of removal.

■ Mounting (Between pump-circulating fluid outlet)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
 - * For the HRS030, fix the hose between the tank and pump with a cable tie to prevent the hose between the pump and circulating fluid outlet port from touching the fan motor bracket.
3. Mount the upper panel and the side panel on the right in reversed order of removal.

High pressure pump

CAUTION

Check the hose is not twisted after connecting.

■ Mounting (Between tank-pump)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
3. Mount the upper panel and the panels on both sides in reversed order of removal.
 - * For the HRS030-A, fix the hose between the pump and circulating fluid outlet port with a cable tie to prevent the hose between the tank and pump from touching the fan motor bracket.

■ Mounting (Between tank-heat exchanger)

1. Mount the hose on the tank using the hose clamp.
2. Install the tank.
3. Mount the hose on the heat exchanger.
4. Hold the hose with the hose clamp. (3 locations)
5. Mount the upper panel and the side panel on the left in reversed order of removal.

■ Mounting (Between pump-circulating fluid outlet)

1. Mount the hose fitting to the hose bracket.



2. Mount the upper panel and the side panel on the right in reversed order of removal.
 - * For the HRS030-A, fix the hose between the tank and pump with a cable tie to prevent the hose between the pump and circulating fluid outlet port from touching the fan motor bracket.
 - * For the HRS030-W, fix the cable tie on the electrical panel.

HRS050/060-A/W-20-□

CAUTION

Check the hose is not twisted after connecting.

■ Mounting (Between tank-pump)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
* For the HRS060, bind heat insulation tube around the hose and fix it with a cable tie to prevent it from touching the upper fan motor.
3. Mount the upper panel and the side panel on the left in reversed order of removal.

■ Mounting (Between tank-union tee)

1. Mount the hose on the tank using the hose clamp.
2. Install the tank.
3. Mount the hose on the union tee.
4. Hold the hose with the hose clamp. (3 locations)
5. Mount the upper panel and the side panel on the left in reversed order of removal.

■ Mounting (Between pump-circulating fluid outlet)

1. Mount the hose fitting to the hose bracket.



2. Mount the upper panel and the side panel on the right in reversed order of removal.

■ Mounting (Between heat exchanger-union tee)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
3. Mount the upper panel and the side panel on the left in reversed order of removal.

■ Mounting (Between pump-union tee)

1. Mount the hose using the hose clamp.
2. Hold the hose with the hose clamp.
3. Mount the upper panel and the panels on both sides in reversed order of removal.

● Replacement of fuse

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal


HRS012/018/024/030-A/W-□



Part number of service parts (Fuse)

Description	Part number
Fuse	HRS-S0024

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the fuse.



Removal of fuse


HRS050/060-A/W-20-□



Part number of service parts (Fuse)

Description	Part number
Fuse	HRS-S0024

1. Remove the upper panel and the side panel on the right referring to removal and the mounting of the panel.
2. Remove the connector of breaker.
3. Remove the breaker. (Screw x 2)
4. Remove the fuse.



Removal of fuse

■ Mounting

HRS012/018/024/030-A/W-□

1. Mount the fuse.
2. Mount the upper panel and the side panel on the right in reversed order of removal.

HRS050/060-A/W-20-□

1. Mount the fuse.
2. Mount the breaker. (Screw x 2)
3. Mount the upper panel and the side panel on the right in reversed order of removal.

● Replacement of valve for automatic water fill

⚠ WARNING



Be sure to shut off the breaker of the facility power supply (the user's machine power supply) before replacement work.

■ Removal

HRS012/018/024/030-A/W-J
HRS050/060-A/W-20-J



Part number of service parts (Valve for automatic water fill)


Description	Part number
Valve for automatic water fill	HRS-S0071

1. Remove the upper panel and the side panel on the right referring the removal and the mounting of the panel.
2. Remove the cable connector of valve from the main board.


Tips

Use "57031-6000" of MOLEX for removing.
Our part no.: HRS-S0056

3. The hose mounted on valve for automatic water fill is removed.
4. Remove the valve for automatic water fill.



Removal of valve for automatic water fill



Removal of valve for automatic water fill

■ Mounting


HRS012/018/024/030-A/W-J

HRS050/060-A/W-20-J

1. Mount the valve for automatic water fill.



2. Mount the cable connector of valve to the main board.





Mount the connector of valve for automatic water fill

3. Mount the hose.

● Spare parts for replacement of the compressor

HRS012/018/024/030-A/W-10/20

Table 4-3. Tools list for repairing refrigerant circuit

Model	Part No	Part name	Qty.	Photo
HRS012-A/W-10 HRS018-A/W-10 HRS024-A/W-10 HRS030-A/W-10	HRS-S0409	Compressor (Include accessories)	1	
HRS012-A/W-20 HRS018-A/W-20 HRS024-A/W-20 HRS030-A/W-20	HRS-S0068	Compressor (Include accessories)	1	

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panels.
2. Remove the left side panel and right side panel.




Fig. 4-80

3. Remove the cap of the high pressure service port on the refrigerant circuit, and then mount a charge valve.




Fig. 4-81

4. Connect the hose of the gauge manifold to the charge valve, and then collect the refrigerant gas, with the refrigerant collector.




Fig. 4-82

5. Open the terminal cover of the compressor, and disconnect the wirings (R,S,T).




Fig. 4-83

6. Cut the cable ties with a pair of nippers, and remove the heat insulator of the accumulator.




Fig. 4-84

7. Remove the heat insulator and remove the fixture from the thermistor sensor.




Fig. 4-85

8. Remove the earth wiring.




Fig. 4-86

9. Warm the brazing filler material of the suction piping A and outlet piping B, using the welding equipment. After melting the brazing filler material, hold and pull out the suction piping A and outlet piping B with pliers.
 - * The suction piping A and outlet piping B of the compressor are to be reused. Use caution not to deform or melt the copper tubings when disconnecting them.

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

⚠ CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-87

10. Loosen the fitting with a spanner, and remove the facility water pipings A and B, and refrigerant piping flare.



Fig. 4-88

11. Loosen and remove the hexagon head nut of the feet of the compressor.

* Since it is difficult to remove the hexagon head bolt 3, remove the support panel first




Fig. 4-89

■ Remount

1. Mount the compressor on the base while aligning it to the holes, and hold it with flat washers and hexagon head bolts by using a spanner.
 - * Do not remove the two rubber caps of the compressor until immediately before brazing in order to prevent oxidization inside the compressor.



Fig. 4-90

2. Remove the rubber caps. Insert copper piping into the suction piping A and outlet piping, and braze them. Mount the refrigerant piping flare to the water control valve.

DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

- * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
- * Before starting to braise, nitrogen gas must be applied inside the copper pipe to avoid oxidization of the internal surface of the copper pipe.
- * After brazing is complete, confirm that the brazing filler material is applied to the entire brazed part by visual observation.




Fig. 4-91

3. Check for any leakage from the brazed parts by filling the refrigerant circuit with refrigerant gas and nitrogen gas.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
4. Check for leakage at the brazed parts using a leak detector.
Set value of the leakage detector: 1.5×10^{-5} std. cc/sec



Fig. 4-92

5. Collect the refrigerant gas and nitrogen gas used for the leakage check.
 - ❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
6. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ The charging hose (Red) shall be 0.92 m length.




Fig. 4-93

7. Charge the specified amount of the refrigerant gas (Refer to Table 4-4.).

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled in.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

❶ The service port is located at high pressure side.

So you cannot add refrigerant during the system in operation.

Table 4-4. The amount of refrigerant

Unit g

Refrigerant	Chiller Model		
	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-W-20
R407C	255 ±5 g	300 ±5 g	495 ±15 g

❶ Refer the refrigerant charge procedure HRX-MM-Q018

They contain useful tips to keep the charge amount controlled.




Fig. 4-94

- 8.** Confirm that no refrigerant gas leaks from the service port
Loosen the charge valve if there is no leakage of the refrigerant gas. (This closes the spring loaded check valve.)
Disconnect the hose of the charge valve, and remove the charge valve.
Mount the cap nut to the service port, and tighten it with a spanner.




Fig. 4-95

- 9.** Connect the facility water piping A and B.
Mount the heat insulator of the accumulator with cable ties (At 2 parts)



Fig. 4-96

- 10.** Install the thermistor sensor with a fixture, and affix a heat insulator.




Fig. 4-97

11. Connect the grounding wire of the compressor.




Fig. 4-98

12. Insert wiring (R, S, T) into the terminals of the compressor, and close the cover by tightening the nut.




Fig. 4-99

13. Mount the panels in order, from left panel, right panel and upper panel.
Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 0.3^{\circ}\text{C}$ of the set temperature.




Fig. 4-100

● Replacement procedure of compressor

HRS050/060-A/W-20

Table 4-5 Replacement parts

Model	Part No.	Description	Qty.	Image
HRS050-A/W-20 HRS060-A/W-20	HRS-S0337	Compressor, (Include accessories)	1	

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel, dust-proof filter, side panel.




Fig. 4-101

2. Remove the cap of the service port on the refrigerant circuit, and then mount a charge valve.

[Air-Cooled type]




Fig. 4-102

[Water-Cooled type]




Fig. 4-103

3. Connect the hose of the gauge manifold to the high pressure service port, and then collect the refrigerant gas, with the refrigerant collector.




Fig. 4-104

4. Open the terminal cover of the compressor, and disconnect the wirings (R,S,C).



Fig. 4-105

5. Remove the earth wiring.




Fig. 4-106

6. Cut the cable ties with a pair of nippers, and remove the heat insulator of the accumulator.




Fig. 4-107

7. Warm the brazing filler material of the suction piping A and outlet piping B, using the welding equipment. After melting the brazing filler material, hold and pull out the suction piping A and outlet piping B with pliers.
- * The suction piping A and outlet piping B of the compressor are to be reused. Use caution not to deform or melt the copper tubings when disconnecting them.




Fig. 4-108

8. Loosen and remove the hexagon head nuts (M8) of the feet of the compressor.



Fig. 4-109

■ Remount

1. Mount the vibration proof rubber and sleeve (Table 1, No.6) on the feet of the compressor while aligning the position of the holes, and mount the compressor on the base.
2. Install the flat washer and the hexagon head bolt, and tighten them with a spanner.
 - * Do not remove the two rubber caps of the compressor until immediately before brazing in order to prevent oxidization inside the compressor.





Fig. 4-110

3. Remove the rubber cap. Insert a copper piping to the suction piping A and outlet piping B, and braze them.

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

- * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
- * Before starting brazing, nitrogen gas must be applied inside the copper tubing to avoid oxidization of the internal surface of the copper tubing.
- * After finishing brazing, confirm that the brazing filler material is applied to the entire brazed part by visual observation.




Fig. 4-111

4. Check for any refrigerant leakage from the brazed parts by filling coolant gas and nitrogen gas inside of the refrigerant circuit.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
5. Check for leakage at the brazed parts using a leak detector.
 - Set value of the leakage detector: 1.5×10^{-6} std.cc/sec



Fig. 4-112

6. Collect the refrigerant gas and nitrogen gas used for the refrigerant leakage check.
 - ❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
7. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ Use the red hose with specified length (0.92 m).




Fig. 4-113

8. Fill the specified amount of refrigerant gas. (See Table 4-6.)

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled in.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

- ❗ The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-6. The amount of refrigerant for each model

Refrigerant	Model No.		
	HRS050-A□-20 HRS050-W□-20	HRS060-A□-20	HRS060-W□-20
R410A	655 ±15 g	845 ±15 g	735 ±15 g

- ❗ Refer the refrigerant charge procedure HRX-MM-Q018
They contain useful tips to keep the charge amount controlled.




Fig. 4-114

9. Confirm that no refrigerant gas leaks from the service port.
10. Loosen the charge valve if there is no leakage of the refrigerant gas. (Close the spring loaded check valve.)
11. Disconnect the hose of the charge valve, and remove the charge valve.
12. Mount the cap nut to the service port, and tighten it with a spanner.




Fig. 4-115

13. Mount the heat insulator of the accumulator with cable ties (at two parts).




Fig. 4-116

14. Connect the earth wire to the compressor.




Fig. 4-117

15. Insert the wirings (R, S and C) into the terminals of the compressor.
Put the cover onto the terminals, and fix the cover by tightening the nuts.



Fig. 4-118

16. Mount the panels in order, from left panel, right panel, dust-proof filter, and upper panel.
Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 3.0^{\circ}\text{C}$ of the set temperature.




Fig. 4-119

● Replacement of heat exchanger

HRS012/018/024/030/050/060-A/W-10/20

Table 4-7. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-A/W-10/20 HRS018-A/W-10/20 HRS024-A/W-20	HRS-S0030	Heat exchanger	1	
HRS012-A/W-10/20-M HRS018-A-W-10/20-M HRS024-A/W-20-M	HRS-S0413			
HRS030-A/W-20	HRS-S0380			
HRS030-A/W-20-M	HRS-S0414			
HRS050-A/W-20 HRS060-A/W-20	HRS-S0184	Heat exchanger	1	
HRS050-A/W-20-M HRS060-A/W-20-M	HRS-S0415			

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel.
2. Remove the left side panel and right side panel.




Fig. 4-120

3. Remove the cap of the high pressure service port on the refrigerant circuit, and then mount a charge valve.




Fig. 4-121

4. Connect the hose of the gauge manifold to the charge valve, and then collect the refrigerant gas, with the refrigerant collector.

⚠ CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-122

5. Remove the hose which is connected to the heat exchanger from the tank and the clip mounted on the tank side. Move the hose band at heat exchanger side (barb fitting side), then pull the hose from the fitting.




Fig. 4-123

6. Cut the cable ties to remove the thermal insulator of the heat exchanger. Remove the temperature sensor connector.

7. Cut the copper tubes of the heat exchanger.

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.




Fig. 4-124

8. Heat the brazed parts where the copper pipes were connected, and pull out the copper pipes (2 pieces) after cutting them. Loosen the domed cap nuts (M6 x 2) and remove the sleeves, thermal insulator and heat exchanger from the panel.




Fig. 4-125

■ Remount

1. Loosen the domed cap nuts (M6 x 2) and remove the sleeve, thermal insulator and heat exchanger from the panel.




Fig. 4-126

2. Protect the electrical wires and heat insulator with wet waste cloth to prevent them from burning out.
Insert a copper pipe while warming the connection part with a burner, then braise it.

- * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
- * Before starting brazing, nitrogen gas must be applied inside the copper tubing to avoid oxidization of the internal surface of the copper tubing.
- * After finishing brazing, confirm that the brazing filler material is applied to the entire brazed part by visual observation.




Fig. 4-127

3. Check for any refrigerant leakage from the brazed parts by filling coolant gas and nitrogen gas inside of the refrigerant circuit.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
 - Set value of the leakage detector: (2×10^{-5} std.cc/sec)



Fig. 4-128

4. Collect the refrigerant gas (R407C) and nitrogen gas used for the refrigerant leakage check.
5. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ The charging hose (Red) shall be 0.92 m length.




Fig. 4-129

6. Fill the specified amount of refrigerant gas. (See Table 4-8, 9.)

⚠ DANGER

- Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled.
- * If air is left inside the hose between the refrigerant cylinder and the charge valve, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

- ❗ The refrigerant cannot be enclosed during operation.

Table 4-8. The amount of refrigerant (HRS012/018/024/030)

Refrigerant	HRS012-A-10 HRS018-A-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-A-20	HRS030-W-20
R407C	320 ±5 g	350 ±5 g	255 ±5 g	300 ±5 g	565 ±15 g	495 ±15 g

Table 4-9. The amount of refrigerant (HRS050/060)

Refrigerant	HRS050-A20	HRS050-W-20	HRS060-A-20	HRS060-W-20
R410A	655 ±15 g	655 ±15 g	845 ±15 g	735 ±15 g

- ❗ Make sure to refer to Procedure for filling refrigerant gas (HRX-MM-Q018) to fill the refrigerant correctly.




Fig. 4-130

- Confirm that no refrigerant gas leaks from the service port. Loosen the charge valve if there is no leakage of the refrigerant gas. (Close the spring loaded check valve.)
- Disconnect the hose of the charge valve, and remove the charge valve. Mount the cap nut to the service port, and tighten it with a spanner.




Fig. 4-131

9. Mount the thermal insulators for tube, heat exchanger and electric expansion valve, and hold them in position.
10. Connect the circulating water hose for heat exchanger, and hold it with a hose band.
11. Remount the panels in order, from left panel, right panel and upper panel.
Test the operation to confirm that the temperature control is correctly performed.
If the temperature is stabilized to within $\pm 3.0^{\circ}\text{C}$ of the set temperature, the replacement work is completed.








Fig. 4-132

● Replacement of air-cooled condenser

HRS012 to 060-A-10/20

Table 4-10. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-A-10/20 HRS018-A-10/20 HRS024-A-20	HRS-S0381	Condenser (For Air-cooled)	1	
HRS030-A-20			2	
HRS050-A-20	HRS-S0382	Condenser (For Air-cooled)	1	
HRS060-A-20	HRS-S0383	Condenser (For Air-cooled)	1 set	 

HRS012/018/024-A-10/20

■ Disassembly

1. Remove the upper panel, left panel, right panel, dust-proof filter and front panel.




Fig. 4-133

CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.

2. Hold the lower part of the service port with a spanner, and remove the cap nut. (Spanner size: 14 mm, 17 mm)
3. After mounting a charge valve onto the service port, collect the refrigerant gas with a refrigerant gas collector.




Fig. 4-134

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

4. Protect the electrical wires and heat insulator with wet waste cloth to prevent them from burning out.
5. Pull the copper pipes out while warming the connection joints of the copper pipes of the air-cooled condenser with a burner.




Fig. 4-135

6. Remove the screw of air-cooled condenser. (4 pcs.)
7. After removing the display connector inside of the front panel, remove the front panel. (3 parts.)




Fig. 4-136

8. Remove the screws of the tank bracket. (2 pcs.)
9. Lift the tank bracket up and remove the Air-Cooled condenser.




Fig. 4-137

HRS030-A-20

■ Disassembly

1. Remove the upper panel, left panel, right panel, dust-proof filter and front panel.




Fig. 4-138

2. Hold the lower part of the service port with a spanner, and remove the cap nut.
(Spanner size: 14 mm, 17 mm)
3. After mounting a charge valve onto the service port, collect the refrigerant gas with a refrigerant gas collector.




Fig. 4-139

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

4. Protect the electrical wires and heat insulator with wet waste cloth to prevent them from burning out.
5. Pull the copper pipes out while warming the connection joints of the copper pipes of the air-cooled condensers No.1 and No.2 with a burner.




Fig. 4-140

6. After removing the display connector backside of the front panel, remove the front panel.
7. Remove the screw of Air-Cooled condenser 1.




Fig. 4-141

8. Remove the screw of Air-Cooled condenser bracket. (Left / 2pcs., right / 3pcs.)
9. Lift the tank bracket up and remove the air-cooled condenser 2.




Fig. 4-142

HRS050-A-20

■ Disassembly

1. Remove the upper panel, left panel, right panel, dust-proof filter.




Fig. 4-143

2. Hold the lower part of the service port with a spanner, and remove the cap nut. (Spanner size: 14 mm, 17 mm)
3. After mounting a charge valve onto the service port, collect the refrigerant gas with a refrigerant gas collector.




Fig. 4-144

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

4. Protect the electrical wires and heat insulator with wet waste cloth to prevent them from burning out.
5. Pull the copper pipes out while warming the connection joints of the copper pipes of the air-cooled condenser with a burner.




Fig. 4-145

6. Remove the bracket of the dust-proof filter.
7. Remove the condenser bracket.




Fig. 4-146

8. Remove the screw of Air-Cooled condenser.




Fig. 4-147

HRS060-A-20

■ Disassembly

1. Remove the upper panel, left panel, right panel, dust-proof filter.




Fig. 4-148

2. Hold the lower part of the service port with a spanner, and remove the cap nut.
(Spanner size: 14 mm, 17 mm)
3. After mounting a charge valve onto the service port, collect the refrigerant gas with a refrigerant gas collector.
4. Protect the electrical wires and heat insulator with wet waste cloth to prevent them from burning out.
5. Pull the copper pipes out while warming the connection joints of the copper pipes of the air-cooled condenser with a burner.




Fig. 4-149

6. After removing the display connector inside of the front panel, remove the front panel.
7. Remove the screws of the condenser bracket and the air-cooled condenser No.1.




Fig. 4-150

8. Remove the condenser bracket, tank bracket.
9. Lift the tank bracket up and remove the air-cooled condenser 2.




Fig. 4-151

■ Remount

1. Remount the new air-cooled condenser.
2. Insert copper pipes while warming the connection joints of the air-cooled condensers and copper pipes with a burner, then braze them.

DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.

- * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
 - * Before starting brazing, nitrogen gas must be applied inside the copper tubing to avoid oxidization of the internal surface of the copper tubing.
 - * After finishing brazing, confirm that the brazing filler material is applied to the entire brazed part by visual observation.
3. Check for any refrigerant leakage from the brazed parts by filling coolant gas and nitrogen gas inside of the refrigerant circuit.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
 - Check for leakage at the brazed parts using a leak detector.
 - Set value of the leakage detector: $(2 \times 10^{-5} \text{ std.cc/sec})$
 4. Collect the refrigerant gas (R410A, R407C) and nitrogen gas used for the refrigerant leakage check.

5. Connect the vacuum pump and draw vacuum for more than 30 minutes.
· After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
6. Fill the specified amount of refrigerant gas.

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- ❗ The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-11. The amount of refrigerant (HRS012/018/024/030)

Refrigerant	HRS012-A-10 HRS018-A-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS030-A-20
R407C	320 ±5 g	350 ±5 g	565 ±15 g

Table 4-12. The amount of refrigerant (HRS050/060)

Refrigerant	HRS050-A-20	HRS060-A-20
R410A	655 ±15 g	845 ±15 g

Make sure to refer to Procedure for filling refrigerant gas (HRX-MM-Q018) to fill the refrigerant correctly.

- * Use a regularly calibrated scale to measure the gas to be filled.
- * If air is left inside the hose between the refrigerant cylinder and the charge valve, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

7. Remove the charge valve to confirm that no refrigerant leakage occurs from the service port, then, hold the lower part of the service port with a spanner and tighten the cap nut. (Spanner size: 14 mm, 17 mm)
8. Test the operation to confirm that the temperature control is correctly performed.






Fig. 4-152



● Replacement of water-cooled condenser

HRS012 to 060-W-10/20

Table 4-13. Replacement parts

Model	Part No.	Part name	Appearance
HRS012-W-10 HRS018-W-10 HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS-S0133	Heat exchanger	
HRS030-W-20	HRS-S0384	Heat exchanger	
HRS050-W-20 HRS060-W-20	HRS-S0152	Heat exchanger	

⚠ WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

⚠ CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel and side panel.




Fig. 4-153

2. Mount the charge valve to the service port.




Fig. 4-154

3. Connect the hose of the gauge manifold to the high-pressure service port, and collect the refrigerant gas with the refrigerant collector.

⚠ CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-155

4. Loosen the fittings with a spanner, and remove the facility water piping A and B.




Fig. 4-156

5. Melt the brazing filler material at the joint of the copper pipes using the brazing equipment. After melting the brazing filler material, hold and pull out the copper pipes with pliers.
 - * The copper pipe is to be reused. Use caution not to deform or melt the copper pipe when disconnecting it.

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.




Fig. 4-157

6. Loosen the cap nuts (2pcs.) that are held to the condenser port, and remove the water-cooled condenser.




Fig. 4-158

7. Install a spacer to the holding bolt at the back of the water-cooled condenser. (The spacer is to be reused.)




Fig. 4-159

8. Mount the water-cooled condenser assembly to the condenser port (Hexagon cap nut /2pcs.), and braise the joint of the condenser connection pipe.




Fig. 4-160

9. Check for any refrigerant leakage from the brazed parts by filling coolant gas and nitrogen gas inside of the refrigerant circuit.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa , and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
10. Check for leakage at the brazed parts using a leak detector.



Fig. 4-161

11. Collect the refrigerant gas and nitrogen used for the refrigerant leakage check.
 - ❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
12. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ Use the red hose with specified length (0.92 m).




Fig. 4-162

13. Fill the specified amount of refrigerant gas. (See Table 4-14.)

CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

- ❶** The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-14. The amount of refrigerant for each model

Refrigerant	Model No.				
	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-W-20	HRS050-W-20	HRS060-W-20
R407C	255 ±5 g	300 ±5 g	495 ±15 g	—	—
R410A	—	—	—	655 ±15 g	735 ±15 g

- ❶** Make sure to refer to Procedure for filling refrigerant gas (HRX-MM-Q018) to fill the refrigerant correctly.




Fig. 4-163

14. Confirm that no refrigerant gas leaks from the service port.
 15. Loosen the charge valve if there is no leakage of the refrigerant gas. (Close the spring loaded check valve.)
 16. Disconnect the hose of the charge valve, and remove the charge valve.
 17. Mount the cap nut to the service port, and tighten it with a spanner.
-




Fig. 4-164


-
18. Remount the panels in order, from left panel, right panel and upper panel.
 19. Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 0.3^{\circ}\text{C}$ of the set temperature.
-



Fig. 4-165

● Replacement of water pressure regulating valve HRS012 to 060-W-10/20

Table 4-15. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-W-10/20 HRS018-W-10/20 HRS024-W-20 HRS030-W-20	HRS-S0385	Water pressure regulating valve	1	
HRS050-W-20 HRS060-W-20	HRS-S0388	Water pressure regulating valve	1	

4

Maintenance

⚠ WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

⚠ CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel and side panel.




Fig. 4-166

2. Mount the charge valve to the service port.




Fig. 4-167

3. Connect the hose of the gauge manifold to the high-pressure service port, and collect the refrigerant gas with the refrigerant collector.

⚠ CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-168

4. Remove the cooling water piping.
5. Remove the flare nut on the copper pipe




Fig. 4-169

6. Remove the facility water piping on the user side.
7. Remove the fitting of the water pressure regulating valve on the side of the facility water outlet on the rear panel.




Fig. 4-170

■ Remount

1. Remount the water pressure regulating valve on the rear panel.
2. Tighten the flare nut on the copper pipe of the water pressure regulating valve with a spanner. (Spanner size: 17 mm)




Fig. 4-171

3. Fill in refrigerant gas and nitrogen gas inside of the refrigerant circuit.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
4. Check for any leakage from the copper pipe flare with a leak detector.



Fig. 4-172

5. Collect the refrigerant gas and nitrogen used for the refrigerant leakage check.
 - ❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
6. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ Use the red hose with specified length (0.92 m).




Fig. 4-173

7. Fill the specified amount of refrigerant gas. (See Table 4-16.)

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled.
- * If air is left inside the hose between the refrigerant cylinder and the charge valve, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

- ❗ The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-16. The amount of refrigerant for each model

Refrigerant	Model No.				
	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-W-20	HRS050-W-20	HRS060-W-20
R407C	255 ±5 g	300 ±5 g	495 ±15 g	—	—
R410A	—	—	—	655 ±15 g	735 ±15 g

- ❗ Make sure to refer to Procedure for filling refrigerant gas (HRX-MM-Q018) to fill the refrigerant correctly.




Fig. 4-174

8. Confirm that no refrigerant gas leaks from the service port.
 9. Loosen the charge valve if there is no leakage of the refrigerant gas. (Close the spring loaded check valve.)
 10. Disconnect the hose of the charge valve, and remove the charge valve.
 11. Mount the cap nut to the service port, and tighten it with a spanner.
-




Fig. 4-175

12. Remount the panels in order, from left panel, right panel and upper panel.
 13. Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 0.3^{\circ}\text{C}$ of the set temperature.
-




Fig. 4-176

● Replacement of filter dryer

HRS012/018/024/030-A/W10/20

Table 4-17 Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-A/W-10/20 HRS018-A/W-10/20 HRS024-A/W-20 HRS030-A/W-20	HRZ-S0387	Filter dryer	1	

⚠ WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

⚠ CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel and side panel.




Fig. 4-177

2. Mount the charge valve to the service port of the refrigerant circuit.





Fig. 4-178

3. Connect the hose of the gauge manifold to the service port, and collect the refrigerant gas with the refrigerant collector.

 **CAUTION**

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-179

4. Melt the brazing filler material at the joint of the copper pipes using the brazing equipment. After melting the brazing filler material, hold and pull out the copper pipes with pliers.
 - * The copper pipe is to be reused. Use caution not to deform or melt the copper pipe when disconnecting it.

DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.




Fig. 4-180

■ Remount

1. Cover the flow direction label on the filter dryer with a wet cloth. Confirm the flow direction of the refrigerant. Insert the copper pipe to the filter dryer, and braze the joint.
 - * Use a regularly calibrated scale to measure the gas to be filled.
 - * If air is left inside the hose between the refrigerant cylinder and the charge valve, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.




Fig. 4-181

2. Check for any leakage from the brazed parts by filling refrigerant gas and nitrogen gas inside of the refrigerant circuit.
3. Check for leakage at the brazed parts using a leak detector.
Set value of the leakage detector: 1.5×10^{-5} std.cc/sec



Fig. 4-182

4. Collect the refrigerant gas and nitrogen used for the refrigerant leakage check.
❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
5. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
❶ The charging hose (Red) shall be 0.92 m length.




Fig. 4-183

6. Fill the specified amount of refrigerant gas. (See Table 4-18.)

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled in.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

❗ The service port is located at high pressure side.

So you cannot add refrigerant during the system in operation.

Table 4-18 The amount of refrigerant for each model

Refrigerant	HRS012-A-10 HRS018-A-10	HRS012-W-10 HRS018-W-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-A-20	HRS030-W-20
R407C	320 ±5 g	255 ±5 g	350 ±5 g	300 ±5 g	565 ±15 g	495 ±15 g

❗ Refer the refrigerant charge procedure HRX-MM-Q018

They contain useful tips to keep the charge amount controlled.




Fig. 4-184

7. Confirm that no refrigerant gas leaks from the service port.
 8. Loosen the charge valve if there is no leakage of the refrigerant gas. (This closes the spring loaded check valve.)
 9. Disconnect the hose of the charge valve, and remove the charge valve.
 10. Mount the cap nut to the service port, and tighten it with a spanner.
-




Fig. 4-185

-
11. Mount the panels in order, from left panel, right panel and upper panel.
 - 12.. Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 3.0^{\circ}\text{C}$ of the set temperature.
-




Fig. 4-186

● Replacement of filter dryer

HRS050/060-A/W-20

Table 4-19. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS050-A/W-20 HRS060-A/W-20	HRZ-S0227	Filter dryer	1	

4

Maintenance

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.

There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the left panel, right panel and upper panel.




Fig. 4-187

2. Remove the cap nut of the high pressure service port on the refrigerant circuit, and then mount a charge valve.

[Air-cooled type]




Fig. 4-188

[Water-cooled type]




Fig. 4-189

3. Connect the hose of the gauge manifold to the high-pressure service port, and collect the refrigerant gas with the refrigerant collector.

⚠ CAUTION

The collection and the disposal of refrigerant (HFC) and compressor oil must be in compliance with the bylaws of the local municipality.




Fig. 4-190

4. Melt the brazing filler material at the joint of the copper pipes of the filter dryer using the brazing equipment. After melting the brazing filler material, hold and pull out the copper pipes with pliers.
 - * The copper pipe is to be reused. Use caution not to deform or melt the copper pipe when disconnecting it.

⚠ DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.




Fig. 4-191

5. Cover the flow direction label on the filter dryer with a wet cloth.
6. Confirm the flow direction of the refrigerant. Insert the filter dryer to the copper pipes, and braise the joint.
 - * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
 - * Before starting brazing, nitrogen gas must be applied inside the copper tubing to avoid oxidization of the internal surface of the copper tubing.
 - * After finishing brazing, confirm that the brazing filler material is applied to the entire brazed part by visual observation.

7. Check for any leakage from the brazed parts by filling the refrigerant circuit with refrigerant gas and nitrogen gas.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.
8. Check for leakage at the brazed parts using a leak detector.
Set value of the leakage detector: 1.5×10^{-5} std. cc/sec



Fig. 4-192

9. Collect the refrigerant gas and nitrogen used for the leakage check.
 - ❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
10. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
 - ❶ Use the red hose with specified length (0.92 m).




Fig. 4-193

11. Fill the specified amount of refrigerant gas. (See Table 4-20.)

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled in.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

❶ The service port is located at high pressure side.

So you cannot add refrigerant during the system in operation.

Table 4-20. The amount of refrigerant for each model

Refrigerant	Model No.		
	HRS050-A-20 HRS050-W-20	HRS060-A-20	HRS060-W-20
R410A	655 ±15 g	845 ±15 g	735 ±15 g

❶ Refer the refrigerant charge procedure HRX-MM-Q018

They contain useful tips to keep the charge amount controlled.




Fig. 4-194

12. Confirm that no refrigerant gas leaks from the service port.
13. Loosen the charge valve if there is no leakage of the refrigerant gas. (This closes the spring loaded check valve.)
14. Disconnect the hose of the charge valve, and remove the charge valve.
15. Mount the cap nut to the service port, and tighten it with a spanner.



Fig. 4-195

16. Mount the panels in order, from left panel, right panel and upper panel.
17. Test the operation to confirm that the temperature control is correctly performed.
The replacement work is now completed, if temperature is controlled within the range of $\pm 3.0^{\circ}\text{C}$ of the set temperature.





Fig. 4-196

● Replacement of Electric expansion valve

HRS012 to 060-A/W-10/20

Table 4-21. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-A/W-10/20 HRS018-A/W-10/20 HRS024-A/W-20 HRS030-A/W-20	HRS-S0029	Electric expansion valve (EV1)	1	
	HRS-S0028	Electric expansion valve (EV2)		
HRS050-A/W-20 HRS060-A/W-20	HRS-S0341	Electric expansion valve (EV1)	1	
	HRS-S0340	Electric expansion valve (EV2)		

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Disassembly

1. Remove the upper panel and side panel.

HRS012 to 030-A/W-10/20




Fig. 4-197

HRS050/060-A/W-20




Fig. 4-198

2. Mount the charge valve to the service port.

HRS012 to 030-A/W-10/20




Fig. 4-199

3. Mount the charge valve to the service port.

HRS050/060-A/W-20




Fig. 4-200

4. Connect the hose of the gauge manifold to the high-pressure service port, and collect the refrigerant gas with the refrigerant collector.




Fig. 4-201

5. Remove the coil which is mounted to the electronic expansion valve.
6. Remove all the thermal insulators around the electronic expansion valve. Handle the insulators with care. They will be reused.




Fig. 4-202

7. Cut the copper pipes (2 places on the side of the electronic expansion valve from the brazed part) for removal.

After the removal, make sure that no compressor oil is left in the copper pipe. If some oil remains, remove it with a waste cloth.




Fig. 4-203

8. Protect the electronic expansion valve, thermal insulator and cables with a wet cloth so that they are not burnt during mounting of the electronic expansion valve.
9. Heat the brazed parts where the electronic expansion valve and the copper pipe were connected, and pull out the copper pipes of the expansion valve (2 places).

DANGER

- Only trained and qualified personnel who are knowledgeable and skilled in brazing can perform the work of this document.
- Brazing has to be performed in a well ventilated area and where no flammable objects are present.




Fig. 4-204

■ Remount

1. Protect the new electronic expansion valve from heat by a wet cloth.




Fig. 4-205

2. The electronic expansion valve may not be inserted into the copper pipe smoothly. Insert the copper pipe of the electronic expansion valve while heating the copper pipe, and braise it.
 - * When brazing, make sure to wear protective glasses for brazing, and do not directly look at the flame.
 - * Before starting brazing, nitrogen gas must be applied inside the copper tubing to avoid oxidization of the internal surface of the copper tubing.
 - * After finishing brazing, confirm that the brazing filler material is applied to the entire brazed part by visual observation.



Fig. 4-206

3. Check for any leakage from the brazed parts by filling the refrigerant circuit with refrigerant gas and nitrogen gas.
 - Fill the refrigerant gas (R407C) into the refrigerant circuit until the gas pressure reaches 0.29 MPa, and fill the nitrogen gas into the refrigerant circuit until the gas pressure reaches 1.37 MPa.

4. Check for leakage at the brazed parts using a leak detector.
Set value of the leakage detector: 1.5×10^{-5} std. cc/sec



Fig. 4-207

5. Collect the refrigerant gas and nitrogen gas used for the leakage check.
❶ Entrust a special industrial waste disposal trader with the mixture of refrigerant gas and nitrogen gas which you have collected.
6. After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
❶ The charging hose (Red) shall be 0.92 m length.




Fig. 4-208

7. Fill the specified amount of refrigerant gas. (See Table 4-22, 23.)

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- * Use a regularly calibrated scale to measure the gas to be filled in.
- * If air is left inside the hose between the refrigerant cylinder and the service port, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

❶ The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-22. The amount of refrigerant (HRS012/018/024/030)

Refrigerant	HRS012-A-10 HRS018-A-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-A-20	HRS030-W-20
R407C	320 ±5 g	350 ±5 g	255 ±5 g	300 ±5 g	565 ±15 g	495 ±15 g

Table 4-23. The amount of refrigerant (HRS050/060)

Refrigerant	HRS050-A-20	HRS050-W-20	HRS060-A-20	HRS060-W-20
R410A	655 ±15 g	655 ±15 g	845 ±15 g	735 ±15 g

❶ Refer the refrigerant charge procedure HRX-MM-Q018
They contain useful tips to keep the charge amount controlled.




Fig. 4-209

8. Confirm that no refrigerant gas leaks from the service port.
9. Loosen the charge valve if there is no leakage of the refrigerant gas. (This closes the spring loaded check valve.)
10. Disconnect the hose of the charge valve, and remove the charge valve.
11. Mount the cap nut to the service port, and tighten it with a spanner.



Fig. 4-210

12. Mount the panels in order, from left panel, right panel and upper panel.
 - ① Initial setting is required after replacing EV1 (electronic expansion valve for cooling). Be sure to refer to How to set the minimum opening of the electronic expansion valve for cooling (HRX-MM-S002) in the attachment.
13. Test the operation to confirm that the temperature control is correctly performed.

The replacement work is now completed, if temperature is controlled within the range of $\pm 3.0^{\circ}\text{C}$ of the set temperature.




Fig. 4-211

● Replacement of Refrigerant Pressure Sensor

HRS012 to 060-A/W-10/20

Table 4-24. Replacement parts

Model	Part No.	Description	Qty.	Image
HRS012-A/W-10/20 HRS018-A/W-10/20 HRS024-A/W-20 HRS030-A/W-20	HRS-S0012	Refrigerant Pressure Sensor (For high pressure)	1	
	HRS-S0013	Refrigerant Pressure Sensor (For low pressure)	1	
HRS050-A-20 HRS060-A-20	HRS-S0183	Refrigerant Pressure Sensor (For high pressure)	1	
	HRS-S0012	Refrigerant Pressure Sensor (For low pressure)	1	

WARNING



There is danger of an electric shock. Make sure to turn OFF the power supply before performing replacement work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.


CAUTION




Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

HRS012 to 030-A/W-10/20**■ Disassembly [High pressure side]**

1. Remove the upper panel and left side panel.

**Fig. 4-212**

2. Hold the lower part of the service port with a spanner, and remove the cap nut (Spanner size: 14 mm, 17 mm)

**Fig. 4-213**

3. After mounting a charge valve to the service port, collect the refrigerant gas. (Refrigerant gas collector)




Fig. 4-214

4. Remove the wiring connector of the refrigerant pressure sensor.
5. Hold the refrigerant pressure sensor body with a spanner and remove the pressure sensor. (Spanner size: 12 mm, 17 mm)



Fig. 4-215

■ Disassembly [Low pressure side]

1. Put a container under the drain port, and remove the drain clip and drain plug to discharge the circulating fluid.
2. Remove the support panel.




Fig. 4-216

3. Remove the wiring connector of the refrigerant pressure sensor.
4. Hold the refrigerant pressure sensor body with a spanner and remove the pressure sensor. (Spanner size: 12 mm, 17 mm)




Fig. 4-217

● Replacement of Refrigerant Pressure Sensor

HRS050/060-A/W-20

■ Disassembly [High pressure side]

1. Remove the upper panel and left side panel.




Fig. 4-218

2. Hold the lower part of the service port with a spanner, and remove the cap nut.
(Spanner size: 14 mm, 17 mm)
3. Mount the charge valve to the service port.




Fig. 4-219

4. After mounting a charge valve to the service port, collect the refrigerant gas. (Refrigerant collector)




Fig. 4-220

5. Remove the wiring connector of the refrigerant pressure sensor.
6. Hold the refrigerant pressure sensor body with a spanner and remove the pressure sensor. (Spanner size: 12 mm, 17 mm)




Fig. 4-221

■ Disassembly [Lower pressure side]

1. Hold the lower part of the service port with a spanner, and remove the cap nut.
(Spanner size: 14 mm, 17 mm)
2. After mounting a charge valve to the service port, collect the refrigerant gas.
(Refrigerant gas collector)
3. Remove the wiring connector of the refrigerant pressure sensor.
4. Hold the refrigerant pressure sensor body with a spanner and remove the pressure sensor.
(Spanner size: 12 mm, 17 mm)




Fig. 4-222

■ Remount [High pressure side, Low pressure side]

1. Hold the new refrigerant pressure sensor body side with a spanner and mount the pressure sensor. (Spanner size: 12 mm, 17 mm)
2. Mount the wiring connector.
3. Connect the vacuum pump and draw vacuum. (For more than 30 minutes.)
After confirming that the refrigerant pressure gage measures zero, start drawing vacuum for more than 30 minutes.
4. Fill the specified amount of refrigerant gas. (Refer to Table 4-25, 26.)
 - * Use a regularly calibrated scale to measure the gas to be filled.
 - * If air is left inside the hose between the refrigerant cylinder and the charge valve, the air enters the refrigerant piping. If air enters the compressor, it may cause the product failure. Make sure to fill the hose with refrigerant before enclosing the refrigerant.

⚠ CAUTION

Apply the correct amount of the refrigerant. The performance of the product may not be realized if the amount is too large or too small.

- ❶ The service port is located at high pressure side.
The refrigerant cannot be enclosed during operation.

Table 4-25. The amount of refrigerant (HRS012/018/024/030)

Refrigerant	HRS012-A-10 HRS018-A-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-A-20	HRS030-W-20
R407C	320 ±5 g	350 ±5 g	255 ±5 g	300 ±5 g	565 ±15 g	495 ±15 g

Table 4-26. The amount of refrigerant (HRS050/060)

Refrigerant	HRS050-A-20	HRS050-W-20	HRS060-A-20	HRS060-W-20
R410A	655 ±15 g	655 ±15 g	845 ±15 g	735 ±15 g

- ❶ Refer the refrigerant charge procedure HRX-MM-Q018
They contain useful tips to keep the charge amount controlled.

5. Remove the charge valve to confirm that no refrigerant gas leakage occurs from the service port.
6. Mount the cap nut to the service port, and tighten it with a spanner.
(Spanner size: 14 mm, 17 mm)
7. Test the operation to confirm that the temperature control is correctly performed. (Temperature stability: +/- 0.1°C)



HRS012 to 030-A/W




HRS050/060-A/W

Fig. 4-223


* For the 200 V only

■ Models with Mechanical Seal


HRS012/018/024/030-A□-20-(M)T




HRS012/018/024/030-W□-20-(M)T



HRS050/060-A□-20-□(M)











HRS050/060-W□-20-□(M)



Service parts to be used

- The mechanical seal set contains the following service parts.
- Please confirm that all of them are present before replacement.

Table 5-1 Mechanical seal set

Model	Part No.	Part name	Qty.	Photo
HRG-S0211	—	Mechanical seal (Stationary)	1	
	—	Mechanical seal (Dynamic)	1	
	—	Mechanical seal (Spring)	1	
	—	Rubber washer	1	
	—	O-ring A	1	
	—	O-ring B	1	
	—	O-ring C	1	
	HRX-OM-Q007	Operation manual	1	

These service parts include three types of O-rings.

Select the appropriate O-ring referring to the comparison table below.

Table 5-2 Appropriate models for each O-ring

O-ring	Applicable models	Remarks
A	HRS012/018/024/030 series	For high pressure pump option (-T)
B	HRS050/060 series	For standard and all options
C	HRG010 series	For standard and all options

■ Tools to be used and recommended protective equipment

- Tools to be used in the replacement work and useful equipment are shown in the table below.
- Please prepare the tools shown in the table.

Table 5-3 Tools list (1)






No.	Description	Photo	Remarks
1	Permanent marker		
2	Allen wrench (Flat size: 5 mm)		
3	Allen wrench (Flat size: 2 mm)		
4	Pliers (which can hold 4-mm key width)		
5	Flat blade screwdriver (which can be inserted into 4-mm key way)		

Table 5-3 Tools list (2)









No.	Description	Photo	Remarks
6	Flat head screwdriver (which can be inserted into a flat blade groove of the shaft on the rear face of the motor)		
7	Pulley remover (Nominal size 3")		
8	Alcohol		
9	Cloth (such as paper towels)		
10	File (flat or triangle)		
11	Sandpaper or sponge abrasive material (#180 to #200)		
12	Pushing tool (for rotating ring and for fixing ring)		
13	Pliers (medium size)		

Table 5-3 Tools list (3)









No.	Description	Photo	Remarks
14	Thickness gauge (0.03 mm)		
15	Thickness gauge (0.05 mm)		
16	Plastic hammer (medium size)		
17	Drain pan (Less than 100 mm in height)		
18	Dustcloth		

Table 5-4 Recommended protective tools

No.	Description	Photo	Remarks
1	Gloves		
2	Goggles		
3	Safety shoes		

Internal construction of the pump




Table 5-5 Internal construction of the pump

No.	Name	No.	Name
1	Mechanical seal	7	(Key)
2	Rubber washer	8	(Hexagon socket head cap screw)
3	O-ring	9	(Set screw x 2)
4	(Body)	10	(Motor)
5	(Cover)	11	(Seal)
6	(Impeller)	12	(Motor shaft)

■ Replacement procedure

⚠ WARNING



The pump may operate suddenly due to automatic operation, which is dangerous. Make sure to turn OFF the power supply before performing replacement work. There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

⚠ CAUTION



Be sure to wear protective footwear and gloves when attaching or removing panels. Sharp edges of the panels may lead to personal injury if not handled properly.

■ Removal procedure

1. Remove the upper and side panels of the thermo-chiller to remove the pump.

Note

Please read and understand the separate service manual (HRX-MM-M056, P013).




Fig. 5-1 Pump for HRS012/018/024-□-20-T, HRS030-□-20-T




Fig. 5-2 Pump for HRS012/018/024-□-20-MT, HRS030-□-20-MT




Fig. 5-3 Pump for HRS050/060-□-20




Fig. 5-4 Pump for HRS050/060-□-20-M

(The following procedure is common for all pump models. The procedure is shown using a HRS050/060-□-20 pump as an example.)

2. Draw alignment reference on the body (front casing), cover (back casing) and motor.

Note

Draw two or three reference.



3. Loosen the hexagon socket head cap screws that have fixed the body.



4. Remove the body.

Note

Remove the body slowly with a flat head screwdriver as a lever.



5. Loosen the two set screws that fix the impeller to the shaft.

Note

Do not completely remove the two set screws from the impeller, so that they will not be lost.



6. Move the impeller forward together with the cover (back casing).

Note

Move the impeller slightly with a pulley remover or an alternative tool.
If it is moved completely, the spring and rotating ring will run into the key.



7. Remove the impeller by hand.




8. Then remove the spring.



9. Remove the key.

Note

Pull the key up out of the way with pliers or an alternative tool.



Note

Insert a flat head (watchmaker's) screwdriver into a gap between the key and key way, and remove the key using the screwdriver as a lever.



-
10. Move the dynamic seal from pump, together with the cover (back casing).

Note

Move them with a pulley remover or an alternative tool.



-
11. Remove the dynamic seal from the motor shaft.



12. Then, remove the cover.



13. Remove the O-ring from the cover.



14. Then, remove the stationary seal which has been fitted into the cover.

Note


Turn the cover over and push the visible stationary seal lightly with a screwdriver end to remove it. Be careful not to damage it.



15. Pull the rubber washer off of the motor shaft.

Note

The rubber washer covers the gap of motor shaft bearing. It can be removed by pulling up with fingers.



16. Removal is complete.



■ Cleaning procedure


Note

Remove the adhered contamination with file, sandpaper and sponge abrasive material.

Note

When wiping off the contamination with alcohol, there should not be a large amount of inflammables or fire, and the area should be sufficiently ventilated.
Never use alcohol in a sealed place.


1. Clean the motor flange (cover mounting face).



2. Clean the key way of the motor shaft.




- 3.** Clean the outer surface and step part of the motor shaft.





-
- 4.** Clean the end surface of the cover.




-
- 5.** Clean the key.



6. Clean the end surface of the impeller.



7. Clean the key way and inner surface of the impeller.




■ Remounting procedure

1. Install a new rubber washer onto the motor shaft, and press it against the outer surface of the motor.

Note

Cover the gap of the motor shaft bearing by pushing it lightly.



2. Install a new stationary seal into the cover.



Note

Push it firmly with a pushing tool or an alternative tool.




3. Install the cover with the stationary seal onto the motor shaft, and push it into the motor bracket.

Note

Confirm that the cover put onto the motor bracket can be rotated by hand.

Note

Align the parts using the "Alignment marks" drawn on before disassembling the product. If the marks have been rubbed off, the water passage block should be mounted pointing at the top of the motor.



Water passage block


4. Install dynamic seal a new rotating ring onto the motor shaft.

Note

Wet the inner part (rubber lip) of the dynamic seal slightly with water and insert the rotating ring by sliding it.

Note

Never apply oil, It can damage the rubber.



Note

Push the dynamic seal until it comes into contact with the fixed ring. Confirm that the end of the rubber lip of the dynamic seal is almost the same surface level as the step part of the motor shaft.

Note

If the dynamic seal does not come into contact with the stationary seal, it may lead to liquid leakage.

Make contact it firmly with a pushing tool or an alternative tool.



5. Install the key into the key way of the motor shaft.

Note


If it is difficult to fit the key, remove the burrs caused by the file.

Note

The direction (right or left; front or rear; front or back) of the key is not specified.

Note

Put the key with pliers and a plastic hammer. Be careful not to crush the R part of the key way with the edge of the key.



6. Install a new spring onto the motor shaft.

Note

Install it with the spring tang pointing to the top of the pump, as shown.



7. Install the impeller onto the motor shaft.

Note


Install it by aligning the key and the key way of the impeller.

Note

If it is difficult to insert the impeller, remove the burrs using a file.

Note

Hang the spring tang on the groove of the impeller.



Groove

8. Slide the impeller to the specified motor shaft position, and fix it with grub screws.

Note


Insert the thickness gauge (Pump manufacturer's model DKH, DNH: 0.03 mm, DKL, DNL: 0.05 mm) into a gap between the impeller and the cover, and tighten it temporarily.

Note

Pull out the thickness gauge after the temporary tightening, and tighten the hollow set screws to the specified tightening torque (1.5 N·m) to fix the impeller.

Note

After tightening the hollow set screws, remove the seal (silver) on the rear face of the motor. And then, insert the flat head screwdriver to the motor shaft to check if it rotates smoothly.



Seal to remove

9. Install a new O-ring (Thickness: 2 mm) onto the cover.




10. Put the body over the cover of Step 9.

Note

The O-ring should not be caught on the body.

Note

Align the parts using the "Alignment marks" draw on before disassembling the product. If the marks have been gone, align the water passage blocks.



11. Fix the body of Step 10 to the motor bracket by tightening the hexagon socket head cap screws.

Note

The tightening torque of the hexagon socket head cap screw is 5.2 N·m.
Tighten them so that a gap remains between the body and motor bracket.
No liquid leakage will occur even if there is a gap as an O-ring seal is used.
Be careful not to tighten the screws excessively, otherwise the body may deform.



Gap should remain

12. Remove the seal (silver) on the rear face of the motor of Step 11. And then, use the flat head screwdriver to check if the motor shaft rotates smoothly.

Note

If it does not rotate smoothly, the body or cover may come into contact with the impeller.
If so, disassemble and reassemble the product again until the motor shaft rotates smoothly.



■ Inspection and precautions before use

1. Install the pump to a thermo-chiller and confirm that no liquid leaks from the mechanical seal.

Note

Refer to the separate service manual (HRX-MM-M056, P013) for installation of the pump to thermo-chiller.

Note

If liquid leaks, perform the removal, cleaning and remounting procedure again until the liquid leakage is stopped.

2. Confirm that there is no abnormality (vibration or noise) when running the pump.

Note

If some errors were found, reinspect the parts and assembly condition.

3. Lastly, wipe off the "Alignment marks" with alcohol. The replacement procedure is complete.

6

Fluorocarbon Recovery Procedure

This section describes the basic structure of the recovery equipment and the recovery method. Please refer to the catalogs and instruction manuals provided by the recovery equipment manufacturer for details.

⚠ CAUTION

The previous “Law Concerning the Recovery and Destruction of Fluorocarbons” was revised, and the new “Act on Rational Use and Proper Management of Fluorocarbons” (abbreviated as the “Fluorocarbons Emission Control Law”, and commonly known as the “Revised Fluorocarbons Law”) was put into force in April 2015.

The new law mandates that the recovery and filling of fluorocarbons during the maintenance of a Class I Specified Product ^{Note 1)} such as a thermo-chiller only be performed by qualified Class I Fluorocarbon Filling and Recovery Operators ^{Note 2)} registered in the prefecture in which the place of maintenance is located and having sufficient knowledge about the special inspections and periodic inspections of fluorocarbons (Class I Refrigerant Fluorocarbons Handling Engineer ^{Note 2)} or Class II Refrigerant Fluorocarbons Handling Engineer ^{Note 3)}.

We ask the owners (or managers) of our thermo-chillers to check the qualifications of the maintenance personnel when they arrive on the premises.

Note 1) Commercial air conditioners, freezing equipment, and refrigeration equipment filled with fluorocarbon as a refrigerant (excluding Class II Specified Products and car air conditioners) including thermo-chillers.

Note 2) Previously known as Class I Fluorocarbon Recovery Operators

Note 3) Qualification certified by the Japan Association of Refrigeration and Air Conditioning Contractors in line with the enforcement of the Fluorocarbons Emission Control Law

Note 4) Qualification certified by the Japan Refrigerants and Environment Conservation Organization

Structure of Recovery Equipment

The fluorocarbon in the thermo-chiller is sucked into the system side port on the recovery equipment (built-in compressor). The fluorocarbon is then liquefied by the built-in air-cooled condenser and discharged from the cylinder side port. The fluorocarbon is then filled into the recovery cylinder.


[Recovery equipment]



Fan (Air-cooled condenser)

Specifications (Example)

Name/Application	Fluorocarbon recovery equipment
Recovery method	Compressor system (with high-pressure cutoff function)
Types of fluorocarbons that can be recovered	R134a, R404A, R407C, R410A, etc.
Recovery cylinder	With float switch exclusively for recovery equipment 21 L
Safety device	Overfilling prevention (High-pressure cutoff, Float switch)
(Power supply)	(100 VAC (50 Hz, 60 Hz))
(Weight)	(Approx. 10 kg)



[Accessories]

① Adapter hose



② IN side filter

③ Red hose
(With ball valve)

④ Power supply cable



Other Tools to be Prepared


1. Prepare a recovery cylinder (designated by the recovery equipment manufacturer) for each type of fluorocarbon.

CAUTION


Be sure to use the cylinder designated by the recovery equipment manufacturer.

CAUTION

When using an empty cylinder for the first time, be sure to vacuum it to -0.1 [MPa] before use. If any uncondensed gas (e.g. nitrogen, air) remains in the cylinder, the inner pressure will rise during the recovery of the fluorocarbon, causing the safety device to be activated. Use extreme caution.



Cylinder vacuuming



Recovery cylinder
(one for each type of fluorocarbon)


2. Prepare a gauge manifold and hose for each type of fluorocarbon.

⚠ CAUTION

Use the gauge manifold and hoses exclusively for each type of fluorocarbon.

Gauge manifold
(one for each type of fluorocarbon)

Red hose (For high pressure)
Blue hose (For low pressure)




■ Connection with Recovery Cylinder and Gauge Manifold

1. Connect one end of the provided red hose to the OUT port on the recovery equipment and the other end to the red valve on the cylinder (liquid side).

⚠ CAUTION

There are cases in which the valve colors are reversed (depending on the recovery equipment manufacturer). Use extreme caution.

2. Connect one end of the yellow hose to the IN port on the recovery equipment and the other end to the provided IN side filter. Then, connect one end of the provided adapter hose to the IN side filter and the other end to the center port of the gauge manifold.



■ Connection of the Power Supply Cable and Float Switch (Safety Device) Cable

1. Connect one end of the provided power supply cable ④ to the recovery equipment and the other end to the 100 VAC power supply.
2. Connect the float switch cable on the recovery equipment to the float switch on the recovery cylinder.

⚠ CAUTION


**Be extremely careful regarding the position of the cable terminal pin.
Connecting the cable forcibly may damage the pin.**

■ Connection with Thermo-chiller

1. Connect one end of the red hose to the gauge manifold and the other end to the charge port (high-pressure side) of the thermo-chiller.


⚠ CAUTION

All connections must be appropriate and sufficiently tightened.




■ Preparation for Recovery

1. Turn both the system side valve and the cylinder side valve on the recovery equipment to the CLOSED position.
2. Read off the weight of the recovery cylinder before starting the recovery process.
3. Open (turn counterclockwise) the red valve (liquid side) on the cylinder.
4. Open the red valve (high-pressure side) on the gauge manifold.
5. Check that the needle of the pressure gauge (high-pressure side) on the gauge manifold goes up.
6. Check again that both the system side (thermo-chiller side) valve and the cylinder side valve on the recovery equipment are set to the CLOSED position.




7. Turn the cylinder side (right side) valve on the recovery equipment to the OPEN position.



Starting the Recovery Process


1. Turn the power supply switch to ON. (Activate the recovery equipment.)
2. Turn the system side (thermo-chiller side) valve on the recovery equipment to the liquid recovery position.



3. Then, turn the system side (thermo-chiller side) valve slowly to the gas recovery position.

Tips

If the recovery equipment generates violent knocking, slowly turn the system side (thermo-chiller side) valve in the CLOSED direction until the knocking weakens. After the knocking weakens, turn the valve to the gas recovery position, and resume the fluorocarbon recovery.




4. After the pressure on the system side (thermo-chiller side) has remained at -0.08 [MPa] for approximately 20 seconds or longer, turn the power supply switch to OFF to stop the recovery equipment.

Tips


When the fluorocarbon remaining in the thermo-chiller has vaporized, the gauge pressure of the gauge manifold will increase again. Continue to repeat the recovery process until the gauge pressure stops increasing.

■ Finishing the Recovery Process

1. Close the red valve (high-pressure side) on the gauge manifold.
2. Close the system side (thermo-chiller side) valve on the recovery equipment. Leave the cylinder side valve open at this point.



3. When the pressure remains stable at -0.08 [MPa], turn the power supply switch to OFF to stop the recovery equipment.
4. Close the red valve on the recovery cylinder.
5. Close the cylinder side valve on the recovery cylinder.



6. Read off the weight of the recovery cylinder after the recovery process.
7. Lastly, disconnect all hoses.

CAUTION

**Check the IN side filter for dirt.
If the filter is dirty, replace it with a new one.**

■ Submission of Certificate for Fluorocarbon Recovered

1. After the recovery process, calculate the difference in the weight of the cylinder before and after the recovery process to obtain the amount recovered.
2. Enter the amount recovered in the “Certificate for Fluorocarbon Recovered,” and submit it to the manager (customer).

Form (Sample)

Certificate for Fluorocarbon Recovered				
Certificate no.				
Date of issue	Month	Date	Year	
Date of recovery	Month	Date	Year	
Type and amount of fluorocarbon recovered	Type (R no.)	R–	Amount (kg)	
Manager who ordered the maintenance (E.g. owner of equipment)	Address			
	Name			
Person in charge of control	Address			
	Name		Department	
	TEL		email	
Location of equipment from which fluorocarbon was recovered	Address			
	Name of facility (E.g. name of building)			
Specific equipment information	Control no.			
	Model no.		Product no.	
Fluorocarbon Filling and Recovery Operator	Address			
	Name			
	TEL		Registration no.	
Recovered by or witnessed by (E.g. Refrigerant Fluorocarbons Handling Engineer)	Name		Qualified person no.	


To managers of equipment
 Note: Store this “Certificate for Fluorocarbon Recovered” as it will be necessary to calculate the leakage amount.

[Reference documents]


- Bosch Automotive Service Solutions Corp., Operation Manual for the RG3000J made by RoBINAIR
- Industrial Network for Fluorocarbon Recovery Promotion (INFREP), Fluorocarbon Recovery Guideline, March 25, 2009
- Ministry of the Environment, Ministry of Economy, Trade, and Industry, “Act on Rational Use and Proper Management of Fluorocarbons (Fluorocarbons Emission Control Law) – Guidelines for Operation Concerning Filling and Recovery Operators” (1st edition issued in March 2015)

Flow Chart

HRS012-A□-□, HRS018-A□-□, HRS024-A□-20, HRS030-A□-20



HRS012-W□-□, HRS018-W□-□, HRS024-W□-20, HRS030-W□-20



Required tools


Some special tools are required in the procedure

Charge valve (Example)

HRS chiller equips Schrader core valve at the service port.

When remove the charging hose from the Schrader core valve, you experienced to have not a little amount of refrigerant was evacuated from the system.

By using the charge valve, you can disconnect the charging hose with minimum refrigerant loss from the system. The size of the parts are varied depending on the model. Please use the charge valve with the service port to fit.



Gauge Manifold for R407c/R410a and charging hose

High pressure gauge ... -1 to 35 x 100 kPa (-1 to 35bar)

Low pressure gauge -1 to 15 x 100 kPa (-1 to 15bar)

Charging hose (Red, Yellow) 0.92 m UNF7/16 (1/4 flare)

You cannot use a gauge manifold for R22



Gauge manifold



Charging hose

❗ We cannot use another length charging hose.

Weight scale

Min. Resolution 2 g, 0.005 lbs. , 0.1 oz.

Accuracy +/- 0.5%

Max. weight 100 kg (220 Pounds)

[Example] Brand: AccuTools

Model#: DS-220R



Weight scale

● Refrigerant gas cylinder

R407C/R410A



Refrigerant gas cylinder

● Vacuum pump



Vacuum pump

● Tools

No.1	Description	Q'ty	Note
1	Screwdriver	1	Phillips head screwdriver
2	Wrench	2	100 mm
3	Protective glove	1	Rubber glove

Procedure

⚠ WARNING



There is danger of an electric shock. Be sure to turn the power off before installation work.



There is danger of an electric shock and burn. Be careful enough not to be hurt during the work.

⚠ CAUTION



When mounting or removing the panel, be sure to wear protective gloves or shoes to prevent injuries from its sharp edges.

1. Remove panel and install the charge valve

View after removal of the upper panel and the side paneler.



The service port is in the high pressure line.





Fig. 7-1

2. Vacuum

The vacuum pumping has to be more than 30 minutes.

❗ The charging hose (Red) shall be 0.92 M length



3. Charging

Setup the equipment as Fig. 7-2 for the refrigerant charging
Purge out the air from the charging hose

⚠ CAUTION



Wear gloves to protect your hands from frostbite from the refrigerant gas.

Charge the refrigerant carefully adjusting the valve opening on the gauge manifold so that you can control precise charge amount



Hint: Close the valve on the gauge manifold when getting 1g before getting the desired charging amount.



After the charging operation, around 12g of the refrigerant will be existing in the 0.92m charging hose (Red hose in the Fig.7-2).

Table 7-1. The amount of refrigerant (HRS012/018/024/030)

Unit g

Refrigerant gas	HRS012-A-10 HRS018-A-10	HRS012-A-20 HRS018-A-20 HRS024-A-20	HRS012-W-10 HRS018-W-10	HRS012-W-20 HRS018-W-20 HRS024-W-20	HRS030-A-20	HRS030-W-20
R407C	320 ±5	350 ±5	255 ±5	300 ±5	565 ±15	495 ±15

Table 7-2. The amount of refrigerant (HRS050/060)

Unit g

Refrigerant gas	HRS050-A-20	HRS050-W-20	HRS060-A-20	HRS060-W-20
R410A	655 ±15	655 ±15	845 ±15	735 ±15

- ❗ You have to count 12 g of refrigerant that will remain in the 0.92 m charging hose
You have to add 12 g extra on above charging amount when you check the scale indication measuring the weight decrease of the refrigerant cylinder.




Fig. 7-2 Charging



Hint: The service port is located in high pressure side of refrigeration system, so you cannot add refrigerant into the system during the chiller in operation,

■ Submission of Certificate for Fluorocarbon Filled

1. After the filling process, calculate the difference in the weight of the cylinder before and after the filling process to obtain the amount filled.
2. Enter the amount filled in the “Certificate for Fluorocarbon Filled,” and submit it to the manager (customer).

Form (Sample)

Certificate for Fluorocarbon Filled				
Certificate no.				
Date of issue	Month	Date	Year	
Date of filling	Month	Date	Year	
Type of fluorocarbon filled	Type (R no.)	R–	GWP value	
Amount of fluorocarbon filled	Amount filled (kg)		Amount filled with fluorocarbon recovered (kg)	
The timing at which the fluorocarbon was filled (Circle either item.)	Filled when maintenance of the equipment was performed		Filled onsite when the new equipment was installed	
Manager who ordered the maintenance (E.g. owner of equipment)	Address			
	Name			
Person in charge of control	Address			
	Name		Department	
	TEL		email	
Location of equipment into which fluorocarbon was filled	Address			
	Name of facility (E.g. name of building)			
Specific equipment information	Control no.			
	Model no.		Product no.	
Fluorocarbon Filling and Recovery Operator	Address			
	Name			
	TEL		Registration no.	
Filled by or witnessed by (E.g. Refrigerant Fluorocarbons Handling Engineer)	Name		Qualified person no.	

To managers of equipment
 Note: Store this “Certificate for Fluorocarbon Filled” as it will be necessary to calculate the leakage amount.

[Reference document]

- Ministry of the Environment, Ministry of Economy, Trade, and Industry, “Act on Rational Use and Proper Management of Fluorocarbons (Fluorocarbons Emission Control Law) – Guidelines for Operation Concerning Filling and Recovery Operators” (1st edition issued in March 2015)

Types of Fluorocarbons and Regulations

Name	Characteristics	Application
CFC / Chlorofluorocarbons	Ozone layer depleting substances including chlorine Complete abolition ^{Note 1)} was required by the Montreal Protocol. Specified CFCs including R11, 12, 113, 114, and 115	<ul style="list-style-type: none"> Refrigerant: Refrigerators, car air conditioners Foaming agent Cleaning agent Aerosol (spray)
HCFC / Hydrochlorofluorocarbons	Alternative CFCs of specified CFCs These are still ozone layer depleting substances including chlorine. Complete abolition ^{Note 2)} was required by the Montreal Protocol. R22, 123, 141b, 142b, 225, etc.	<ul style="list-style-type: none"> Refrigerant: Refrigerators, room air conditioners, packaged air conditioners, air dryers, chillers, etc. Foaming agent Cleaning agent
HFC / Hydrofluorocarbons	Alternative CFCs of specified CFCs Although these do not include chlorine, and thus do not deplete ozone layers, these are called greenhouse gases because their global warming potential (GWP) is approximately hundreds to four thousand times that of carbon dioxide. These are listed in the substances targeted for reduction specified by the Kyoto Protocol ^{Note 3)} . R32, R134a, 404A, 407C, 410A, etc.	<ul style="list-style-type: none"> Refrigerant: Refrigerators, room air conditioners, packaged air conditioners, air dryers, thermo-chillers, etc. Foaming agent Cleaning agent Aerosol (spray)
HFO / Hydrofluoroolefins	Substances having low GWP and less impact on global warming However, there are few examples of these substances being used in refrigeration equipment because of their combustion characteristics. R1234yf, 1234ze, etc.	<ul style="list-style-type: none"> Refrigerant: Car air conditioners Foaming agent Cleaning agent
Natural refrigerant / Refrigerants other than fluorocarbons	Substances used as refrigerant during the initial stages of refrigeration equipment development Ammonia (NH ₃ , GWP0), which is hazardous if it leaks during handling, carbon dioxide (CO ₂ , GWP1), water (H ₂ O), hydrocarbons (HC) such as propane, air, etc.	<ul style="list-style-type: none"> Refrigerant: Refrigerators of some manufacturers and commercial refrigerators Foaming agent Cleaning agent Aerosol (spray) Dry-cleaning (solvent)

Note 1) They have already been abolished completely in advanced nations. They were abolished at the end of 2009 in developing nations.


Note 2) They will be abolished completely by 2020 in advanced nations, and by 2030 in developing nations.

Note 3) Concerning Japan's CO₂ reduction target, Japan was able to successfully reduce emissions by 8.4%, achieving their target (reduction by 6% compared to 1990) of the first commitment period (2008 to 2012).

For the target (reduction by 25% compared to 1990) of the second commitment period (2013 to 2020), Japan declared non-participation due to the Great East Japan Earthquake.

For more information, refer to the website of the Ministry of Economy, Trade, and Industry and the Ministry of the Environment.

Reduction Plan in Accordance with the Montreal Protocol, Kyoto Protocol, and Paris Agreement



Excerpt: Ministry of the Environment and Ministry of Economy, Trade, and Industry, "Overview of the Fluorocarbons Emission Control Law - Required Efforts based on the Revised Law" (January 2015)

The “Act on Rational Use and Proper Management of Fluorocarbons” (the “Fluorocarbons Emission Control Law”) was put into force in April 2015.

To protect the ozone layer and prevent global warming, owners (or managers) of chillers are obliged to control the emission of fluorocarbons (CFC, HCFC, HFC).

In response to this, measures that must be implemented by customers are described below.

We ask customers to implement these measures appropriately.



Obligation concerning the installation of equipment

Check!

■ Install equipment in an appropriate location.

To prevent damage to the equipment, install the equipment in an appropriate location and maintain the installation environment.

* Do not install a source of vibration near the equipment. Provide sufficient space for inspection and repair. Clean around the equipment.



Obligations concerning the use of equipment

Inspect!

■ Implement equipment inspection.

Implement the simple inspection of all pieces of equipment. For equipment larger than the specified size, implement periodic inspection by an expert.

* To fulfill the obligation, consider making a list of equipment owned or to be managed, establishing an inspection system and creating a schedule.

Repair!

■ Implement leak prevention measures and prohibit the filling of unrepaired equipment with refrigerant*.

Repair the equipment when a leak of fluorocarbon is found.

Filling unrepaired equipment with fluorocarbon is prohibited as a rule.

* The filling of fluorocarbons must be entrusted to a Class I Fluorocarbon Filling and Recovery Operator registered in the relevant prefecture.

Record!

■ Store inspection history.

Concerning the equipment inspection and maintenance history, keep records for each piece of equipment, and store these records until the equipment is disposed of.

Calculate! Report!

■ Calculate and report the fluorocarbon leakage amount.

Calculate the leakage amount upon receipt of the “Certificate for Fluorocarbon Filled/Recovered” issued by the Class I Fluorocarbon Filling and Recovery Operator. If the leakage amount is more than the specified level, this must be reported to the nation every fiscal year.

* The leakage amount reported is officially announced with the name of the company.

* To fulfill the obligation, consider establishing a system of tallying the amount filled and amount recovered and creating a schedule.



Obligation concerning the disposal of equipment

Recover!

■ Thoroughly recover fluorocarbons* when disposing of equipment.

Entrust the recovery of unnecessary fluorocarbons, issue the “Request for Recovery” or the “Confirmation of Entrustment,” and bear the cost of the recovery, recycling, and destruction of the fluorocarbons.

* The recovery of fluorocarbons must be entrusted to a Class I Fluorocarbon Filling and Recovery Operator registered in the relevant prefecture.

*1

Implement equipment inspection.

The two types of equipment inspection based on the “Fluorocarbons Emission Control Law” are as follows:

■ **Simple inspection intended for all commercial air conditioners, freezing equipment, and refrigeration equipment (Visual checks of product appearance, etc.)**

■ **Periodic inspection intended for commercial air conditioners, freezing equipment, and refrigeration equipment larger than the specified size (Inspection conducted by an expert)**

The table below summarizes the products subject to periodic inspection and the inspection frequency based on the laws.

For refrigerated air dryers and refrigerated thermo-chillers (including coolers) * Excerpted from website

	Inspection frequency	Compressor output	Refrigerated air dryer	Refrigerated thermo-chiller (Production of the underlined series has been terminated.)
Simple inspection	At least once every 3 months	Less than 7.5 [kW]	All IDF□ series IDU series IDH series INOD series	All HRZ□ series HRS□ series INR-496 series <u>INR-497 series</u> <u>INR-499 series</u> INR-242-12□ HRG□ series <u>INR-242 series</u> <u>INR-338 series</u> <u>INR-341 series</u> <u>INR-57□ series</u>
Periodical inspection	At least once every year	7.5 [kW] or more	IDF370B IDF370D only	HRZ008-L HRZ008-L1 only

*2

Store inspection history.

Carefully read the instructions below, and be sure to store the “Refrigerant Leakage Inspection and Maintenance Record” (refer to page 453).

[Instructions for filling out the Refrigerant Leakage Inspection and Maintenance Record]

- ① Visit the website of the Japan Association of Refrigeration and Air Conditioning Contractors (<http://www.jarac.or.jp/kirokubo/>), and download the “Refrigerant Leakage Inspection and Maintenance Record” (normal version of Excel macro execution type) in compliance with the “Fluorocarbons Emission Control Law”. Prepare a record for each thermo-chiller and store it in an appropriate location. Ensure that the name of the manager has been entered.
- ② Use one of the specialized companies (a Class I Fluorocarbon Filling and Recovery Operator) tied up with SMC, wherever possible.
Only an expert qualified as a Class I or Class II Fluorocarbons Handling Engineer may implement inspection.
- ③ For the refrigerant to be used, total initial amount filled, and initial amount filled at production, copy the refrigerant type and the amount filled provided on the nameplate on the rear of the thermo-chiller or in the catalog. Enter “Less than 7.5 kW” for the compressor output and “0.00 kg” for the additional amount filled at installation.
- ④ Conduct a simple inspection of all thermo-chillers at least once every three months, and record the results. Conduct a comprehensive inspection along with the “Daily Check Sheet” (indirect method) provided in the Operation Manual.
- ⑤ Inspection can be undertaken by one of the specialized companies tied up with SMC in place of the customer.
- ⑥ If any repairs are made, record the amount recovered, amount filled, and repair details.
- ⑦ Continue to conduct inspections and record the results according to the specified frequency.

[illegible]

For information about how to perform daily checks of the thermo-chiller, refer to section "8.21 Daily Check" in the "Operation Manual".

Check and record the condition at startup right after setting up.

[illegible]

*3

Calculate and report the fluorocarbon leakage amount.

It is necessary to calculate the leakage amount (each business operator, each business place) using the formula below based on the “Certificate for Fluorocarbon Filled/Recovered” issued by the Class I Fluorocarbon Filling and Recovery Operator.

$$\text{Fluorocarbon leakage amount calculated (CO}_2\text{-t)} \\ = (\text{Amount filled (kg)} - \text{Amount recovered at maintenance of} \\ \text{equipment (kg)}) \times \text{Global warming potential}/1,000$$

If the leakage amount calculated every fiscal year exceeds 1,000 CO₂-t, it must be reported to the nation (government agency in charge of business) by the end of July of the next fiscal year.

A penalty is imposed on companies that violate the obligation required by the “Fluorocarbons Emission Control Law” as below.

- Discharge of fluorocarbons without good reason **Imprisonment for up to 1 year or fine of up to 500,000 yen**
- Violation of the municipal or prefectural governor's orders concerning the obligations related to the use or disposal of equipment **Fine of up to 500,000 yen**
- Non-report or false report of leakage amount calculated .. **Administrative penalty of up to 100,000 yen**

If you need further information regarding the management of equipment, the recovery of fluorocarbons, etc., contact the manufacturer of the air conditioner, freezing equipment, or refrigeration equipment, or the maintenance agency, prefectural government, Ministry of the Environment, Ministry of Economy, Trade, and Industry, or visit the website shown below.

Ministry of the Environment,

Global Environment Bureau, Climate Change Policy Division,
Office of Fluorocarbons Control Policy
1-4-2, Kasumigaseki, Chiyoda-ku, Tokyo 100-0013

[TEL] 03-3581-3351 (Main number)
[URL] <http://www.env.go.jp/seisaku/list/ozone.html>

Ministry of Economy, Trade, and Industry,

Manufacturing Industries Bureau, Chemical Management Policy
Division, Fluoride Gases Management Office
1-3-1 Kasumigaseki, Chiyoda-ku, Tokyo 100-8901

[TEL] 03-3501-1511 (Main number)
[URL] http://www.meti.go.jp/policy/chemical_management/ozone/index.html

* The list of contacts of prefectural bureaus in charge of the Fluorocarbons Emission Control Law is provided on the website of the Ministry of the Environment.

[Excerpt]

Ministry of the Environment, the “Act on Rational Use and Proper Management of Fluorocarbons” (the “Fluorocarbons Emission Control Law”) was put into effect in April 2015.

8

Fluorocarbons

Importing restrictions on Hydrofluorocarbons (HFCs) into the European Union (EU).

Did you know that?

EU F-Gas Regulation (517/2014)

Refrigeration equipment using HFC refrigerant imported into the EU from January 2017, such as refrigerated Thermo-chillers and Air dryers, is subject to this regulation.



HFCs imported into the EU must be from the EU Quota system.


- It shall apply to producers or importers of 100 tonnes and more **CO₂ equivalent*** of hydrofluorocarbons per year.
- European Commission annually allocates 'Quotas' to manufacturers and importers of HFC refrigerants.
- Quota holders can give 'authorisation' to refrigeration equipment importers to use a specified amount of quota held by the quota holder.

* **CO₂ equivalent** is calculated by multiplying the global warming potential (GWP) with the amount of HFC refrigerants.
100 tonnes
Ex.: equivalent to 156 of Thermo-chiller (HRS024-A-20).

SMC Europe

holds 'Authorisation' for import.

Purchasing products from our local subsidiaries eliminates complex procedures.




List of local subsidiaries of SMC Europe (with import quota licenses available)

Ireland	SMC Pneumatics (Ireland) Ltd.	Spain/Portugal	SMC España SA
U.K.	SMC Pneumatics (U.K.) Ltd.	Denmark	SMC DANMARK A/S
Italy/Greece	SMC Italia S.p.A.	Germany	SMC Deutschland GmbH
Austria	SMC Pneumatik GmbH (Austria)	Finland	SMC Automation Oy
Netherlands	SMC Nederland BV	France	SMC France
Sweden	SMC Automation AB	Belgium	SMC Belgium NV/SA

* For more information, refer to page 456.


EU F-Gas Regulation (517/2014)

The European Union aims to reduce the environmental impact of HFCs via regulation. The EU commission released the new F-gas regulation. One of the key changes is implementing a phase down of the quantity of HFC that can be placed in the market by producers and importers between 2015 and 2030.



Effect of the EU F-Gas Regulation

From January 2017, importers who intend to import refrigeration equipment into the EU must first register on the European Commission 'HFC register' and obtain authorisation from an EU quota holder. This is mandatory.



Customer management of the F-Gas regulation*:

Each importer (customers local subsidiary / agent or end user) who receives the refrigeration equipment directly, must perform the above five tasks in Europe.

* This information is based on SMC's own investigation. It is recommended that customers conduct their own investigation into the European F-Gas Regulation 517/2014 and take appropriate actions at their discretion.

Safety Instructions Be sure to read the "Handling Precautions for SMC Products" (M-E03-3) and "Operation Manual" before use.

■ Handling of Thermo-chillers That Have Become Unnecessary

As SMC is not registered as a specialized handling operator based on the “Fluorocarbons Emission Control Law” and the “Industrial Waste Disposal Law,” we are not permitted to collect and dispose of thermo-chillers that users no longer require. If you are requested by users to collect such thermo-chillers, take action as described below.

<Response to users>

Explain to users that SMC is not permitted to collect unnecessary thermo-chillers (industrial waste) as we are not a Class I Fluorocarbon Filling and Recovery Operator, and then take either action described below.

Response 1: Introduce a maintenance agency qualified to conduct disposal.

Response 2: Ask users to directly request an operator registered with the local government.
(A list of registered operators can be found on the website of the relevant prefectural government or municipality.)

Filling and recovery of fluorocarbons and collection and transfer of industrial waste

1. Recovery of fluorocarbons

Equipment containing fluorocarbons must be disposed of by a Class I Fluorocarbon Filling and Recovery Operator based on the “Fluorocarbons Emission Control Law.”

<Reference>

Fluorocarbon Filling and Recovery Operators can implement the recovery process only in the prefecture where they are registered.

E.g.) An operator registered in Hiroshima Prefecture can only recover fluorocarbons in Hiroshima Prefecture and bring them to a Fluorocarbon Destruction Operator in Hiroshima Prefecture.

In the case where the fluorocarbons are recovered in Hiroshima Prefecture and then brought to a Fluorocarbon Destruction Operator in Yamaguchi Prefecture, this Fluorocarbon Filling and Recovery Operator must be registered in both Hiroshima and Yamaguchi Prefectures.

2. Disposal of industrial waste

After fluorocarbons are recovered from thermo-chillers, these chillers are handled as industrial waste. Based on the “Industrial Waste Disposal Law,” disposal of industrial waste must be entrusted to an Industrial Waste Collection and Transfer Operator registered with the local government.

<Reference>

Industrial Waste Collection and Transfer Operators must be registered in the location where they perform loading and unloading.

E.g.) If an operator loads the industrial waste in Kanagawa Prefecture and unloads it in Fukushima Prefecture, they must be registered in both of these prefectures.

Precautions when SMC collects and inspects a product

When a product is collected from the user to inspect alarm causes and it is determined that repair is not possible, you may be asked by the user to dispose of the product instead of returning it to them. However, SMC is not permitted to perform disposal due to the abovementioned “Fluorocarbons Emission Control Law” and the “Industrial Waste Disposal Law.”

When you are requested to collect and inspect a product, be sure to explain before collection that the product will be returned to the user even if it turns out to be irreparable.

Earthquake Resistance Strength Calculation: Selection of Anchor Bolts

This chapter describes how to select the anchor bolts that need to be prepared to prevent the product from falling in the case of an earthquake.

For customers, please provide the calculated values in this chapter when you make a request for the installation of a product to a company specializing in construction, foundation concrete placement, or installation work.

For companies specializing in construction, foundation concrete placement, or installation work, please check the calculated values in this chapter when you have received a request for product installation from a customer.

⚠ CAUTION

This chapter provides earthquake-proof calculations to cope with earthquakes of an anticipated side. These calculations do not guarantee resistance for earthquakes beyond anticipation. We ask for your understanding.

⚠ CAUTION

Calculation results vary greatly depending on the installation location (penthouse, roof floor, higher floors, middle floors, ground floor, or basement), horizontal seismic intensity for design, equipment weight, center of gravity position, or the interval, quantity, size or embedded length of the anchor bolts. Refer to “Seismic Design and Construction Guideline for Building Equipment” (2014 Edition) issued by The Building Center of Japan.

■ Installation Location and Anticipated Seismic Force

1) HRS012/018-A/W-10

Item			Model	HRS012/018 -A-10		HRS012/018 -W-10	
Thermo-chiller	Dry mass		[kg]	45			
	Tank capacity		[L]	5			
	Other capacity (Piping, etc.)		[L]	2			
	Fluid			Tap water			
	Fluid density		[kg/L]	1			
	Operating mass		m [kg]	52			
	Center of gravity	Height	h [cm]	25			
		From the left	[cm]	19		20	
		From the front	[cm]	28			
From the closest anchor bolt		Lg [cm]	11.85		10.85		
Installation location	Seismic zoning factor		Z [-]	1.0			
	Standard seismic intensity for design		Ks [-]	2.0			
	Horizontal seismic intensity for design		Z·Ks [-]	2.0			
	Vertical seismic intensity for design		Z·Ks/2 [-]	1.0			
Anticipated seismic force	Horizontal direction		F _H = m·Z·Ks [N]	1020			
	Vertical direction		F _V = m·Z·Ks/2 [N]	510			

2) HRS012/018/024-A/W-20

Item		Model	HRS012/018/024 -A-20	HRS012/018/024 -W-20
Thermo-chiller	Dry mass	[kg]	48	
	Tank capacity	[L]	5	
	Other capacity (Piping, etc.)	[L]	2	
	Fluid		Tap water	
	Fluid density	[kg/L]	1	
	Operating mass	m [kg]	55	
	Center of gravity	Height	h [cm]	26
		From the left	[cm]	18
		From the front	[cm]	28
		From the closest anchor bolt	Lg [cm]	11.15
Installation location	Seismic zoning factor	Z [-]	1.0	
	Standard seismic intensity for design	Ks [-]	2.0	
	Horizontal seismic intensity for design	Z·Ks [-]	2.0	
	Vertical seismic intensity for design	Z·Ks/2 [-]	1.0	
Anticipated seismic force	Horizontal direction	$F_H = m \cdot Z \cdot K_s$ [N]	1079	
	Vertical direction	$F_v = m \cdot Z \cdot K_s / 2$ [N]	539	

3) HRS050/060-A/W-20

Item		Model	HRS050/060 -A-20	HRS050/060 -W-20
Thermo-chiller	Dry mass	[kg]	69	67
	Tank capacity	[L]	5	
	Other capacity (Piping, etc.)	[L]	3	
	Fluid		Tap water	
	Fluid density	[kg/L]	1	
	Operating mass	m [kg]	77	75
	Center of gravity	Height	h [cm]	48.8
		From the left	[cm]	18.85
		From the front	[cm]	296
		From the closest anchor bolt	Lg [cm]	12
Installation location	Seismic zoning factor	Z [-]	1.0	
	Standard seismic intensity for design	Ks [-]	2.0	
	Horizontal seismic intensity for design	Z·Ks [-]	2.0	
	Vertical seismic intensity for design	Z·Ks/2 [-]	1.0	
Anticipated seismic force	Horizontal direction	$F_H = m \cdot Z \cdot K_s$ [N]	1510	1471
	Vertical direction	$F_v = m \cdot Z \cdot K_s / 2$ [N]	755	735

■ Anchor Bolt (M8), Anti-quake Bracket (HRS-TK001/002) Specifications

Item			Specifications
Anchor bolt	Nominal		M8
	Total quantity	n [pcs.]	4
	Quantity per side	nt [pcs.]	2
	Effective area (For coarse bolts)	A_n [mm ²]	36.6
	Material		SS400
	Tensile strength	[MPa] (N/mm ²)	400 to 510
	Yield point or proof stress	[MPa] (N/mm ²)	235 or more
Anti-quake bracket (Optional accessory)	Part no.		HRS-TK001/002
	Anchor bolt through-hole pitch	Short side L [cm]	24
		Long side [cm]	Refer to the Web Catalog.
Construction method	Embedded length [mm]		40
	Foundation strength (Concrete)	[MPa] (N/mm ²)	18 or more

■ Force Acting on Anchor Bolts

1) HRS012/018-A/W-10

Item		Model	HRS012/018 -A-10	HRS012/018 -W-10
Overturning moment (Seismic force in horizontal direction)		$M_H = F_H \cdot h$ [N·m]	255	
Vertical moment (Seismic force in vertical direction)		$M_v = F_v \cdot L_g$ [N·m]	60.4	55.3
Resisting moment (Dead weight of thermo-chiller)		$M_m = 9.8 \cdot m \cdot L_g$ [N·m]	60.4	55.3
Force acting on anchor bolts	Pull-out force	$R_b = (M_H + M_v - M_m) / (L \cdot n_t)$ [N/pc.]	531	531
		Short-term allowance (Refer to page 462.) [N/pc.]	3,000	
	Tensile stress	$\sigma = R_b / A_n$ [MPa/pc.]	14.51	14.51
		Short-term allowance [= Yield point or proof stress] [MPa/pc.]	235	
	Shearing stress	$\tau = F_H / (n \cdot A_n)$ [MPa/pc.]	6.97	
		Short-term allowance [= Yield point or proof stress/ $\sqrt{3}$] [MPa/pc.]	136	

2) HRS012/018/024-A/W-20

Item		Model	HRS012/018/024 -A-20	HRS012/018/024 -W-20
Overturning moment (Seismic force in horizontal direction)		$M_H = F_H \cdot h$ [N·m]	280	
Vertical moment (Seismic force in vertical direction)		$M_V = F_V \cdot L_g$ [N·m]	60.1	63.9
Resisting moment (Dead weight of thermo-chiller)		$M_m = 9.8 \cdot m \cdot L_g$ [N·m]	60.1	63.9
Force acting on anchor bolts	Pull-out force	$R_b = (M_H + M_V - M_m) / (L \cdot n_i)$ [N/pc.]	584	584
		Short-term allowance (Refer to page 462.) [N/pc.]	3,000	
	Tensile stress	$\sigma = R_b / A_n$ [MPa/pc.]	15.96	15.96
		Short-term allowance [= Yield point or proof stress] [MPa/pc.]	235	
	Shearing stress	$\tau = F_H / (n \cdot A_n)$ [MPa/pc.]	7.37	
		Short-term allowance [= Yield point or proof stress/ $\sqrt{3}$] [MPa/pc.]	136	

3) HRS050/060-A/W-20

Item		Model	HRS050/060 -A-20	HRS050/060 -W-20
Overturning moment (Seismic force in horizontal direction)		$M_H = F_H \cdot h$ [N·m]	737	718
Vertical moment (Seismic force in vertical direction)		$M_V = F_V \cdot L_g$ [N·m]	90.6	88.3
Resisting moment (Dead weight of thermo-chiller)		$M_m = 9.8 \cdot m \cdot L_g$ [N·m]	90.6	88.3
Force acting on anchor bolts	Pull-out force	$R_b = (M_H + M_V - M_m) / (L \cdot n_i)$ [N/pc.]	1,535	1,496
		Short-term allowance (Refer to page 462.) [N/pc.]	3,000	
	Tensile stress	$\sigma = R_b / A_n$ [MPa/pc.]	42.0	40.9
		Short-term allowance [= Yield point or proof stress] [MPa/pc.]	235	
	Shearing stress	$\tau = F_H / (n \cdot A_n)$ [MPa/pc.]	10.3	10.0
		Short-term allowance [= Yield point or proof stress/ $\sqrt{3}$] [MPa/pc.]	136	


Result of Anchor Bolt Selection (Result of Earthquake Resistance Strength Calculation)

If an anchor bolt with a sufficient pull-out load, compared to the pull-out force acting on the anchor bolt shown in the above calculation sheets, is selected, the size of the anchor bolt will be larger than the extension type shown below. Check with the bolt manufacturer for details.

Anchor bolts will differ depending on the installation location at the customers' premises and the strength of the floor or foundation concrete.

Regarding these points, consult with the company specializing in construction, foundation concrete placement, or installation work with which you request installation.

Post-installed male thread type mechanical anchor bolt



Extension type

Short-term allowable pull-out load (kgf)


Bolt size d (Nominal)	Concrete thickness (mm)				Embedded length L (mm)
	120	150	180	200	
M8	300	300	300	300	40
M10	380	380	380	380	45
M12	670	670	670	670	60
M16	920	920	920	920	70
M20	1,200	1,200	1,200	1,200	90
M24	1,200	1,200	1,200	1,200	100
Limit of embedded length of bolt (L)	100 or less	120 or less	160 or less	180 or less	

[Excerpt] "Earthquake-proof Calculation Software for Equipment" explanatory material prepared by the Japan Federation of Mechanical & Electrical Consulting Firms Association


10

Customer Support Flow Chart for Use in the Event of a Problem

Customer support flow chart for when there is a problem with a product an end user in country B has purchased from a distributor in country A



This flow chart has been created based on the information provided in the “S-ComPa 2 PAGE” and “Chiller Maintenance” materials. Refer to these materials for details.



Question		Answer	Refer to
Replacement parts	How can I find the part number of the replacement parts?	Refer to "Construction" and "Replacement Parts List" in this handbook as well as the Service Manual.	This handbook: Construction, Replacement Parts List (pages 33 to 111)
	What is the replacement cycle of the mechanical seal?	The approximate cycle is every 6,000 to 8,000 hours of operation. When 8,000 hours have passed, you will be notified by AL28 (Pump maintenance). When this alarm is generated, consider conducting a leak inspection and replacing the mechanical seal.	This handbook: Parts Replacement Cycle (page 112), Maintenance Standards, Operation Manual, etc.
	How do I replace the mechanical seal?	Refer to this handbook as well as the Service Manual. This work can be carried out by any of the service companies tied up with SMC. Please consider outsourcing the replacement work. When replacement is performed by the customer, be sure to conduct pre-training.	This handbook: 5 Replacement Procedure for Mechanical Seal (pages 409 to 434)
Alarm handling	What do I do when AL01 (Low level in tank) is generated?	The level in the tank is low. Check that there is no leakage from the piping, including that of the customer's equipment. If no leakage is found, fill the tank with circulating fluid in accordance with the Operation Manual.	This handbook: 4 Maintenance (pages 138 and 139)
	What do I do when AL06 (High circulating fluid discharge pressure) is generated?	Resistance (pressure loss) of the piping, including that of the customer's equipment, has exceeded the pump capacity of the thermo-chiller. Check whether there are throttles in the piping, including that of the customer's equipment. If throttles are present, increase the piping size or relieve the circulating liquid flow rate by providing bypass piping (set).	This handbook: 4 Maintenance (pages 163 to 165)
	What do I do when AL28 (Pump maintenance) is generated?	This alarm notifies you that the pump or mechanical seal needs to be inspected or replaced. This work can be carried out by any of the service companies tied up with SMC. Please consider outsourcing the replacement work. When replacement is performed by the customer, be sure to conduct pre-training.	This handbook: 4 Maintenance (page 238)

Question		Answer	Refer to
Circulating fluid	Can I use circulating fluids or additive agents not listed in the catalog?	SMC can check this for you. Inform us of the chemical compositions of the circulating fluids and additive agents you wish to use and the names of the manufacturers or distributors of them. All wetted parts materials are listed in the SMC Thermo-chiller catalog. Confirm these materials, and also contact the distributor or manufacturer if needed.	Catalog, Operation Manual (Specific Product Precautions, Water Quality Standards)
	Will you verify circulating fluids and additive agents not included in the catalog?	SMC can check this for you. When a circulating fluid and additive agent blended by the manufacturer (distributor) for long-term use is used, it is very difficult to find problems in a short-term life test. Therefore, all wetted parts materials are listed in the SMC Thermo-chiller catalog. Confirm these materials, and also contact the distributor or manufacturer if needed.	
Storage	What should I do when the product will not be in use for long periods?	Leaving a product that contains circulating fluid inactive may cause the pump to get stuck. When you do not plan to use the product for long periods (one month or longer), conduct a non-load operation periodically or remove the circulating fluid from the product before storing it.	Operation Manual (For long-term stoppage)
Support system	How is the maintenance system in Japan?	In Japan, our 54 branch offices and 94 distributors with 500 sales offices provide support for customers. A number of service companies tied up with SMC provide support for the thermo-chiller. As SMC's sales offices are also capable of providing support, we will be able to help you even in emergencies.	SMC Website, Support Guide
	How is the maintenance system overseas?	In countries overseas, our 500 sales offices in 83 countries/regions provide support for customers. Support for the thermo-chiller is accepted by 3 offices in North, Central, and South America, by 9 offices in Europe, and by 10 offices in Asia (22 offices in total). As SMC's sales offices in Japan also serve as mediators, we will be able to help you even in emergencies.	

A		Flow sensor/Flow switch.....Page 472	PV.....Page 474
Accumulator.....Page 470		Fluorinated fluids.....Page 473	PWM control.....Page 474
Adjustment sensitivity (Hysteresis).....Page 474		Fluorinert™.....Page 473	R
Air-cooled condenser.....Page 469	G	Fundamentals of refrigeration circuits.....Page 469	Refrigerant dryer.....Page 469
Analog communication.....Page 476	GALDEN®.....Page 473		Refrigerator.....Page 469
ARW width (Anti-Reset Windup width).....Page 474	Gear pump.....Page 471		Relay.....Page 475
Auto-tuning.....Page 474	H		Relief valve.....Page 472
B	Hardware interlock.....Page 475		RS232C.....Page 475
Band width, Temperature upper/lower limit width.....Page 475	Heat.....Page 472		RS485.....Page 476
Breaker.....Page 475	Heat load.....Page 472		RTD (Resistance Temperature Detector).....Page 473
C	Hot gas bypass.....Page 470		S
Capillary tube.....Page 469	I		Sealing mechanism.....Page 471
Cascade pump.....Page 471	Impedance protection.....Page 475		SEMI F47.....Page 476
CE marking.....Page 476	Insulation resistance.....Page 476		SEMI S2.....Page 476
Centrifugal pump.....Page 471	Insulation withstand voltage.....Page 476		SEMI S8.....Page 476
CFC refrigerant.....Page 469	Inverter control.....Page 470		Signal input/output, I/O.....Page 476
Check valve.....Page 472	L		Solenoid valve.....Page 472
Circulating fluid, constant temperature circulating fluid.....Page 473	Learning control.....Page 474		Solid state relay (SSR).....Page 475
Compressor.....Page 469	Level switch.....Page 472		Specific heat, specific heat capacity.....Page 472
Condenser.....Page 469	Lifting height/Pressure.....Page 470		Specific resistance.....Page 473
Cooler.....Page 469	M		Specified CFC.....Page 469
Cooling capacity.....Page 472	Magnet pump.....Page 472		SV.....Page 474
Cooling tower.....Page 470	Mechanical seal pump.....Page 471		T
CSA standards.....Page 476	N		Tap water.....Page 473
D	Non-return valve.....Page 472		Temperature fuse.....Page 474
DC canned pump.....Page 472	NRTL (National Recognized Test Laboratories).....Page 476		Thermal relay.....Page 475
DC power supply.....Page 475	O		Thermistor.....Page 473
Degree of viscosity.....Page 472	Offset function.....Page 474		Thermo couple.....Page 473
Deionized water.....Page 473	ON/OFF temperature control.....Page 474		Thermoelectric device.....Page 470
Density, specific gravity.....Page 472	Overload relay.....Page 475		Thermoelectric system.....Page 470
DeviceNet.....Page 476	P		Thermo-module.....Page 470
DI filter.....Page 472	Particle filter.....Page 472		Thermostat.....Page 473
E	Peltier device.....Page 470		Three-phase power supply.....Page 475
Electric conductivity.....Page 473	Phase reversal relay (Plugging relay).....Page 475		Time division proportional output.....Page 474
Electromagnetic contactor.....Page 475	PID control.....Page 474		Turbine pump.....Page 471
Electromagnetic switch.....Page 475	Pipe resistance.....Page 471		U
EMO circuit.....Page 475	Power supply frequency.....Page 475		UL standards.....Page 476
Ethylene glycol aqueous solution.....Page 473	Propylene glycol aqueous solution.....Page 473		V
eti mark.....Page 476	Protective devices in refrigeration circuits.....Page 470		Vane pump.....Page 471
ETL mark.....Page 476	PT sensor, platinum resistance temperature detector.....Page 473		Vortex pump.....Page 471
Evaporator.....Page 469	Pump capacity/Water-supply capacity.....Page 470		W
Expansion valve.....Page 469	Pump heat input.....Page 472		Water-regulating valve.....Page 470
External sensor.....Page 474			Water-cooled condenser.....Page 469
F			
Facility water.....Page 470			

Refrigeration Circuits, Peltier Devices, Cooling Sources

Compressor

A compressor draws in low-pressure chlorofluorocarbon (CFC) refrigerant gas, compresses the gas and then discharges it as a high-pressure, high-temperature gas. Compressors are classified into various types (reciprocating, rotary, screw, etc.) according to the mechanical compression method used.

Refrigerator

A compressor that compresses a refrigerant gas. These are called refrigerators to distinguish them from machines such as air compressors.

CFC refrigerant

CFC (chlorofluorocarbon) refrigerants are organic compounds made up of elements including carbon, hydrogen, chlorine and fluorine. They are referred to generically using the DuPont brand name of Freon®.

When CFCs are used as heat-transfer mediums and circulated inside refrigeration circuits, causing heating and cooling during their condensation and evaporation phase changes, the CFCs are referred to as CFC refrigerants.

Specified CFC

Due to their stability as a chemical substance and their safety with respect to humans, CFCs came to be widely used as industrial materials, particularly refrigerants. However, it was later recognized that when CFCs (and HCFCs (hydrochlorofluorocarbons)) containing chlorine are released into the atmosphere, they rise up into the ozone layer and deplete it. This resulted in the establishment of the Montreal Protocol in 1987, which classified CFCs such as Freon R12 and HCFCs such as Freon R22 as "specified CFCs" and prohibited their manufacture. As a result, their use has now almost completely died out.

Instead of specified CFCs and HCFCs, SMC products now use HFC refrigerants such as R134a and R404A that have an ozone depletion potential (ODP) of zero.

Fundamentals of refrigeration circuits

In a refrigeration circuit, refrigerant gas injected into the circuit repeatedly travels through a cycle of compression, condensation, expansion and evaporation, creating high-temperature and low-temperature sections in the circuit. The compressor compresses low-pressure refrigerant gas and discharges the gas at a high temperature and pressure level. The hot, pressurized refrigerant gas enters the condenser where it is cooled by the external air or cooling water and condenses to form a high-pressure liquid refrigerant. As the high-pressure liquid refrigerant passes through a constricting mechanism, such as an expansion valve, it rapidly depressurizes and some of the refrigerant evaporates. The release of evaporation heat causes the refrigerant itself to cool

so that it becomes a combination of gas and liquid at a low-temperature and pressure level. In its combined gas-liquid state, the refrigerant enters the evaporator where it continually evaporates while absorbing the heat within the evaporator, thereby cooling the interior of the evaporator. When the refrigerant emerges from the evaporator, it evaporates entirely and becomes a low-pressure refrigerant gas. The low-pressure refrigerant gas is then drawn into the compressor and again becomes a high-temperature, high-pressure gas as the cycle is repeated.

Condenser

A heat exchanger used to condense high-temperature, high-pressure refrigerant gas. A condenser has the function of releasing heat drawn up by the refrigeration circuit to the outside. Condensers can be air-cooled or water-cooled, depending on the cooling method used.

Air-cooled condenser

Air-cooled condensers are generally made up of copper tubes through which the refrigerant flows, with numerous thin aluminum fins attached around the outside of the tubes. Outside air is forced over the fins by a device, such as a fan motor, to cool the pipes to the ambient temperature and condense the refrigerant gas.

If an air-cooled condenser is installed inside a building, it can be used to heat the interior of the building since the heat generated by the refrigeration circuit is released as waste heat from the outside of the condenser. The room in which an air-cooled condenser is installed must have adequate ventilation or air-conditioning equipment.

Water-cooled condenser

A heat exchanger that uses cooling water to cool and condense the coolant. Water-cooled condensers can be used in environments, such as large factories where cooling tower water or the cooling water for an air-conditioning system can be circulated and used.

Depending on their construction, heat exchangers can be double-pipe type, shell-and-tube type or plate type units.

Refrigerant dryer

In a refrigeration circuit, a refrigerant dryer consists of filters that absorb and remove moisture inside the refrigeration circuit. Refrigerant dryers are normally installed in pipes carrying liquid refrigerant after it emerges from the condenser.

Expansion valve

A component that creates an expansion in the refrigeration circuit. As the refrigerant passes through this valve, a large pressure loss results, thereby making it possible to create high-pressure and low-pressure segments within the refrigeration circuit.

There are several types of expansion valve, including constant-pressure expansion valves and thermal expansion valves. Such types allow the size of the valve aperture to be adjusted using refrigerant pressure or temperature feedback from an outlet passage.

Capillary tube


The capillary tubes used in refrigeration circuits are simply small-caliber copper tubes, normally used in the expansion step, that act as a fixed restrictor in the refrigerant passage.

Evaporator

A heat exchanger used to cool the target substance (e.g., water or air) using the evaporative heat from a low-temperature, low-pressure combined gaseous and liquid refrigerant in the refrigeration circuit.

Cooler

→ Evaporator



● Accumulator

A tank installed in a refrigeration circuit on the inlet side of the compressor. A compressor is a component designed to compress gas, so a malfunction will occur if any liquid coolant enters the compressor. Installing an accumulator has the function of separating out the coolant gas that is sucked into the compressor and any remaining refrigerant, and of preventing the liquid refrigerant from being sucked into the compressor. The inclusion of an accumulator creates a system that is highly resistant to variability in factors such as the cooling load.

● Hot gas bypass

A refrigeration circuit sometimes includes a circuit that allows high-temperature, high-pressure refrigerant gas (hot gas) discharged from the compressor to bypass the condenser so that it reaches the evaporator (on the low-pressure side) without being condensed. This prevents the evaporator temperature (on the low-pressure side) from dropping too far and reduces the risk of liquid refrigerant being drawn into the compressor when the cooling load is low (if there is nothing to refrigerate), thereby ensuring more stable functions of the refrigeration circuit.

This also allows a flow of hot gas to be intentionally directed to the evaporator with the aim of heating the evaporator rather than cooling it.

● Water-regulating valve

A control valve, installed on the cooling water pipe for a water-cooled condenser, used to adjust the amount of cooling water flowing to the condenser. Water-regulating valves can be either pressure-regulated or temperature-regulated, with the amount of flow regulated using feedback from the condensing pressure or condensing temperature, respectively.

When the cooling water temperature is low, a large flow of cooling water to a water-cooled condenser reduces the condensing pressure and lowers the cooling capacity. In this sort of situation, a water-regulating valve restricts the cooling water flow and maintains the condensing pressure at the desired value. Water-regulating valves also have the function of reducing water consumption by preventing unnecessarily large flows of cooling water.

● Inverter control

In compressors that use an ordinary AC motor, the motor rotation rate is fixed according to the frequency of the AC power supply, with the result that the refrigerant discharge rate is also fixed. Inverter control in a refrigeration circuit is the use of an inverter to vary the compressor rotation rate and thereby control the rate of refrigerant circulation.

This provides means of saving energy by, for example, running the compressor at a slower rate when the cooling load is low.

● Protective devices in refrigeration circuits

In refrigeration circuits, protection must be provided for electrical components such as compressors, and against abnormal refrigerant pressures. Protective measures for compressors (motors) include protective devices such as overload relays (built into the compressor to detect overcurrent and overheating), thermal relays (fitted externally to detect motor overcurrent) and temperature switches.

The devices used to protect against pressure faults include pressure switches, safety valves and rupture disks. However, in refrigeration circuits built into compact devices, the protective devices are often confined to just overload relays, or just thermal relays and pressure switches depending on the anticipated level of risk.

● Facility water

The cooling water flowing through a water-cooled condenser used to expel waste heat generated in the refrigeration circuit

to the outside.

In ordinary factories or buildings, fluids such as cooling tower water or chiller water are used as facility water.

● Cooling tower

A cooling tower is a facility that uses cooling water to expel the waste heat circulated and collected inside a factory or other building into the outside air. Cooling towers are installed in outdoor locations such as on the rooftops of buildings. The cooling water is sprayed down like a shower from the top of the cooling tower and forcibly brought into contact with the outside air by a fan motor. As well as being directly cooled by the temperature of the outside air, the partial evaporation of the cooling water itself draws off evaporation heat, cooling the water further.

Because cooling towers are directly cooled by the outside air, the resulting cooling water temperature varies seasonally depending on the climatic conditions. In addition, the cooling water cannot theoretically be cooled to a temperature any lower than 5°C above the wet-bulb temperature of the outside air.

● Peltier device

An element with a structure made up of alternating layers of flat P-type and N-type semiconductors arrayed in series. When a direct current flows through the element, heat moves from one plate surface to the next, so that one surface is cooled as the opposing surface is heated. This is referred to as the Peltier effect.

By changing the direction of current flow, the direction of heat movement can also be changed, providing a simple means of cooling and heating.

● Thermo-module

→ Peltier device

● Thermoelectric device

→ Peltier device

● Thermoelectric system

A temperature control system that uses a Peltier element to directly cool and heat a liquid, gas or solid.

Heat exchangers suitable for fluids are installed on both sides of the Peltier element, with the fluid to be temperature-controlled on one side of the element while the heat exchanger on the other side is used to dissipate heat.

Fluid Control and Heat-related

● Pump capacity/Water-supply capacity

A pump's water-supply capacity is indicated by the amount of water it can cause to flow at a given pressure (lifting height).

The characteristic curve (pump curve) that indicates the correlation between pressure and flow rate varies depending on the pump type, and thus, the user must check that the type of pump selected is suitable for the intended application.

● Lifting height/Pressure

Lifting height (in meters) is often used instead of pressure to indicate the pump capacity. Lifting height is a numerical value that indicates the capacity of a pump in terms of the height (in meters) to which it can lift a fluid.

The value for pressure is obtained by multiplying the lifting height by the density of the fluid; for example, if a pump capable of generating a lifting height of 10 meters is used to pump water, which has a density of 1 kg/L, the unit pressure generated by the pump is 1 kgf/cm² (0.1 MPa).


If a more dense fluid is used, the pressure is higher even though the lifting height remains the same.

● Pipe resistance

When water or another fluid is caused to flow through a passage composed of pipes, valves, etc., the pressure differential generated by friction between the various devices and the fluid is known as "pipe resistance." A synonymous term is "pressure loss."


● Centrifugal pump

This is one type of pump in which a bladed wheel (impeller) spins inside the pump chamber (casing), applying centrifugal force to the fluid. This force is converted to pressure that discharges the fluid. A large volume of fluid can be pumped, but it is difficult to attain high pressure. When high-pressure is desired, a type fitted with multistage impellers can be used. This is a low-lifting height, high-flow volume pump.



● Vortex pump

In this type of pump, a bladed wheel (impeller) spins inside the pump chamber (casing), applying centrifugal force to the fluid. This force is converted to pressure that discharges the fluid. As in a centrifugal pump, the fluid is discharged using centrifugal force, but the impeller has more blades than in a centrifugal pump, and in the pump chamber (casing), the aperture (clearance) is set more narrowly, allowing for a higher discharge pressure. The pressure and flow rate characteristics attained are somewhere between that of a centrifugal pump and a vane pump. This is a mid-lifting height, mid-flow volume pump.



● Turbine pump


→ Vortex pump

● Cascade pump

→ Turbine pump

● Vane pump


In this type of pump, vanes set in a rotor inside the pump chamber brush against the inside walls of the chamber as they rotate, pushing out and discharging the fluid that is surrounded by the vanes, rotor and pump chamber walls. This is a type of PD (positive displacement) pump. This is a high-lifting height, low-flow volume pump. The vanes slide against the interior walls of the pump chamber, generating abrasion powder. In addition, this type of pump is susceptible to entry of foreign matter such as outside debris, etc.



● Gear pump

Like the vane pump, this is a type of PD (positive displacement) pump, in which a pair of gears meshes with one another and rotates, pushing the fluid through the gap between them and discharging it.

This is a high-lifting height, low-flow volume pump.



● Sealing mechanism

The bladed wheel (impeller) in the pump chamber through which the fluid passes is linked to the shaft of the external electric motor, and the rotation of the impeller discharges the fluid. As water or other fluids seeping through the motor shaft and reaching the electric motor can cause short circuits and other damage, it is necessary to have a mechanism sealing the pump chamber off from the shaft. This is known as a "sealing mechanism."


There are mechanical seal types, magnet coupling types and others.

● Mechanical seal pump

This is a general terms for pumps that use mechanical seals for the sealing mechanism.

The rotating seal mounted on the motor shaft side and the fixed seal mounted on the pump chamber side rotate, and their surfaces touch one another, sealing off the fluid. As a result, there is a slight, external leakage of fluid. The volume of leakage increases over time, so it is necessary to replace the seal portions regularly.

This type can be used for applications where the motor shaft and impeller are directly linked and there is high-shaft power.




● Magnet pump

This is a general term for pumps that use magnetic coupling for the sealing mechanism.

Using magnetism to couple the rotor on the inside of the pump chamber to the permanent magnet mounted on the motor shaft side, with the pump chamber wall between them, the rotation is conveyed to the rotor inside the pump chamber. Since the pump chamber can be completely separated, pump chamber can be completely sealed off, so there is absolutely no external leakage.

Since a large magnet coupling is needed, this type of pump is more difficult to make in small sizes than the mechanical seal type, and the cost is also higher.



● DC canned pump

A pump with a sealless construction combining the motor and the pump in one. It can be made in compact sizes with absolutely no external leakage of fluid. A DC brushless motor is used.

● Pump heat input

The volume of heat applied to the circulation loop, generated by the operation of the pump. When calculating the overall volume of heat applied to the circulation loop, it is necessary to consider the volume of heat generated by the pump, along with that of the object being cooled.

The pump converts the electrical power entering the motor into the kinetic energy of the fluid, which causes the fluid to circulate. This kinetic energy is reduced as a result of undergoing pressure loss inside the piping, and eventually the entirety of the kinetic energy is released into the circulating fluid as heat.

While there are differences depending on the type of pump, for rough calculations, the nominal heat emitted from the pump can be treated as the pump heat input.

● Solenoid valve

A component that switches the flow of fluid from ON to OFF, or changes the direction by moving the plunger (iron core) using the force of electromagnetism.

● Relief valve

When the inlet pressure exceeds a set level, this valve opens to release the outlet pressure.

● Flow sensor/Flow switch

These components monitor the flow rate of the fluid. The flow sensor measures the flow rate linearly. The flow switch only has the function of commencing operation when the flow rate reaches a certain level, and does not perform measurement of the flow volume.

● Particle filter

A filter that removes debris and other particles.

● Check valve

A check valve is a device that prevents reverse flow of the fluid, keeping it flowing in one direction only.

● Non-return valve

→ Check valve

● Level switch

A switch that detects the fluid level inside the liquid tank. There are many different types, but the most common type employs a floating buoy, which causes a lead switch (magnetic switch) to turn ON and OFF.

● DI filter

A filter that is filled with ion exchange resin used to remove leftover ions from the water. DI stands for "deionized," while "DI water" is deionized water, or water with its ions removed.

Fluid Properties, Materials, Physical Values

● Density, specific gravity

The weight per unit of volume, measured in units of $[\text{kg}/\text{m}^3]$. Specific gravity is the ratio of the density of a given substance to the density of water ($1.0 [\text{g}/\text{cm}^3]$), and is a dimensionless quantity. When expressing this quantity within the CGS system of units, density and specific gravity have the same value.

● Degree of viscosity

Thickness of a fluid. The units used to express absolute degree of viscosity are $[\text{Pa}\cdot\text{s}]$ units, but it is often expressed within the CGS system of units with $[\text{P}]$ (Poise).

$$1 [\text{Pa}\cdot\text{s}] = 10 [\text{P}]$$

The value obtained by dividing absolute degree of viscosity by density is called the kinetic viscosity. This can be measured in $[\text{m}^2/\text{s}]$ units, but in general, $[\text{St}]$ (Stokes) are used.

$$1 [\text{St}] = 0.0001 [\text{m}^2/\text{s}]$$

● Specific heat, specific heat capacity

The heat energy required to increase the temperature of an object by a certain temperature interval, under specific pressure and volume conditions.

$$\text{The specific heat of water: } 1 [\text{cal}/\text{g}\cdot\text{K}] = 4.184 \times 10^3 [\text{J}/\text{kg}\cdot\text{K}]$$

● Cooling capacity

The volume of heat (heat energy) that temperature control equipment can absorb (cool) per unit of time, at an arbitrary temperature.

● Heat load

→ Cooling capacity

● Heat

Terms such as heat, heat load, cooling capacity, etc., that are used in this catalog, indicate quantities of heat that can be absorbed or radiated per unit of time. As a result, the units employed are $[\text{W}] = [\text{J}/\text{s}]$ (work rate) or $[\text{kcal}/\text{hr}]$.

$$1 \text{ kW} = 860 \text{ kcal/hr}$$

- **Specific resistance**

A value indicating the electrical insulating properties of a liquid, and the unit used is [Ω -cm]. When expressing the specific resistance of deionized water, it is sometimes called "DI level." At 25°C, the specific resistance of theoretically 100% deionized water is 18.3 [$M\Omega$ -cm].

- **Electric conductivity**

A value indicating the ease with which electricity passes through a liquid, and is inversely proportional to the specific resistance. The unit used is [S /m], incorporating [S] (Siemens), the opposite of [Ω] (resistance).

At 25°C, the electric conductivity of theoretically 100% deionized water is 0.055 [μS /cm].

- **Tap water**

Water that has been filtered and distilled and any impurities eliminated. It is also known as purified water.

- **Deionized water**

Water that has had any impurities or ion elements removed. It is obtained by removing ion elements with ion exchange resin, after filtering out impurities with a particle filter. Its theoretical specific resistance has a limit of 18.3 [$M\Omega$ -cm], but it is impossible to actually attain this value. As a general rule, water with a specific resistance of 1 to 10 $M\Omega$ -cm is referred to as deionized water.

- **Ethylene glycol aqueous solution**

Ethylene glycol is a type of alcohol, and adding it to water causes the freezing point of the water to drop. It is a major ingredient in antifreeze for automobiles. At a concentration of 60%, the freezing point drops to -40°C or lower, but the viscosity increases as the temperature drops, so taking fluidity into account, it is practical to consider about -20°C as the minimum temperature.

By adding ethylene glycol to deionized water, it is possible to raise the fluid's specific resistance, so it can be used for applications where circulating fluid with high insulating properties is desired.

- **Propylene glycol aqueous solution**

Propylene glycol is a type of alcohol, and adding it to water causes the freezing point of water to drop. Like ethylene glycol, it is a major ingredient in antifreeze for automobiles.

It has lubricating properties, and is characteristically non-volatile.

- **Fluorinated fluids**

Inert fluids in the fluorine series. There are many types, including perfluoropolyether (PFPE), perfluorocarbon (PFC), hydrofluoropolyether (HFPE), and hydrofluoroether (HFE), but they share the characteristic of high electrical insulation properties, and grades can be selected with appropriate fluidity even at low temperatures, such as -100°C, and high temperatures, such as 200°C and above.

They are chemically inert and non-poisonous.

Products are sold on the market, such as Fluorinert, made by 3M, and GALDEN, made by Solvay Solexis.

- **GALDEN®**

The product name of a fluorinated fluid manufactured by Solvay Solexis. It is a perfluoropolyether with a high polymer compound, and various grades can be selected with differing temperature ranges and viscosity ranges depending on the degree of polymerization.

- **Fluorinert™**

The product name of a fluorinated fluid manufactured by 3M. Its basic structure is a perfluorocarbon, but it has a wide variety of chemical structures, and various grades can be selected with differing temperature and viscosity ranges.

- **Circulating fluid, constant temperature circulating fluid**

Fluid that circulates among the user's equipment, with temperature controlled by a chiller.

Taking freezing temperature, boiling point, electrical insulation properties and so on into consideration, tap water, deionized water, ethylene glycol aqueous solution, fluorinated fluids, etc., can be selected depending on the application.

Temperature Measurement and Control

- **PT sensor, platinum resistance temperature detector**

A type of temperature sensor taking advantage of the properties of platinum (Pt), which has an electric resistance that increases in proportion to the temperature. A sensor with the specification Pt 100 Ω has a resistance of 100 Ω at 0°C. As the resistance value is relatively small, and the sensor is easily influenced by the resistance value of the conductive wires, an input circuit is generally used which cancels out the resistance value of the conductive wires, by using, for instance, 3-wire or 4-wire wiring configurations and long conductive wires.

- **RTD (Resistance Temperature Detector)**

→ PT sensor

- **Thermo couple**

This is created by forming a loop, connecting the ends of two wires made of two different metals, and by keeping the two wires at separate temperatures at the connecting point. Thermoelectric power is generated according to this temperature differential (the Seebeck effect).

As a sensor, by keeping the end of one wire at a standard temperature and measuring the thermoelectric power generated, it can determine the temperature of the other wire terminal. A thermo couple is a sensor employing this principle.

- **Thermistor**

A temperature sensor employing a semiconductor with electric resistance that changes in accordance with the temperature. There are two types,

PTC: positive temperature coefficient (a type for which the resistance increases as the temperature rises)

NTC: negative temperature coefficient (a type for which the resistance decreases as the temperature rises.)

The resistance value is generally large, amounting to several $M\Omega$, and there is little influence from the resistance of the conductive wires, so a 2-wire configuration is generally used.

- **Thermostat**

A switch that turns ON or OFF when it reaches a certain set temperature. Most thermostats are bimetallic.

They are sometimes used for direct temperature control, such as switching a heater ON or OFF, but are also used often for safety circuits which switch OFF when the temperature becomes abnormally high.

The switch can be returned to its original position either automatically or manually.

● Temperature fuse

A fuse in which an internal metal wire melts, breaking the circuit when exposed to a temperature exceeding the set temperature. When this kind of fuse blows, it cannot be reset and must be replaced.

● PV

PV: Process Value. In temperature control equipment, this indicates the current temperature measured by the temperature sensor.

● SV

SV: Set Value. In temperature control equipment, this indicates the target value (set value) for performing temperature control.


● ON/OFF temperature control

A control method for adjusting temperature by turning temperature control output ON or OFF relative to the set temperature. When the temperature is above (below) the set temperature, output of the refrigerator (heater) is turned ON, and when the temperature is below (above) the set temperature, output is turned OFF.

Since there are only two operating rates relative to the set temperature, 0% or 100%, this is also called 2-position control.

● Adjustment sensitivity (Hysteresis)

When the PV is extremely close to the SV in ON/OFF control, there may be "chattering" where the temperature control output repeatedly turns ON/OFF with small temperature variations, and this may have an adverse impact on output relays and connected equipment. To prevent this, spacing is provided between ON and OFF operation to stabilize control. This operation spacing is called adjustment sensitivity (hysteresis). For example, if the cooling output ON point (SV) is set to 20.0°C and hysteresis is set to 1.0°C, then cooling output will go OFF when temperature drops to 19.0°C, and go ON when temperature rises to 20.0°C.



● PID control

A control method for producing temperature control output by comparing the temperature difference between the input value from the temperature sensor (PV) and the set temperature (SV), and using a combination of P (Proportional) operation, I (Integral) operation and D (Derivative) operation.

Output is linearly variable from 0 to 100%, and this enables smooth temperature control with no temperature wavering.

P (Proportional) operation: Operation where the amount of output is varied from 0 to 100% in proportion to the deviation between PV and SV (temperature difference). The range of temperatures for performing proportional operation (proportional band) must be input as a parameter.

I (Integral) operation: Operation where the temperature discrepancy is corrected by adjusting the amount of output relative to the

time that deviation between PV and SV has continued. Since the amount of output is determined in response to the time that deviation continues, the integral time must be input as a parameter.

D (Derivative) operation: Operation where output is produced in accordance with the derivative (speed of change) of the temperature deviation. This is used to quickly correct sudden temperature variations when there is a sudden change in the ambient environment or load. The derivative time is input as a parameter, and the longer the derivative time, the stronger the correction output that is produced.

● ARW width (Anti-Reset Windup width)

Range of integral operation used for PID control. This value is used to designate the range for calculating the integral term, to suppress buildup of the integral component.

● Auto-tuning

In PID control, P, I, D and each parameter must be optimally set for the balance of the heat capacity of all parts where the circulation loop is connected. Auto-tuning refers to a function for automatically determining the setting of those parameters. SMC's temperature control equipment is shipped with PID parameters set at factory shipment to the greatest common factor for the various use conditions. However, if those parameter settings are likely to be unsuitable for the actual operating environment, some models provide a function which can automatically set parameters by using auto-tuning.

● Time division proportional output

When controlling output of a heater or other device via a relay or SSR, this method of operation makes the ratio of ON time to OFF time proportional to the control output over a fixed time (0.2 to 1.0 sec) in accordance with a previously set time cycle. For example, if the control cycle is 1.0 sec, and the control output is 70%, then the ON time will be 0.7 sec and the OFF time 0.3 sec.

● PWM control

→ Time division control

● Offset function

Function for shifting the target temperature for actual temperature control from SV by adding or subtracting a separately set offset value (+ or – a certain number of °C) to or from the set temperature (SV).

For example, if the temperature upon arrival at the object of temperature control is shifted higher (or lower) relative to the temperature discharged from the chiller because a certain amount of heat input is received from piping due to the effects of ambient temperature, this offset value is set to correct that effect.

● Learning control

A function for automatically calculating and setting the offset value (correction value for the set temperature).

A temperature sensor (external sensor) is provided near the object to be temperature controlled, and those signals are input to the chiller. The offset value is automatically calculated from the deviation between the discharged temperature and the external sensor.

● External sensor

Temperature sensor mounted to the outside of temperature control equipment and used for learning control, etc.

● **Band width, Temperature upper/lower limit width**

Temperature range for outputting alarms, etc., when PV deviates by more than a fixed temperature from the set temperature (SV).

Power Supply, Electrical Equipment

● **Power supply frequency**

There are two frequencies for commercial AC power: 50 Hz and 60 Hz. The AC motors installed in temperature control equipment turn at a rotation speed corresponding to the power supply frequency. When operating with a 60 Hz power supply, the rotation speed is generally 10% faster than with 50 Hz. In the case of a pump, the flow rate and pressure increase, and in the case of a compressor in a refrigeration circuit, the cooling capacity increases. Current consumption also increases in the same way.

In the case of a resistance load, such as a DC pump or heater, performance does not depend on the frequency.

● **Three-phase power supply**

With three-line AC current or AC voltage, the phases of the lines are shifted by 120°.

The current values of each line are $1/\sqrt{3}$ smaller than single phase with the same level of transmitted power, so thinner wires can be used. There is also the advantage that a rotating magnetic field can be easily produced. (It is possible to use a 3-phase motor with a simple structure.)

A 3-phase power supply is used for equipment with high output.

● **Breaker**

A device which protects load circuits and wires by breaking the circuit when an abnormal current flows in an outlet circuit due to problems such as overload or shorting. Depending on the application, a breaker may be called a motor breaker, circuit protector or other names. Earth leakage breakers monitor both current in the main circuit and leakage current, and break the circuit if leakage current is too high.

● **Relay**

A switch which turns a mechanical contact ON/OFF with the power of an electromagnet (solenoid). This makes it possible to turn ON/OFF the high power of the contact with the low power needed to drive the electromagnet only, and thus relays are used for amplification. They are also frequently used as logic elements in sequence circuits.

● **Electromagnetic contactor**

An electric device for turning power circuits ON/OFF to start and stop power equipment (e.g. motors, heaters). Just like a relay, these devices open or close a mechanical contact with the power of a solenoid. The principle of operation is the same as a relay, but a contactor is designed for high-voltage and large current.

● **Thermal relay**

A circuit protection device incorporated into the power input circuit of a motor to provide output when motor overcurrent is detected. It is comprised of a heater which heats up in response to current, and a bimetal which opens and closes a contact in response to that heat. Since the thermal relay itself cannot open and close a high capacity power circuit, the main circuit for a motor or other device is broken by incorporating a control circuit with an electromagnetic contactor or relay.

● **Electromagnetic switch**

A device integrating an electromagnetic contactor with a thermal relay.

● **Overload relay**

This has the same structure as a thermal relay, and is used for the same purpose. Overload relays built into the compressors of small refrigeration circuits are installed on the wall of the compressor, and are actuated not by heat due to overcurrent but by the temperature of the compressor itself. In many small compressors, the main circuit is directly broken by the overload relay.

● **Impedance protection**

A type of motor protection generally used for small AC fan motors and other small motors.

The motor is constructed so that it will not rise above a certain temperature, even when locked for some reason, due to the inherent impedance (AC resistance) of the motor coil itself. Therefore, the motor itself is protected against burnout, even though no thermal relay or other protective device is installed.

● **Solid state relay (SSR)**

A relay which enables switching of high power using low power by using a thyristor or other semiconductor element. In comparison with an electromagnetic relay, this type has no mechanical moving parts, and thus is capable of high-speed switching. SSRs are compact, and have a long service life.

However, this does not mean that contacts are physically isolated. The fact that there is some leakage current even when the device is OFF must be taken into account.

● **Phase reversal relay (Plugging relay)**

A switch which monitors the phase sequence of a 3-phase main power supply, and issues a warning if anything is abnormal.

When driving a 3-phase motor with a 3-phase power supply, the motor will turn backwards if the phase sequence of wiring is wrong. This relay is installed to prevent such reverse rotation. These relays are also called plugging relays.

● **DC power supply**

A device which produces DC power from commercial AC power. DC power is for CPUs inside equipment and other control circuits. Peltier elements for Peltier circulators, thermoelectric baths and other equipment are driven with DC power, so they have a high-capacity DC power supply built-in.

● **EMO circuit**

An EMO (Emergency Off) circuit is an electrical circuit provided to shut off all power and ensure safe conditions when an emergency stop button (EMO button) is pressed in an emergency.

● **Hardware interlock**

This is an equipment control circuit for shutting off power in case of trouble. The circuit is logically configured using only relays and other hardware, and does not use software running on the CPU.

● **RS232C**

A standard for serial communication. This is the communication standard when connecting a PC with an acoustic coupler or modem, and is used for one-to-one communication between PCs. Since RS232C itself only roughly stipulates the use of wiring systems and other hardware, detailed hardware specifications and software protocols are determined independently by each equipment manufacturer.

● **RS485**

A standard for serial communication. Only one-to-one communication between devices can be done with RS232C, but with RS485 it is possible to communicate simultaneously with multiple devices by wiring them in a chained, multidrop fashion, and providing addresses via software.

Since RS485 itself only roughly stipulates the use of wiring systems and other hardware, detailed hardware specifications and software protocols are determined independently by each equipment manufacturer. Actual detailed protocols are determined independently by each equipment manufacturer.

● **DeviceNet**

A standard for serial communication.

An open network owned by ODVA (Open DeviceNet Vendor Association Inc.), a non-profit organization headquartered in the US. This is a field network standard covering a wide scope, from the sensor level to the device level.

● **Analog communication**

A method of communicating with external devices using voltage output such as 0 to 10 V. This enables output of PV (measured temperature, etc.) and reception of values like SV (set temperature).

● **Signal input/output, I/O**

Input/Output signals such as alarm signal, or operation signals. Since there are various communication methods depending on the equipment model, such as relay output and open collector output, communication specifications must be checked before wiring.

● **Insulation withstand voltage**

Electric potential difference where an insulator material will not be destroyed. In withstand voltage testing at product shipment from the factory, a high AC voltage of 1.5 kV (varies depending on the model) is applied between the electric circuit conductor and the chassis (grounded). Then it is checked that there is no flow of leakage current above the reference value.

● **Insulation resistance**

Electric resistance between the conductor inside the device and the chassis (grounded). In insulation resistance testing at product shipment from the factory, it is checked that the resistance value with a measured DC voltage of 500 V (or 250 V) is at or above the reference value (a value such as 1 M Ω ; varies depending on the model).

Safety Standards

● **CE marking**

For machinery and other equipment distributed in the EU (European Union), it is mandatory to display the CE mark. To display the CE mark, a product must declare itself to be in compliance with EU Directives. The main EU Directives relating to the products in this catalog are the Machinery Directive, EMC Directive and Low Voltage Directive. Each directive requires product compliance with the corresponding EN Standard (European Standard).

● **UL standards**

Standards of a non-profit testing organization founded by the US National Fire Protection Association.

In the US, some states and municipalities require UL certification for the sale of electrical products.

● **CSA standards**

Safety standards by the Canadian Standard Association, a non-governmental Canadian standardization organization. Electrical products distributed in Canada must be CSA certified.

● **NRTL (National Recognized Test Laboratories)**

Testing organizations capable of certification (of UL or CSA standards, etc.) which have been recognized according to Occupational Safety and Health Law set forth by OSHA (the US Occupational Safety and Health Administration). At present, 18 organizations have been recognized as NRTLs. UL and CSA are examples of certified organizations.

● **eti mark**

eti (Electro-Test Inc.) is the mark that demonstrates compliance with UL standards.

● **ETL mark**

Intertek ETL SEMKO is an NRTL, and issues the ETL mark. This mark demonstrates compliance with UL standards.

● **SEMI S2**

SEMI is an international industry association of companies producing equipment and materials for the manufacture of semiconductors and flat panel displays. It has established its own standards as safety guidelines for the design of semiconductor manufacturing equipment.

SEMI S2 requirements relate to the work environment, health and safety for products used in semiconductor manufacturing, and cover chemical, radiation, electrical, physical, mechanical, environmental, fire, earthquake, emissions and ergonomics, as well as quality, documentation, manuals, etc. Many semiconductor manufacturers require that equipment operating in their plants comply with SEMI S2.

● **SEMI S8**

SEMI S8 is a guideline on ergonomics which is more detailed than the ergonomic requirements in Section 14 of SEMI S2.

● **SEMI F47**

SEMI F47 is a SEMI standard which stipulates guidelines regarding voltage sag immunity. Semiconductor manufacturers require this standard for temperature control equipment, just like SEMI S2.

SMC Corporation

Akihabara UDX 15F,
4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN
<http://www.smcworld.com>

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

© 2018 SMC Corporation All Rights Reserved

D-G