



### Typical Coolport Application

Coolport installations require two Coolports.

#### At the Desk:

The Coolport's launch lead is plugged into the nearest wall outlet and the back of the Coolport.

This Coolport is then affixed either to the wall itself or onto the desk top (as in the photo to the left).

The two or three data/voice devices are then plugged directly into the Coolport (In this example, the PC is plugged into the Coolport's data port, and the telephone is plugged into the Coolport's voice port. (Note: If the telephone's plug is LJU then an RJ45 adaptor will be required)

#### In the Comms Room: or Cabinet:

The other Coolport is located in the comms room or cabinet.

Using the adhesive pads included, it can easily be affixed to a 2U blanking plate, or the side of the cabinet or rack.

The launch lead is plugged into the wall outlet's matching patch panel data port. Then, using patch leads, the matching Coolport data or voice ports are connected to the hub or PABX.

