

Insertor BBR-004

| Name of product | Type name | Quantity | Remarks |
|-----------------|-------------------|----------|------------------|
| Insertor | 1.0mm for BBR-004 | One | Nokkupun formula |


Step -1

Hole you want to through-hole machining, and the drilled hole with a drill bit attached. (Please use the 1.21mm bit 1.04,1.2 pin 1.0 pin)



Procedure -2

And put a board on top of the pedestal press, push pins Nokkupun type inserter.



Procedure -3

Fold the pin to defeat big to the left or right pin inserter arrives on a pedestal.



Procedure -4

Hitting by pressing strongly Ategai down the center of the pin auto punch. (Please also hit from the opposite side)



Procedure -5

I Place the solder on both sides of the pin in the soldering iron.



Procedure -6

If you suck at once the solder in the pin in Desoldering solder, and is finished in a beautiful through-hole of the hollow.



Procedure -7

If there is no sucker, solder jump out if you hit the board at the end of the table as soon as I put the solder on the back side, I am finished as shown.
(Do not hit the component mounting board)



Procedure -8

And put up a post as shown in Figure, please work at the top of the post if already mounted board.





