

OPERATING INSTRUCTIONS

1. INSERT CONTACT

2. CLOSE THE JAWS
ONTO THE TERMINAL.

STOP LOCATOR

INSULATION STOP

3. INSERT WIRE INTO
THE CONTACT.

4. SQUEEZE HANDLES
UNTIL AUTOMATIC
RATCHET RELEASES.

5. TAKE CARE WHEN
YOU REMOVE THE
CONTACT FROM
THE DIE.

