

Spacer bar for Workshop bench

- Spacer bar is used to stabilise the bench.
- It is necessary if the bench consists only of legs and bench top.

Width mm	Code	Code RS Components
1500-2250	836 451-49	1357236

