

System Accessories



For Cordless Tools					
Pic.	Description		Ah	Colour	Part no.
1	9.6 V O-Pack battery	NiCd	1.2	black	2 607 335 524
		NiCd	1.5	black	2 607 335 540
		NiCd	2.4	red	2 607 335 674
		NiMH	2.6	red	2 607 335 682
2	12 V O-Pack battery	NiCd	1.2	black	2 607 335 526
		NiCd	1.5	black	2 607 335 542
		NiCd	2.4	red	2 607 335 676
		NiMH	2.6	red	2 607 335 684
3	14.4 V O-Pack battery	NiCd	1.2	black	2 607 335 528
		NiCd	1.5	black	2 607 335 534
		NiCd	2.4	red	2 607 335 678
		NiMH	2.6	red	2 607 335 686
4	14.4 V slide-in battery pack	Li-Ion	1.3	black	2 607 336 038
5	14.4 V slide-in battery pack	Li-Ion	1.5	black	2 607 336 206
6	18 V O-Pack battery	NiCd	1.5	black	2 607 335 536
		NiCd	2.4	red	2 607 335 680
7	18 V slide-in battery pack	Li-Ion	1.3	black	2 607 336 040
8	18 V slide-in battery pack	Li-Ion	1.5	black	2 607 336 208
9	24 V O-Pack battery	NiCd	1.5	black	2 607 335 538
		NiCd	2.4	red	2 607 335 448

For Cordless Tools		
Pic.	Description	Part no.
10	3.6 V straight battery for PSR and PTK 3.6 V as of 6/05	2 607 335 790
not illus.	30-minute quick charger AL 2450 DV for 7.2–24 V, for batteries with APT	2 607 225 028
not illus.	10-minute quick charger AL 2498 FC for 7.2–24 V, for batteries with APT	2 607 224 484
11	6-hour charger AL 2404 for 7.2–24 V, for batteries with APT 1-hour truck/car quick charger AL 2422 DC for 7.2–24 V, for batteries with APT Operation via 12/24 volt direct current source (cigarette lighter)	2 607 225 184
		2 607 224 410
12	Charger for PSR 2.4 V as of 06/02 for PSR 3.6 V as of 06/02	2 607 224 786 2 607 224 790
13	3-hour charger AL 2204 CV for 14.4 V and 18 V Li-Ion batteries 1-hour charger AL 2215 for 14.4 V and 18 V Li-Ion batteries	2 607 225 274
		2 607 225 472
14	Intermediate adapter For charging old type and flat shape batteries without APT insertion end with the new Bosch chargers.	2 607 000 198