

# ACTUONIX – actuator cable extensions



## Extension Cable For P-Series Actuators

1 metre long extension cable for L12-P, L16 -P, P16-P and T16-P actuators. One male and one female end, 5 conductor, 26 AWG. Plug and play with any of the P-Series micro linear actuators except for the PQ12-P, which requires PQ12cableAdapterwithPextensioncable



## Extension Cable For R-Series Servos

1 metre long extension Cable for our L12-R and L16-R linear servos. One male and one female end, 3 conductor cable, 26 AWG. You can also 2 of these in tandem as an extension cable for L12-I actuators.

Plug and play compatible with any of our R-Series micro linear servos.



## Extension Cable For S-Series Actuators

1 metre long extension cable for L12 -S, L16 -S, P16-S and T16-S actuators. One male and one female end, 2 conductor, 26 AWG. This cable is plug and play compatible with all S-Series actuators except for the PQ12-S, which requires PQ12cableAdapterwithSextensioncable