


3361493 HGPL-63-100-A-B Parallel gripper - Series: All



3361493 HGPL-63-100-A-B Parallel gripper - Series: All

Pos.	Part no.	Type	Note	Qty.	Unit
A	752917	HGPL-63-A Set of wearing parts	Spare parts: 1, 3, 4, 7, 9, 11, 12, 31	1	PC
1			Not available separately, see position A	2	PC
2			Not available	2	PC
3			Not available separately, see position A Grease using during assembly. See position 31	2	PC
4			Not available separately, see position A Grease using during assembly. See position 31	2	PC
5			Not available	2	PC
6			Not available	2	PC
7			Not available separately, see position A Grease using during assembly. See position 31	2	PC
8			Not available	2	PC
9			Not available separately, see position A Grease using during assembly. See position 31	2	PC
10			Not available	2	PC
11			Not available separately, see position A Grease using during assembly. See position 31	2	PC
12			Not available separately, see position A Grease using during assembly. See position 31	2	PC
13			Not available separately, see position 16	4	PC
14			Not available separately, see position 16	1	PC
15	371076	9,9X10,0 Buffer element		1	PC
16	567831	HGPL-HR-63 Stroke reduction		1	PC
17			Not available	6	PC
18			Not available	2	PC
19			Not available	2	PC
20			Not available	7	PC
21			Not available	2	PC
22			Not available Tighten screw slightly and then unscrew it by a quarter turn	2	PC
23			Not available	1	PC
24			Not available	1	PC
25			Not available	1	PC
26			Not available	1	PC
27			Not available	1	PC
28	3836190	HGPL-63-...-A / -B Assortment of spare parts		1	PC
29			Not available Lubricate with Molykote BR2 Plus during assembly	1	PC
30			Not available	1	PC
31	665354	LUB-KB1-SILIKONFREI-20ML Lubricating grease	Only for piston chamber!	1	PC