


## Usage of jacketed cable with boot RS 167-9540



**No. of contacts**

**X max.**

2, 3, 4

22

5, 6, 7

26