

## Injector Seat Cleaning Kit



### Description:

- For all COMMON RAIL diesel engines.
- To clean injector wells and parting surfaces.
- To be used with a bolter or drill.
- 1 Metal brushes Ø 18mm for injector hole cleaning.
- 1 Metal brushes Ø 20mm for injector hole cleaning.
- 1 Metal brushes Ø 25mm for injector hole cleaning.
- 2 Front brushes for injector seat cleaning.
- 1 Front brush extension.
- Patch to surface parting surfaces.
- 2 Seal plugs to close the injector hole while cleaning.
- 1 Seal plug holder to place and remove the plug.
- Protection caps to avoid contaminating engine cylinders.
- Adapters and extensions.

	Length L [mm]	Weight [Kg]	Height H [mm]
<b>DCR.ICB</b>	330.0	1.5	65.0