

BC.TGVE

VE GLOVE TESTER

Selling Propositions

- Truncated end with two grooves for holding the glove under test.
- Central piston at the bottom of the tester.
- Flexible valve at the bottom of the bowl on the upper part.
- 2 rubber rings to hold the glove during inflation.
- Purpose of the tester is to ensure that glove is absolutely air tight. For your safety, this test should be done before and after using the gloves.

Standard Equipment

Warranty specifications

- legal

Specifications	
Weight	500.0 g
Height	13.5 cm
Width	12.5 cm
Length	13.5 cm