



Switch Type	Buzzer & LED on when	LED
PNP Normally Open	Target in range	PNP
PNP Normally Closed	Target not in range	PNP
NPN Normally Open	Target in range	NPN
NPN Normally Closed	Target not in range	NPN

If the proximity switch does not give such feedback when correctly connected to the tester, it has probably failed. [Note: This Tester will not test two wire AC or DC switches]

LED Functions

Green I/O LED	Switch connected & unit on
Red (Batt) LED	Battery low indicator
PNP or NPN LED	Indicated switch type