

# Date Code / Coding Primary Lithium Cylindrical

## For bare Cells:

### 1) [Series CR ... AA](#)

The products are coded with a **Week / Year** Code (on the cell):

**Example:** **15 10**

15	<b>Week 15</b>
10	<b><u>2010</u></b>

### 2) [Series CR ... \(coiled\)](#)

The products are coded with a **Month / Year** Code (on the cell):

**Example:** **09 10**

09	<b>September</b>
10	<b><u>2010</u></b>

### 3) [Series ER ...](#)

The products are coded with a **Year / Month** Code (on the cell):

**Example:** **10 09**

10	<b><u>2010</u></b>
09	<b>September</b>

## For assembled Batteries:

- 1) [Series CR ... AA](#)
- 2) [Series CR ... 2/3 AH](#)

The products are coded with a **MMYR** Code:

**MM** = Month (01 = Jan, 02 = Feb, ... 12 = Dec)  
**Y** = Year (2010 = 0, 2011 = 1, 2019 = 9)  
**R** = Reference number or figure (for this case, F = the assembly line code)

### Example 1:

**05 1 F** → May 2011 / assembly line code F

### Example 2:

**06 0 1** → June 2010 / assembly line code 1

- 3) [Series ER ...](#)

The products are coded with a **Year / Month** Code (on the cell):

Example: **10 09**

<b>10</b>	<b><u>2010</u></b>
<b>09</b>	<b>September</b>

The products are coded with an additional lot and production code

Example: **JA29A** → for internal use only