


7 Local Sever Deployment

1. Installation

Please download the deployment software from the link below:

http://thermometer.oss-cn-beijing.aliyuncs.com/web/company_attendance/General/2.0.4/Attendance_E_Setup.exe

Select a computer as the local server and install the Environment Configuration software in the computer.

Double click  Attendance_E_Setup.exe to install the software. Please install the software in a non-system disk directory , The default directory is "D:\attendance".

After successful installation, the shortcut icon  will be generated on the desktop.