





# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

## by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB32014AD110CC0	7449128	Selector switch, complete	3SU11004BF113FA0	1812857	3SU11000AB101BA0	8742020	3SU11300AB101BA0	8742086	3SU11500AB101BA0	8742121	-	-
3SB32020AA11	7352749	Push button, complete	3SU11000AB101BA0	8742020	3SU11000AB103BA0	3SU11000AB103BA0	3SU11300AB103BA0	3SU11300AB103BA0	3SU11500AB103BA0	-	-	-
3SB32020AA110CC0	7449137	Push button, complete	3SU11000AB103BA0	1812843	3SU11000AB201BA0	1736756	3SU11300AB201BA0	8742099	3SU11500AB201BA0	1736793	-	-
3SB32020AA21	7448954	Push button, complete	3SU11000AB201BA0	1736756	3SU11000AB301BA0	1736757	3SU11300AB301BA0	8742096	3SU11500AB301BA0	1736795	-	-
3SB32020AA31	7448957	Push button, complete	3SU11000AB301BA0	1736757	3SU11000AB303BA0	-	-	-	3SU11500AB303BA0	-	-	-
3SB32020AA310CC0	7449130	Push button, complete	3SU11000AB303BA0	1934206	3SU11000AB401BA0	8742033	3SU11300AB401BA0	8742106	3SU11500AB401BA0	8742131	-	-
3SB32020AA41	7448853	Push button, complete	3SU11000AB401BA0	8742033	3SU11000AB403BA0	-	3SU11300AB403BA0	-	3SU11500AB403BA0	-	-	-
3SB32020AA410CC0	7449134	Push button, complete	3SU11000AB403BA0	1933218	3SU11000AB501BA0	8741932	3SU11300AB501BA0	8741709	3SU11500AB501BA0	1736796	-	-
3SB32020AA51	7448822	Push button, complete	3SU11000AB501BA0	8741932	3SU11000AB503BA0	-	-	-	3SU11500AB503BA0	-	-	-
3SB32020AA510CC0	7449143	Push button, complete	3SU11000AB503BA0	1812846	3SU11000AB601BA0	1736758	3SU11300AB601BA0	8741702	3SU11500AB601BA0	1736797	-	-
3SB32020AA61	7448913	Push button, complete	3SU11000AB601BA0	1736758	3SU11000AB603BA0	-	-	-	3SU11500AB603BA0	-	-	-
3SB32020AA610CC0	7449146	Push button, complete	3SU11000AB603BA0	1933192	3SU11000AB701BA0	-	-	-	3SU11500AB701BA0	-	-	-
3SB32020AA71	7449140	Push button, complete	3SU11000AB701BA0	1933195	3SU11002BF01NA0	8742042	3SU11302BF01NA0	1736781	3SU11502BF01NA0	8742140	3SU11302BF601BA0	1736781
3SB32022HA11	7352743	Selector switch, complete	3SU11002BF01BA0	8742030	3SU11002BL601NA0	8742042	3SU11302BF601BA0	1736781	3SU11502BF601BA0	8742140	3SU11302BF601BA0	1736781
3SB32022KA11	7448847	Selector switch, complete	3SU11002BF601BA0	8742030	3SU11002BL601NA0	8742042	3SU11302BF603BA0	-	3SU11502BF603BA0	-	3SU11302BF603BA0	-
3SB32022KA110CC0	7448951	Selector switch, complete	3SU11002BF603BA0	1736763	3SU11004BF111BA0	8741948	3SU11304BF111BA0	1355651	3SU11504BF111BA0	1355657	3SU11304BF111BA0	1355651
3SB32024AD11	7448800	Selector switch, complete	3SU11004BF111BA0	8741948	3SU11004BF113BA0	-	3SU11304BF113BA0	-	3SU11504BF113BA0	-	3SU11304BF113BA0	-
3SB32024AD110CC0	7448960	Selector switch, complete	3SU11004BF113BA0	1812856	3SU11000AB101CA0	1736755	3SU11300AB101CA0	8742080	3SU11500AB101CA0	1736792	-	-
3SB32030AA11	7448872	Push button, complete	3SU11000AB101CA0	1736755	3SU11000AB201CA0	8742024	3SU11300AB201CA0	8742092	3SU11500AB201CA0	8742125	-	-
3SB32030AA21	7448963	Push button, complete	3SU11000AB201CA0	8742024	-	-	-	-	-	-	-	-
3SB32031CA21	7448812	Push button, complete	3SU11001BA201CA0	1736759	-	-	-	-	-	-	-	-
3SB32031CA210CC0	7449159	Push button, complete	3SU11001BA203CA0	1935154	-	-	-	-	-	-	-	-
3SB32031HA200AC0	7449152	Push button, complete	3SU11001HB201CF0	1809497	-	-	-	-	-	-	-	-
3SB32031HA200CC0	7449156	Push button, complete	3SU11001HB203CH0	1736761	-	-	-	-	-	-	-	-
3SB32031HA26	7449165	Push button, complete	3SU10001NB200AA0	-	-	-	-	-	-	-	-	-
3SB32031HA260CC0	7449168	Push button, complete	3SU10001NB200AA0	-	-	-	-	-	-	-	-	-
3SB32031HP20	7449162	Push button, complete	3SU11001HB201CJ0	1812850	3SU11001HB201CG0	1038532	-	-	3SU11501HB201CG0	1038533	-	-
3SB32031HR20	7450320	Push button, complete	3SU11001HB201CG0	1038532	3SU11001HA201CH0	1736760	-	-	3SU11501HA201CH0	-	-	-
3SB32031TA20	7448967	Push button, complete	3SU11001HA201CH0	1736760	3SU11036AA201AA0	-	-	-	3SU11536AA201AA0	-	-	-
3SB32046AA20	7448904	Indicator light complete	3SU11036AA201AA0	1809500	3SU11036AA203AA0	-	-	-	3SU11536AA203AA0	-	-	-
3SB32046AA200CC0	7449171	Indicator light complete	3SU11036AA203AA0	1933864	3SU11036AA301AA0	-	-	-	3SU11536AA301AA0	-	-	-
3SB32046AA30	7448907	Indicator light complete	3SU11036AA301AA0	1812864	3SU11066AA301AA0	1736779	-	-	3SU11566AA301AA0	1736812	-	-
3SB32046AA300CC0	7449174	Indicator light complete	3SU11066AA301AA0	1736779	3SU11036AA401AA0	-	-	-	3SU11536AA401AA0	-	-	-
3SB32046AA40	7448901	Indicator light complete	3SU11036AA401AA0	1812865	3SU11036AA403AA0	-	-	-	3SU11536AA403AA0	-	-	-
3SB32046AA400CC0	7449178	Indicator light complete	3SU11036AA403AA0	1932961	3SU11036AA501AA0	-	-	-	3SU11536AA501AA0	-	-	-
3SB32046AA50	7449187	Indicator light complete	3SU11036AA501AA0	1934759	3SU11036AA503AA0	-	-	-	3SU11536AA503AA0	-	-	-
3SB32046AA500CC0	7449180	Indicator light complete	3SU11036AA503AA0	1935198	3SU11036AA601AA0	-	-	-	3SU11536AA601AA0	-	-	-
3SB32046AA60	7448976	Indicator light complete	3SU11036AA601AA0	1809501	3SU11036AA603AA0	-	-	-	3SU11536AA603AA0	-	-	-
3SB32046AA600CC0	7449184	Indicator light complete	3SU11036AA603AA0	1932950	3SU11036AA701AA0	-	-	-	3SU11536AA701AA0	-	-	-
3SB32046AA70	7352752	Indicator light complete	3SU11036AA701AA0	1812866	3SU11036AA703AA0	-	-	-	3SU11536AA703AA0	-	-	-
3SB32046AA700CC0	7449193	Indicator light complete	3SU11036AA703AA0	1932954	3SU11036AA201AA0	-	-	-	3SU11536AA201AA0	-	-	-
3SB32046BA20	7448979	Indicator light complete	3SU11036AA201AA0	1809500	3SU11036AA203AA0	-	-	-	3SU11536AA203AA0	-	-	-
3SB32046BA200CC0	7449196	Indicator light complete	3SU11036AA203AA0	1933864	3SU11036AA301AA0	-	-	-	3SU11536AA301AA0	-	-	-
3SB32046BA30	7449190	Indicator light complete	3SU11036AA301AA0	1812864	3SU11066AA301AA0	1736779	-	-	3SU11566AA301AA0	1736812	-	-
3SB32046BA300CC0	7449200	Indicator light complete	3SU11066AA301AA0	1736779	3SU11036AA401AA0	-	-	-	3SU11536AA401AA0	-	-	-
3SB32046BA40	7449203	Indicator light complete	3SU11036AA401AA0	1812865	3SU11036AA403AA0	-	-	-	3SU11536AA403AA0	-	-	-
3SB32046BA400CC0	7448973	Indicator light complete	3SU11036AA403AA0	1932961	3SU11036AA501AA0	-	-	-	3SU11536AA501AA0	-	-	-
3SB32046BA50	7449207	Indicator light complete	3SU11036AA501AA0	1934759	3SU11036AA503AA0	-	-	-	3SU11536AA503AA0	-	-	-
3SB32046BA500CC0	7449216	Indicator light complete	3SU11036AA503AA0	1935198	3SU11036AA601AA0	-	-	-	3SU11536AA601AA0	-	-	-
3SB32046BA60	7449219	Indicator light complete	3SU11036AA601AA0	1809501	3SU11036AA603AA0	-	-	-	3SU11536AA603AA0	-	-	-
3SB32046BA600CC0	7449223	Indicator light complete	3SU11036AA603AA0	1932950	3SU11036AA701AA0	-	-	-	3SU11536AA701AA0	-	-	-
3SB32046BA70	7449222	Indicator light complete	3SU11036AA701AA0	1812866	3SU10010AB200AA0	8741759	3SU10310AB200AA0	1038515	3SU10510AB200AA0	8741958	3SU10610JB200AA0	1736742
3SB32046BA700CC0	7449225	Front element for indicator light	3SU10010AB200AA0	8741771	3SU10010AB200AA0	8741759	3SU10310AB200AA0	1038515	3SU10510AB200AA0	8741958	3SU10610JB200AA0	1736742
3SB32050AA21	7449229	Front element for push button	3SU10010AB200AA0	8741759	3SU10010AB300AA0	8741633	3SU10310AB300AA0	1038516	3SU10510AB300AA0	8741967	3SU10610JB300AA0	1736743
3SB32050AA210CC0	7449238	Front element for push button	3SU10010AB300AA0	8741633	3SU10010AB300AA0	8741633	3SU10310AB300AA0	1038516	3SU10510AB300AA0	8741967	3SU10610JB300AA0	1736743
3SB32050AA31	7449231	Front element for push button	3SU10010AB300AA0	8741633	3SU10010AB400AA0	8741642	3SU10310AB400AA0	1038518	3SU10510AB400AA0	8741960	3SU10610JB400AA0	1736745
3SB32050AA310CC0	7449235	Front element for push button	3SU10010AB300AA0	8741633	3SU10010AB400AA0	8741642	3SU10310AB400AA0	1038518	3SU10510AB400AA0	8741960	3SU10610JB400AA0	1736745
3SB32050AA41	7448799	Front element for push button	3SU10010AB400AA0	8741642	3SU10010AB500AA0	8741645	3SU10310AB500AA0	1038519	3SU10510AB500AA0	8741964	3SU10610JB500AA0	1736746
3SB32050AA410CC0	7449244	Front element for push button	3SU10010AB400AA0	8741642	3SU10010AB500AA0	8741645	3SU10310AB500AA0	1038519	3SU10510AB500AA0	8741964	3SU10610JB500AA0	1736746
3SB32050AA51	7449247	Front element for push button	3SU10010AB500AA0	8741645	3SU10010AB600AA0	8741649	3SU10310AB600AA0	1038520	3SU10510AB600AA0	8741973	3SU10310AB600AA0	1038520
3SB32050AA510CC0	7449241	Front element for push button	3SU10010AB500AA0	8741645	3SU10010AB600AA0	8741649	3SU10310AB600AA0	1038520	3SU10510AB600AA0	8741973	3SU10310AB600AA0	1038520
3SB32050AA61	7449250	Front element for push button	3SU10010AB700AA0	8741649	3SU10010AB700AA0	8741658	3SU10310AB700AA0	1038521	3SU10510AB700AA0	8741976	3SU10610JB700AA0	1736747
3SB32050AA610CC0	7449253	Front element for push button	3SU10010AB700AA0	8741649	3SU10010AB700AA0	8741658	3SU10310AB700AA0	1038521	3SU10510AB700AA0	8741976	3SU10610JB700AA0	1736747
3SB32050AA71	7448828	Front element for push button	3SU10010AB800AA0	8741658	3SU10010AB300AA0	8741633	3SU10310AB300AA0	1038516	3SU10510AB300AA0	8741967	3SU10610JB300AA0	1736743
3SB32050AA710CC0	7449257	Front element for push button	3SU10010AB800AA0	8741658	3SU10010AB300AA0	8741633	3SU10310AB300AA0	1038516	3SU10510AB300AA0	8741967	3SU10610JB300AA0	1736743
3SB32060AA31	7448982	Front element for push button	3SU10010AB800AA0	8741633	3SU10010AB400AA0	8741642	3SU10310AB400AA0	1038518	3SU10510AB400AA0	8741960	3SU10610JB400AA0	1736745

# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

## by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB3206AA310CC0	7449266	Front element for push button	3SU10010AB300AA0	8741633	3SU10010AB400AA0	8741642	3SU10310AB400AA0	1038518	3SU10510AB400AA0	8741960	3SU10610JB400AA0	1736745
3SB3206AA41	7448783	Front element for push button	3SU10010AB400AA0	8741642	3SU10010AB500AA0	8741645	3SU10310AB500AA0	1038519	3SU10510AB500AA0	1038519	3SU10610JB500AA0	1736746
3SB3206AA410CC0	7449269	Front element for push button	3SU10010AB400AA0	8741642	3SU10010AB500AA0	8741645	3SU10310AB500AA0	1038519	3SU10510AB500AA0	1038519	3SU10610JB500AA0	1736746
3SB3206AA51	7448985	Front element for push button	3SU10010AB500AA0	8741645	3SU10010AB600AA0	8741649	3SU10310AB600AA0	1038520	3SU10510AB600AA0	8741973	3SU10610JB600AA0	1038520
3SB3206AA510CC0	7449263	Front element for push button	3SU10010AB500AA0	8741645	3SU10010AB600AA0	8741649	3SU10310AB600AA0	1038520	3SU10510AB600AA0	8741973	3SU10610JB600AA0	1038520
3SB3206AA61	7448774	Front element for push button	3SU10010AB600AA0	8741649	3SU10010AB700AA0	8741658	3SU10310AB700AA0	1038521	3SU10510AB700AA0	8741976	3SU10610JB700AA0	1736747
3SB3206AA610CC0	7448989	Front element for push button	3SU10010AB600AA0	8741649	3SU10010AB700AA0	8741658	3SU10310AB700AA0	1038521	3SU10510AB700AA0	8741976	3SU10610JB700AA0	1736747
3SB3206AA71	7352755	Front element for push button	3SU10010AB700AA0	8741658	3SU10010AB200AA0	8741759	3SU10310AB200AA0	1038515	3SU10510AB200AA0	8741958	3SU10610JB200AA0	1736742
3SB3206AA710CC0	7449272	Front element for push button	3SU10010AB700AA0	8741658	3SU10010AB200AA0	8741759	3SU10310AB200AA0	1038515	3SU10510AB200AA0	8741958	3SU10610JB200AA0	1736742
3SB32070AA21	7352759	Front element for push button	3SU10010AB200AA0	8741759	3SU11002BL601NA0	8742042	3SU10322BL600AA0	1038526	3SU10522BL600AA0	8742005	3SU10322BL600AA0	1038526
3SB32070AA210CC0	7448991	Front element for push button	3SU10010AB200AA0	8741759	3SU11002BL601NA0	8742042	3SU10322BM600AA0	1038527	3SU10522BM600AA0	8741945	3SU10322BM600AA0	1038527
3SB3208DA11	7448995	Front element for selector switch	3SU10022BL600AA0	8741787	3SU11002BL601NA0	8742042	3SU11302BL601NA0	1355649	3SU11502BL601NA0	1355654	3SU11302BL601NA0	1355649
3SB32082EA11	7448819	Front element for selector switch	3SU10022BM600AA0	8741780	3SU11002BL601NA0	8742042	3SU11302BL603NA0	-	3SU11502BL603NA0	-	3SU11302BL603NA0	-
3SB3210DA11	7449008	Selector switch, complete	3SU11002BL601NA0	8742042	3SU11002BL601NA0	8742042	3SU11302BM601NA0	1355650	3SU11502BM601NA0	1355655	3SU11302BM601NA0	1355650
3SB3210DA110CC0	7449275	Selector switch, complete	3SU11002BL603NA0	1812855	3SU11002BL601NA0	8742042	3SU10322BM600AA0	1038527	3SU10522BM600AA0	8741945	3SU10322BM600AA0	1038527
3SB32102EA11	7448806	Selector switch, complete	3SU11002BM601NA0	8742046	-	-	-	-	-	-	-	-
3SB32102EA110CC0	7449279	Front element for selector switch	3SU10022BM600AA0	8741780	3SU11066AA201AA0	8742070	-	-	3SU11566AA201AA0	8742200	-	-
3SB32111XA20	7449288	Push button, complete	3SU11001LB201PH0	1812852	3SU11066AA301AA0	1736779	-	-	3SU11566AA301AA0	1736812	-	-
3SB32126AA20	7448881	Indicator light complete	3SU11066AA201AA0	8742070	3SU11066AA401AA0	8742074	-	-	3SU11566AA401AA0	8742204	-	-
3SB32126AA30	7449281	Indicator light complete	3SU11066AA301AA0	1736779	3SU11066AA501AA0	-	-	-	3SU11566AA501AA0	-	-	-
3SB32126AA40	7449285	Indicator light complete	3SU11066AA401AA0	8742074	3SU11066AA601AA0	8742083	-	-	3SU11566AA601AA0	8742213	-	-
3SB32126AA50	7449294	Indicator light complete	3SU11066AA501AA0	1812871	3SU11066AA701AA0	-	-	-	3SU11566AA701AA0	-	-	-
3SB32126AA60	7448884	Indicator light complete	3SU11066AA601AA0	8742083	3SU11060AB201CA0	1736777	3SU11360AB201CA0	-	3SU11560AB201CA0	1736809	3SU11360AB201CA0	-
3SB32126AA70	7449001	Indicator light complete	3SU11066AA701AA0	1837281	3SU11060AB301BA0	-	3SU11360AB301BA0	-	3SU11560AB301BA0	1736810	3SU11360AB301BA0	-
3SB32130AA21	7449297	Push button, complete	3SU11060AB201CA0	1736777	-	-	-	-	-	-	-	-
3SB32130AA31	7448866	Push button, complete	3SU11060AB301BA0	1837278	-	-	-	-	-	-	-	-
3SB32130AA41	7449291	Push button, complete	3SU11060AB401BA0	1736778	-	-	-	-	-	-	-	-
3SB32130AA51	7449301	Push button, complete	3SU11060AB501BA0	1934836	-	-	-	-	-	-	-	-
3SB32130AA61	7449304	Push button, complete	3SU11060AB601BA0	1837280	-	-	-	-	-	-	-	-
3SB32130AA71	7449308	Push button, complete	3SU11060AB701BA0	1812869	-	-	-	-	-	-	-	-
3SB32140AA31	7449317	Push button, complete	3SU11060AB301BA0	1837278	-	-	-	-	-	-	-	-
3SB32140AA41	7449310	Push button, complete	3SU11060AB401BA0	1736778	-	-	-	-	-	-	-	-
3SB32140AA51	7449314	Push button, complete	3SU11060AB501BA0	1934836	-	-	-	-	-	-	-	-
3SB32140AA61	7449323	Push button, complete	3SU11060AB601BA0	1837280	-	-	-	-	-	-	-	-
3SB32140AA71	7449326	Push button, complete	3SU11060AB701BA0	1812869	3SU11026AA203AA0	-	-	-	3SU11526AA203AA0	-	-	-
3SB32140AB11	7449320	Push button, complete	3SU11060AB601BA0Z/Y10	-	3SU11026AA301AA0	8742061	-	-	3SU11526AA301AA0	1736806	-	-
3SB32160AA21	7449339	Push button, complete	3SU11060AB201CA0	1736777	3SU11026AA401AA0	8742064	-	-	3SU11526AA401AA0	8742159	-	-
3SB32176AA20	7352768	Indicator light complete	3SU11026AA203AA0	1812860	3SU11026AA501AA0	1355647	-	-	3SU11526AA501AA0	1736807	-	-
3SB32176AA30	7352761	Indicator light complete	3SU11026AA301AA0	8742061	3SU11026AA601AA0	8742068	-	-	3SU11526AA601AA0	8741885	-	-
3SB32176AA40	7352765	Indicator light complete	3SU11026AA401AA0	8742064	3SU11026AA701AA0	1736776	-	-	3SU11526AA701AA0	1736808	-	-
3SB32176AA50	7449332	Indicator light complete	3SU11026AA501AA0	1355647	3SU11020AB201CA0	1736769	3SU11320AB201CA0	1736784	3SU11520AB201CA0	1736802	3SU11320AB201CA0	1736784
3SB32176AA60	7449014	Indicator light complete	3SU11026AA601AA0	8742068	3SU11020AB301BA0	1736771	3SU11320AB301BA0	1736785	3SU11520AB301BA0	1736803	3SU11320AB301BA0	1736785
3SB32176AA70	7449336	Indicator light complete	3SU11026AA701AA0	1736776	3SU11020AB401BA0	8742055	3SU11320AB401BA0	1736786	3SU11520AB401BA0	8742143	3SU11320AB401BA0	1736786
3SB32180AA21	7449345	Push button, complete	3SU11020AB201CA0	1736789	3SU11020AB501BA0	1736774	3SU11320AB501BA0	1736787	3SU11520AB501BA0	1736804	3SU11320AB501BA0	1736787
3SB32200AA31	7449348	Push button, complete	3SU11020AB301BA0	1736771	3SU11020AB601BA0	8742058	3SU11320AB601BA0	1736789	3SU11520AB601BA0	8742147	3SU11320AB601BA0	1736789
3SB32200AA41	7449342	Push button, complete	3SU11020AB401BA0	8742055	3SU11020AB701BA0	8741936	3SU11320AB701BA0	1736790	3SU11520AB701BA0	1736805	3SU11320AB701BA0	1736790
3SB32200AA51	7449351	Push button, complete	3SU11020AB501BA0	1736774	3SU11020AB201FA0	1736770	3SU11320AB201FA0	-	3SU11520AB201FA0	-	3SU11320AB201FA0	-
3SB32200AA61	7449017	Push button, complete	3SU11020AB601BA0	8742058	3SU11020AB301FA0	-	3SU11320AB301FA0	-	3SU11520AB301FA0	-	3SU11320AB301FA0	-
3SB32200AA71	7449354	Push button, complete	3SU11020AB701BA0	8741936	3SU11020AB401FA0	1736773	3SU11320AB401FA0	-	3SU11520AB401FA0	-	3SU11320AB401FA0	-
3SB32210AA21	7449358	Push button, complete	3SU11020AB201FA0	1736770	3SU11020AB501FA0	-	3SU11320AB501FA0	-	3SU11520AB501FA0	-	3SU11320AB501FA0	-
3SB32210AA31	7449367	Push button, complete	3SU11020AB301FA0	1812858	3SU11020AB601FA0	-	3SU11320AB601FA0	-	3SU11520AB601FA0	-	3SU11320AB601FA0	-
3SB32210AA41	7449360	Push button, complete	3SU11020AB401FA0	1736773	3SU11020AB701FA0	1736775	3SU11320AB701FA0	-	3SU11520AB701FA0	-	3SU11320AB701FA0	-
3SB32210AA51	7449011	Push button, complete	3SU11020AB501FA0	1812859	3SU12006KB101AA0	1736813	-	-	3SU12506KB101AA0	-	-	-
3SB32210AA61	7449364	Push button, complete	3SU11020AB601FA0	1809499	3SU12006KC101AA0	-	-	-	3SU12506KC101AA0	-	-	-
3SB32210AA71	7449373	Push button, complete	3SU11020AB701FA0	1736775	3SU12006KF101AA0	-	-	-	3SU12506KF101AA0	-	-	-
3SB32337BA10	5067553	Acoustic indicator	3SU12006KB101AA0	1736813	3SU10016AA600AA0	8741762	-	-	3SU10516AA600AA0	8741995	-	-
3SB32347BA10	7449376	Acoustic indicator	3SU12006KC101AA0	1932627	3SU11026AA201AA0	8742052	-	-	3SU11526AA201AA0	8742156	-	-
3SB32357BA10	5067569	Acoustic indicator	3SU12006KF101AA0	1812875	3SU11026AA203AA0	-	-	-	3SU11526AA203AA0	-	-	-
3SB32406BA60	7449370	Front element for indicator light	3SU10016AA600AA0	8741762	3SU11026AA301AA0	8742061	-	-	3SU11526AA301AA0	1736806	-	-
3SB32446AA20	7448816	Indicator light complete	3SU11026AA201AA0	8742052	3SU11026AA303AA0	-	-	-	3SU11526AA303AA0	-	-	-
3SB32446AA200CC0	7449389	Indicator light complete	3SU11026AA203AA0	1812860	3SU11026AA401AA0	8742064	-	-	3SU11526AA401AA0	8742159	-	-
3SB32446AA30	7448862	Indicator light complete	3SU11026AA301AA0	8742061	3SU11026AA403AA0	-	-	-	3SU11526AA403AA0	-	-	-
3SB32446AA300CC0	7449382	Indicator light complete	3SU11026AA303AA0	1812861	3SU11026AA501AA0	1355647	-	-	3SU11526AA501AA0	1736807	-	-
3SB32446AA40	7448910	Indicator light complete	3SU11026AA401AA0	8742064	3SU11026AA503AA0	-	-	-	3SU11526AA503AA0	-	-	-
3SB32446AA400CC0	7449020	Indicator light complete	3SU11026AA403AA0	1812862	3SU11026AA601AA0	8742068	-	-	3SU11526AA601AA0	8741885	-	-
3SB32446AA50	7449023	Indicator light complete	3SU11026AA501AA0	1355647	3SU11026AA603AA0	-	-	-	3SU11526AA603AA0	-	-	-



# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

## by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB32446AA500CC0	7449386	Indicator light complete	3SU11026AA503AA0	1932768	3SU11026AA701AA0	1736776	-	-	3SU11526AA701AA0	1736808	-	-
3SB32446AA60	7448796	Indicator light complete	3SU11026AA601AA0	8742068	3SU11026AA703AA0	-	-	-	3SU11526AA703AA0	-	-	-
3SB32446AA600CC0	7449027	Indicator light complete	3SU11026AA603AA0	1932764	3SU11026AA201AA0	8742052	-	-	3SU11526AA201AA0	8742156	-	-
3SB32446AA70	7448825	Indicator light complete	3SU11026AA701AA0	1736776	3SU11026AA203AA0	-	-	-	3SU11526AA203AA0	-	-	-
3SB32446AA700CC0	7449395	Indicator light complete	3SU11026AA703AA0	1933635	3SU11026AA301AA0	8742061	-	-	3SU11526AA301AA0	1736806	-	-
3SB32446BA20	7448856	Indicator light complete	3SU11026AA201AA0	8742052	3SU11026AA303AA0	-	-	-	3SU11526AA303AA0	-	-	-
3SB32446BA200CC0	7449036	Indicator light complete	3SU11026AA203AA0	1812860	3SU11026AA401AA0	8742064	-	-	3SU11526AA401AA0	8742159	-	-
3SB32446BA30	7448888	Indicator light complete	3SU11026AA301AA0	8742061	3SU11026AA403AA0	-	-	-	3SU11526AA403AA0	-	-	-
3SB32446BA300CC0	7449398	Indicator light complete	3SU11026AA303AA0	1812861	3SU11026AA501AA0	1355647	-	-	3SU11526AA501AA0	1736807	-	-
3SB32446BA40	7449039	Indicator light complete	3SU11026AA401AA0	8742064	3SU11026AA503AA0	-	-	-	3SU11526AA503AA0	-	-	-
3SB32446BA400CC0	7449033	Indicator light complete	3SU11026AA403AA0	1812862	3SU11026AA601AA0	8742068	-	-	3SU11526AA601AA0	8741885	-	-
3SB32446BA50	7448831	Indicator light complete	3SU11026AA501AA0	1355647	3SU11026AA603AA0	-	-	-	3SU11526AA603AA0	-	-	-
3SB32446BA500CC0	7449392	Indicator light complete	3SU11026AA503AA0	1932768	3SU11026AA701AA0	1736776	-	-	3SU11526AA701AA0	1736808	-	-
3SB32446BA60	7449402	Indicator light complete	3SU11026AA601AA0	8742068	3SU11026AA703AA0	-	-	-	3SU11526AA703AA0	-	-	-
3SB32446BA600CC0	7449405	Indicator light complete	3SU11026AA603AA0	1932764	3SU11020AB301BA0	1736771	3SU11320AB301BA0	1736785	3SU11520AB301BA0	1736803	3SU11320AB301BA0	1736785
3SB32446BA70	7449042	Indicator light complete	3SU11026AA701AA0	1736776	3SU11020AB401BA0	8742055	3SU11320AB401BA0	1736786	3SU11520AB401BA0	8742143	3SU11320AB401BA0	1736786
3SB32446BA700CC0	7449409	Indicator light complete	3SU11026AA703AA0	1933635	3SU11020AB501BA0	1736774	3SU11320AB501BA0	1736787	3SU11520AB501BA0	1736804	3SU11320AB501BA0	1736787
3SB32450AA31	7449045	Push button, complete	3SU11020AB301BA0	1736771	3SU11020AB601BA0	8742058	3SU11320AB601BA0	1736789	3SU11520AB601BA0	8742147	3SU11320AB601BA0	1736789
3SB32450AA41	7448878	Push button, complete	3SU11020AB401BA0	8742055	3SU11020AB701BA0	8741936	3SU11320AB701BA0	1736790	3SU11520AB701BA0	1736805	3SU11320AB701BA0	1736790
3SB32450AA51	7449049	Push button, complete	3SU11020AB501BA0	1736774	3SU11020AB201CA0	1736769	3SU11320AB201CA0	1736784	3SU11520AB201CA0	1736802	3SU11320AB201CA0	1736784
3SB32450AA61	7449058	Push button, complete	3SU11020AB601BA0	8742058	3SU11020AB201FA0	1736770	3SU11320AB201FA0	-	3SU11520AB201FA0	-	3SU11320AB201FA0	-
3SB32450AA71	7448840	Push button, complete	3SU11020AB701BA0	8741936	3SU11020AB301FA0	-	3SU11320AB301FA0	-	3SU11520AB301FA0	-	3SU11320AB301FA0	-
3SB32460AA21	7448844	Push button, complete	3SU11020AB201CA0	1736769	3SU11020AB303FA0	-	3SU11320AB303FA0	-	3SU11520AB303FA0	-	3SU11320AB303FA0	-
3SB32470AA21	7448834	Push button, complete	3SU11020AB201FA0	1736770	3SU11020AB401FA0	1736773	3SU11320AB401FA0	-	3SU11520AB401FA0	-	3SU11320AB401FA0	-
3SB32470AA31	7449051	Push button, complete	3SU11020AB301FA0	1812858	3SU10010AB500AA0	8741645	3SU10310AB500AA0	1038519	3SU10510AB500AA0	8741964	3SU10610JB500AA0	1736746
3SB32470AA310CC0	7449418	Push button, complete	3SU11020AB303FA0	1934826	3SU11020AB601FA0	-	3SU11320AB601FA0	-	3SU11520AB601FA0	-	3SU11320AB601FA0	-
3SB32470AA41	7448897	Push button, complete	3SU11020AB401FA0	1736773	3SU11020AB701FA0	1736775	3SU11320AB701FA0	-	3SU11520AB701FA0	-	3SU11320AB701FA0	-
3SB32470AA51	7449411	Front element for push button	3SU10010AB500AA0	8741645	3SU11020AB703FA0	-	3SU11320AB703FA0	-	3SU11520AB703FA0	-	3SU11320AB703FA0	-
3SB32470AA61	7448890	Push button, complete	3SU11020AB601FA0	1809499	3SU11036AA201AA0	-	-	-	3SU11536AA201AA0	-	-	-
3SB32470AA71	7449055	Push button, complete	3SU11020AB701FA0	1736775	3SU11036AA301AA0	-	-	-	3SU11536AA301AA0	-	-	-
3SB32470AA710CC0	7449415	Push button, complete	3SU11020AB703FA0	1932775	3SU11036AA401AA0	-	-	-	3SU11536AA401AA0	-	-	-
3SB32486AA20	7449424	Indicator light complete	3SU11036AA201AA0	1809500	3SU11036AA601AA0	-	-	-	3SU11536AA601AA0	-	-	-
3SB32486AA30	7449427	Indicator light complete	3SU11036AA301AA0	1812864	3SU11036AA701AA0	-	-	-	3SU11536AA701AA0	-	-	-
3SB32486AA40	7449421	Indicator light complete	3SU11036AA401AA0	1812865	3SU11036AA201AA0	-	-	-	3SU11536AA201AA0	-	-	-
3SB32486AA50	7449430	Indicator light complete	3SU11036AA501AA0	1934759	3SU11036AA301AA0	-	-	-	3SU11536AA301AA0	-	-	-
3SB32486AA60	7449433	Indicator light complete	3SU11036AA601AA0	1809501	3SU11036AA401AA0	-	-	-	3SU11536AA401AA0	-	-	-
3SB32486AA70	7449437	Indicator light complete	3SU11036AA701AA0	1812866	3SU11036AA601AA0	-	-	-	3SU11536AA601AA0	-	-	-
3SB32486BA20	7449446	Indicator light complete	3SU11036AA201AA0	1809500	3SU11036AA701AA0	-	-	-	3SU11536AA701AA0	-	-	-
3SB32486BA30	7449064	Indicator light complete	3SU11036AA301AA0	1812864	-	-	-	-	-	-	-	-
3SB32486BA40	7449449	Indicator light complete	3SU11036AA401AA0	1812865	-	-	-	-	-	-	-	-
3SB32486BA50	7449443	Indicator light complete	3SU11036AA501AA0	1934759	-	-	-	-	-	-	-	-
3SB32486BA60	7449452	Indicator light complete	3SU11036AA601AA0	1809501	-	-	-	-	-	-	-	-
3SB32486BA70	7449455	Indicator light complete	3SU11036AA701AA0	1812866	3SU11066AA201AA0	8742070	-	-	3SU11566AA201AA0	8742200	-	-
3SB32500AA21	7449459	Push button, complete	3SU11030AB201CA0	1932772	3SU11066AA203AA0	-	-	-	3SU11566AA203AA0	-	-	-
3SB32510AA21	7449468	Push button, complete	3SU11030AB301FA0	1935149	3SU11066AA301AA0	1736779	-	-	3SU11566AA301AA0	1736812	-	-
3SB32510AA31	7449461	Push button, complete	3SU11030AB301FA0	1932776	3SU11066AA303AA0	-	-	-	3SU11566AA303AA0	-	-	-
3SB32510AA41	7449465	Push button, complete	3SU11030AB401FA0	1932777	3SU11066AA401AA0	8742074	-	-	3SU11566AA401AA0	8742204	-	-
3SB32510AA51	7449474	Push button, complete	3SU11030AB501FA0	1934726	3SU11066AA403AA0	-	-	-	3SU11566AA403AA0	-	-	-
3SB32510AA61	7449477	Push button, complete	3SU11030AB601FA0	1932788	3SU11066AA501AA0	-	-	-	3SU11566AA501AA0	-	-	-
3SB32510AA71	7449471	Push button, complete	3SU11030AB701FA0	1932769	3SU11066AA503AA0	-	-	-	3SU11566AA503AA0	-	-	-
3SB32526AA20	7449067	Indicator light complete	3SU11066AA201AA0	8742070	3SU11066AA601AA0	8742083	-	-	3SU11566AA601AA0	8742213	-	-
3SB32526AA200CC0	7449480	Indicator light complete	3SU11066AA203AA0	1933580	3SU11066AA603AA0	-	-	-	3SU11566AA603AA0	-	-	-
3SB32526AA30	7449061	Indicator light complete	3SU11066AA301AA0	1736779	3SU11066AA701AA0	-	-	-	3SU11566AA701AA0	-	-	-
3SB32526AA300CC0	7449483	Indicator light complete	3SU11066AA303AA0	1933042	3SU11066AA703AA0	-	-	-	3SU11566AA703AA0	-	-	-
3SB32526AA40	7449070	Indicator light complete	3SU11066AA401AA0	8742074	3SU11066AA201AA0	8742070	-	-	3SU11566AA201AA0	8742200	-	-
3SB32526AA400CC0	7449487	Indicator light complete	3SU11066AA403AA0	1812870	3SU11066AA203AA0	-	-	-	3SU11566AA203AA0	-	-	-
3SB32526AA50	7449073	Indicator light complete	3SU11066AA501AA0	1812871	3SU11066AA301AA0	1736779	-	-	3SU11566AA301AA0	1736812	-	-
3SB32526AA500CC0	7449496	Indicator light complete	3SU11066AA503AA0	1933003	3SU11066AA303AA0	-	-	-	3SU11566AA303AA0	-	-	-
3SB32526AA60	7448894	Indicator light complete	3SU11066AA601AA0	8742083	3SU11066AA401AA0	8742074	-	-	3SU11566AA401AA0	8742204	-	-
3SB32526AA600CC0	7449499	Indicator light complete	3SU11066AA603AA0	1809502	3SU11066AA403AA0	-	-	-	3SU11566AA403AA0	-	-	-
3SB32526AA70	7449077	Indicator light complete	3SU11066AA701AA0	1837281	3SU11066AA501AA0	-	-	-	3SU11566AA501AA0	-	-	-
3SB32526AA700CC0	7449493	Indicator light complete	3SU11066AA703AA0	1933012	3SU11066AA503AA0	-	-	-	3SU11566AA503AA0	-	-	-
3SB32526BA20	7449086	Indicator light complete	3SU11066AA201AA0	8742070	3SU11066AA601AA0	8742083	-	-	3SU11566AA601AA0	8742213	-	-
3SB32526BA200CC0	7449089	Indicator light complete	3SU11066AA203AA0	1933580	3SU11066AA603AA0	-	-	-	3SU11566AA603AA0	-	-	-
3SB32526BA30	7448875	Indicator light complete	3SU11066AA301AA0	1736779	3SU11066AA701AA0	-	-	-	3SU11566AA701AA0	-	-	-
3SB32526BA300CC0	7449503	Indicator light complete	3SU11066AA303AA0	1933042	3SU11066AA703AA0	-	-	-	3SU11566AA703AA0	-	-	-



















# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB35012FA71	7430647	Front element for selector switch	3SU10522BN600AA0	1809492	-	-	-	-	-	-	-	-
3SB35012GA21	7430641	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012GA31	7430650	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012GA41	7430653	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012GA51	7430657	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012GA71	7430666	Front element for selector switch	3SU10522CP600AA0	1933172	-	-	-	-	-	-	-	-
3SB35012GA710PA0	7430669	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012HA71	7430663	Front element for selector switch	3SU10522BF600AA0	8741992	-	-	-	-	-	-	-	-
3SB35012KA01	7430672	Front element for selector switch	3SU10522BF000AA0	1933504	-	-	-	-	-	-	-	-
3SB35012KA21	7430675	Front element for selector switch	3SU10522BF200AA0	1355640	-	-	-	-	-	-	-	-
3SB35012KA31	7430679	Front element for selector switch	3SU10522BF300AA0	1933511	-	-	-	-	-	-	-	-
3SB35012KA41	7430688	Front element for selector switch	3SU10522BF400AA0	1355642	3SU10016AA200AA0	8741752	-	-	3SU10516AA200AA0	8741970	-	-
3SB35012KA51	7430681	Front element for selector switch	3SU10522BF600AA0	8741992	3SU10016AA300AA0	8741756	-	-	3SU10516AA300AA0	8741989	-	-
3SB35012KA71	7430685	Front element for selector switch	3SU10522BF600AA0	8741992	3SU10016AA400AA0	8741765	-	-	3SU10516AA400AA0	8741982	-	-
3SB35012LA21	7430694	Front element for selector switch	3SU10522BC200AA0	1935160	3SU10016AA500AA0	8741768	-	-	3SU10516AA500AA0	8741986	-	-
3SB35012LA31	7430697	Front element for selector switch	3SU10522BC300AA0	1935161	3SU10016AA600AA0	8741762	-	-	3SU10516AA600AA0	8741995	-	-
3SB35012LA41	7430691	Front element for selector switch	3SU10522BC400AA0	1355638	3SU10016AA700AA0	8741771	-	-	3SU10516AA700AA0	8741998	-	-
3SB35012LA51	7430701	Front element for selector switch	3SU10522BC500AA0	1934189	-	-	-	-	-	-	-	-
3SB35012LA71	7430704	Front element for selector switch	3SU10522BC600AA0	1355639	3SU10016AA200AA0	8741752	-	-	3SU10516AA200AA0	8741970	-	-
3SB35012PA01	7430708	Front element for selector switch	3SU10522BF000AA0	1933504	3SU10016AA300AA0	8741756	-	-	3SU10516AA300AA0	8741989	-	-
3SB35012PA21	7429922	Front element for selector switch	3SU10522BF200AA0	1355640	3SU10016AA400AA0	8741765	-	-	3SU10516AA400AA0	8741982	-	-
3SB35012PA31	7430717	Front element for selector switch	3SU10522BF000AA0	1933504	3SU10016AA500AA0	8741768	-	-	3SU10516AA500AA0	8741986	-	-
3SB35012PA41	7430710	Front element for selector switch	3SU10522BF400AA0	1355642	3SU10016AA600AA0	8741762	-	-	3SU10516AA600AA0	8741995	-	-
3SB35012PA51	7430714	Front element for selector switch	3SU10522BF600AA0	8741992	3SU10016AA700AA0	8741771	-	-	3SU10516AA700AA0	8741998	-	-
3SB35012PA71	7429931	Front element for selector switch	3SU10522BF600AA0	8741992	3SU11000AB101FA0	1736863	3SU11300AB101FA0	-	3SU11500AB101FA0	-	-	-
3SB35012QA21	7430723	Front element for selector switch	3SU10522BC200AA0	1935160	3SU11000AB201FA0	-	3SU11300AB201FA0	-	3SU11500AB201FA0	-	-	-
3SB35012QA31	7430726	Front element for selector switch	3SU10522BC300AA0	1935161	3SU11000AB501FA0	-	3SU11300AB501FA0	-	3SU11500AB501FA0	-	-	-
3SB35012QA41	7430720	Front element for selector switch	3SU10522BC400AA0	1355638	3SU11501HB201FH0	-	-	-	3SU11501HB201FH0	-	-	-
3SB35012QA51	7430739	Front element for selector switch	3SU10522BC500AA0	1934189	3SU11001HB201FG0	-	-	-	3SU11501HB201FG0	-	-	-
3SB35012QA71	7430732	Front element for selector switch	3SU10522BC600AA0	1355639	-	-	-	-	-	-	-	-
3SB35012SA01	7430736	Front element for selector switch	3SU10522BL300AA0	1933364	3SU11002BF601FA0	-	3SU11302BF601FA0	-	3SU11502BF601FA0	-	3SU11302BF601FA0	-
3SB35012SA21	7430745	Front element for selector switch	3SU10522BL200AA0	1933359	3SU11004BF111FA0	1736764	3SU11304BF111FA0	-	3SU11504BF111FA0	1736799	3SU11304BF111FA0	-
3SB35012SA31	7430748	Front element for selector switch	3SU10522BL300AA0	1933364	3SU11000AB101BA0	8742020	3SU11300AB101BA0	8742086	3SU11500AB101BA0	8742121	-	-
3SB35012SA41	7430742	Front element for selector switch	3SU10522BL400AA0	1355643	3SU11000AB301BA0	1736757	3SU11300AB301BA0	8742096	3SU11500AB301BA0	1736795	-	-
3SB35012SA51	7430751	Front element for selector switch	3SU10522BL600AA0	8742005	3SU11000AB401BA0	8742033	3SU11300AB401BA0	8742106	3SU11500AB401BA0	8742131	-	-
3SB35012SA71	7430754	Front element for selector switch	3SU10522BL600AA0	8742005	3SU11000AB501BA0	8741932	3SU11300AB501BA0	8741709	3SU11500AB501BA0	1736796	-	-
3SB35012TA01	7430758	Front element for selector switch	3SU10522BM000AA0	1934888	3SU11000AB601BA0	1736758	3SU11300AB601BA0	8741702	3SU11500AB601BA0	1736797	-	-
3SB35012TA21	7430767	Front element for selector switch	3SU10522BM200AA0	1933366	3SU11002BF601BA0	8742030	3SU11302BF601BA0	1736781	3SU11502BF601BA0	8742140	3SU11302BF601BA0	1736781
3SB35012TA31	7430760	Front element for selector switch	3SU10522BM300AA0	1812837	3SU10022BF600AA0	8741778	3SU10322BF600AA0	1038524	3SU10522BF600AA0	8741992	3SU10322BF600AA0	1038524
3SB35012TA41	7430764	Front element for selector switch	3SU10522BM400AA0	1355644	3SU11000AB201CA0	8742024	3SU11300AB201CA0	8742092	3SU11500AB201CA0	8742125	-	-
3SB35012TA51	7430773	Front element for selector switch	3SU10522BM500AA0	1933501	3SU11001HB201CH0	8742036	-	-	3SU11501HB201CH0	8741807	-	-
3SB35012TA71	7430776	Front element for selector switch	3SU10522BM600AA0	8741945	3SU11001HB201CG0	1038532	-	-	3SU11501HB201CG0	1038533	-	-
3SB35012UA21	7430770	Front element for selector switch	3SU10522BN200AA0	1933367	3SU11036AA201AA0	-	-	-	3SU11536AA201AA0	-	-	-
3SB35012UA31	7430789	Front element for selector switch	3SU10522BN600AA0	1809492	3SU10016AA400AA0	8741765	-	-	3SU10516AA400AA0	8741982	-	-
3SB35012UA41	7430782	Front element for selector switch	3SU10522BN400AA0	1933503	3SU11002BL601LA0	-	3SU11302BL601LA0	-	3SU11502BL601LA0	-	3SU11302BL601LA0	-
3SB35012UA51	7430786	Front element for selector switch	3SU10522BN800AA0	1809492	3SU10022BL600AA0	8741787	3SU10322BL600AA0	1038526	3SU10522BL600AA0	8742005	3SU10322BL600AA0	1038526
3SB35012UA71	7430795	Front element for selector switch	3SU10522BN600AA0	1809492	3SU10022BM600AA0	8741780	3SU10322BM600AA0	1038527	3SU10522BM600AA0	8741945	3SU10322BM600AA0	1038527
3SB35012VA01	7430798	Front element for selector switch	3SU10522BP600AA0	1812838	3SU11002BL601NA0	8742042	3SU11302BL601NA0	1355649	3SU11502BL601NA0	1355654	3SU11302BL601NA0	1355649
3SB35012VA21	7430792	Front element for selector switch	3SU10522BP600AA0	1812838	3SU11002BM601NA0	8742046	3SU11302BM601NA0	1355650	3SU11502BM601NA0	1355655	3SU11302BM601NA0	1355650
3SB35012VA31	7430802	Front element for selector switch	3SU10522BP600AA0	1812838	3SU10022BL600AA0	8741787	3SU10322BL600AA0	1038526	3SU10522BL600AA0	8742005	3SU10322BL600AA0	1038526
3SB35012VA41	7430805	Front element for selector switch	3SU10522BP600AA0	1812838	3SU10022BM600AA0	8741780	3SU10322BM600AA0	1038527	3SU10522BM600AA0	8741945	3SU10322BM600AA0	1038527
3SB35012VA51	7430809	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35012VA71	7430818	Front element for selector switch	3SU10522BP600AA0	1812838	-	-	-	-	-	-	-	-
3SB35013PA21	7430811	Front element for selector switch	3SU10522CF200AA0	1933360	3SU11026AA201AA0	8742052	-	-	3SU11526AA201AA0	8742156	-	-
3SB35013PA31	7430815	Front element for selector switch	3SU10522CF300AA0	1933362	3SU11026AA301AA0	8742061	-	-	3SU11526AA301AA0	1736806	-	-
3SB35013PA41	7430824	Front element for selector switch	3SU10522CF400AA0	1933358	3SU11026AA401AA0	8742064	-	-	3SU11526AA401AA0	8742159	-	-
3SB35013PA51	7430827	Front element for selector switch	3SU10522CF500AA0	1934879	3SU11026AA501AA0	1355647	-	-	3SU11526AA501AA0	1736807	-	-
3SB35013PA71	7430821	Front element for selector switch	3SU10522CF600AA0	1812840	3SU11026AA601AA0	8742068	-	-	3SU11526AA601AA0	8741885	-	-
3SB35013QA21	7430830	Front element for selector switch	3SU10522CC600AA0	1812839	3SU11020AB301BA0	1736771	3SU11320AB301BA0	1736785	3SU11520AB301BA0	1736803	3SU11320AB301BA0	1736785
3SB35013QA31	7430833	Front element for selector switch	3SU10522CC300AA0	1935118	3SU11020AB401BA0	8742055	3SU11320AB401BA0	1736786	3SU11520AB401BA0	8742143	3SU11320AB401BA0	1736786
3SB35013QA41	7430837	Front element for selector switch	3SU10522CC400AA0	1933505	3SU11020AB601BA0	8742058	3SU11320AB601BA0	1736789	3SU11520AB601BA0	8742147	3SU11320AB601BA0	1736789
3SB35013QA51	7430846	Front element for selector switch	3SU10522CC500AA0	1935119	3SU11020AB201CA0	1736769	3SU11320AB201CA0	1736784	3SU11520AB201CA0	1736802	3SU11320AB201CA0	1736784
3SB35013QA71	7430849	Front element for selector switch	3SU10522CC600AA0	1812839	3SU11020AB201FA0	1736770	3SU11320AB201FA0	-	3SU11520AB201FA0	-	3SU11320AB201FA0	-
3SB35013SA21	7430843	Front element for selector switch	3SU10522CL200AA0	1812841	3SU11020AB301FA0	-	3SU11320AB301FA0	-	3SU11520AB301FA0	-	3SU11320AB301FA0	-
3SB35013SA31	7430852	Front element for selector switch	3SU10522CL600AA0	1812842	3SU11020AB401FA0	1736773	3SU11320AB401FA0	-	3SU11520AB401FA0	-	3SU11320AB401FA0	-
3SB35013SA41	7430855	Front element for selector switch	3SU10522CL400AA0	1935283	3SU11020AB501FA0	-	3SU11320AB501FA0	-	3SU11520AB501FA0	-	3SU11320AB501FA0	-









# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

## by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB39021EP	4533526	Text plate for control circuit devices	3SU19000AC160DW0	1932539	-	-	-	-	-	-	-	-
3SB39021EQ	4533548	Text plate for control circuit devices	3SU19000AC160DX0	1934712	-	-	-	-	-	-	-	-
3SB39021EU	4533554	Text plate for control circuit devices	3SU19000AC160EA0	1934863	-	-	-	-	-	-	-	-
3SB39021EV	4533560	Text plate for control circuit devices	3SU19000AC160EB0	1932541	-	-	-	-	-	-	-	-
3SB39021EW	4533576	Text plate for control circuit devices	3SU19000AC160EC0	1932551	-	-	-	-	-	-	-	-
3SB39021MB	4533582	Text plate for control circuit devices	3SU19000AC160QA0	1932543	-	-	-	-	-	-	-	-
3SB39021MC	4533598	Text plate for control circuit devices	3SU19000AC160QB0	1934720	-	-	-	-	-	-	-	-
3SB39021MF	4114141	Text plate for control circuit devices	3SU19000AC160QG0	1932554	-	-	-	-	-	-	-	-
3SB39021ML	4533605	Text plate for control circuit devices	3SU19000AC160QJ0	1932588	8742272	8742272	-	-	3SU15500AA100AA0	8742288	-	-
3SB39021NA	4533611	Text plate for control circuit devices	3SU19000AC160AZ0QY	-	-	-	-	-	-	-	-	-
3SB39021NJ	4533627	Text plate for control circuit devices	3SU19000AC160QS0	1933617	3SU19000FA100AA0	8742415	3SU19300FA800AA0	-	3SU19500FA800AA0	-	3SU19300FA800AA0	-
3SB39031AA	7352771	Text plate for control circuit devices	3SU19000AF160AA0	8742370	-	-	-	-	-	-	-	-
3SB39031EC	7450480	Text plate for control circuit devices	3SU19000AE160DK0	1932297	-	-	-	-	-	-	-	-
3SB39031EF	7450483	Text plate for control circuit devices	3SU19000AE160DN0	1932351	-	-	-	-	-	-	-	-
3SB39031EL	7450487	Text plate for control circuit devices	3SU19000AE160DT0	1932352	-	-	-	-	-	-	-	-
3SB39051AA	7541753	Text plate for control circuit devices	3SU19000AD160AA0	8742355	-	-	-	-	-	-	-	-
3SB39061AA	7541757	Text plate for control circuit devices	3SU19000AF160AA0	8742377	3SU10004BN010AA0	-	3SU10304BN010AA0	-	3SU10504BN010AA0	-	3SU10304BN010AA0	-
3SB39061AB	7541618	Text plate for control circuit devices	3SU19000AF160AB0	1932635	-	-	-	-	-	-	-	-
3SB39061AC	7541612	Text plate for control circuit devices	3SU19000AF160AC0	1932638	-	-	-	-	-	-	-	-
3SB39061AD	7541621	Text plate for control circuit devices	3SU19000AF160AD0	1932634	-	-	-	-	-	-	-	-
3SB39061AE	7541624	Text plate for control circuit devices	3SU19000AF160AE0	1933679	-	-	-	-	-	-	-	-
3SB39061AL	7541628	Text plate for control circuit devices	3SU19000AF160AL0	1932688	-	-	-	-	-	-	-	-
3SB39061AS	7541637	Text plate for control circuit devices	3SU19000AF160AS0	1932691	-	-	-	-	-	-	-	-
3SB39061EK	7541630	Text plate for control circuit devices	3SU19000AF160DS0	1932652	-	-	-	-	-	-	-	-
3SB39061EL	7450496	Text plate for control circuit devices	3SU19000AF160DT0	1933817	-	-	-	-	-	-	-	-
3SB39061EM	7450499	Text plate for control circuit devices	3SU19000AF160DU0	1932667	-	-	-	-	-	-	-	-
3SB39061EY	7541634	Text plate for control circuit devices	3SU19000AF160DA0	1933845	-	-	-	-	-	-	-	-
3SB39061MC	7541643	Text plate for control circuit devices	3SU19000AF160QB0	1932696	3SU10005BL110AA0	8741639	3SU10305BL110AA0	1736718	3SU10505BL110AA0	8741954	3SU10305BL110AA0	1736718
3SB39061NA	7541646	Text plate for control circuit devices	3SU19000AF160QR0	1932699	-	-	-	-	-	-	-	-
3SB39104A	7541640	Accessories for control circuit devices	3SU19500FB800AA0	1038579	3SU10022BN600AA0	-	3SU10322BN600AA0	-	3SU10522BN600AA0	-	3SU10322BN600AA0	-
3SB39210AA	4555419	Accessories for control circuit devices	3SU19000FA100AA0	8742415	-	-	-	-	-	-	-	-
3SB39210AB	4112955	Text plate for control circuit devices	3SU19000BC310AA0	8742361	-	-	-	-	-	-	-	-
3SB39210AC	4112882	Text plate for control circuit devices	3SU19000BC310AT0	8742395	-	-	-	-	-	-	-	-
3SB39210AD	4533633	Text plate for control circuit devices	3SU19000BC310DA0	1038560	3SU10022BN600AA0	-	3SU10322BN600AA0	-	3SU10522BN600AA0	-	3SU10322BN600AA0	-
3SB39210AE	7450493	Accessories for control circuit devices	3SU19600KB100AA0	1736870	3SU10022BN600AA0	-	3SU10322BN600AA0	-	3SU10522BN600AA0	-	3SU10322BN600AA0	-
3SB39210AG	7541659	Text plate for control circuit devices	3SU19000BC310GQ0	1932424	3SU10022BN600AA0	-	3SU10322BN600AA0	-	3SU10522BN600AA0	-	3SU10322BN600AA0	-
3SB39210AH	7450503	Accessories for control circuit devices	3SU19000DB700AA0	8742402	-	-	-	-	-	-	-	-
3SB39210AJ	7450506	Accessories for control circuit devices	3SU19000ED700AA0	1812885	-	-	-	-	-	-	-	-
3SB39210AK	4533649	Accessories for control circuit devices	3SU19000DY300AA0	8742406	-	-	-	-	-	-	-	-
3SB39210AM	7541652	Accessories for control circuit devices	3SU19000EE700AA0	1934693	-	-	-	-	-	-	-	-
3SB39210AN	7541656	Text plate for control circuit devices	3SU19000BC310JA0	1934684	-	-	-	-	-	-	-	-
3SB39210AQ	7541665	Accessories for control circuit devices	3SU19000DG700AA0	1038565	-	-	-	-	-	-	-	-
3SB39210AU	7541668	Text plate for control circuit devices	3SU19000AX100AA0	1932390	-	-	-	-	-	-	-	-
3SB39210AX	7450500	Accessories for control circuit devices	3SU19000DY300AA0	8742406	-	-	-	-	-	-	-	-
3SB39210BA	7450519	Accessories for control circuit devices	3SU19000DD700AA0	1933921	-	-	-	-	-	-	-	-
3SB39210BC	4533655	Accessories for control circuit devices	-	-	-	-	-	-	-	-	-	-
3SB39210BT	7541662	Accessories for control circuit devices	3SU19000EB100AA0	1932449	-	-	-	-	-	-	-	-
3SB39210BW	7541671	Text plate for control circuit devices	3SU19000BC310NB0	8742399	-	-	-	-	-	-	-	-
3SB39210CG	7541674	Accessories for control circuit devices	3SU19500DX300AA0	1736861	-	-	-	-	-	-	-	-
3SB39210CK	7541678	Text plate for control circuit devices	3SU19000BC310AS0	1932423	-	-	-	-	-	-	-	-
3SB39210DY	7541687	Text plate for control circuit devices	3SU19000BB310AA0	1038559	-	-	-	-	-	-	-	-
3SB39220AS	7541680	Text plate for control circuit devices	3SU19000AN100AA0	1934683	-	-	-	-	-	-	-	-
3SB39220AV	4112343	Text plate for control circuit devices	3SU19000AG100AA0	8742389	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39220AW	7541684	Text plate for control circuit devices	3SU19000AN100AA0	1934683	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39220AY	7541766	Text plate for control circuit devices	3SU19000AK100AA0	1934731	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39230AS	7541693	Text plate for control circuit devices	3SU19000AQ100AA0	1932451	-	-	-	-	-	-	-	-
3SB39230AV	7450512	Text plate for control circuit devices	3SU19000AT100AA0	8742367	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39230AX	7352780	Text plate for control circuit devices	3SU19000AQ100AA0	1932451	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39250AT	7541769	Text plate for control circuit devices	3SU19000AH100AA0	1932758	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39250AV	7541763	Text plate for control circuit devices	3SU19000AS100AA0	8742364	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39300CA2	7541772	Accessories for control circuit devices	3SU19010FT200AA0	1932520	-	-	-	-	-	-	-	-
3SB39300CA3	7541775	Accessories for control circuit devices	3SU19010FT300AA0	1932529	3SU18010AA000AB2	8742226	-	-	3SU18510AA000AB2	-	-	-
3SB39300CA4	7541779	Accessories for control circuit devices	3SU19010FT400AA0	1933680	-	-	-	-	-	-	-	-
3SB39300CA5	7541788	Accessories for control circuit devices	3SU19010FT500AA0	1932537	3SU18030AA000AB1	8742311	-	-	3SU18530AA000AB1	8742333	-	-
3SB39300CA6	7541781	Accessories for control circuit devices	3SU19010FT600AA0	1038576	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-
3SB39300CA7	7541785	Accessories for control circuit devices	3SU19010FT700AA0	1038577	3SU10022BP600AA0	-	3SU10322BP600AA0	-	3SU10522BP600AA0	-	3SU10322BP600AA0	-

# SIRIUS 3SB3 to SIRIUS ACT (3SU1) Cross Reference List

## by RS Components and Siemens

SIRIUS 3SB3 Range (Full Range Phase Out September 2019)			SIRIUS ACT (3SU1) Direct 3SB3 replacement recommendation		Alternative SIRIUS ACT variant in plastic black		Alternative SIRIUS ACT variant in plastic with metal front ring (matt finish)		Alternative SIRIUS ACT variant in metal (shiny finish)		Alternative SIRIUS ACT variant in metal (matt finish)	
Siemens Order Number	RS Order Number	Description	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number	Siemens Order Number	RS Order Number
3SB39300EA6	7541794	Accessories for control circuit devices	3SU19000FT600AA0	1933884	3SU10022BP600AA0		3SU10322BP600AA0		3SU10522BP600AA0		3SU10322BP600AA0	
3SB39300GA0	7450516	Accessories for control circuit devices	3SU19010FT000AA0	1932528	3SU10022BP600AA0		3SU10322BP600AA0		3SU10522BP600AA0		3SU10322BP600AA0	
3SB39300GA3	7541797	Accessories for control circuit devices	3SU19010FT300AA0	1932529	-		-		-		-	
3SB39300GA4	7541791	Accessories for control circuit devices	3SU19010FT400AA0	1933680	-		-		-		-	
3SB39300GA5	7450525	Accessories for control circuit devices	3SU19010FT500AA0	1932537	-		-		-		-	
3SB39300GA6	7541801	Accessories for control circuit devices	3SU19010FT600AA0	1038576	-		-		-		-	
3SB39300GA7	7541804	Accessories for control circuit devices	3SU19010FT700AA0	1038577	-		-		-		-	
3SB39300HA7	7541690	Accessories for control circuit devices	3SU19010FS700AA0	1934801	-		-		-		-	
3SB39306BA2	7541700	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306BA3	7541703	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306BA4	7541707	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306BA5	7541716	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306BA6	7541719	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306CA2	7450528	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306CA3	7541713	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306CA4	7450522	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306CA6	7541722	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39306CA7	7450531	Siemens Lens for use with 3SB3 Series	None	-	-		-		-		-	
3SB39310AA	7450534	Siemens Lens for use with 3SB3 Series	3SU15000AA100AA0	8742272	-		-		-		-	
3SB39310AC	7541729	Auxiliary contact block	3SU15500AA100AA0	8742288	3SU18010AA000AB1	8742308	-		3SU18510AA000AB1	8742134	-	
3SB39410AA	7541738	Accessories for control circuit devices	3SU19000FA100AA0	8742415	3SU18010NA002AC2	8742305	-		3SU18510NA002AC2	8742336	-	
3SB39410AB	7541731	Text plate for control circuit devices	3SU19000BC310AA0	8742361	3SU18010NA002AA2	8742301	-		3SU18510NA002AA2	8742327	-	
3SB39410AD	7541735	Text plate for control circuit devices	3SU19000BC310DA0	-	3SU18040AA000AB1	8742320	-		3SU18540AA000AB1	8742345	-	
3SB39410AF	7541744	Text plate for control circuit devices	None	-	-		-		-		-	