

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

# LTE Cat.1 8 Click





PID: MIKROE-6560

LTE Cat.1 8 Click is a compact add-on board designed to provide reliable cellular connectivity for embedded applications. This board features the SIM7500E, LTE Cat 1 module from SIMCom, supporting LTE-FDD mode with multi-band coverage for Europe. The module offers data rates of up to 10Mbps downlink and 5Mbps uplink, multi-constellation GNSS, and supports drivers for operating systems like Windows, Linux, and Android. Key features include a UART interface for communication, a USB interface, firmware upgrade functionality, and visual indicators for network and power status. This Click board<sup>™</sup> is ideal for IoT applications such as telematics, industrial routers, remote monitoring, and diagnostics.

For more information about LTE Cat.1 8 Click visit the official product page.

### How does it work?

LTE Cat.1 8 Click is based on the SIM7500E, LTE Cat 1 module from SIMCom. This module enables LTE Category 1 communication and is capable of operating across various wireless standards including LTE-TDD, LTE-FDD, HSPA+, GSM, GPRS, and EDGE. Its compatibility with LTE, UMTS, and GSM networks ensures broad global coverage, making it ideal for applications that require dependable mobile connectivity across different regions. Its frequency band compatibility includes LTE-FDD on bands B1, B3, B7, B8, and B20, as well as GSM on 900 and 1800 MHz, enabling the device to adapt to multiple carrier networks efficiently. Designed for IoT scenarios like telematics, remote monitoring, CPE systems, industrial routers, and remote diagnostics, the LTE Cat. 1 8 Click stands out as a reliable platform for developers seeking stable and versatile mobile communication in embedded systems.


Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com



With support for download speeds of up to 10Mbps and upload speeds of up to 5Mbps, the SIM7500E provides a balanced data throughput suitable for a wide range of IoT use cases. In addition to its robust cellular communication capabilities, the module also features advanced location services through integrated multi-constellation GNSS support, ensuring high-accuracy positioning using various satellite systems. The SIM7500E also comes equipped with an array of embedded network protocols, including TCP/IP, IPv4, IPv6, Multi-PDP, FTP, FTPS, HTTP, HTTPS, and DNS, providing a comprehensive solution for secure and flexible data transmission. Furthermore, it supports USB drivers across major operating systems such as Windows, Linux, and Android, allowing integration into diverse development environments.

Communication between the SIM7500E and the host MCU is made through a UART interface, using standard UART RX and TX pins and hardware flow control pins (CTS/RTS/RI - Clear to Send/Ready to Send/Ring Indicator) for data transfer. The module defaults to a communication speed of 115200bps, allowing for data exchange over AT commands. This Click board™ also includes a USB Type C connector for both power and data transfer, which is compliant with the USB 2.0 specification (peripheral only), I2C interface only for read/write register values of the I2C peripheral devices, a BOOT switch on the back of the board to manage firmware upgrades (0 for normal operation, 1 for USB download), and FLIGHT switch for switching the board between Normal (1) and Flight (0) operation mode.

The LTE Cat.1 8 Click includes several additional functionalities that enhance its usability and control. The PWR button allows users to easily power the module ON or OFF, while the RESET button provides a quick way to reset the module. These functions can also be controlled digitally via the mikroBUS $^{\text{TM}}$  pins PWR and RST, offering greater flexibility. Moreover, these controls have dedicated test points for easier debugging and testing. The board also features some visual indicators to provide real-time status updates.

The first red NET LED indicates the module's current network status. When the LED is always on, the device searches for a network. A faster blinking pattern (200ms ON/OFF) indicates data transmission or 4G network registration. If the LED blinks slowly with an 800ms ON/OFF pattern, the module is registered on a 2G or 3G network. When the LED is OFF, the device is powered OFF or sleep mode. The second yellow STAT LED indicates the module's power status, which stays off when the module is OFF and turns ON when the module is powered on.

The board features three u.Fl connectors for LTE, Auxiliary-diversity, and optional GNSS antennas that MIKROE offers, like the <u>GSM/GPRS antenna</u> combined with an <u>IPEX-SMA cable</u> for flexible and efficient connectivity options. In addition, the user can easily choose the power

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918
Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

supply of the optional GNSS antenna by choosing between 3.3V and 5V on the GNSS ANT jumper. However, please note that GNSS functionality is not currently supported on this Click board  $^{\text{\tiny M}}$ , and as a result, GNSS-related components are not soldered. The board is equipped with a micro SIM card holder that supports both 1.8V and 3.0V uSIM cards, ensuring compatibility with a wide range of cellular networks and allowing users to select the most appropriate service provider for their particular use case.

This Click board™ can operate with both 3.3V and 5V logic voltage levels selected via the VCC SEL jumper. Since the SIM7500E module operates at 3.8V, logic-level translators, the TXB0106 and PCA9306, are also used for proper operation and an accurate signal-level translation. This way, both 3.3V and 5V capable MCUs can use the communication lines properly. Also, this Click board™ comes equipped with a library containing easy-to-use functions and an example code that can be used as a reference for further development.

# **Specifications**

Туре	4G LTE,GSM/LTE		
Applications	Ideal for IoT applications such as telematics, industrial routers, remote monitoring, and diagnostics		
On-board modules	SIM7500E - LTE Cat 1 module from SIMCom		
Key Features	LTE Cat.1 connectivity, support for LTE-FDD/HSPA+/GSM networks, multi-constellation GNSS support, UART and USB interfaces, I2C interface for peripheral access, firmware upgrade, network and power status LEDs, three u.Fl antenna connectors for LTE, diversity, and GNSS, micro SIM card holder supporting 1.8V and 3.0V uSIMs, mikroSDK-compatible software library with example code, and more		
Interface	I2C,UART,USB		
Feature	ClickID		
Compatibility	mikroBUS™		
Click board size	L (57.15 x 25.4 mm)		
Input Voltage	3.3V or 5V		

## **Pinout diagram**

This table shows how the pinout on LTE Cat.1 8 Click corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin	, mikro~ , b BUS				Pin	Notes	
Module Power-ON	PWR	1	AN	PWM	16	RI	Ring Indicator	
Reset / ID SEL	RST	2	RST	INT	15	RTS	UART RTS	
UART CTS / ID COMM	CS	3	CS	RX	14	TX	UART TX	
	NC	4	SCK	TX	13	RX	UART RX	
	NC	5	MISO	SCL	12	SCL	I2C Clock	

MIKTOE produces entire development rooicnains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 1178 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

	NC	6	MOSI	SDA	11	SDA	I2C Data
Power Supply	3.3V	7	3.3V	5V	10	5V	Power Supply
Ground	GND	8	GND	GND	9	GND	Ground

# **Onboard settings and indicators**

Label	Name	Default	Description
LD1	PWR	-	Power LED Indicator
LD2	NET	-	Network Activity
			Status LED Indicator
LD3	STAT	-	Module Operational
			Status LED Indicator
JP1	VCC SEL	Left	Power Voltage Level
			Selection 3V3/5V: Left
			position 3V3, Right
			position 5V
JP2	GNSS ANT	Unsoldered	GNSS Antenna Supply
			Selection 3V3/5V: Left
			position 3V3, Right
			position 5V
T1	RESET	-	Module Reset Button
T2	PWR	<b> </b> -	Module Power-ON
			Button
SW1	FLIGHT	Left	USB FW Upgrade
			Switch 0/1: Position 0
			for Flight mode,
			Position 1 for Normal
			mode
SW2	BOOT	Left	USB FW Upgrade
			Switch 1/0: Position 1
			for USB
			download, Position 0
			for Normal operation

# LTE Cat.1 8 Click electrical specifications


Description	Min	Тур	Max	Unit
Supply Voltage	3.3	-	5	V
LTE Frequency Range	758	-	2570	MHz
LTE Output Power	-	+23	-	dBm


# **Software Support**

<u>LTE Cat.1 8 Click</u> demo application is developed using the <u>NECTO Studio</u>, ensuring compatibility with <u>mikroSDK</u>'s open-source libraries and tools. Designed for plug-and-play implementation and testing, the demo is fully compatible with all development, starter, and mikromedia boards featuring a  $\underline{\text{mikroBUS}}^{\text{m}}$  socket.

## **Example Description**

Application example shows device capability of connecting to the network and sending SMS or TCP/UDP messages using standard "AT" commands.









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

### **Key Functions**

- Itecat18 cfg setup This function initializes Click configuration structure to initial values.
- Itecat18\_init This function initializes all necessary pins and peripherals used for this Click board.
- Itecat18 set sim apn This function sets APN for sim card.
- ltecat18\_send\_sms\_text This function sends text message to a phone number.
- Itecat18\_cmd\_set This function sets a value to a specified command of the Click module.

Application Init

Initializes the driver and logger.

**Application Task** 

Application task is split in few stages:

• LTECAT18 POWER UP:

Powers up the device, performs a device factory reset and reads system information.

• LTECAT18\_CONFIG\_CONNECTION:

Sets configuration to device to be able to connect to the network.

• LTECAT18 CHECK CONNECTION:

Waits for the network registration indicated via CREG command and then checks the signal quality report.

• LTECAT18 CONFIG EXAMPLE:

Configures device for the selected example.

• LTECAT18 EXAMPLE:

Depending on the selected demo example, it sends an SMS message (in PDU or TXT mode) or TCP/UDP message. By default, the TCP/UDP example is selected.

## **Application Output**

This Click board can be interfaced and monitored in two ways:

 Application Output - Use the "Application Output" window in Debug mode for real-time data monitoring. Set it up properly by following <u>this tutorial</u>. Mikroe produces entire development roolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

• UART Terminal - Monitor data via the UART Terminal using a <u>USB to UART converter</u>. For detailed instructions, check out this tutorial.

#### **Additional Notes and Information**

The complete application code and a ready-to-use project are available through the NECTO Studio Package Manager for direct installation in the <u>NECTO Studio</u>. The application code can also be found on the MIKROE GitHub account.

#### Resources

mikroBUS™

**mikroSDK** 

Click board™ Catalog

Click boards™

**ClickID** 


#### **Downloads**

LTE Cat.1 8 click example package

LTE Cat.1 8 click 2D and 3D files v100

LTE Cat.1 8 click schematic v100

SIM7500 datasheet







health and safety management system.