



## Recycle bin

Product code: Bin01

### Overview

The Skipper sack holder bin is designed for multi-purpose waste and recycling use. With a wealth of versatile attachments it can be used indoors and outdoors with the Skipper Post & Base system via a collar, the cord strap clip, the Skipper suction pad bracket and, for permanent fixing, the Skipper wall clip.

### Product Specifications

<b>Width:</b> 338mm	<b>Height:</b> 194mm
<b>Depth:</b> 376mm	<b>Weight:</b> 1.1kg

### Key selling points

- Versatile design allows the recycle bin to attach to almost any surface
- Available in a range of lid colours (orange, green, red, blue, silver)

### Key features

- Connects to the post & base collar, cord strap clip, wall clip and suction pad bracket
- Holds up to 15KG
- Supplied with stickers to designate general waste or recycling use

2 recycle bins can be attached to the Skipper post and base system via the post & base collar



### Product FAQs

- Q. What types of bag should be used with the recycle bin?**
- A.** You can use any standard sized bag (simply lift the outer and inner lid and tuck the bag into the groove).
- Q. What should I use the bin for?**
- A.** The bin is designed to be used in a range of sectors including cleaning & hygiene, utilities, facilities management and construction (up to 15KG weight)