


AFR - AFP - Screw holder screwdrivers



Description:

- For slotted and Phillips® head.Screw holder and screwing with the same tool.
- The guide is moved with the thumb, the spring holds the screw on the blade.





30	A [mm]	A [in]	Length L [mm]	F [mm]	Length L1 [mm]	Weight [g]	Phillips Tip Number ["]
AFP.1			260.0		150.0	100.0	PH1
AFP.2			285.0		175.0	120.0	
AFR.3X100	3.0		190.0	0.5	100.0	37.0	
AFR.4X125	4.0		225.0	0.6	125.0	65.0	
AFR.5X150	5.0		260.0	0.7	150.0	95.0	