

Fume Extraction

Tip Extraction Units + FE Irons

Safety Rests with Stop+Go function for FE Irons with WFE or WFE P

The Weller safety rests with Stop + Go function are recommended accessories for FE irons using the WFE or WFE P extraction units. A fibre optic sensor switches the extraction unit on when the FE iron is removed from the safety rest and when the FE iron is replaced in the safety rest, after a short delay to gather the fumes from any solder on the tip it switches the unit off. This reduces running costs.



Order No.	Model	Description
005 15 086 99	KHP	Basic unit pneumatic (for WFE) safety rest with Stop+Go function with fibre optic sensor for FE 25, FE 50, FE 50M, FE 75 and FE 80



005 15 076 99	KHE	Basic unit electric (for WFE P) safety rest with Stop+Go function with fibre optic sensor for FE 25, FE 50, FE 50M, FE 75 and FE 80
---------------	-----	---



005 15 080 99	KHE/P	Second safety rest with fibre optic sensor for extending to 2 workplaces for FE 25, FE 50, FE 50M, FE 75 and FE 80
---------------	-------	--



005 15 084 99	KHP 80	Basic unit pneumatic (for WFE) safety rest with Stop+Go function with fibre optic sensor for WSP 80FE
---------------	--------	---



005 15 083 99	KHE 80	Basic unit electric (for WFE P) safety rest with Stop+Go function with fibre optic sensor for WSP 80FE
---------------	--------	--



005 15 141 99	KHE 80/P 80	Second safety rest with fibre optic sensor for extending to 2 workplaces for WSP 80 FE
---------------	-------------	--



005 15 156 70	WDH 50E/P	Safety rest with Stop+Go function with fibre optic for Micro soldering iron WMRP
---------------	-----------	--