

Checking your crimping dies

Go-no-go gauge

Gauges for diagnosing the wear of your crimping dies.

Gauge for tools

	Ref. of the gauge
TH1 - TH1S - TH1-90 - ET331	PG1
TH2 - TH2S - ET332	PG2
TH3 - TH3-2 - ET333 - ET333-2	PGH3
PMM1CF	PGM1

Gauge for hexagonal dies

	Ref. of the gauge
ELP	PGP10
FLP	PGP16
NP	PGP25
ELS	PGN10
FLS	PGN16
TN25	PGTN25
TN35	PGTN35
TN50	PGTN50
TN60	PGTN60
TN70	PGTN70
TN95	PGTN95
TN120	PGTN125
TN150	PGTN150
TN185	PGTN185
TN240	PGTN240
TN300	PGTN300



NEW