



Drafting Pens and Cartridges

Product Stock No.


Pens 159-2926, 159-2932, 159-2948, 159-2954 and 159-2960 Cartridges 159-2982, 159-2998, 159-3008, 159-3014 and 159-3020




Activation



Pull off white plastic ring with snap-on cap. Remove plastic ring.




Press barrel and snap-on cap together.




Shake to start ink flow.

Replacing the functional cartridge



Press empty cartridge out of barrel.



Insert new functional cartridge into barrel. Remove protective sleeve. Press barrel and snap-on cap together as in figure 3. Shake to start ink flow as in figure 4.