Schematic diagrams

STEVAL-ISB038V1T transmitter control stage

GSPG200716 1110SG

STEVAL-ISB038V1T transmitter power stage

Layout note : GND plan dedicated to the bridge and the power supply connector

Layout note : GND plan dedicated to the bridge and the power supply connector

GSPG20071611130SG

STEVAL-ISB038V1T USB to UART dongle

GSPG200716150SG

STEVAL-ISB038V1R receiver board

GSPG2007161035SG

STEVAL-ISB038V1R USB-I²C dongle

GSPG2007161000SG