GUYARD SAS 22-24 rue Lucien Rouzet ZA Villedieu s/Indre 36250 NIHERNE Tél: 02.54.35.63.70

# USER INSTRUCTIONS compliance with European Standards Européennes

Nov 2022

Index 2

## EN 175 EN 166 EN 169 CATEGORY II

MODEL BEFERRINGE MAGONE (ACAA

## **MODEL REFERENCE: MASQUE 63612**

### **Instructions for use of the MASQUE 63612**

#### Description:

Mask in pigmented split cowhide leather, chrome-tanned, can be folded into a wallet, closure with self-gripping strips, equipped with a zipper box to adapt ECHELON 11 protection filters according to EN 169.

A sewn elastic band holds the mask on the head.

Sewn with 100% aromatic polyamide thread tex-theoretical 88.

Length flat: 270 mm Width flat: 287 mm

#### Recommendations:

Mask designed to adapt protective filters with or without guard glasses or reinforcement lenses, 105 x 50 mm, in compliance with standards EN 166, EN 169, EN 175 and following the recommendations of the protection manufacturer.

To protect the eyes and face part of the operator's head against harmful optical radiation and against other specific risks due to the usual welding, cutting or other related techniques, except laser welding.

#### Warnings:

Filter eyepieces made of reinforced mineral glass should only be used in conjunction with a suitable reinforcement eyepiece.

Scratched or damaged eyepieces should be replaced.

MASQUE 63612



<u>CE marking</u>: This mask has undergone a CE type examination by an authorized body on the basis of European standards 89/686/EC 21/12/1989. The CE marking affixed to this mask signifies compliance with the essential requirements of European regulation EU 2016/425 relating to personal protective equipment (PPE).



#### Marking of the protective filters: Welding filter compliant with EN166/EN 169 standard

Grade: 11 Optical class: 1 Reinforced solidity: S Notified Organization 0196

Certification mark: DIN - Manufacturer identification: SO - CE marking

Protection limits: Do not use for handling chemicals or liquids.

Before use, make sure that the different parts of the equipment are not damaged, otherwise, replace the damaged parts.

#### Safety:

The materials and components constituting the mask do not contain substances at levels such that they are known or suspected to have adverse effects on the hygiene or health of the user under foreseeable conditions of use. Its design does not cause any irritation or discomfort to the wearer.

A risk of allergy is possible in sensitive individuals whose skin comes into contact with the elements constituting this mask.

# Cleaning, disinfection and storage:

Clean the leather part using a cloth dampened with neutral soap and a lint-free cloth for the filters. It is advisable to store the products in a cool, dry and ventilated place away from light.

The masks, once folded, are packaged in packs of 5.

A USER MANUAL will be included with the smallest packaging of masks.

<u>Usage time:</u> As soon as you notice the slightest wear of one of the materials, replace the worn part. Expiry date: 5 years from the date of manufacture indicated on the mask.

Assembly:

Unfold the mask, insert the filter suitable for the desired operation into the housing, put it on and make sure that your eyes are well protected.

Do not start welding until this operation is completed.

Certificate of conformity issued by : AC n ° 2754 ZAdu sanital -21 Rue Albert EINSTEIN-86100 CHATELLERAULT