


STEMlab

Logic Analyzer

The graphical user interface of the Logic Analyzer fits well into the overall design of the Red Pitaya applications providing the same operating concept. The Logic Analyzer user interface is shown below.




Apart from the actual graph, there are again 5 key areas/elements, in which the surface is divided:

1. **Auto:** Resets the zoom and brings the trigger event in the middle of the graph.
2. **Run / Stop:** Starts recording the input signals, and interrupts it when the recording is active.
3. **Channels / trigger / Measuring Tools:** This menu provides controls for inputs, triggers, and guides.
4. **Axis control panel:** The horizontal +/- buttons enable you to select the scaling of the X axis and to change it, and to select the time range displayed in the graph. The vertical +/- buttons change the Y axis, and thus the height of the graph display. In addition, the setting for the time frame, trigger and sampling rate are displayed.
5. **Status Display:** Displays information about the current state of the recording (stop, wait, ready).

FEATURES

ANALYZING BINARY SIGNALS



By selecting the gear button behind the DIGITAL selection field you enter the menu for the channel configuration. In the LINES register, the channels can be activated or deactivated by simply clicking the check mark. As long as no bus systems have been configured, the channels operate as purely digital inputs and correspondingly show the progress. The tab ACQ opens the selection field for the Sample rate settings. When selecting the values there is one thing to note: the sample rate has a significant influence on the time section, which can be represented. The memory depth of the Logic Analyzer applications is 1 MS, so it can store and display 1,000,000 binary values. From this it is clear that the sampling rate determines how many values are recorded per second. If we choose the highest sampling rate (125MS/s), 125,000,000 values would be recorded per second. Since 1,000,000 values can be stored in the time memory, we get a 0.008 second time window. With a sampling rate of 1MS/s, the time window of the recorded signal will be one full second.


When the Pre-sample data buffer value is set, at which point of the recording the trigger event is located. This makes particular sense if you want to find out what happened before the defined trigger event. To illustrate with an example: the sample rate is set to 4MS / s, the stored time segment thus amounts to approximately 0.25s = 250ms. If the Pre-sample data buffer is set to 10ms, then the recorded signal shows what has happened 10ms before the event, and 240ms after the event.



TRIGGER:

By clicking the gear behind TRIG settings, the trigger menu is opened. Each channel can be set as a trigger source with the desired condition. For acquisition to start, the Trigger source and Rising Edge needs to be defined.


The possible criteria for Trigger event are next:




By clicking the RUN button the recording is started. The status display informs you whether the process is still running (WAITING) or has already been completed (DONE). After finishing the acquisition, the results are displayed in a graph. Additional trigger options LOW and HIGH are used for the so called Patterned triggering. For example: If you set the trigger source to be DIN0 – Rising edge (to have one channel defined as a trigger source with a rising or falling edge is a mandatory condition for the acquisition to start), DIN1 to HIGH and DIN2 to LOW this will cause such a behavior that the application logic will wait for the state where DIN0 goes from 0 to 1, DIN1 is 1 and DIN2 is 0 to start the acquisition.

DECODE BUS DATA:

In the DIGITAL → BUS menu the decoding of the desired lines can be selected. Up to 4 buses can be defined. The available decoding protocols are I2C, UART, and SPI. By selecting the desired protocol, the setting menu for the selected protocol is opened.



Two options are possible for the display of the decoded data: firstly, the data is placed as a separate layer in the graph directly on the signal. Secondly, using the DIGITAL → DATA menu where the decoded data are represented in a table format. You can select ASCII, DEC, BIN and HEX data formatting. With the EXPORT button the decoded data can be packed into a CSV file. This then ends up directly in the download folder and can be used for further analysis.



CURSORS:

As with the Oscilloscope the Logic Analyze rApp also provides CURSORS for quick measurements. Because there are no variable amplitude readings but only discrete signal levels, the cursors are available exclusively for the X axis. When enabled, the

cursors will show the relative time respectively to zero point (trigger event) and the difference between the two.

What is needed to use STEMlab board as Logic Analyzer?

For using Red Pitaya STEMlab boards as Logic Analyzer it is required to have additional SW and HW. There are two options:

- **Logic Analyzer Basic** - Using directly the GPIO expansion connector of the STEMLab board. **Works only with STEMlab 125-10!**
- **Logic Analyzer Pro** - Enabling different logic levels, board protection and higher performances. **Works with STEMlab 125-14 & STEMlab 125-10**

SPECIFICATIONS

The Logic analyzer specifications are given in table below.

	Basic Logic Analyzer	Logic Analyzer PRO
Channels	8th	8th
Sampling rate (max.)	12MS/s	125ms/s
Maximum Input Frequency	3MHz	50MHz
Supported bus protocols	I2C, SPI, UART	I2C, SPI, UART
Input voltage	3.3V	2.5 ... 5.5V
Overload protection	-	integrated
Level thresholds	-	0.8V (low) 2.0V (high)
Input impedance	-	100k, 3 pF
Trigger types	Level, edge, pattern	Level, edge, pattern
Memory depth	1 MS (typical)	1 MS (typical)
Sampling interval	84ns	8ns
Minimum pulse duration	100ns	10ns

Hardware/Connections

Alongside the Logic analyzer application for maximal performance and protection of your STEMLab board the Logic analyzer extension module (Logic Analyzer PRO) is

recommended. Using the LA extension module is straightforward, just plug it on your



STEMLab and connect the leads to the desired measurement points.

- To use the Logic analyzer without the extension module (Basic Logic Analyzer) you need to be more careful in connecting the Logic analyzer probes to the extension connector E1 on the STEM Lab board. The pins used for Logic analyzer board are shown in picture below.

