


ISO-TECH Sound Level Meter

SLM-52N

INSTRUCTION MANUAL



CONTENTS

Title	Page
1. INSTRUMENT CARE	1
2. FEATURES.....	2
3. MEASUREMENT PARAMETERS.....	2
4. SPECIFICATIONS	2
5. CONTROLS AND FUNCTIONS	9
6. DISPLAY DESCRIPTION	11
7. PREPARATION FOR USE	12
8. CALIBRATION PROCEDURE	14
9. MEASUREMENT PROCEDURE.....	14
10. STORE OPERATIONS	15
11. OUTPUT CONNECTORS.....	16
12. ADJUSTMENT DATA FOR CALIBRATOR (B&K TYPE 4226 PRESSURE MODE).....	16
13. TYPICAL INSTRUMENT FREQUENCY RESPONSE AT 0° INCIDENCE.	16
14. TYPICAL FREQUENCY RESPONSE DUE TO CASE REFLECTIONS AT 0° INCIDENCE	17
15. TYPICAL FREQUENCY RESPONSE OF 65mm WINDSCREEN AT 0° INCIDENCE	17
16. DIRECTIONAL CHARACTERISTICS OF THE COMPLETE INSTRUMENT	18
17. APPENDIX A FREQUENCY WEIGHTING NETWORK.....	20
18. APPENDIX B RMS DETECTION CIRCUIT AND TIME WEIGHTING	21
19. APPENDIX C INFLUENCE OF BACKGROUND NOISE	23

1. INSTRUMENT CARE

- Do not attempt to remove the mesh cover from the microphone as this will cause damage and affect the accuracy of the instrument.
- Protect the instrument from impact. Do not drop it or subject it to rough handling. Transport it in the supplied carrying case.
- Protect the instrument from water, dust, extreme temperatures, high humidity and direct sunlight during storage and use.
- Protect the instrument from air with high salt or sulphur content, gases and stored chemicals, as this may damage the delicate microphone and sensitive electronics.
- Always turn the instrument off after use. Remove the batteries from the instrument if it is not to be used for a long time. Do not leave exhausted batteries in the instrument, as they may leak and cause damage.
- Clean the instrument only by wiping it with a soft, dry cloth or, when necessary, with a cloth lightly moistened with water. Do not use any solvents, alcohol or cleaning agents.

2. FEATURES

The ISO-TECH SLM-52N Sound Level Meter complies with the requirements of IEC 61672-1: 2002 standard for a Class 2 instrument.

The instrument contains several features which permit sound level measurements under a variety of conditions.

Features include:

- Ease of use.
- Easy to read large display.
- Five measurement ranges.
- Fast and Slow time weightings.
- A and C frequency weightings.
- Both AC and DC signal outputs are available from a single standard 3.5mm coaxial socket suitable for use with a frequency analyzer, level recorder, FFT analyzer, graphic recorder, etc.

3. MEASUREMENT PARAMETERS

The following parameters are used on the instrument.

- LA → “A” frequency weighting sound pressure level
- LC → “C” frequency weighting sound pressure level
- FAST → Fast time weighting
- SLOW → Slow time weighting
- max → Maximum time-weighted sound pressure level

The various settings depend on the condition the instrument was in before it was last turned off.

4. SPECIFICATIONS

- Specifications apply to Model SLM-52N fitted with Microphone model MC-21 and Microphone Preamplifier model AP-21
- Applicable standards:** IEC61672-1: 2002 Class 2
IEC60651: 1979 Type 2
ANSI S1.4: 1983 Type 2

□ **Measurement functions:**

- **Main processing functions**

Sound level: Current time-weighted sound pressure level A or current time-weighted sound pressure level C

Maximum time-weighted sound pressure level A or Maximum time-weighted sound pressure level C

- **Total range:** 30 to 130dB A & C weighted

- **Max. measurement level:** 130dB

- **Self-generated noise level:**

Typical values at 23 using the nominal microphone equivalent capacitance of 27pF (30-90dB range)

Weighting	Electrical	Total
"A"	22.7dB	26.1dB
"C"	21.8dB	29.5dB

Linearity operating range: A-weighted, 1000Hz, 60dB dynamic range.

Total linear operating range:

In accordance with IEC 61672-1, A-weighted, 1000Hz: 30dB to 130dB.

Level range selection:

5 ranges in 10dB steps 30 to 90dB , 40 to 100dB
50 to 110dB , 60 to 120dB
70 to 130dB

LINEAR OPERATING RANGES (L.O.R.)

RANGE: 30 – 90 dB. Test starting point 64 dB for all weightings and frequencies except 31.5Hz A-weighted, for which the starting point is 44 dB.

FREQUENCY Hz	WEIGHTING	L.O.R. dB	WEIGHTING	L.O.R. dB
31.5	A	36.1 – 50.6	C	39.5 – 87.0
1000	A	36.1 – 90.0	C	39.5 – 90.0
4000	A	36.1 – 90.0	C	39.5 – 89.2
8000	A	36.1 – 88.9	C	39.5 – 87.0

RANGE: 40 – 100 dB. Test starting point 74 dB for all weightings and frequencies except 31.5Hz A-weighted, for which the starting point is 54 dB.

FREQUENCY Hz	WEIGHTING	L.O.R., dB	WEIGHTING	L.O.R dB
31.5	A	40.0 – 60.6	C	40.0 – 97.0
1000	A	40.0 – 100.0	C	40.0 – 100.0
4000	A	40.0 – 100.0	C	40.0 – 99.2
8000	A	40.0 – 98.9	C	40.0 – 97.0

RANGE: 50 – 110 dB. Test starting point 84 dB for all weightings and frequencies except 31.5Hz A-weighted, for which the starting point is 64 dB.

FREQUENCY Hz	WEIGHTING	L.O.R dB	WEIGHTING	L.O.R dB
31.5	A	50.0 – 70.6	C	50.0 – 107.0
1000	A	50.0 – 110.0	C	50.0 – 110.0
4000	A	50.0 – 110.0	C	50.0 – 109.2
8000	A	50.0 – 108.9	C	50.0 – 107.0

RANGE: 60 – 120 dB. Test starting point 94 dB for all weightings and frequencies except 31.5Hz A-weighted, for which the starting point is 74 dB.

FREQUENCY Hz	WEIGHTING	L.O.R. dB	WEIGHTING	L.O.R. dB
31.5	A	60.0 – 80.6	C	60.0 – 117.0
1000	A	60.0 – 120.0	C	60.0 – 120.0
4000	A	60.0 – 120.0	C	60.0 – 119.2
8000	A	60.0 – 118.9	C	60.0 – 117.0

RANGE: 70 – 130 dB. Test starting point 104 dB for all weightings and frequencies except 31.5Hz A-weighted, for which the starting point is 84 dB.

FREQUENCY Hz	WEIGHTING	L.O.R. dB	WEIGHTING	L.O.R. dB
31.5	A	70.0 – 90.6	C	70.0 – 127.0
1000	A	70.0 – 130.0	C	70.0 – 130.0
4000	A	70.0 – 130.0	C	70.0 – 129.2
8000	A	70.0 – 128.9	C	70.0 – 127.0

Frequency range:

Overall characteristics including microphone: 20 to 8000Hz

Frequency weighting: A, meets the requirement of IEC 61672-1 for class 2 “A” weighting.

C, meets the requirement of IEC 61672-1 for class 2 “C” weighting.

Time weighting (RMS detection): Fast, according to IEC 61672-1 class 2.
Slow, according to IEC 61672-1 class 2.

- **Reference conditions:**

- Type of the acoustic field:** Free

- Reference sound pressure level:** 94.0dB (related to 20 μ Pa)

- Reference level range:** 60 to 120dB

- Reference frequency:** 1000Hz

- Reference temperature:** +23

- Reference relative humidity:** 50%RH

- Reference static pressure:** 101.325 kPa

- Reference incidence direction:** Perpendicular to the front of the microphone diaphragm.

- **Calibration:** Acoustic using calibrator ISO-TECH SLC -1356, B&K 4231 or equivalent.
Calibration check frequency is 1000Hz.

- Nominal calibration level for the free field:** 94.1dB


- Nominal calibration level for the diffuse field:** 94.0dB

- **Frequency for acoustic testing:** 8000Hz.
- **Warm-up time:** 2min
- **Sampling interval:** Bar graph indication \rightarrow 125 ms approx.
Numeric indication \rightarrow 1 sec approx.
- **Microphone equivalent electrical impedance (electrical input device) :** Replace the microphone capsule with a series capacitance of 27pF +/- 3pF

- **Microphone:**


- **Model:** MC-21
- **Nominal diameter:** 1/2 inch electret condenser type
- **Sensitivity:** -37dB (0dB = 1V/Pa)
- **Frequency response:** 20Hz to 8000Hz
- **Capacitance:** 27pF
- **Reference direction and position:** Perpendicular to the front of the microphone diaphragm at its geometric centre.
- **Maximum input sound level:** 131dB at microphone for no damage.
- **Operating temperature:** -10 to +50
- **Temperature coefficient:** Approx. 0.008dB/ at 1000Hz
- **Dimensions:** 13.2dia x 14mm

Frequency Response



Freq units	31.5 Hz	63 Hz	125 Hz	250 Hz	500 Hz	1000 Hz	2000 Hz	4000 Hz	8000 Hz
dB	+0.6	+0.8	+0.2	+0.0	0.0	0.0	+0.8	+1.3	+3.0

Typical free-field response 0° incidence




Freq units	31.5 Hz	63 Hz	125 Hz	250 Hz	500 Hz	1000 Hz	2000 Hz	4000 Hz	8000 Hz
dB	+0.1	+0.4	0.0	+0.5	-0.2	0.0	+0.2	0.0	-0.5

Typical diffuse-field response for random incidence

□ Preamplifier:

- **Model:** AP-21
- **Input impedance:** 470MΩ
- **Output impedance:** 550Ω at 1000Hz
- **Maximum input voltage:** 2.828V peak-to-peak at electrical input for no damage.
- **Measuring input (viewed from top of instrument):**



- A: ground
- B: ground
- C: +10V
- D: signal input
- E: N.C.

□ Display LCD

- **Display screens:**

- 4 digit numerical indication of sound level, from 30.0 to 130.0dB with 0.1dB resolution.

- Bar-graph indication of current sound level with 1dB resolution.

- Sound level range indicator: 30–90dB, 40–100dB, 50–110dB, 60–120dB or 70–130dB in five ranges.

- Elapsed time display : hour : minute : second.

- Memory and Read indicator : 99 sets

- **Display update rate:** 1 second

- **Display first indication:** Depends on the condition the instrument when it was last turned off.

- **Warning indications:**

- Out-of-range indications:

- Ov** displayed at upper limit of the range

- Un** displayed at lower limit of the range

□ Outputs

- **AC output** (using selected frequency weighting)

- Output voltage:** 1Vrms (at full-scale of the range)

- Output impedance:** 5k

- Load impedance:** 1M

- **DC output**

- Output voltage:** 10mV/dB

- Output impedance:** 5k

- Load impedance:** 1M

□ Clock: Elapsed time

□ Power requirements

- **One 9V battery (006P or IEC6F22) manganese super heavy duty batteries or equivalent.**

- **Battery life:** Approx. 25 hours

- **External power source:** DC voltage from 6V to 12V

- Current rating:** Approx. 10mA @ 6V

□ Ambient conditions:

- **Environmental conditions:** 23 °C, 50%RH and 101.325 kPa

- **Operating conditions:** -10 °C to +50 °C, 30% to 90%RH non-condensing

- **Storage conditions:** -10 °C to +60 °C, <70%RH non-condensing

- **Effect of temperature:** < 0.5dB (-10 °C to +50 °C)

- **Effect of humidity:** < 0.5dB (for 30%RH to 90%RH at 40 °C, 1000Hz)

- **Effect of vibration:** A 40 Hz 1m/s vibration produces no noticeable effect.
- **Effect of magnetic field:** No noticeable effect.

□ **Compliance with standards:**

- **CE** : indicates compliance with applicable European Union Directives.
- **EMC Emission:** IEC 61000-6-3, Generic emission standard for residential, commercial and light industrial environments.
No significant emissions from the instrument.
IEC 61672-1, Instrumentation standard classification group X and performance class 2 sound level meter.
- **EMC Immunity:** IEC 61000-6-2, Generic standard-Immunity for industrial environments.
No degradation in performance when subjected to 10V/m for 80% modulation at 1KHz.
IEC 61672-1, Instrumentation standard classification group X and performance class 2 sound level meter.
No permanent degradation of performance, loss of function, change of operating state or configuration, or loss or corruption of stored data due to ESD discharges as specified in the above standard.
- No degradation in performance when the instrument was subjected to ESD at 8kV per IEC 801-2.


□ **Dimensions:** Approx. 264(L)×68(W)×27(H) mm

□ **Weight (including battery):** Approx. 260g

□ **Supplied accessories:** Battery 9V, Wind shield, Screwdriver (adjustment), 3.5φ plug (3pin AC/DC output), Carrying case, Instruction manual

□ **Optional equipment (Not supplied):** AC adaptor, Sound calibrator SLC-1356.


5. CONTROLS AND FUNCTIONS



1. **Microphone and preamplifier:** The MC-21 microphone capsule is connected to the AP-21 preamplifier for normal operation. The microphone capsule may be carefully removed from the preamplifier and substituted with the appropriate electrical impedance (See sect. 4. "Specifications") for electrical verification of the instrument.
2. **Display:** The LCD shows the sound level as a numeric value and a bar graph. The display also shows the operation mode of the instrument, the selected measurement parameters, warning indications and elapsed time.
3. **Ⓞ Button :** Turns the meter on and off.
4. **A, C buttons :** Sets the frequency weighting to A or C mode.
5. **FAST, SLOW buttons :** Sets the time weighting to FAST or SLOW mode.
6. **MAX button :** Used for reading the maximum time-weighted sound level encountered during a measurement.
Press this button to enter maximum recording mode. The "max" indicator will appear on the display. Press again to exit maximum recording mode.

- 7. MEM button** : Press to store measurement data sets in memory.
- 8. READ button** : Press to read the stored data sets in memory, press again to exit read mode.
- 9. buttons** :
- ① Level range buttons : select the level range for the measurement. The following five settings are available : 30 to 90dB, 40 to 100dB, 50 to 110dB, 60 to 120dB, 70 to 130dB.
 - ② When in read mode, the buttons select the memory address to be displayed.
- 10. DC/AC output** : AC output signal with frequency weighting.
DC output signal corresponding to sound level.
- 11. External DC 9V power supply jack** : Type 1.3 coaxial power connector ; center negative, nominal 9V DC.
- 12. CAL potentiometer** : Calibration potentiometer for level adjustment.
- 13. Battery Cover.**
- 14. Tripod mounting thread** : ¼" - 20 UNC Female thread.
- 15. Windscreen** : When making outdoor measurement in windy weather or when measuring air conditioning equipment or similar, wind noise at the microphone can cause measurement errors.

6. DISPLAY DESCRIPTION



1. Sound level range indicator (5 ranges): 30–90dB, 40–100dB, 50–110dB, 60–120dB and 70–130dB
2. Bar graph shows the current sound level (1dB resolution).
3. **Un** : Under-range indicator.
4. **Un** : Under-range indicator for processed value.
5. **A, C** : “A” Frequency weighting or “C” Frequency weighting indicator.
6. **Ov** : Over-range indicator for processed value.
7. **Ov** : Over-range indicator.
8. **|||||** : Battery capacity indicator.
9. **FAST** : Fast time weighting indicator.
10. **SLOW** : Slow time weighting indicator.
11. **88:88:88** Elapsed time indicator (max. 100hours).
12. **FULL** : Manual data memory full indicator.
13. **M** : Data memory indicator.
14. **R** : Data read indicator.
15. **88** : Memory address display (max. 99 sets).
16. **dB** : Sound level unit.
17. **max** : Maximum time-weighted sound level reading.
18. **1888** : Sound level reading (0.1dB resolution): 30.0 – 130.0dB


7. PREPARATION FOR USE



Power Supply

The instrument can be powered by internal batteries, or for extended operation by an optional external 9V DC supply such as a suitable AC mains adapter or battery pack. Rechargeable batteries may be used in the instrument, but cannot be recharged when fitted as the instrument is not designed to recharge batteries.

Before inserting or replacing the batteries and before connecting the AC adaptor, be sure to turn the instrument off.


1. Battery Installation

When the low battery indication symbol "" appears on the display, there is insufficient power to make accurate measurements and the batteries must be replaced.


- ① Before replacing the batteries, press the  button to turn off the instrument.
- ② Remove the cover of the battery compartment.
- ③ Insert the new 9V battery.
- ④ Replace the battery cover.
- ⑤ Press the  button to turn on the instrument and check for correct operation.

2. Battery capacity indicator


When use battery operating the meter, periodically check this indicator to determine the remaining battery capacity. The number of segments decreases as the battery are used up. When the display starts to flash, correct measurement is no longer possible. Replace the battery with a new one. The indicator is also displayed while the meter is powered from the AC adaptor.



3. Using an external power source


Insert the plug of the AC adaptor or external battery pack into the DC 9V (DC source from 6V to 12V) socket on the side of the instrument. When a connector is inserted into this socket, the internal batteries will be disconnected and the instrument will be powered from the external source. The low battery symbol "" will appear on the display if the external voltage is insufficient for the instrument to provide accurate measurements.

Note: Ensure the external power source is connected with the polarity as indicated in the following diagram, otherwise damage may be caused to the instrument and external power source.




4. Windscreen

When making measurements outdoors in strong winds or when measuring air conditioning equipment or similar, wind noise and strong air movements at the microphone can cause measurement errors. Such effect can be reduced by using the windscreen.



5. Tripod Mounting


For long-term measurements, the instrument may be mounted on a standard camera tripod using the integral $\frac{1}{4}$ " x 20 UNC mounting thread.



8. CALIBRATION PROCEDURE

Most national standards recommend that you calibrate your sound level meter before each set of measurements and check the calibration after each set.

The procedure to check/adjust the displayed sound level in response to acoustic calibrator types SLC-1356 or B&K 4231 (or equivalent) is as follows:



1. Turn off the sound calibrator.
2. Press the $\text{\textcircled{1}}$ button to turn on the instrument.
3. Use the “ \square ” and “ \square ” buttons to select the 60 to 120dB reference sound level range.
4. Use the $\text{\textcircled{A}}$ button to select “A” frequency weighting.
5. Use the $\text{\textcircled{FAST}}$ button to select “FAST” time weighting.
6. Insert the microphone very carefully and slowly all the way into the sound calibrator coupling orifice.
7. Switch on the 1000Hz sound calibrator in its nominal 94 dB level setting.
8. Adjust the CAL potentiometer of the instrument, until the display reading for diffuse field is the same as the certified pressure level of the calibrator, or is 0.1 dB higher than this pressure level for free-field. This applies to calibrators type SLC-1356 or B&K4231.



9. Set the power switch of the sound calibrator to OFF.
10. Remove the microphone very carefully and slowly from the coupler.

9. MEASUREMENT PROCEDURE

Sound level measurement

1. Press the $\text{\textcircled{1}}$ button to turn on the instrument. The initial state depends on the condition the instrument was in before it was last turned off.
2. Press the $\text{\textcircled{A}}$ or $\text{\textcircled{C}}$ button to select the desired frequency weighting. For normal sound level measurements, select the “LA” setting.
3. Press the $\text{\textcircled{FAST}}$ or $\text{\textcircled{SLOW}}$ button to select the desired time weighting (dynamic characteristics). Normally, the “FAST” setting should be used.

4. When performing measurement according to IEC or other standards, the frequency weighting and time weighting setting required by the standard should be selected.
5. Press the “ ” and “ ” buttons to select desired level range. Choose a setting in which the bar graph indication registers approximately the middle of the range. If the “ **Ov** ” indicator appear during measurement, the upper limit of the selected range has been exceeded. Increase the range setting until the symbol remains off during measurement. Similarly, if the “ **Un** ” indicator appears, reduce the range setting until the symbol remains off during measurement. Both indicators are non-latching and will clear when the correct range is selected.
6. The numeric level indication shows the currently measured sound level. The reading is updated once every second.
7. If an over-range or under-range condition has occurred at least once during measurement the “ **Ov** ” or “ **Un** ” indication is shown on the display, to indicate that over-range or under-range data were included in the sound level measurement values for processing.
8. Press the **MAX** button to record the maximum time-weighted sound level encountered during a measurement period; the “max” indicator will appear on the display. Press this button again to exit this mode.

10. STORE OPERATIONS

1. To memorize the reading

- ① Press **MEM** button each time to store one set measurement data and each elapsed time in memory, and LCD will show “ **M** ” and memory location numbers (1 to 99).
- ② When the data number 99 is reached, the “FULL” indication is shown on the display, does not change further and does not return to 1.

2. To recall and read the reading


- ① Press **READ** button to recall the reading memory data mode. LCD will show “ **R** ” and memory location numbers.
- ② Press or button to scroll through the logged readings.
- ③ Press **READ** button again to exit READ mode.

3. To clean the memory

- ① Press “ **Ⓢ** ” button to turn-off the meter.
- ② Press and hold down **MEM** button then press “ **Ⓢ** ” button to turn on the meter, LCD will show “CLr” and all stored data are clear.

11. OUTPUT CONNECTORS

3.5φ Plug Wiring Connection



AC Output:

An AC signal corresponding to the frequency-weighted signal is available at this connector.

Output voltage: $1V_{rms} \pm 100mV_{rms}$ (scale upper limit)

Output impedance: approx. 5k

Load impedance: 1M

The output voltage when the instrument is in calibration mode (-6dB from scale upper limit, 1000Hz sine wave) is $0.5V_{rms}$.

DC Output:

A level-converted DC signal generated by RMS detection and logarithmic compression is available at this connector. The signal reflects the frequency and time weighting settings of the instrument.

Output voltage: $10mV \pm 0.1mV/dB$

Output impedance: approx. 5k


Load impedance: 1M

The output voltage when the instrument is reading 94dB is nominally 0.94V DC.

12. ADJUSTMENT DATA FOR CALBRATOR (B&K TYPE 4226 PRESSURE MODE)

Freq units	31.5 Hz	63 Hz	125 Hz	250 Hz	500 Hz	1000 Hz	2000 Hz	4000 Hz	8000 Hz
dB	+0.2	+0.3	+0.1	-0.1	-0.2	-0.1	0	+1.2	+3.9

13. TYPICAL INSTRUMENT FREQUENCY RESPONSE AT 0° INCIDENCE



Freq units	31.5 Hz	40 Hz	50 Hz	63 Hz	80 Hz	100 Hz	125 Hz	160 Hz	200 Hz	250 Hz	315 Hz	400 Hz	500 Hz
0deg dB	1.6	2.3	1.1	1.2	1.1	1.0	0.9	1.2	0.4	0.0	0.5	0.5	0.3
Freq units	630 Hz	800 Hz	1000 Hz	1250 Hz	1600 Hz	2000 Hz	2500 Hz	3150 Hz	4000 Hz	5000 Hz	6300 Hz	8000 Hz	
0deg dB	0.2	0.2	0.0	-0.3	0.2	0.2	1.2	2.3	2.3	2.9	4.5	3.4	

**14. TYPICAL FREQUENCY RESPONSE DUE TO CASE REFLECTIONS AT 0°
INCIDENCE**

Freq units	31.5 Hz	63 Hz	80 Hz	100 Hz	125 Hz	160 Hz	200 Hz	250 Hz	315 Hz	400 Hz	500 Hz	630 Hz
Case Reflections in dB	-0.1	0.0	0.0	+0.1	+0.2	0.0	0.0	0.0	-0.3	-0.2	0.1	0.1
Freq units	800 Hz	1000 Hz	1250 Hz	1600 Hz	2000 Hz	2500 Hz	3150 Hz	4000 Hz	5000 Hz	6300 Hz	8000 Hz	
Case Reflections in dB	+0.1	0.0	-0.2	0.0	0.4	0.3	0.4	0.3	-0.3	+0.6	+0.6	

Absolute effect at 1000Hz = 0.0 dB

Case reflections for an ISO-TECH 52N meter fitted with an MC-21 microphone as per IEC 61672-1 and IEC 60651, relative to 1000Hz.

**15. TYPICAL FREQUENCY RESPONSE OF 65mm WINDSCREEN AT 0°
INCIDENCE**


Freq units	31.5 Hz	63 Hz	80 Hz	100 Hz	125 Hz	160 Hz	200 Hz	250 Hz	315 Hz	400 Hz	500 Hz	630 Hz
Windshield Effects in dB	-0.2	-0.2	-0.1	-0.1	-0.2	-0.2	-0.2	-0.2	-0.1	-0.2	-0.1	-0.1
Freq units	800 Hz	1000 Hz	1250 Hz	1600 Hz	2000 Hz	2500 Hz	3150 Hz	4000 Hz	5000 Hz	6300 Hz	8000 Hz	
Windshield Effects in dB	-0.1	0.0	0.1	0.1	0.1	0.4	0.5	0.4	0.4	0.6	0.4	

Absolute effect at 1000Hz = +0.2 dB


Frequency response effects for a 65mm dia. windshield fitted with an MC-21 microphone as per IEC 61672-1 and IEC 60651, relative to 1000Hz.

16. DIRECTIONAL CHARACTERISTICS OF THE COMPLETE INSTRUMENT


The directional characteristics of a microphone give a measure of its differing sensitivity for sound waves arriving from various angles. Since the pre-polarized condenser microphone used in the instrument is a pressure-sensitive type, it should be equally sensitive in all directions. However, refraction and cavity effects cause certain microphone directional characteristics at high frequencies. The diagrams below show the directional characteristics of the complete instrument with the microphone MC-21.




Directional characteristics for frequency equal to 1000Hz



Directional characteristics for frequency equal to 2000Hz




Directional characteristics for frequency equal to 4000Hz



Directional characteristics for frequency equal to 8000Hz

17. APPENDIX A FREQUENCY WEIGHTING NETWORK

The SLM-52N provides frequency weightings A, and C. The electrical characteristics of the weighting network at AC output connector are as shown below.



Frequency weighting characteristics

The human perception of a sound depends not only on the sound pressure level, but also on the frequency. At high or low frequencies, a sound is felt to be less loud than a sound of equal level in the midrange. The frequency weighting A compensates for this effect and produces measurement results which are close to the perceived sound level. For this reason, this type of frequency weighting is widely used for purposes such as sound level evaluation.


The frequency weighting C curve produces almost flat response, but with a roll off below 20Hz and above 8000Hz. This is suitable for sound pressure level measurements in situations with unwanted low-frequency or high-frequency components.

18. APPENDIX B RMS DETECTION CIRCUIT AND TIME WEIGHTING

The sound level meter uses rms detection. The effective value E (rms) is defined by the following equation.

$$E(rms) = \sqrt{\frac{1}{T} \int_0^T e^2 dt}$$

The voltage e which changes over time is raised to the power of 2, and integration for the time interval T is performed. The result is divided by T and the square root is extracted. The circuit configuration for performing the above mathematical operation looks as follows.



During sound level measurements, the level often fluctuates drastically, which would make it difficult to evaluate readings if some kind of averaging were not applied. Sound level meters therefore provide the capability for index weighting (index averaging) using the rms circuit. The parameters of this weighting process are called the time weightings, determined by the time constant (see next page).


Sound level meters usually have a F(Fast) and S(Slow) setting for the time weighting. The time range that is considered for averaging is narrow in the F(Fast) setting and wide in the S(Slow) setting. In the F(Fast) setting, the instantaneous level has a larger bearing on the displayed value than in the S(Slow) setting. From the point of view of the measurement objective, the F(Fast) setting is more suitable to situations with swiftly changing sound level, whereas the S(Slow) setting yields a more broadly averaged picture. The F(Fast) setting is more commonly used, and sound pressure level values given without other indication are usually made with F(Fast) characteristics.

Time weightings and time constant


Time Weightings	Time constant	
	Rise time	Decay time
F(Fast)	125ms	125ms
S(Slow)	1s	1s

The time weighting network of the sound level meter performs index averaging on the square of the sound pressure signal. The equivalent circuit is shown at right. τ is the time constant, which equals CR.

The response of the index averaging circuit to a single burst signal is shown below.



Equivalent electrical circuit



19. APPENDIX C INFLUENCE OF BACKGROUND NOISE

When measuring a certain sound in a certain location, all other sounds present at that location except the measurement target sound are background noise (also called ambient noise or dark noise). Since the sound level meter will display the combination of target sound and background noise, the amount of background noise must be taken into consideration when determining the level of the target sound.

If the difference between the instrument reading in absence of the target sound and the reading with the target sound is more than 10dB, the influence of background noise is small and may be disregarded. If the difference is less than 10dB, the values shown in the table below may be used for compensation, to estimate the level of the target sound.

Background noise compensation

Display reading difference with and without target sound (dB)	4	5	6	7	8	9
Compensation value (dB)	-2			-1		

If for example the measured sound level when operating a machine is 70dB, and the background noise level when the machine is not operating is 63dB, the compensation value for the difference of 7dB is -1dB. Therefore the sound level of the machine can be taken to be $70\text{dB} + (-1\text{dB}) = 69\text{dB}$.

The above principle for compensating the influence of the background noise assumes that both the background noise and the target sound are approximately constant. If the background noise fluctuates, or contains very different spectral content and especially if it is close in level to the target sound, compensation is difficult and will often be meaningless.