

Please be informed that the data shown in this PDF Document is generated from our Online Catalog. Please find the complete data in the user's documentation. Our General Terms of Use for Downloads are valid (http://phoenixcontact.com/download)



Contact insert frames, Range of articles: VARIOCON, Sleeve frame, type: VC4, housing material: Polyamide, color: black

The figure shows the version VC-TR 1/2 M

RoHS

Key Commercial Data

Packing unit	5 рс
Minimum order quantity	5 рс
GTIN	4 017918 134334
GTIN	4017918134334

Technical data

Dimensions

Height	27.5 mm
Width	95.2 mm
Length	20.2 mm

Ambient conditions

Ambient temperature (operation)	-40 °C 100 °C

General

Size	VC4
Color	black
Torque	0.8 Nm 0.8 Nm
Material	PA-GF
Housing material	Polyamide
Cable gland material	Steel, galvanized
Flammability rating according to UL 94	V2

Standards and Regulations



Technical data

Standards and Regulations

and/or property. • WARNING: Commission property functioning products only. The products must be regularly inspected for damage. Decommission defective products immediately. Replace damaged products. Repairs are not possible. • WARNING: Only electrically qualified personnel may install and operate the product. They must beserve the following safety notes. The qualified personnel must be familiar with the basics of electrical engineering. They must be able to recognize and prevent danger. The relevant symbol on the packaging indicates that only personnel familiar with electrical engineering are allowed to install and operate the product electrical device engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • When operating the product in direct connection with third-party manufacturers, the user is responsible. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoeniccontact.com/products). • When using the product in direct connector huith third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • VDE 1000/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: o On the packing label o In the supplied documentation o On the packing label o In the supplied docume			
products must be regularly inspected for damage. Decommission defective products immediately. Replace damaged products. Repairs are not possible. • WARNING: Only electrically qualified personnel may install and operate the product. They must observe the following safety noise. The qualified personnel must be infinitely with the basics of electrical regimeering. They must be dark with the basics of electrical regimeering. They must be dark with the track of electrical regimeering. They must be dark with the track of electrical regimeering. • The products are suitable for applications in plant, controller, and electrical device engineering. • When operating the connectors in outdor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufactures the user's responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Consure that the product in direct connection with third-party connected. • Observe the corresponding technical data. You will find information: o On the packing label 0 in the supplied boliconmentation 0 On the packing label 0 in the supplied boliconmentation 0 On the packing label 0 in the supplied documentation 0 On the pack	Safety note	under load. Ignoring the warning or improper use may damage persons	
operate the product. They must be basic observe the following safety notes. The qualified personnel must be familiar with the basics of electrical engineering. They must be able to recognize and prevent danger. The relevant symbol on the packaging indicates that only personnel familiar with electrical engineering are allowed to install and operate the product electrical device engineering. • The products are suitable for applications in plant, controller, and electrical device engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at pheenkrochust.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings mus be grounded • For operating voltages > 50 V AC, conductive connector housings mus be grounded • DDE 0100/137 § 411.13.2 and DIN EN 60 204/11.98 § 14.13 are applicable when corresponding technical data. You will find information: o On the product • Observe the corresponding technical data. You will find information: o On the product • On the product • Only use tools recommended by Phoenix Contact • The installation notes/Design in documents online on the download page at phoenixconatact.com/products must be observed for this product <td></td> <td colspan="2">products must be regularly inspected for damage. Decommission defective products immediately. Replace damaged products. Repa</td>		products must be regularly inspected for damage. Decommission defective products immediately. Replace damaged products. Repa	
electrical device engineering. • When operating the connectors in outdoor applications, they must be separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings must be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector on the product • Observe the corresponding technical data. You will find information: o On the product • On the product • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Use a protective cap to protect connectors that are not in use. The subable accessories are available online in the standards. • Operate the connector only when it is fully plugged in		operate the product. They must observe the following safety notes. The qualified personnel must be familiar with the basics of electrical engineering. They must be able to recognize and prevent danger. The	
separately protected against environmental influences. • Assembled products may not be manipulated or improperly opened. • Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings muse be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: o On the product • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact. com/products must be observed for this product • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the minum bending radius of the cable. Lay the cable without tivisting it.			
Only use mating connectors that are specified in the technical data of the standards listed (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). When using the product in direct connection with third-party manufacturers, the user is responsible. For operating voltages > 50 V AC, conductive connector housings mus be grounded Ensure that the protective or functional ground has been properly connected. VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector Observe the corresponding technical data. You will find information: o On the product o On the product o On the product Online at phoenixcontact.com/products under the product Online at phoenixcontact.com/products must be observed for this product VDs enter the corresponding technical data. You will find information: o On the packing label o In the supplied documentation o Online at phoenixcontact.com/products under the product Only use tools recommended by Phoenix Contact The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products. Operate the connector only when it is fully plugged in. Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. Observe the minimum bending radius of the cable. Lay the cable without twisting it. The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warmings (e.g. DIN			
of the standards itsel (e.g. the ones listed in the product accessories online at phoenixcontact.com/products). • When using the product in direct connection with third-party manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings musbe grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: o On the product • On the product • Online at phoenixcontact.com/products under the product • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it.		Assembled products may not be manipulated or improperly opened.	
manufacturers, the user is responsible. • For operating voltages > 50 V AC, conductive connector housings musble grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the product • On the product • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warmings (e.g. DIN		of the standards listed (e.g. the ones listed in the product accessories	
be grounded • Ensure that the protective or functional ground has been properly connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the packing label • In the supplied documentation • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN			
connected. • VDE 0100/1.97 § 411.1.3.2 and DIN EN 60 204/11.98 § 14.1.3 are applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the packing label • In the supplied documentation • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN		For operating voltages > 50 V AC, conductive connector housings must be grounded	
applicable when combining several circuits in a cable and/or connector • Observe the corresponding technical data. You will find information: • On the product • On the packing label • In the supplied documentation • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN			
o On the product o On the packing label o In the supplied documentation o Online at phoenixcontact.com/products under the product • Only use tools recommended by Phoenix Contact • Only use tools recommended by Phoenix Contact • The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN			
 The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products Operate the connector only when it is fully plugged in. Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. Observe the minimum bending radius of the cable. Lay the cable without twisting it. The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN 		o On the product o On the packing label o In the supplied documentation	
page at phoenixcontact.com/products must be observed for this product • Use a protective cap to protect connectors that are not in use. The suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN		Only use tools recommended by Phoenix Contact	
suitable accessories are available online in the accessory section of the product at phoenixcontact.com/products • Operate the connector only when it is fully plugged in. • Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN		• The installation notes/Design In documents online on the download page at phoenixcontact.com/products must be observed for this product.	
Ensure that when laying the cable, the tensile load on the connectors does not exceed the upper limit specified in the standards. Observe the minimum bending radius of the cable. Lay the cable without twisting it. The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN		suitable accessories are available online in the accessory section of the	
does not exceed the upper limit specified in the standards. • Observe the minimum bending radius of the cable. Lay the cable without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN		Operate the connector only when it is fully plugged in.	
without twisting it. • The connector warms up in normal operation. Depending on the ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN			
ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN			
		ambient conditions, the surface of the connector can continue to warm up. In this case, the user is responsible for posting warnings (e.g. DIN	

Environmental Product Compliance




Technical data

Environmental Product Compliance

China RoHS Environmentally friendly use period: unlimited = EFUP-e	
No hazardous substances above threshold values	

Drawings

Dimensional drawing



Classifications

eCl@ss

eCl@ss 10.0.1	27144001
eCl@ss 11.0	27144001
eCl@ss 4.0	27141200
eCl@ss 4.1	27141200
eCl@ss 5.0	27144000
eCl@ss 5.1	27144000
eCl@ss 6.0	27144000
eCl@ss 7.0	27144001
eCl@ss 9.0	27144001

ETIM

ETIM 2.0	EC000007
ETIM 3.0	EC000007
ETIM 4.0	EC000007
ETIM 6.0	EC000007
ETIM 7.0	EC000007

UNSPSC

UNSPSC 6.01	43172601
UNSPSC 7.0901	31261501
UNSPSC 11	43172601
UNSPSC 12.01	31261501
UNSPSC 13.2	31261501
UNSPSC 18.0	31261501
UNSPSC 19.0	31261501
UNSPSC 20.0	31261501

01/03/2022 Page 3 / 4



Classifications

http://www.phoenixcontact.com

UNSPSC		
UNSPSC 21.0	31261501	
Approvals		
Approvals		
Approvals		
EAC		
Ex Approvals		
Approval details		
EAC		B.01742
Phoenix Contact 2022 © - all rights reserved http://www.phoenixcontact.com		
PHOENIX CONTACT GmbH & Co. KG		
Flachsmarktstr. 8		
32825 Blomberg		
Germany Tel. +49 5235 300		
Fax +49 5235 3 41200		