

4. Auxiliary Contact Blocks

Table 18.113:

| Terminals | Contact Indicates | Contact Normal Status | Contact State for Each Mode▲ |       |     |                    |                              |                                     | Catalog Number | \$ Price |
|-----------|-------------------|-----------------------|------------------------------|-------|-----|--------------------|------------------------------|-------------------------------------|----------------|----------|
|           |                   |                       | Off                          | Ready | Run | Short Circuit Trip | Overload Trip (Manual Reset) | Overload Trip (Remote/ Auto Reset)■ |                |          |
| Screw     | Ready condition   | N.O.                  | O                            | I     | I   | O                  | O                            | I                                   | LUA1C11        | 23.      |
|           | Fault condition   | N.C.                  | I                            | I     | I   | O                  | O                            | I                                   |                |          |
| Screw     | Ready condition   | N.O.                  | O                            | I     | I   | O                  | O                            | I                                   | LUA1C20        |          |
|           | Fault condition   | N.O.                  | O                            | O     | O   | I                  | I                            | O                                   |                |          |

▲ I-indicates closed contact; O-indicates open contact  
■ Requires multifunction or advanced control unit plus fault differentiation module LUFDDA10.

Table 18.114: Additional Accessories

| Description            | For use on:   | Catalog Number | \$ Price |
|------------------------|---|----------------|----------|
| Control Terminal Block | Power base LUB* and LUS*  | LU9BN11        | 23.      |
| Pre-wire connector     | Power bases LUB* and LUS* to pre-wire 24 Vdc from LUFC00, ASILUFC5, or LULC031            | LU9BN11C       | 38.      |
|                        | Power bases LU2B* to pre-wire 24 Vdc from LUFC00, ASILUFC5, or LULC031 to reversing block | LU9MRC         |          |
| Blanking covers        | Auxiliary contact function module cavity  | LU9C1          | 5.       |
|                        | Auxiliary contact block cavity  | LU9C2          |          |

Table 18.115: Reversing Blocks and Accessories

| Mounting                           | Control Connections   | Catalog Number ♦ | \$ Price |
|------------------------------------|---|------------------|----------|
| Directly beneath power base        | Without terminals   | LU2MB0♦          | 148.     |
| Separate (panel or 35 mm DIN rail) | Without terminals   | LU6MB0♦          | 148.     |
| Coil terminals                     | Direct mounted for LUBA0*, LU2BB0*, LU2MB0*, or LU6MBO*   | LU9M1            | 10.      |
| Control block                      | Separately mounted for LU6MBO*  | LU9MR1           | 10.      |
| Pre-wire connector                 | Direct mounting of reversing block for connections between power base and connector block (required for direct mounting of reversing block) | LU9MR1C          | 21.      |

♦ Complete the catalog number by selecting the proper voltage code from the table below. For example: LU2MB0FU.

Table 18.116: Voltage Codes

| Volts    | 24 | 48-72 | 110-240 |
|----------|----|-------|---------|
| DC       | BL | —     | —       |
| AC       | B  | —     | —       |
| DC or AC | —  | ES    | FU      |

