

Manual Supplement

Manual Title: 279 FC Users
Print Date: March 2016
Revision/Date:

Supplement Issue: **2**
Issue Date: 11/16
Page Count: 1

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1, 300

On page 32, under **Firmware Updates**, in step 2, replace the first two paragraphs with:

2. Connect a USB 2.0 (High Speed) cable to the Multimeter.

Plug in the large (USB “A”) connector of the cable to your PC and the small (USB “Mini B”) connector to the Multimeter.

On page 32, under **IR Image Management**, in step 2, replace the first two paragraphs with:

2. Connect a USB 2.0 (High Speed) cable to the Multimeter.

Plug in the large (USB “A”) connector of the cable to your PC and the small (USB “Mini B”) connector to the Multimeter.

Change #2, 577

On page 43, replace the **Temperature** section, under **Infrared Camera**:

Infrared Camera

Temperature

Temperature Measurement Range..... -10 °C to +200 °C

Temperature Measurement Accuracy ±5 °C or ±5 %, whichever is greater, at 25 °C, (Ambient)
for target temperatures below 20 °C, add 0.05 °C for each degree °C.

Temperature Coefficient 0.2 °C or 0.2 %, whichever is greater, for each °C from 25 °C