

LifeDrive™


Read This First

palmOne®


Start Here

Here's what you'll do with this guide:


- Charge and set up your device.
- Install Palm® Desktop software and other software for synchronizing, moving files, and more.
- Synchronize your device with your computer.




USB sync cable



Pouch



LifeDrive™ from palmOne




Software installation CD

AC charger

1 Connect and charge

- a. Plug the sync cable into your device and into a USB port on the back of your computer.
- b. Plug the AC charger into the Multi-connector on the sync cable and into an outlet.
- c. Charge for **three hours**. Be sure to fully charge your device before going on to the next step.



2 °Set up

- a. Slide the power switch to the right.
- b. Remove the stylus.
- c. Follow the onscreen instructions to set up your device.

Tip: Take the Quick Tour  to learn more about the great features of your device.



Problems? See the "Troubleshooting" section in the upcoming pages.

Important! Already use a palmOne™ device?

Upgrading? Before you start step 3, read this:

Your new device uses a different file structure from the one on your current handheld. Because of this, some third-party applications may not work correctly on your new device. When you synchronize using your existing username, any third-party applications that may not work correctly on your device do not install. All of your personal (PIM) information-calender events, contacts, tasks, and memos-is installed to your device.

What about the third-party applications that were not installed?

Check each third-party application's website for news about an updated version that works on your new device. Be sure to install only applications that specifically state they are compatible with your device. For more information on third-party applications and the new file structure, go to www.palmOne.com/intl.

3 Install software


To install Palm Desktop software, the LifeDrive™ Manager application, and other important software, insert the CD into your computer's CD drive.

Windows

Follow the installation instructions that appear on your computer screen.

Mac

Double-click the CD icon, and then double-click `palmOneDesktop.pkg`.



Tip: During the installation process on a Windows computer, you can select to synchronize with Outlook.

Already use a palmOne device?

To switch from synchronizing with Palm Desktop software to Outlook, select Change your synchronization method at the end of the installation process.

Get answers, learn more

Take the tutorial



Discover your device

palmOne™


- Set up your email
- Get Organized. Have Fun.
- Where to get help
- Add software to your device
- Change your synchronization method
- Register your device

[Quit](#)

Click here to take the interactive tutorial.

Learn to use the popular features of your device. Insert the installation CD in your computer and click here for an **interactive tutorial**.

Get more information



Palm Desktop

File Edit View Tools HotSync Help

LifeDrive(TM) Getting Started Guide

Online Support

Category: All

Tuesday, June 22, 2004

	8 am	9	10
Calendar			
Contacts			
Tasks			

Open Palm Desktop software on your computer and click **Help**.

Click here for the **manual**. For more detail, go online: www.palmone.com/lifedrive-handbook.

Click **Online Support** (www.palmone.com/intl/support) for the latest software updates and answers to frequently asked questions.

Troubleshooting

Support information is also available at www.palmOne.com/intl/support.

IMPORTANT! Take care of your device

- Be especially careful with your device when the amber indicator light is flashing. This means that the hard drive is processing information, and you could lose some or all of the information on the drive if you shake or drop the device.
- Do not open your device for any reason. If you attempt to remove the hard drive, the warranty is voided.
- Do not drop, bang, shake, or cause any strong impact to your device.

► **Your handheld does not turn on, or does not respond when you tap it**

1. Try turning it on by pressing one of the quick buttons on the front panel.
2. Do a soft reset. Press the reset button on the bottom of the device with the tip of the stylus.
3. Make sure the AC charger is fully connected to the device or the sync cable and to a working outlet. Charge for another three full hours.

► **Palm Desktop Installer does not start when you put the CD into the drive**

Windows:

1. Click the Start button and select Run.
2. Click Browse to locate the drive that contains the CD that came with your device.
3. Double-click autorun.exe on the CD.

Mac:

1. Double-click the CD icon on the Mac desktop.
2. Double-click palmOneDesktop.pkg.

► If Synchronization does not begin

Be sure the sync cable is plugged into your device and a USB port on the back of your computer.

Check your computer:

Windows:

1. Make sure the HotSync® icon appears in the group of icons in the lower-right part of your screen.

HotSync icon



If not:

- a. Click the Start button and then select Programs.
- b. Select palmOne, and then select HotSync Manager.

2. Check the connection type:
 - a. Disconnect and then reconnect the sync cable.
 - b. Make sure there is a checkmark next to Local USB.
If there is not, click Local USB.







Mac:

1. Make sure HotSync Manager is enabled:
 - a. Double-click the HotSync Manager icon in the Palm folder.
 - b. In the HotSync Controls tab, click Enabled.
2. Make sure the USB connection is working:
 - a. Disconnect and then reconnect the sync cable.
 - b. Restart your computer.

Check your device:

1. Press the Home  button twice, and then tap HotSync  in Applications.
2. In the HotSync application, make sure of the following:
 - Local is highlighted. If it isn't highlighted, tap Local.
 - Cradle/Cable appears. If not, tap the pick list, and then tap Cradle/Cable.
3. Tap the HotSync icon on the screen.





palmOne, Inc.
400 N. McCarthy Blvd.
Milpitas, CA 95035
U.S.A

Copyright

© 2005 palmOne, Inc. All rights reserved.

palmOne, Palm Desktop, HotSync, and LifeDrive are among the trademarks or registered trademarks owned by or licensed to palmOne, Inc. palmOne, Inc. uses the Bluetooth wireless technology trademark under express license from Bluetooth SIG, Inc. and uses the Wi-Fi wireless technology trademark under express license from the Wi-Fi alliance. All other brand and product names are or may be trademarks of, and are used to identify products or services of, their respective owners.

Disclaimer and Limitation of Liability

palmOne, Inc. assumes no responsibility for any damage or loss resulting from the use of this guide.

palmOne, Inc. assumes no responsibility for any loss or claims by third parties which may arise through use of this software. palmOne, Inc. assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs.

Be sure to make backup copies of all important data on other media to protect against data loss.

IMPORTANT

Please read the End User Software License Agreement with this product before using the accompanying software program(s). Using any part of the software indicates that you accept the terms of the End User Software License Agreement.

Software Download Available

Palm® Desktop software is available on CD. Check www.palmOne.com/intl/support for updates and new versions of the software.

Agency Compliance Information

Product regulatory and compliance information can be found in the *User Guide* at www.palmone.com/lifedrive-handbook.

PN: 406-10283-10

