







DBEE/U 103 Multipole Receptacles

All dimensions see note 1)


Contact polarity A

Contact polarity Z






CONTACT CONFIGURATION	Contacts	Solder cup \varnothing	C	PIN \varnothing
103 A Z 051	2	1.18	-	-
103 A Z 052	3	1.18	-	-
103 A Z 053	4	0.79	-	-
103 A Z 054	5	0.79	10.3	0.63

Pin layout / PCB hole pattern for polarity A - View from F (3)



Polarity Z - View from F



All dimensions in mm

Rev. 1 Pages 1/2

Notes:
 1) All tolerances resulting from connector assembly are typically ± 0.3 mm
 2) If receptacle is screwed directly into threaded hole, oversize thread by +0.05mm

3) Recommended PCB hole dimensions may be adjusted to application
 4) Please contact us
 Part number example : DBEE 103 A058-130

600544

1

1/2









www.fischerconnectors.com

DBEE/U 103 Multipole Receptacles

All dimensions see note 1)



Contact polarity A

Contact polarity Z



CONTACT CONFIGURATION	Contacts	Solder cup \varnothing	C	PIN \varnothing
103 A Z 056	6	0.79	10.3	0.50
103 A Z 057	7	0.79	-	-
103 A Z 058	8	0.79	-	-
103 A Z 062	12	0.43	-	-

Pin layout / PCB hole pattern for polarity A - View from F (3)



All dimensions in mm

Rev. 1 Pages 2/2

Notes:
 1) All tolerances resulting from connector assembly are typically ± 0.3 mm
 2) If receptacle is screwed directly into threaded hole, oversize thread by $+0.05$ mm

3) Recommended PCB hole dimensions may be adjusted to application
 4) Please contact us
 Part number example : DBEE 103 A058-130

600544

1

2/2



www.fischerconnectors.com