
New



Modular F.R.L. Units

Easy replacement of the element ----

The element and the bowl are in one piece. Replacement can be done in hand.



Reduced required maintenance space

Max. 46% reduction



Energy saving regulator

Pressure drop: Max. 50% improvement



Better visibility & safer

Double layer design

The bowl is covered with a transparent bowl guard!

- The inside is visible from 360°.
- The bowl is completely protected from the environment. Safety improved



Bowl guard

* Body size: 30 or more

Adding Bowl Variation!







oowl Metal bowl

Metal bowl with level gauge

Series AC

Filter Regulator

Mist Separator

Filter

Regulator

Lubricator

Air Filter

Air Filter Mist Separator Regulator

Lubricator


Regulator



Transparent bowl guard

●Better visibility: 360°





• Condensate can be monitored from anywhere.

Light weight: Max. 90 g reduction

* Except AW

Weight 360 g Weight 450 g


 Metal related corrosion does not occur.




Resin body does not rust.









Series Configuration

					Port size			
	Product	Model	1/8	1/4	3/8	1/2	3/4	INDEX
	Air Filter + Regulator + Lubricator	AC20-A	0					
	AF AR AL	AC25-A		•	0			
	250.5	AC30-A		•	•			P.1
		AC40-A		•	•	•		
		AC40-06-A					•	
	Filter Regulator + Lubricator	AC20A-A		•				
	AW AL	AC30A-A						P.7
		AC40A-A] F./
		AC40A-06-A						
Air Combination	Air Filter + Regulator AF AR	AC20B-A	0	•				
nbin	All D	AC25B-A		•	•			
Con		AC30B-A		•	•			P.11
Ą		AC40B-A		•	0	0		
		AC40B-06-A					0	
	Air Filter + Mist Separator + Regulator	AC20C-A	0	0				
	AF AFM AR	AC25C-A		•	•			
	201. 201. 2	AC30C-A		•	•			P.15
	* *	AC40C-A		0	0	0		
		AC40C-06-A						
	Filter Regulator + Mist Separator AW AFM	AC20D-A	0					
	ATVI	AC30D-A		•	•			P.19
		AC40D-A		•	•	•		
		AC40D-06-A						
	TT BB							

ΑF

Series Configuration

	D 1					Port size			
	Produc) t	Model	1/8	1/4	3/8	1/2	3/4	INDEX
	AF		AF20-A	0					
			AF30-A		•	•			
<u>~</u>	20 5 A . The	Cha	AF40-A				0		P.28
Air Filter			AF40-06-A						
Ai									
	AFM		AFM20-A	•	•				
<u>.</u>		ATTACAS TO THE STATE OF THE STA	AFM30-A		•	•			D 00
rato	Mist Separator		AFM40-A		0	•	•		P.28
Sepa			AFM40-06-A					0	
	AFD		AFD20-A	0	•				
ō	AFD		AFD20-A		0	0			-
oarat		Control on	AFD40-A		0	0	0		P.28
t Sep	Con.	2	AFD40-06-A					0	
Micro Mist Separator									
	AR		AR20-A	0	0				
			AR25-A		•	•			
Ž	● ************************************	line line	AR30-A		•	•			P.48
Regulator	Co	COR ED	AR40-A		0	0	0	_	
Reg		1 11	AR40-06-A					0	

Series Configuration

	Duo do		BAI - I			Port size			INDEV
	Produ	CI	Model	1/8	1/4	3/8	1/2	3/4	INDEX
	AL	70	AL20-A	0	0				
	F4.		AL30-A		0	0			D 56
to	4104	224	AL40-A		0	0	0		P.56
Lubricator	TOTAL	1 1	AL40-06-A					•	
Lu		- Proposition							
	AW		AW20-A	•					
	600		AW30-A		•	0			D 60
			AW40-A		•	0	•		P.62
ator			AW40-06-A						
Regulator	To delicate on 1	Maria della							

Simple Specials System

A system designed to respond quickly and easily to your special ordering needs



Filter

Short lead times

This system enables us to respond to your special needs, such as additional machining, accessory assembly, or modular unit, and deliver such special products as quickly as standard products.

Repeat orders


Once we receive a Simple Special part number from your previous order, we will process the order, manufacture the product, and deliver it to you.

Attachment List

Check valve

Page 22

■ A check valve with intermediate branch port can be easily installed to prevent a back-flow of lubricant when branching the air flow and releasing the air on the outlet side of the regulator.




- Air Filter + Regulator + Lubricator (AC□0-A)
- Filter Regulator + Lubricator (AC□0A-A)
 - * Port size: Except 06

Pressure switch

Page 23

A compact integrated pressure switch can be easily installed and facilitates the pressure detection of the line.




- Air Filter + Regulator + Lubricator (AC□0-A)
- Filter Regulator + Lubricator (AC□0A-A)
- Air Filter + Regulator (AC□0B-A)
- Air Filter + Mist Separator + Regulator (AC□0C-A)
- Filter Regulator + Mist Separator (AC□0D-A)

T-shaped spacer

Page 23

■ Using a T-shaped spacer facilitates the branching of air flow.



- Air Filter + Regulator + Lubricator (AC□0-A)
- Air Filter + Regulator (AC□0B-A)
- Air Filter + Mist Separator + Regulator ($AC \square 0C-A$)

Pressure relief 3 port valve

Page 24

■ With the use of a pressure relief 3 port valve, pressure left in the line can be easily exhausted.



- Air Filter + Regulator + Lubricator (AC□0-A)
 - Filter Regulator + Lubricator (AC□0A-A)
- Air Filter + Regulator (AC□0B-A)
 - Air Filter + Mist Separator + Regulator ($AC\square 0C-A$)
- Filter Regulator + Mist Separator (AC □ 0D-A)

Cross spacer

Page 24

■ Pipings are possible in all 4 directions.




* Needs to be ordered by single unit.

Piping adapter

Page 25


A piping adapter allows installation/removal of the component without removing the piping and thus makes maintenance easier.



* Needs to be ordered by single unit.




Attachment List





Related Products



Air Combination

Air Filter + Regulator + Lubricator

AC20-A to AC40-A

Symbol



How to Order



Option/Semi-standard: Select one each for a to m.
 Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AC30-F03DM-KSTV-13NR-A

			Symbol	Description		Body	/ size			
					20	25	30	40		
			_	Rc		•	•			
2	TI	hread type	N	NPT	•	•	•	•		
		,	F	G	•	• • •				
-			+				ı			
			01	1/8	•	_	_	_		
			02	1/4	•	•	•	•		
3		Port size	03	3/8	_	•	•	•		
			04	1/2	_	_	_			
			06	3/4	_	_	_	•		
			+							
			_	Without auto drain	•	•	•	•		
_	а	Float type auto drain	C Note 2)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•	•		
lote 1		auto urairi	D Note 3)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•	•		
Option Note 1)			+							
ptic		_	_	Without pressure gauge		•	•	•		
0	b	Pressure gauge Note 4)	G	Round type pressure gauge (with limit indicator)	•	•	•	•		
		gauge	M	Round type pressure gauge (with colour zone)	•	•	•	•		
			+	, , , , ,						
	_	Chashinakia	_	Without attachment		•	•	•		
	С	Check valve	K	Mounting position: AF+AR+K+AL	•	•	•	Note 5)		
			+			•		I .		
1		Pressure	_	Without attachment						
neu	d	switch	S Note 6)	Mounting position: AF+AR+S+AL	•	•	•	•		
G Attachment			+			•	•			
ıtta		T-shaped	_	Without attachment	•	•	•	•		
₹	е	spacer	T Note 6)	Mounting position: AF+T+AR+AL	•	•	•	•		
		•	+			•	•			
		Pressure relief	_	Without attachment	•	•	•	•		
	f	3 port valve	V	Mounting position: AF+AR+AL+V	•	•	•	•		
			+							
		Set	_	0.05 to 0.7 MPa setting	•	•	•	•		
	g	pressure Note 7)	1	0.02 to 0.2 MPa setting	•	•	•	•		
rd			+			•		I .		
Semi-standard			_	Polycarbonate bowl	•	•	•			
Star 6			2	Metal bowl	•	•	•	•		
H.	la.	Devid	6	Nylon bowl	•	•	•	•		
Se	h	Bowl	8	Metal bowl with level gauge	_	•	•	•		
			С	With bowl guard	•	_	_	_		
			6C	With bowl guard (Nylon bowl)	•	_	_	_		

Air Combination Series AC20-A to AC40-A





AC₂

AC ²

	_	_							
				Symbol	Description		Body	size	
						20	25	30	40
				_	With drain cock	•	•	•	•
			Filter	J Note 8)	Drain guide 1/8	•	_	_	_
		ı	drain port	J	Drain guide 1/4	_	•		
				W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•	•	
				+					
			Lubricator lubricant	_	Without drain cock				•
	Semi-standard	J	exhaust port	3 Note 9)	Lubricator with drain cock				•
6	tan			+					
	i-S-iC	k	Exhaust	_	Relieving type				
	Sen	K	mechanism	N	Non-relieving type				•
	0)			+					
			Flow direction	_	Flow direction: Left to right				
		•	riow direction	R	Flow direction: Right to left				•
				+					
		m	Pressure unit	_	Name plate and pressure gauge in imperial units: MPa				
		111	Pressure unit Z Note 10		Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	Note 11)	Note 11)	Note 11)	Note 11)

- Note 1) Option G, M are not assembled and supplied loose at the time of shipment.
- Note 2) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 3) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is
- Note 4) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 5) Not available with piping port size: 06 Note 6) The bracket position varies depending on the T-shaped spacer or pressure switch mounting.
- Note 7) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

Note 8) Without a valve function

Note 9) When choosing with W: Filter drain port, the drain cock of a lubricator will be with barb

Note 10) For thread type: NPT.

MPa and psi are shown together on the pressure unit.

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 11) O: For thread type: NPT only

Note 12) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications


Mo	odel	AC20-A	AC25-A	AC30-A	AC40-A	AC40-06-A							
	Air Filter	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A							
Component	Regulator	AR20-A	AR25-A	AR30-A	AR40-A	AR40-06-A							
	Lubricator	AL20-A	AL30-A	AL30-A	AL40-A	AL40-06-A							
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4							
Pressure gauge port size		1/8											
Fluid		Air											
Ambient and f	luid temperature		 5 to 60°C (with no freezing) 										
Proof pres	ssure			1.5 MPa									
Max. opera	ting pressure	1.0 MPa											
Set press	ure range	0.05 to 0.7 MPa											
Nominal fil	tration rating	5 μm											
Recommen	ded lubricant	Class 1 turbine oil (ISO VG32)											
Bowl mate	erial		Polycarbonate										
Bowl guar	rd	Semi-standard (Steel)		Standard (Po	olycarbonate)								
Regulator	construction		·	Relieving type									
Weight [k	g]	0.39	0.67	0.82	1.26	1.43							





Series AC20-A to AC40-A


Flow-rate Characteristics (Representative values)


Condition: Inlet pressure 0.7 MPa














Pressure Characteristics (Representative values)


Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)







AC40-A/AC40-06-A



뒴

Specific Product Precautions

sure to read before handling. Refer to back cover for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) and the Operation Manual for F.R.L. Precautions.

Piping

\land Warning

1. When mounting a check valve, make sure the arrow (IN side) points in the correct direction of air flow.

Air Supply

∕!\ Caution

1. Use an air filter with 5 µm or less filtration rating on the inlet side of the valve to avoid any damage to the seat caused by dust when mounting a pressure relief 3 port valve on the inlet side.

Mounting/Adjustment

∖ Caution

1. When the bowl is installed on the air filter, filter regulator, lubricator, mist separator, or micro mist separator, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



Selection

⚠ Caution

- 1. When releasing air at the intermediate position using a Tshaped spacer on the inlet side of the lubricator, lubricant may back flow. Therefore, releasing air that does not contain traces of lubricant is not possible.
 - To release air that does not contain traces of lubricant, use a check valve (Series AKM) on the inlet side of the lubricator to prevent a backflow of the lubricant.
- 2. If a pressure relief 3 port valve is mounted on the inlet side of the lubricator, causing a backflow of air, it can result in a backflow of oil or damage to internal parts. Please do not use it in this fashion. Please, locate it on the outlet side of the lubricator.
- 3. An F.R.L. unit shipped from the plant has its model number labeled. However, components that are combined together during the distribution process do not have a label on them.




Series AC20-A to AC40-A

Dimensions


Clearance for maintenance

AC20-A



Drain

AC25-A to AC40-06-A



Applicable model		AC2	20-A		AC25-A to AC40-06-A
Optional/Semi-standard specifications	With auto drain (N.C.)	With drain guide	Metal bowl	Metal bowl with drain guide	With auto drain (N.O./N.C.)
Dimensions	M5 x 0.8	Width across flats 14 1/8	B	Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting

P2
(Pressure gauge port size)

Applicable model			AC2	5-A to AC40-06-A		
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting
Dimensions	a	Width across flats 17	a v	/——	Width across flats 17	Barb fitting Applicable tubing: T0604


		Standard specifications															
Model	P ₁	P ₂	Α	В	(Е	F	G		Bracket mount							
	Pi	P2	Α	В	C	_		G	J	M	N	Q1	Q2	R	S	U	V
AC20-A	1/8, 1/4	1/8	126.4	87.6	35.9	_	41.6	60	23.4	30	43.2	24	33	5.5	12	3.5	29
AC25-A	1/4, 3/8	1/8	167.4	115.1	38.1	30	55.1	80	30.5	41	57.2	35	_	7	14	4	41
AC30-A	1/4, 3/8	1/8	167.4	115.1	38.1	30	55.1	80	30.5	41	57.2	35	_	7	14	4	41
AC40-A	1/4, 3/8, 1/2	1/8	220.4	147.1	39.8	38.4	72.6	110	36.1	50	75.2	40	_	9	18	5	48
AC40-06-A	3/4	1/8	235.4	149.1	37.8	38.4	77.6	110	39.6	50	80.2	40	_	9	18	5	48

		Optio	nal specifica	ations		Semi-standard specifications							
Model	Round type pressure gauge		Round type pressure gauge (with colour zone)		With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide		
	H J		Н	J	В	В	В	В	В	В	В		
AC20-A	ø37.5	58.5	ø37.5	59.5	104.9	_	91.4	87.4	93.9	_	_		
AC25-A	ø37.5	58.5	ø37.5	59.5	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC30-A	ø37.5	65	ø37.5	66	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC40-A	ø42.5	72	ø42.5	72	186.9	155.6	153.9	149.6	154.1	169.6	174.1		
AC40-06-A	ø42.5	72	ø42.5	72	188.9	157.6	155.9	151.6	156.1	171.6	176.1		




Filter Regulator + Lubricator AC20A-A to AC40A-A

Symbol



How to Order



- Option/Semi-standard: Select one each for a to I.
- Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AC30A-F03DM-KSV-13NR-A

							0	
				Symbol	Description		Body size	
						20	30	40
				_	Rc	•	•	•
2		Tł	read type	N	NPT	•	•	•
				F	G	•	•	•
				+				
				01	1/8		_	_
				02	1/4		•	•
3		- 1	Port size	03	3/8	_	•	•
				04	1/2	_	_	•
				06	3/4	_	<u> </u>	•
				+				
			Float type	_	Without auto drain	•	•	•
	=	а	auto drain	C Note 2)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•
	Note			D Note 3)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•
4	Option Note 1)			+				
	Dg		Pressure	_	Without pressure gauge	•	•	•
		b	gauge Note 4)	G	Round type pressure gauge (with limit indicator)	•	•	•
				M	Round type pressure gauge (with colour zone)		•	•
				+			_	
		С	Check valve	_	Without attachment		•	•
			Oncon vaivo	K	Mounting position: AW+K+AL			Note 5)
	Attachment			+				
6	빌	d	Pressure		Without attachment	•	•	•
	ttac		switch	S Note 6)	Mounting position: AW+S+AL		•	•
	¥			+				
		е	Pressure relief	_	Without attachment	•	•	•
			3 port valve	V	Mounting position: AW+AL+V		•	•
				+	0.051 0.7140 111			
		f	Set pressure Note 7)	_	0.05 to 0.7 MPa setting		•	
			pressure (10007)	1	0.02 to 0.2 MPa setting		•	•
				+	<u></u>			
				_	Polycarbonate bowl			
	5			2	Metal bowl		•	
	lda	g	Bowl	6	Nylon bowl	_	•	
6	star			8	Metal bowl with level gauge	_	•	
	Semi-standard			С	With bowl guard		_	_
				6C	With bowl guard (Nylon bowl)			
				+	Mith drain apple			
			Filter		With drain cock			_
		h	regulator	J Note 8)	Drain guide 1/8		_	_
			drain port	W Note 12)	Drain guide 1/4	_		
				VV (2)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_		

7

Air Combination Series AC20A-A to AC40A-A



AC40A-A

							0	
				Symbol	Description		Body size	
						20	30	40
			Lubricator lubricant	_	Without drain cock	•	•	•
		•	exhaust port	3 Note 9)	Lubricator with drain cock	•	•	•
				+				
	ard		Exhaust	_	Relieving type	•	•	•
	nde	J	mechanism	N	Non-relieving type		•	
6	Semi-standard			+				
	Ë	k	Flow direction	_	Flow direction: Left to right	•	•	•
	Se	,	riow direction	R	Flow direction: Right to left	•	•	•
				+				
			Pressure unit	_	Name plate and pressure gauge in imperial units: MPa		•	
		ľ	Fressure unit	Z Note 10)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	Note 11)	Note 11)	Note 11)

- Note 1) Option G, M are not assembled and supplied loose at the time of shipment.
- Note 2) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 3) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- Note 4) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 5) Not available with piping port size: 06 Note 6) The bracket position varies depending on the pressure switch mounting.
- Note 7) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- Note 8) Without a valve function

- Note 9) When choosing with W: Filter regulator drain port, the drain cock of a lubricator will be with barb fitting.
- Note 10) For thread type: NPT. MPa and psi are shown together on the pressure unit. Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.
 - Note 11) O: For thread type: NPT only
 - Note 12) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications


	Model	AC20A-A	AC30A-A	AC40A-A	AC40A-06-A						
0	Filter Regulator	AW20-A	AW30-A	AW40-A	AW40-06-A						
Component	Lubricator	AL20-A	AL30-A	AL40-A	AL40-06-A						
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Pressure gau	ge port size	1/8									
Fluid		Air									
Ambient and	fluid temperature	- 5 to 60°C (with no freezing)									
Proof pressur	е	1.5 MPa									
Maximum ope	erating pressure	1.0 MPa									
Set pressure	range	0.05 to 0.7 MPa									
Nominal filtra	tion rating		5	μm							
Recommende	d lubricant		Class 1 turbine	oil (ISO VG32)							
Bowl material			Polyca	rbonate							
Bowl guard		Semi-standard (Steel) Standard (Polycarbonate)									
Regulator cor	nstruction	Relieving type									
Weight [kg]		0.33	0.66	1.22	1.34						



Series AC20A-A to AC40A-A

Dimensions

AC20A-A AC30A-A to AC40A-06-A 2 x **P**1 (Port size) S S Q IN OUT OUT တ် Pressure gauge B Pressure gauge (Option) U (Option) Ω Clearance for maintenance (Pressure gauge port size) Drain P₂ Ε Ŋ Clearance for maintenance **G** (Pressure gauge port size) 2 x **P**1 Drain (Port size)



Applicable model			AC30	A-A to AC40A-06-A				
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting		
Dimensions	a	Width across flats 17	a v	Width across flats 17	Width across flats 17	Barb fitting Applicable tubing: T0604		

		Standard specifications														
Model	P ₁	P ₂		В	C Note)	_	_	•			Bracket mount					
	P1	P2	A		C Note)	E	F	G	J [M	Q ₁	Q ₂	R	S	U	V
AC20A-A	1/8, 1/4	1/8	83.2	87.6	67.4	_	41.6	60	23.4	30	24	33	5.5	12	3.5	29
AC30A-A	1/4, 3/8	1/8	110.2	115.1	83.5	30	55.1	80	30.5	41	35	_	7	14	4	41
AC40A-A	1/4, 3/8, 1/2	1/8	145.2	147.1	100	38.4	72.6	110	36.1	50	40	_	9	18	5	48
AC40A-06-A	3/4	1/8	155.2	149.1	101.5	38.4	77.6	110	39.6	50	40	_	9	18	5	48

		Optio	nal specifica	ations		Semi-standard specifications							
Model	Round	d type e gauge	Round type pressure gauge (with colour zone)		With auto drain	With barb fitting	With drain guide Metal box		Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide		
	Н	J	Н	J	В	В	В	В	В	В	В		
AC20A-A	ø37.5	58.5	ø37.5	59.5	104.9	_	91.4	87.4	93.9	_	_		
AC30A-A	ø37.5	65	ø37.5	66	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC40A-A	ø42.5	72	ø42.5	72	186.9	155.6	153.9	149.6	154.1	169.6	174.1		
AC40A-06-A	ø42.5	72	ø42.5	72	188.9	157.6	155.9	151.6	156.1	171.6	176.1		

Note) The total length of C dimension is the length when the filter regulator knob is unlocked.




Air Filter + Regulator

AC20B-A to AC40B-A

Symbol



How to Order



- Option/Semi-standard: Select one each for a to j.
- Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AC30B-F03DM-SV-1NR-A

		_							
				Symbol	Description		Body	size	
						20	25	30	40
				_	Rc		•	•	•
2		Th	read type	N	NPT		•	•	•
			71	F	G		•	•	•
				+					
				01	1/8		_	_	_
				02	1/4			•	
3			Port size	03	3/8	_	•	•	•
				04	1/2	_	_	_	•
				06	3/4	_	_	_	
				+	0 , .				
				_	Without auto drain				
		а	Float type	C Note 2)	N.C. (Normally closed) Drain port is closed when pressure is not applied.		•	•	
	Note 1)		auto drain	D Note 3)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•	
4	Ž			+	(· · · · · · · · · · · · · · · · · · ·				
	Option			_	Without pressure gauge			•	
			Pressure	G	Round type pressure gauge (with limit indicator)		•	•	
			gauge Note 4)	M	Round type pressure gauge (with colour zone)		•	•	
				+	Tiound type procedure gauge (Milit doleur 20110)				
			Pressure	_	Without attachment			•	•
		С	switch	S Note 5)	Mounting position: AF+S+AR			•	•
	lent		T-shaped spacer	T Note 5)	Mounting position: AF+T+AR			•	
6	Attachment		' '	+					
	ttac			_	Without attachment		•	•	•
	<	d	Pressure relief	V	Mounting position: AF+AR+V		•	•	•
			3 port valve	V1 Note 6)	Mounting position: V+AF+AR		•	•	•
				+	• •				
			Set		0.05 to 0.7 MPa setting		•	•	•
		е	pressure Note 7)	1	0.02 to 0.2 MPa setting	•	•	•	•
				+					
				_	Polycarbonate bowl	•	•	•	•
				2	Metal bowl	•	•	•	•
	larc		5 .	6	Nylon bowl		•	•	•
	Semi-standard	f	Bowl	8	Metal bowl with level gauge	_	•	•	•
6	i-st			С	With bowl guard	•	_	_	_
	em			6C	With bowl guard (Nylon bowl)		_	_	_
	S			+					
				_	With drain cock	•	•	•	•
			Filter	Note 8)	Drain guide 1/8	•	_	_	_
		g	drain port	J Note 8)	Drain guide 1/4	_	•	•	•
				W Note 11)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•	•	•



Air Combination Series AC20B-A to AC40B-A



AC40B-A

	_	_					(
				Symbol	Description		Body	size	
						20	25	30	40
		la la	Exhaust	_	Relieving type	•	•	•	•
		h	mechanism	N	Non-relieving type		•	•	•
	dar			+					
	standard		Flow direction	_	Flow direction: Left to right	•			
6		•	riow direction	R	Flow direction: Right to left				
	Semi			+					
	0)		Pressure unit	_	Name plate and pressure gauge in imperial units: MPa			•	
		J	Fressure unit	Z Note 9)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	Note 10)	Note 10)	Note 10)	Note 10)

- Note 1) Option G, M are not assembled and supplied loose at the time of shipment.
- Note 2) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 3) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- Note 4) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 5) The bracket position varies depending on the T-shaped spacer or pressure switch mounting.
- Note 6) Make sure that the outlet pressure is released to atmospheric pressure using a pressure gauge.
 - For V1 specification, use the regulator with a set pressure of 0.15 MPa or more to ensure the pressure release.
- Note 7) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- Note 8) Without a valve function
- Note 9) For thread type: NPT.
 - MPa and psi are shown together on the pressure unit.
 - Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.
- Note 10) O: For thread type: NPT only
- Note 11) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications

М	odel	AC20B-A	AC25B-A	AC30B-A	AC40B-A	AC40B-06-A						
	Air Filter	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A						
Component	Regulator	AR20-A	AR25-A	AR30-A	AR40-A	AR40-06-A						
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Pressure gaug	je port size	1/8										
Fluid		Air										
Ambient and f	luid temperature	−5 to 60°C (with no freezing)										
Proof pressure	Э			1.5 MPa								
Maximum ope	rating pressure	1.0 MPa										
Set pressure r	ange	0.05 to 0.7 MPa										
Nominal filtrat	ion rating			5 μm								
Bowl material				Polycarbonate								
Bowl guard		Semi-standard (Steel)	Semi-standard (Steel) Standard (Polycarbonate)									
Regulator con	struction		Relieving type									
Weight [kg]		0.27 0.42 0.57 0.79										




Series AC20B-A to AC40B-A

Dimensions

AC20B-A

AC25B-A to AC40B-06-A



Applicable model		AC2	0B-A		AC25B-A to AC40B-06-A
Optional/Semi-standard specifications	With auto drain (N.C.)	With drain guide	Metal bowl	Metal bowl with drain guide	With auto drain (N.O./N.C.)
Dimensions	M5 x 0.8	Width across flats 14 1/8	B	Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting

Applicable model			AC25	B-A to AC40B-06-A		
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting
Dimensions	a	Width across flats 17	B	Width across flats 17	Width across	Barb fitting Applicable tubing: T0604


		Standard specifications														
Model	P ₁	P ₂		В	_	Е	_	G		Bracket mount						
AC20B-A	P1	P2	A	В			Г	G	J	M	Q ₁	Q2	R	S	U	V
AC20B-A	1/8, 1/4	1/8	83.2	87.6	23.5	_	41.6	25	23.4	30	24	33	5.5	12	3.5	29
AC25B-A	1/4, 3/8	1/8	110.2	115.1	23.5	30	55.1	35	30.5	41	35	_	7	14	4	41
AC30B-A	1/4, 3/8	1/8	110.2	115.1	27	30	55.1	35	30.5	41	35	_	7	14	4	41
AC40B-A	1/4, 3/8, 1/2	1/8	145.2	147.1	33.5	38.4	72.6	40	36.1	50	40	_	9	18	5	48
AC40B-06-A	3/4	1/8	155.2	149.1	33.5	38.4	77.6	40	39.6	50	40	_	9	18	5	48

		Optio	nal specifica	ations		Semi-standard specifications							
Model	Round	,,	Round type pressure gauge (with colour zone		With auto drain	With With barb fitting drain guide		Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide		
	Н	J	Н	J	В	В	В	В	В	В	В		
AC20B-A	ø37.5	58.5	ø37.5	59.5	104.9	_	91.4	87.4	93.9	_	_		
AC25B-A	ø37.5	58.5	ø37.5	59.5	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC30B-A	ø37.5	65	ø37.5	66	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC40B-A	ø42.5	72	ø42.5	72	186.9	155.6	153.9	149.6	154.1	169.6	174.1		
AC40B-06-A	ø42.5	72	ø42.5	72	188.9	157.6	155.9	151.6	156.1	171.6	176.1		

Air Filter + Mist Separator + Regulator AC20C-A to AC40C-A



How to Order



- Option/Semi-standard: Select one each for a to j.
- Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AC30C-F03DM-SV-1NR-A

	_							D	
				Symbol	Description		Body	/ size	
						20	25	30	40
				_	Rc	•	•	•	•
2		Th	read type	N	NPT		•	•	•
				F	G		•	•	•
				+					
				01	1/8		_	_	_
				02	1/4		•	•	•
3			Port size	03	3/8	_	•	•	•
				04	1/2	_	_	_	•
				06	3/4	_	_	_	•
				+				'	
			· ·	_	Without auto drain		•	•	•
_	_	а	Float type auto drain	CNote 2)	N.C. (Normally closed) Drain port is closed when pressure is not applied.		•	•	•
100	1016		auto urain	D ^{Note 3)}	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•	•
4	Option Note 1)			+			•		
	ğ.		Dunnanuna	_	Without pressure gauge		•	•	•
- 1		b	Pressure gauge Note 4)	G	Round type pressure gauge (with limit indicator)		•	•	•
			gauge	M	Round type pressure gauge (with colour zone)		•	•	•
				+					
			Pressure		Without attachment				
	ŧ∣	С	switch	S Note 5)	Mounting position: AF+AFM+S+AR		•		
	me		T-shaped spacer	T Note 5)	Mounting position: AF+AFM+ T +AR				
6	Attachment			+					
;	Att		Pressure relief		Without attachment		•	•	•
		d	3 port valve	V	Mounting position: AF+AFM+AR+V		•	•	•
				V1 Note 6)	Mounting position: V+AF+AFM+AR		•	•	
	_			+					
		е	Set		0.05 to 0.7 MPa setting		•	•	
			pressure Note 7)	1	0.02 to 0.2 MPa setting		•		
				+					
					Polycarbonate bowl		•	•	•
				2	Metal bowl		•	•	•
		f	Bowl	6	Nylon bowl		•	•	•
	standard			8	Metal bowl with level gauge		•	•	•
	and			С	With bowl guard			_	_
				6C	With bowl guard (Nylon bowl)		_		_
	Semi			+					_
(S		Filter		With drain cock		•	•	•
		g	Mist separator	J Note 8)	Drain guide 1/8				_
			drain port		Drain guide 1/4		•	•	•
				W Note 11)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)				
				+			_		_
		h	Exhaust		Relieving type				•
		n	mechanism	N	Non-relieving type		•	•	

Air Combination Series AC20C-A to AC40C-A



				Symbol	Description		Body	/ size	
						20	25	30	40
	ırd		Elevery Constitution	_	Flow direction: Left to right	•	•	•	•
	standard	1	Flow direction	R	Flow direction: Right to left	•	•	•	•
6	sta			+		,			
	Semi-		Dunnait	_	Name plate and pressure gauge in imperial units: MPa	•	•	•	•
			Pressure unit	Z Note 9)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O Note 10)	Note 10)	Note 10)	Note 10)

- Note 1) Option G, M are not assembled and supplied loose at the time of shipment.
- Note 2) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 3) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- Note 4) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 5) The bracket position varies depending on the T-shaped spacer or pressure switch mounting.
- Note 6) Make sure that the outlet pressure is released to atmospheric pressure using a pressure gauge. For V1 specification, use the regulator with a
 - set pressure of 0.15 MPa or more to ensure the pressure release.
- Note 7) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

- Note 8) Without a valve function
- Note 9) For thread type: NPT.
 - MPa and psi are shown together on the pressure unit.
 - Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.
- Note 10) O: For thread type: NPT only
- Note 11) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications

	Model	AC20C-A	AC25C-A	AC30C-A	AC40C-A	AC40C-06-A						
	Air Filter	AF20-A	AF30-A	AF30-A	AF40-A	AF40-06-A						
Component	Mist Separator	AFM20-A	AFM30-A	AFM30-A	AFM40-A	AFM40-06-A						
	Regulator	AR20-A	AR25-A	AR30-A	AR40-A	AR40-06-A						
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Pressure gaug	ge port size	1/8										
Fluid				Air								
Ambient and f	luid temperature	- 5 to 60°C (with no freezing)										
Proof pressure	е			1.5 MPa								
Maximum ope	rating pressure			1.0 MPa								
Minimum oper	rating pressure			0.05 MPa								
Set pressure r	ange	0.05 to 0.7 MPa										
Nominal filtrat	ion rating	AF: 5 μm, AFM: 0.3 μm (99.9% filtered particle size)										
Outlet side oil n	nist concentration		MAX 1.0 mg/m³ (ANR) (≈ 0.8 ppm) Note 2) Note 3)									
Rated flow [L/	min (ANR)] Note 1)	200	450	450	1100	1100						
Bowl material				Polycarbonate								
Bowl guard		Semi-standard (Steel) Standard (Polycarbonate)										
Regulator con	struction	Relieving type										
Weight [kg]		0.38	0.67	0.82	1.26	1.42						

Note 1) Conditions: Mist separator inlet pressure: 0.7 MPa; The rated flow varies depending on the inlet pressure.


Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side. Note 2) When the compressor oil mist discharge concentration is 30 mg/m³ (ANR).


Note 3) Bowl O-ring and other O-rings are slightly lubricated.



Series AC20C-A to AC40C-A

Dimensions





Applicable model			AC25	C-A to AC40C-06-A		
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting
Dimensions	a	Width across flats 17	m m	Width across flats 17	Width across flats 17	Barb fitting Applicable tubing: T0604

		Standard specifications															
Model	P ₁	P ₂	P ₂ A B C E F G J							Bracke	Bracket mount						
	Pi	P2	Α	В	C		-	G	J	M	N	Q1	Q2	R	S	U	V
AC20C-A	1/8, 1/4	1/8	126.4	87.6	23.5	_	41.6	40	23.4	30	43.2	24	33	5.5	12	3.5	29
AC25C-A	1/4, 3/8	1/8	167.4	115.1	23.5	30	55.1	50	30.5	41	57.2	35	_	7	14	4	41
AC30C-A	1/4, 3/8	1/8	167.4	115.1	27	30	55.1	50	30.5	41	57.2	35	_	7	14	4	41
AC40C-A	1/4, 3/8, 1/2	1/8	220.4	147.1	33.5	38.4	72.6	75	36.1	50	75.2	40	_	9	18	5	48
AC40C-06-A	3/4	1/8	235.4	149.1	33.5	38.4	77.6	75	39.6	50	80.2	40	-	9	18	5	48


		Optio	nal specific	ations			Semi-standard specifications							
Model	Round type pressure gauge		Round type pressure gauge (with colour zone)		With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide			
	Н	J	Н	J	В	В	В	В	В	В	В			
AC20C-A	ø37.5	58.5	ø37.5	59.5	104.9	_	91.4	87.4	93.9	_	_			
AC25C-A	ø37.5	58.5	ø37.5	59.5	156.8	123.6	121.9	117.6	122.1	137.6	142.1			
AC30C-A	ø37.5	65	ø37.5	66	156.8	123.6	121.9	117.6	122.1	137.6	142.1			
AC40C-A	ø42.5	72	ø42.5	72	186.9	155.6	153.9	149.6	154.1	169.6	174.1			
AC40C-06-A	ø42.5	72	ø42.5	72	188.9	157.6	155.9	151.6	156.1	171.6	176.1			

SMC

Filter Regulator + Mist Separator

AC20D-A to AC40D-A

Symbol



How to Order



- Option/Semi-standard: Select one each for a to j.
- Option/Attachment/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AC30D-F03DM-SV-1NR-A

	_					0	
			Symbol	Description		Body size	
					20	30	40
			_	Rc	•	•	•
	T	nread type	N	NPT	•	•	•
		, , , , , , , , , , , , , , , , , , ,	F	G	•	•	•
			+	<u> </u>			
			01	1/8	•	_	_
			02	1/4	•	•	•
		Port size 03		3/8	_	Body size 20 30 40	•
			04	1/2	_	_	•
			06	3/4	_	_	
			+				
			_	Without auto drain		•	•
	а	Float type	C Note 2)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•
Option Note 1)		auto drain	D Note 3)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•
Ž			+	, , , , , , , , , , , , , , , , , , ,			
ptic			_	Without pressure gauge	•	•	•
0	b	Pressure	G	Round type pressure gauge (with limit indicator)	•	•	•
		gauge Note 4)	M	Round type pressure gauge (with colour zone)	•		•
			+	gauge (
		Pressure		Without attachment	•		
۱ŧ	С	switch	S Note 5)	Mounting position: AW+S+AFM			
Attachment			+	The same of the sa			
딣			_	Without attachment	•		•
Att	d	Pressure relief	V	Mounting position: AW+AFM+V	•	•	•
		3 port valve	V1 Note 6)	Mounting position: V+AW+AFM	•	•	•
			+				
		Set	_	0.05 to 0.7 MPa setting		•	•
	е	pressure Note 7)	1	0.02 to 0.2 MPa setting	•	•	•
			+				
			_	Polycarbonate bowl		•	•
			2	Metal bowl	•	•	•
		D. I	6	Nylon bowl	•	•	•
	f	Bowl	8	Metal bowl with level gauge	_	•	•
			С	With bowl guard	•	_	_
laro			6C	With bowl guard (Nylon bowl)	•	_	_
andard			+				
i-sta			_	With drain cock	•	•	•
Semi-st		Filter regulator	J Note 8)	Drain guide 1/8	•	_	_
Š	g	Mist separator	J Note 8)	Drain guide 1/4	_	•	•
		drain port	W Note 11)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_		
			+	J. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			
		Exhaust	_	Relieving type	•		
	h	mechanism	N	Non-relieving type	•	_	
			+	· · · · · · · · · · · · · · · · · · ·			
				Flow direction: Left to right	•		
	i	Flow direction	R	Flow direction: Right to left		•	•

Air Combination Series AC20D-A to AC40D-A



AC20D-A

AC40D-A

	Symbol	Description
Brossure unit	_	Name plate and pressure gauge in imperial units: MPa
6 Pressure unit	Z Note 9)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F
Note 1) Option G. M are not asse	embled an	d supplied Note 4) When the pressure gauge is attached, a

- loose at the time of shipment.
- Note 2) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 3) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 5) The bracket position varies depending on the pressure switch mounting.
- Note 6) Make sure that the outlet pressure is released to atmospheric pressure using a pressure gauge.
 - For V1 specification, use the regulator with a set pressure of 0.15 MPa or more to ensure the pressure release.

	Body size												
20	30	40											
•	•	•											
Note 10)	Note 10)	Note 10)											
Note 7) Dressure can be set higher than the													

Note 7) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

Note 8) Without a valve function

Note 9) For thread type: NPT.

MPa and psi are shown together on the pressure unit.

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 10) O: For thread type: NPT only

Note 11) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications

	Model	AC20D-A	AC30D-A	AC40D-A	AC40D-06-A						
Company	Filter Regulator	AW20-A	AW30-A	AW40-A	AW40-06-A						
Component	Mist Separator	AFM20-A	AFM30-A	AFM40-A	AFM40-06-A						
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Pressure gauge	e port size	1/8									
Fluid		Air									
Ambient and fl	luid temperature	− 5 to 60°C (with no freezing)									
Proof pressure	;	1.5 MPa									
Maximum oper	rating pressure	1.0 MPa									
Minimum opera	ating pressure	0.05 MPa									
Set pressure ra	ange	0.05 to 0.7 MPa									
Nominal filtrati	on rating	A\	W: 5 μm, AFM: 0.3 μm (99.9% filtered particle size)							
Rated flow [L/r.	min (ANR)] Note 1)	150	330	800	800						
Outlet side oil	mist concentration		MAX 1.0 mg/m³ (ANR)	d) (≈ 0.8 ppm) Note 2) Note 3)							
Bowl material			Polyca	rbonate							
Bowl guard		Semi-standard (Steel) Standard (Polycarbonate)									
Regulator cons	struction		Relievi	ing type							
Weight [kg]		0.32	0.65	1.22	1.34						

Note 1) Conditions: Mist separator inlet pressure: 0.5 MPa; The rated flow varies depending on the inlet pressure.


Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.


Note 2) When the compressor oil mist discharge concentration is 30 mg/m³ (ANR).

Note 3) Bowl O-ring and other O-rings are slightly lubricated.

Series AC20D-A to AC40D-A

Dimensions





Applicable model			AC30I	D-A to AC40D-06-A		
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting
Dimensions	a	Width across flats 14	a v	Width across flats 17	Width across flats 17	Barb fitting Applicable tubing: T0604

		Standard specifications														
Model	P ₁	P ₂	Δ.	В	C Note)	Е	_	G				Br	acket mou			
	FI	P2	A	В	C Note)		F	G	J	M	Q ₁	Q2	R	S	U	V
AC20D-A	1/8, 1/4	1/8	83.2	87.6	67.4	_	41.6	40	23.4	30	24	33	5.5	12	3.5	29
AC30D-A	1/4, 3/8	1/8	110.2	115.1	83.5	30	55.1	50	30.5	41	35	_	7	14	4	41
AC40D-A	1/4, 3/8, 1/2	1/8	145.2	147.1	100	38.4	72.6	75	36.1	50	40	_	9	18	5	48
AC40D-06-A	3/4	1/8	155.2	149.1	101.5	38.4	77.6	75	39.6	50	40	_	9	18	5	48

	Optional specifications						Semi-standard specifications						
Model	Round type pressure gauge				With auto drain	With barb fitting	I IMETAL DOW		Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide		
	Н	J	Н	J	В	В	В	В	В	В	В		
AC20D-A	ø37.5	58.5	ø37.5	59.5	104.9	_	91.4	87.4	93.9	_	_		
AC30D-A	ø37.5	65	ø37.5	66	156.8	123.6	121.9	117.6	122.1	137.6	142.1		
AC40D-A	ø42.5	72	ø42.5	72	186.9	155.6	153.9	149.6	154.1	169.6	174.1		
AC40D-06-A	ø42.5	72	ø42.5	72	188.9	157.6	155.9	151.6	156.1	171.6	176.1		

Note) The total length of C dimension is the length when the filter regulator knob is unlocked.



Air Combination Series AC Options/Attachments

Options/Attachments Part No.


					Part no.				
_			For AC20-A	For AC25-A	For AC30-A	For AC40-A	For AC40-06-A		
tior		Model	For AC20A-A	_	For AC30A-A	For AC40A-A	For AC40A-06-A		
Section	Туре		For AC20B-A	For AC25B-A	For AC30B-A	For AC40B-A	For AC40B-06-A		
(0)			For AC20C-A	For AC25C-A	For AC30C-A	For AC40C-A	For AC40C-06-A		
			For AC20D-A	_	For AC30D-A	For AC40D-A	For AC40D-06-A		
_	Round type Round type Round type (with color zone)	Standard		G36-10-□01		G46-1	0-□01		
Option	_{ම්} type	0.02 to 0.2 MPa setting		G36-4-□01		G46-4	4-□01		
pd	Round typ	oe Standard		G36-10-□01-L		G46-10)-□01-L		
Ľ	을 (with cold	o.02 to 0.2 MPa setting Standard 0.02 to 0.2 MPa setting		G36-4-□01-L		G46-4	-□01-L		
	Spacer		Y200-A	Y30	00-A	Y400-A	Y500-A		
	Spacer w	ith bracket	Y200T-A	Y30	OT-A	Y400T-A	Y500T-A		
	Check valve Note 2) Note 3)		AKM2000-□01-A	AKM300	0-(□01)-A	AKM4000-(□02)-A	_		
			(□02)-A		□02-A	□03-A	_		
	Pressure switch Note 3)		IS10M-20-A	IS10N	M-30-A	IS10M-40-A	IS10M-50-A		
	T-shaped spacer Note 2) Note 3)		Y210-□01-A	Y310-((□01)-A	Y410-(□02)-A	Y510-(□02)-A		
	1-Silapeu	Spacei	(□02)-A		□02-A	□03-A	□03-A		
1.	Pressure	roliof	VHS20-□01A	VHCo	0-□02A	□02A			
en	3 port val		VH320-⊟01A □02A	VIISS	□03A	VHS40-□03A	VHS40-□06A		
Attachment	o port var	ve /	□02A		⊔USA	□04A			
ac			□01-A		□02-A	□02-A			
ΑĦ	Dining od	apter Note 3)	E200-□02-A		-□03-A	E400-□03-A	E500-□06-A		
	ripiliy au	apiei	□03-A		□04-A	□04-A			
						□06-A			
			□01-A		□02-A	□02-A			
		switch with	IS10E-20□02-A	IS10F-3	30□03-A	IS10E-40□03-A	_		
	piping ad	g adapter Note 3)		10102	□04-A	□04-A	_		
						□06-A			
	Cross en	acer Note 3)	Y24-□01-A	Y34-[□01-A	Y44-□02-A	Y54-□03-A		
	orosa spe	20C1 ·····/	□02-A	[□02-A	□03-A	□04-A		

Note 1) ☐ in part numbers for a round pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for psi unit specifications.

Note 2) For F.R.L. units, port sizes without () are standard specifications.

Check Valve: (K) 1/8, 1/4, 3/8


A check valve with intermediate air release port can be easily installed to prevent a backflow of lubricant when redirecting the air flow and releasing the air on the outlet side of the regulator.



Note 3) Separate interfaces are required for modular unit.

Pressure Switch: (S)

A compact integrated pressure switch can be easily installed and facilitates the pressure detection of the line.



- \bullet Semi-standard: Select one each for ${\bf a}$ to ${\bf c}.$
- Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) IS10M-30-6LP

			·						
			Symbol	Description	Body size				
						20	30	40	50
			Set pressure	_	0.1 to 0.4 MPa				
	ठ	а	range	6 Note 1)	0.1 to 0.6 MPa		•	•	
	lar			+					
	=			I	0.5 m		•	•	
2	-standard	b	Lead wire	L	3 m		•	•	
	<u> </u>		length	Z	5 m				
	Semi			+					
	တ	С	Pressure unit of		MPa				
			the scale plate	P Note 2)	MPa/psi dual scale				

Note 1) Set pressure range of 6P (L, Z) is 0.2 to 0.6 MPa (30 to 90 psi).

Specifications

Opcomoduono	
Fluid	Air
Ambient and fluid temperature	-5 to 60°C (with no freezing)
Proof pressure	1.0 MPa
Maximum operating pressure	0.7 MPa
Set pressure range (when OFF)	0.1 to 0.4 MPa
Hysteresis	0.08 MPa or less

Switch Characteristics


Contact point configuration	1a
Maximum contact point capacity	2 VA (AC), 2 W (DC)
Operating voltage: AC, DC	100 V or less
Maximum operating current	12 V to 24 VAC, DC: 50 mA 48 VAC, DC: 40 mA 100 VAC, DC: 20 mA

Note) For detailed specifications on the IS10 series, please refer to the section of our website IS10 series, http://www.smc.eu

Symbol







Model	Α	В	С	D	Applicable model
IS10M-20-A	10.6	74.2	64.4	28	AC20□-A
IS10M-30-A	12.6	84.5	70.5	30	AC25□-A, AC30□-A
IS10M-40-A	14.6	93.3	75.3	36	AC40□-A
IS10M-50-A	16.6	97.3	77.3	44	AC40□-06-A

^{*} Separate spacers are required for modular unit.

T-shaped Spacer: (T) 1/8, 1/4, 3/8


Using a T-shaped spacer facilitates the branching of air flow.





Caution on Mounting

If a T-shaped spacer is used on the IN side of the lubricator, lubricant may be mixed. Use the AKM series check valve to avoid such possibility.



Model Note)	Port size	Α	В	C	D	ш	Applicable model
Y210-□01-A	1/8	14.6	41.8	32	28	19	AC20-A, AC20B-A
Y210-□02-A	1/4	14.0				10	AC20C-A
Y310-□01-A	1/8	14.6	52.7	38.7	30	19	AC25-A, AC25B-A AC25C-A, AC30-A
Y310-□02-A	1/4	14.0	52.7				AC30B-A, AC30C-A
Y410-□02-A	1/4	18.6	62	44	36	24	AC40-A, AC40B-A
Y410-□03-A	3/8	10.0	02	44	30	4	AC40C-A
Y510-□02-A	1/4	18.6	66	46	44	24	AC40-06-A, AC40B-06-A
Y510-□03-A	3/8	10.0	00	40	44	24	AC40C-06-A

Note) \square in model numbers indicates a thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.


- * Separate interfaces are required for modular unit.
- * Refer to the attachment table on page 22 for standard port sizes when using with the AC.



AFM / AFD


Pressure Relief 3 Port Valve: (V)

With the use of a pressure relief 3 port valve, pressure left in the line can be easily exhausted.



- Semi-standard: Select one each for a to b.
- Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) VHS30-03A-RZ




Note) For thread type: NPT only.

Specifications

Opcomo	ationic												
	Port size		Specifications										
Model	INI OLIT	EXH	IN ·	→ OUT		OUT → EXH							
	IIN, OUT		C(dm3/s·bar)	b	Cv	C(dm3/s·bar)	b	Cv					
VHS20	1/8	1/8	2.4	0.43	0.65	2.5	0.39	0.69					
	1/4	1/6	3.3	0.40	0.88	3.1	0.51	0.84					
VHS30	1/4	1/4	6.4	0.45	1.7	6.2	0.38	1.7					
VH530	3/8	1/4	8.3	0.41	2.3	7.0	0.41	1.9					
	1/4		7.3	0.49	2.0	8.5	0.35	2.3					
VHS40	3/8	3/8	10.9	0.45	3.0	11.6	0.40	3.1					
	1/2		14.2	0.39	3.8	13.3	0.43	3.6					
VHS40-06	3/4	1/2	18.3	0.31	5.0	17.7	0.37	4.8					
Note\ Llee or	oir filto	an th	a INI aida fa		tina nro	tootion							

Note) Use an air filter on the IN side for operating protection.

Pressure relief 3 port valve OUT (Port size)



EXH


Standard specifications											
P 1	P ₂	Α	В	C	D	Е	E	G	Н	1	
1/8, 1/4	1/8	66.4	22.3	40	37.5	14	46.6	33.6	28	37.5	
1/4, 3/8	1/4	80.3	29.4	53	49	19	52	38	30	49	
1/4, 3/8, 1/2	3/8	104.9	38.5	70	63	22	58	44	36	63	
3/4	1/2	110.4	42	75	63	22	58	44	44	63	
1	1/8, 1/4 1/4, 3/8 1/4, 3/8, 1/2	1/8, 1/4	P1 P2 A 1/8, 1/4 1/8 66.4 1/4, 3/8 1/4 80.3 1/4, 3/8, 1/2 3/8 104.9	P1 P2 A B 1/8, 1/4 1/8 66.4 22.3 1/4, 3/8 1/4 80.3 29.4 1/4, 3/8, 1/2 3/8 104.9 38.5	P1 P2 A B C 1/8, 1/4 1/8 66.4 22.3 40 1/4, 3/8 1/4 80.3 29.4 53 1/4, 3/8, 1/2 3/8 104.9 38.5 70	P1 P2 A B C D 1/8, 1/4 1/8 66.4 22.3 40 37.5 1/4, 3/8 1/4 80.3 29.4 53 49 1/4, 3/8, 1/2 3/8 104.9 38.5 70 63	P1 P2 A B C D E 1/8, 1/4 1/8 66.4 22.3 40 37.5 14 1/4, 3/8 1/4 80.3 29.4 53 49 19 1/4, 3/8, 1/2 3/8 104.9 38.5 70 63 22	P1 P2 A B C D E F 1/8, 1/4 1/8 66.4 22.3 40 37.5 14 46.6 1/4, 3/8 1/4 80.3 29.4 53 49 19 52 1/4, 3/8, 1/2 3/8 104.9 38.5 70 63 22 58	P1 P2 A B C D E F G 1/8, 1/4 1/8 66.4 22.3 40 37.5 14 46.6 33.6 1/4, 3/8 1/4 80.3 29.4 53 49 19 52 38 1/4, 3/8, 1/2 3/8 104.9 38.5 70 63 22 58 44	P1 P2 A B C D E F G H 1/8, 1/4 1/8 66.4 22.3 40 37.5 14 46.6 33.6 28 1/4, 3/8 1/4 80.3 29.4 53 49 19 52 38 30 1/4, 3/8, 1/2 3/8 104.9 38.5 70 63 22 58 44 36	

Cross Spacer: 1/8, 1/4, 3/8, 1/2

Pipings are possible in all 4 directions.


IN/OUT ports are not machined for threads.

Please contact SMC if threaded (machined) ports are required.



Caution on Mounting

- When mounting a cross spacer directly on the IN side of the lubricator, be sure to use the AKM series check valve between the lubricator and cross spacer.
- 2. Factory mounting of a cross spacer on the AC model is available as a special order.




E: 4 x Rc
F: Without thread

Model Note)	Port size	Α	В	C	D	Applicable model	
Y24-□01-A	1/8	40	40	22	40	AC20□-A	
Y24-□02-A	1/4	40	40	22	40	AC2U⊔-A	
Y34-□01-A	1/8	49	43	28	48	AC25□-A, AC30□-A	
Y34-□02-A	1/4	49	40				
Y44-□02-A	1/4	60	48	36	54	AC40□-A	
Y44-□03-A	3/8	00	40			AC40⊔-A	
Y54-□03-A	3/8	72	62	40	62	AC40□-06-A	
Y54-□04-A	1/2	12	02	40	02	AC40	

- Note) \Box in model numbers indicates a thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.
- * If threaded IN/OUT ports are required, they are available as a special order. Please contact SMC.
- st Two hexagon socket head plugs are included in the package.

Piping Adapter: 1/8, 1/4, 3/8, 1/2, 3/4



Model Note)	Port size	Α	В	D	Applicable model	
E200-□01-A	1/8					
E200-□02-A	1/4	29.8	23.5	28	AC20□-A	
E200-□03-A	3/8					
E300-□02-A	1/4					
E300-□03-A	3/8	31.8	30	30	AC25□-A, AC30□-A	
E300-□04-A	1/2					
E400-□02-A	1/4					
E400-□03-A	3/8	31.8	36	36	AC40□-A	
E400-□04-A	1/2	31.6	36	30	AC40⊔-A	
E400-□06-A	3/4					
E500-□06-A	3/4	31.8	40	44	AC40□-06-A	

Note) \square in model numbers indicates a thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.

Right

m


Centre of F.R.L. body

Pressure switch with piping adapter

- * Separate interfaces are required for modular unit.
- * Factory mounting of a piping adapter on the AC models is available as a special order.


Symbol

Pressure Switch with Piping Adapter



- Semi-standard: Select one each for a to d.
- Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) IS10E-30N03-6PRZ

				_					J
		_		Symbol	Description	20	ody siz	ze 40	
			-		р.				1
					Rc		•	-	-
2		Th	read type	N Note)	NPT				4
				F Note)	G				
				+					_
				01	1/8		<u> </u>	<u> </u>	╛
_				02	1/4				
3		F	Port size	03	3/8				1
				04	1/2				1
				06	3/4		T —		1
				+			•		•
			Set pressure	_	0.1 to 0.4 MPa]
		а	range	6 Note 1)	0.1 to 0.6 MPa				1
				+					,
	-			_	0.5 m				1
	lar	b	Lead wire	L	3 m				1
	l a		length	Z	5 m		ě		1
4	Semi-standard			+	- · · ·				1
	ı iii		Pressure unit of		MPa				1
	S	С	the scale plate	P Note 2)	MPa/psi dual scale				1
				+	i a poi dudi ocale				1
			Mounting	<u>-</u>	Right				1
		d	position	R	Left				1
			FILMON		Leit]



Note 2) For thread type: NPT only.

Specifications

Fluid	Air
Ambient and fluid temperature	-5 to 60°C (with no freezing)
Proof pressure	1.0 MPa
Maximum operating pressure	0.7 MPa
Set pressure range (when OFF)	0.1 to 0.4 MPa
Hysteresis	0.08 MPa or less

Switch Characteristics

Contact point configuration	1a
Maximum contact point capacity	2 VA (AC), 2 W (DC)
Operating voltage: AC, DC	100 V or less
Maximum operating current	12 V to 24 V AC, DC: 50 mA 48 V AC, DC: 40 mA 100 V AC, DC: 20 mA

Model Note 1)	Port size	Α	В	O	D	Е	Applicable model			
IS10E-20□01-A	1/8									
IS10E-20□02-A	1/4	29.8	66.3	55.3	28	16	AC20□-A			
IS10E-20□03-A	3/8									
IS10E-30□02-A	1/4		72.8	58.8			AC25□-A, AC30□-A			
IS10E-30□03-A	3/8	31.8			30	13				
IS10E-30□04-A	1/2									
IS10E-40□02-A	1/4									
IS10E-40□03-A	3/8	04.0	70.0	00.0	07	10.5	Note 2) AC40 □-A			
IS10E-40□04-A	1/2	31.8	78.8	60.8	37	12.5	AC40⊔-A			
IS10E-40□06-A	3/4									

Port

Note 1) \square in the model numbers indicates a thread type. No indication is necessary for Rc; however, indicate N for NPT, and F for G.

Note 2) Cannot be mounted on the AC40□-06-A.

- * Separate interfaces are required for modular unit.
- * The pressure switch on the AC40□-06-A can be mounted by screwing IS10-01S into the piping adapter E500-□06-A-X501 (with top-face thread Rc1/8). Products with a premounted switch are available as a special order. Please contact SMC regarding their availability.




Accessories (Spacers/Brackets)

Spacer




Model	Α	В	С	D	Applicable model
Y200-A	3.2	22.4	11.2	44.9	AC20□-A
Y300-A	4.2	34.2	17.1	57.9	AC25□-A, AC30□-A
Y400-A	5.2	42.2	21.1	68.5	AC40□-A
Y500-A	5.2	46.2	23.1	75.6	AC40□-06-A



Replacement Parts

Description	Material		Part	no.	
Description	iviateriai	Y200-A	Y300-A	Y400-A	Y500-A
Seal	HNBR	Y220P-050S	Y320P-050S	Y420P-050S	Y520P-050S

Spacer with Bracket




Model	Α	В	С	D	Е	EE	F	G	Н	J	K	Applicable model
Y200T-A	3.2	67	29	53.4	24	33	12	5.5	15.5	3.5	30	AC20□-A
Y300T-A	4.2	82	41	71.5	35	_	14	7	19	4	41	AC25□-A, AC30□-A
Y400T-A	5.2	96	48	86.1	40	_	18	9	26	5	50	AC40□-A
Y500T-A	5.2	96	48	89.6	40	_	18	9	26	5	50	AC40□-06-A

Replacement Parts

Description	Motorial		Parl	no.	
Description	Material	Y200T-A	Y300T-A	Y400T-A	Y500T-A
Seal	HNBR	Y220P-050S	Y320P-050S	Y420P-050S	Y520P-050S

Mounting Position for Spacer with Bracket



Attachment		K			S	1			٧			KS			KT			K	V			KST	
Model	A1	A2	A3	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	A4	A1	A2	A3
AC20-A	41.6	43.2	43.2	41.6	43.2	41.6	61	41.6	43.2	43.2	41.6	43.2	57	41.6	61	43.2	41.6	43.2	43.2	43.2	41.6	61	57
AC25-A	55.1	57.2	57.2	55.1	57.2	55.1	76	55.1	57.2	57.2	55.1	57.2	74	55.1	76	57.2	55.1	57.2	57.2	57.2	55.1	76	74
AC30-A	55.1	57.2	57.2	55.1	57.2	55.1	76	55.1	57.2	57.2	55.1	57.2	74	55.1	76	57.2	55.1	57.2	57.2	57.2	55.1	76	74
AC40-A	72.6	75.2	75.2	72.6	75.2	72.6	99	72.6	75.2	75.2	72.6	75.2	95	72.6	99	75.2	72.6	75.2	75.2	75.2	72.6	99	95
AC40-06-A	_	_	_	77.6	80.2	77.6	104	77.6	80.2	80.2	_	_	_	_	_	_	_	_	_		_	_	_

Attachment		KS	SV			K٦	ΓV		KSTV					Т		SV		STV			TV		
Model	A1	A2	A3	A4	A1	A2	A3	A4	A1	A2	A3	A4	A1	A2	A1	A2	A3	A1	A2	А3	A1	A2	A3
AC20-A	41.6	43.2	57	43.2	41.6	61	43.2	43.2	41.6	61	57	43.2	41.6	61	41.6	43.2	57	41.6	61	57	41.6	61	43.2
AC25-A	55.1	57.2	74	57.2	55.1	76	57.2	57.2	55.1	76	74	57.2	55.1	76	55.1	57.2	74	55.1	76	74	55.1	76	57.2
AC30-A	55.1	57.2	74	57.2	55.1	76	57.2	57.2	55.1	76	74	57.2	55.1	76	55.1	57.2	74	55.1	76	74	55.1	76	57.2
AC40-A	72.6	75.2	95	75.2	72.6	99	75.2	75.2	72.6	99	95	75.2	72.6	99	72.6	75.2	95	72.6	99	95	72.6	99	75.2
AC40-06-A	_	_		_	_	_	_	_	_	_		_	77.6	104	77.6	80.2	102	77.6	104	102	77.6	104	80.2

Attachment			S	V		K	S		KV			KSV		S	V
Model	A1	A2	A1	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2
AC20A-A	41.6	43.2	41.6	41.6	43.2	41.6	57	41.6	43.2	43.2	41.6	57	43.2	41.6	57
AC30A-A	55.1	57.2	55.1	55.1	57.2	55.1	74	55.1	57.2	57.2	55.1	74	57.2	55.1	74
AC40A-A	72.6	75.2	72.6	72.6	75.2	72.6	95	72.6	75.2	75.2	72.6	95	75.2	72.6	95
AC40A-06-A	_	_	77.6	77.6	80.2	_	_	_	_	_	_	_	_	77.6	102

Attachment	S	T	١ ١	V		V1		V	S١	/1	Т	V	T\	/1
Model	A1	A1	A1	A2	A1	A2	A1	A2	A1	A2	A1	A2	A1	A2
AC20B-A	41.6	41.6	41.6	43.2	41.6	43.2	41.6	57	41.6	43.2	41.6	61	41.6	43.2
AC25B-A	55.1	55.1	55.1	57.2	55.1	57.2	55.1	74	55.1	57.2	55.1	76	55.1	57.2
AC30B-A	55.1	55.1	55.1	57.2	55.1	57.2	55.1	74	55.1	57.2	55.1	76	55.1	57.2
AC40B-A	72.6	72.6	72.6	75.2	72.6	75.2	72.6	95	72.6	75.2	72.6	99	72.6	75.2
AC40B-06-A	77.6	77.6	77.6	80.2	77.6	80.2	77.6	102	77.6	80.2	77.6	104	77.6	80.2

Attachment S		T V		V1		SV		SV1		TV		TV1										
Model	A1	A2	A1	A2	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	A3	A1	A2	А3	A1	A2	A3
AC20C-A	41.6	43.2	41.6	43.2	41.6	43.2	43.2	41.6	43.2	43.2	41.6	43.2	57	41.6	43.2	43.2	41.6	43.2	61	41.6	43.2	43.2
AC25C-A	55.1	57.2	55.1	57.2	55.1	57.2	57.2	55.1	57.2	57.2	55.1	57.2	74	55.1	57.2	57.2	55.1	57.2	76	55.1	57.2	57.2
AC30C-A	55.1	57.2	55.1	57.2	55.1	57.2	57.2	55.1	57.2	57.2	55.1	57.2	74	55.1	57.2	57.2	55.1	57.2	76	55.1	57.2	57.2
AC40C-A	72.6	75.2	72.6	75.2	72.6	75.2	75.2	72.6	75.2	75.2	72.6	75.2	95	72.6	75.2	75.2	72.6	75.2	99	72.6	75.2	75.2
AC40C-06-A	77.6	80.2	77.6	80.2	77.6	80.2	80.2	77.6	80.2	80.2	77.6	80.2	102	77.6	80.2	80.2	77.6	80.2	104	77.6	80.2	80.2

Attachment	S	V		V	1	S	V	SV1		
Model	A1	A1	A2	A1	A2	A1	A2	A1	A2	
AC20D-A	41.6	41.6	43.2	41.6	43.2	41.6	57	41.6	43.2	
AC30D-A	55.1	55.1	57.2	55.1	57.2	55.1	74	55.1	57.2	
AC40D-A				72.6			95	72.6	75.2	
AC40D-06-A	77.6	77.6	80.2	77.6	80.2	77.6	102	77.6	80.2	

- A1: Dimensions from the end of the IN side to the center of the mounting hole for the first bracket.
- A2: Mounting hole pitch between the first and the second brackets.
- A3: Mounting hole pitch between the second and the third brackets.
 A4: Mounting hole pitch between the third and the fourth brackets.

ΑF

Modular Type Air Filters

Series AF/AFM/AFD

Air Filter Series AF	Model	Port size	Filtration μm	Options
	AF20-A	1/8, 1/4		
	AF30-A	1/4, 3/8	5	Bracket
	AF40-A	1/4, 3/8, 1/2	5	Float type auto drain
P.29 to 37	AF40-06-A	3/4		
Mist Separator Series AFM	AFM20-A	1/8, 1/4		
THE T	AFM30-A	1/4, 3/8	0.3	Bracket
	AFM40-A	1/4, 3/8, 1/2		Float type auto drain
P.39 to 46	AFM40-06-A	3/4		
Micro Mist Separator Series AFD	AFD20-A	1/8, 1/4		
men.	AFD30-A	1/4, 3/8	0.01	Bracket
	AFD40-A	1/4, 3/8, 1/2	0.01	Float type auto drain
P.39 to 46	AFD40-06-A			

Air Filter

AF20-A to AF40-A

Symbol

Air Filter

Air Filter with Auto Drain










AF20-A

AF40-A

How to Order



Option/Semi-standard: Select one each for **a** to **f**.

 Option/Semi-standard symbol: When more than 6.

• Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AF30-03BD-R-A

					(Refer to pages 36 and 37 for details.)					
	_	_				Body size				
				Symbol	Description					
						20	30	40		
				_	Rc	•	•	•		
2	Thread type N Note :				NPT	•	•	•		
				F Note 2)	G	•	•	•		
				+						
				01	1/8	•	_	_		
				02	1/4	•	•	•		
3	3 Port size			03	3/8	_	•	•		
				04	1/2	_	_	•		
					3/4	_	_	•		
				+						
			Mounting	_	Without mounting option	•	•	•		
		а	Mounting	B Note 3)	With bracket	•	•	•		
	Option			+						
4	Opt		□ + + · ·	_	Without auto drain	•	•			
	_	b	Float type auto drain	C Note 4)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•		
			dato didiri	D Note 5)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•		
				+						
			Bowl Note 6)	_	Polycarbonate bowl	•	•			
		С		2	Metal bowl		•			
				6	Nylon bowl	•	•	•		
				8	Metal bowl with level gauge	_	•	•		
				С	With bowl guard	•	Note 7)	Note 7)		
				6C	With bowl guard (Nylon bowl)	•	Note 7)	Note 7)		
	ard			+						
	nde			_	With drain cock	•	•			
6	sta	d	Drain port ^{Note 11)}	J Note 8)	Drain guide 1/8	•	_	_		
	Semi-standard				Drain guide 1/4	_	•	•		
	Se			W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•			
				+						
		е	Flow direction	_	Flow direction: Left to right	•	•	•		
		-	1 low direction	R	Flow direction: Right to left	•	•	•		
				+						
		f	Pressure unit	_	Name plate and caution plate for bowl in imperial units: MPa	•	•	•		
		•	1 1033u10 u1llt	Z Note 9)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 10)	Note 10)	Note 10)		

Note 1) Drain guide is NPT1/8 (applicable to the AF20-A) and NPT1/4 (applicable to the AF30-A to AF40-A).

The auto drain port comes with ø3/8" One-touch fitting (applicable to the AF30-A to AF40-A).

Note 2) Drain guide is G1/8 (applicable to the AF20-A) and G1/4 (applicable to the AF30-A to AF40-A).

Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.

Note 4) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.

Note 5) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended. Note 6) Refer to Chemical data on page 32 for chemical resistance of the bowl.

Note 7) A bowl guard is provided as standard equipment (polycarbonate).

Note 8) Without a valve function

Note 9) For thread type: NPT.

Note 10) O: For thread type: NPT only

Note 11) The combination of float type auto drain: ${\bf C}$ and ${\bf D}$ is not available.

Note 12) The combination of metal bowl: 2 and 8 is not available



Air Filter Series AF20-A to AF40-A

Standard Specifications

Model	AF20-A	AF30-A	AF40-A	AF40-06-A					
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2 3/4						
Fluid		А	ir						
Ambient and fluid temperature		-5 to 60°C (with no freezing)							
Proof pressure	1.5 MPa								
Maximum operating pressure	1.0 MPa								
Nominal filtration rating		5 <u>j</u>	um						
Drain capacity [cm³]	8	25	4	5					
Bowl material		Polyca	rbonate						
Bowl guard	Semi-standard (Steel) Standard (Polycarbonate)								
Weight [kg]	0.08	0.18	, , ,						

Options/Part No.

Optional specifications		Model							
		AF20-A	AF30-A	AF40-A	AF40-06-A				
Bracket assembly Note 1)		AF22P-050AS	AF32P-050AS	AF42P-050AS AF42P-070AS					
Float type auto drain Note 2) Note 3) N.C. N.O.		AD27-A	AD37-A	AD4	17-A				
		_	AD38-A	AD4	18-A				

Semi-standard/Bowl Assembly Part No.

S	emi-stan	ndard spe	cification	s			Mod	del		
Bowl material	Note 2) Note 3) Float type auto drain		With drain	With	With	AF20-A	AF30-A	AF40-A	AF40-06-A	
	N.C.	N.O.	guide	fitting	guard					
	_	_	_	_		C2SF-C-A	_		_	
Dalvaardaarada		_				AD27-C-A	_		_	
Polycarbonate bowl	_	_		_	_	C2SF-J-A	C3SF-J-A	C4S	F-J-A	
DOWI	_	_			_	_	C3SF-W-A	C4S	F-W-A	
	_	_		_		C2SF-CJ-A	_		_	
	_	_	_	_	_	C2SF-6-A	C3SF-6-A	C4S	F-6-A	
	_	_	_	_		C2SF-6C-A	_	_		
	•	_	_	_	_	AD27-6-A	AD37-6-A	AD4	7-6-A	
Nylon bowl	— ● — — — AD38-6-A AD48-6-A	-6-A								
Nylon bowi	•	_	_	_		AD27-6C-A	_		_	
	_	_	•	_	_	C2SF-6J-A	C3SF-6J-A	C4S	=-6J-A	
	_	_	_	•	_	_	C3SF-6W-A	C4SF	-6W-A	
	_	_	•	_		C2SF-6CJ-A	_		_	
	_	_	_	_	_	C2SF-2-A	C3SF-2-A	C4S	F-2-A	
Matal band	•	_	_	_	_	AD27-2-A	AD37-2-A	AD4	7-2-A	
Metal bowl	_	•	_	_	_	_	AD38-2-A	AD4	8-2-A	
		_	•		_	C2SF-2J-A	C3SF-2J-A	C4S	=-2J-A	
	_	_	_	_	_	_	C3LF-8-A	C4L	F-8-A	
Metal bowl	•	_	_	_	_	_	AD37-8-A	AD4	7-8-A	
with level gauge	_	•	_	_	_	_	AD38-8-A	AD4	8-8-A	
		_			_	_	C3LF-8J-A	C4LI	-8J-A	

Note 1) Assembly of a bracket and 2 mounting screws


Note 2) Minimum operating pressure: N.O. type–0.1 MPa; N.C. type–0.1 MPa (AD27-A) and 0.15 MPa (AD37-A/47-A). Please consult with SMC separately for psi and °F unit display specifications.


Note 3) Please consult with SMC for details on drain piping to fit NPT or G port sizes.


Note) Bowl assembly for the AF20-A to AF40-A models comes with a bowl O-ring.


Series AF20-A to AF40-A

Flow-rate Characteristics (Representative values)









Design/Selection

⚠ Warning

1. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

			Material			
Туре	Chemical name	Application examples	Polycar- bonate	Nylon		
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×		
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0		
Inorganic salts	Sodium sulfide Sulfate of potash Sulfate of soda	_	×	Δ		
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ		
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ		
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×		
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×		
Oil	Gasoline Kerosene	_	×	0		
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0		
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0		
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×		
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ		
O: Essentia	lly safe. △: Some effec	cts may occur. X: Effe	ects will o	occur.		

When the above factors are present, or there is some doubt, use a metal bowl for safety.

Maintenance

\land Warning

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

Mounting/Adjustment

⚠ Caution

1. When the bowl is installed on the air filter, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.







Series AF20-A to AF40-A

Working Principle: Float Type Auto Drain


N.O. type: AD38-A, AD48-A



N.C. type: AD37-A, AD47-A



Compact auto drain N.C. type: AD27-A



When pressure inside the bowl is released:

When pressure is released from the bowl 1, piston 7 is lowered by spring 6.

The sealing action of seal 10 is interrupted, and the outside air flows inside the bowl 1 through housing hole 9 and drain cock 1.

Therefore, if there is an accumulation of condensate in the bowl ①, it will drain out through the drain cock.

When pressure is applied inside the bowl:

When pressure exceeds 0.1 MPa, the force of piston (3) surpasses the force of spring (6), and the piston goes up.

This pushes seal 10 up so that it creates a seal, and the inside of the bowl 1, is shut off from the outside air.

If there is no accumulation of condensate in the bowl 1 at this time, float 2 will be pulled down by its own weight, causing valve 4, which is connected to lever 3, to seal valve seat 5.

When there is an accumulation of condensate in the bowl:

Float ② rises due to its own buoyancy and pushes open the seal created by the valve seat ⑤

This allows the pressure inside the bowl 1 to enter the chamber 8. The result is that the combined pressure inside chamber 8 and the force of the spring 6 lowers the piston 7.

This causes the sealing action of seal ① to be interrupted, and the accumulated condensate in the bowl ① drains out through the drain cock ①. Turning drain cock ① manually counterclockwise lowers piston ②, which pushes open the seal created by seal ⑩, thus allowing the condensate to drain out.

When pressure inside the bowl is released:

Even when pressure inside the bowl 1 is released, spring 6 keeps piston 7 in its upward position.

This keeps the seal created by the seal ① in place; thus, the inside of the bowl ① is shut off from the outside air.

Therefore, even if there is an accumulation of condensate in the bowl ①, it will not drain out.

When pressure is applied inside the bowl:

Even when pressure is applied inside the bowl ①, the combined force of spring ⑥ and the pressure inside the bowl ① keeps piston ⑦ in its upward position.

This maintains the seal created by the seal 1 in place; thus, the inside of the bowl 1 is shut off from the outside air.

If there is no accumulation of condensate in the bowl 1 at this time float 2 will be pulled down by its own weight, causing valve 4, which is connected to lever 3, to seal valve seat 5.

When there is an accumulation of condensate in the bowl:

Float ② rises due to its own buoyancy and pushes open the seal created by the valve seat ⑤. Pressure passes from the bowl ① to chamber ⑧.

The result is that the pressure inside chamber § surpasses the force of the spring ⑥ and pushes piston ⑦ downward.

This causes the sealing action of seal 0 to be interrupted and the accumulated condensate in the bowl 1 drains out through the drain cock 1. Turning drain cock 1 manually counterclockwise lowers piston 2, which pushes open the seal created by seal 0, thus allowing the condensate to drain out.

When pressure inside the bowl is released:

Even when pressure inside the bowl ① is released, the weight of the float ② causes valve ④, which is connected to lever ③, to seal valve seat ⑤. As a result, the inside of the bowl ① is shut off from the outside air.

Therefore, even if there is an accumulation of condensate in the bowl 1, it will not drain out.

When pressure is applied inside the bowl:

Even when pressure is applied inside the bowl ①, the weight of the float ② and the differential pressure that is applied to valve ④ cause valve ④ to seal valve seat ⑤, and the outside air is shut off from the inside of the bowl ①.

When the drain is accumulated in the bowl:

Float ② rises due to its own buoyancy and the seal at valve seat ⑤ is interrupted.

The condensate inside the bowl 1 drains out through the knob 6.


Turning knob (§) manually counterclockwise lowers it and causes the sealing action of valve seat (§) to be interrupted, which allows the condensate to drain out.




Air Filter Series AF20-A to AF40-A

Construction

AF20-A



AF30-A to AF40-06-A



Component Parts

No.	Description	Material	Colour
1	Body	Aluminium die-cast	White

Replacement Parts

No	lo. Description	Material -	Part no.							
INO.			AF20-A	AF30-A	AF40-A	AF40-06-A				
2	Filter element	Non-woven fabric	AF20P-060S	AF30P-060S	AF40P-060S					
3	Baffle	PBT	AF22P-040S	AF32P-040S	AF42P-040S					
4	Bowl O-ring	NBR	C2SFP-260S	C32FP-260S	C42FP-260S					
5	Bowl assembly Note)	Polycarbonate	C2SF-A	C3SF-A	C4SF-A					


 $Note) \ Bowl \ O-ring \ is \ included. \ Please \ contact \ SMC \ regarding \ the \ bowl \ assembly \ supply for \ psi \ and \ ^cF \ unit \ specifications.$


Series AF20-A to AF40-A

Dimensions

AF20-A

AF30-A to AF40-06-A





Applicable model		AF20-A									
Optional/Semi-standard specifications	With auto drain (N.C.)	With drain guide	Metal bowl	Metal bowl with drain guide	With auto drain (N.O./N.C.)						
Dimensions	M5 × 0.8	Width across flats 14 1/8	B	Width across flats 14	N.O.: Black N.C.: Gray Thread type/Rc, G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting						

Applicable model			AF3	0-A to AF40-06-A		
Optional/Semi-standard specifications	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	With drain guide	Drain cock with barb fitting
Dimensions	B	Width across flats 17	a v	Width across flats 17	Width across flats 17	Barb fitting Applicable tubing: T0604

		Standard specifications							Optional specifications								
Model		Standard Specifications								Bracket mount							With auto drain
	Р	Α	В	С	D	Е	G	J	M	N	Q	R	S	Т	U	V	В
AF20-A	1/8, 1/4	40	87.6	9.8	20	_	25	20	30	27	22	5.4	8.4	40	2.3	28	104.9
AF30-A	1/4, 3/8	53	115.1	14	26.7	30	35	26.7	41	40	23	6.5	8	53	2.3	30	156.8
AF40-A	1/4, 3/8, 1/2	70	147.1	18	35.5	38.4	40	35.5	50	54	26	8.5	10.5	70	2.3	35	186.9
AF40-06-A	3/4	75	149.1	20	35.5	38.4	40	35.5	50	54	25	8.5	10.5	70	2.3	34	188.9

				Semi-standard specifications		
Model	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide
	В	В	В	В	В	В
AF20-A	_	91.4	87.4	93.9	_	_
AF30-A	123.6	121.9	117.6	122.1	137.6	142.1
AF40-A	155.6	153.9	149.6	154.1	169.6	174.1
AF40-06-A	157.6	155.9	151.6	156.1	171.6	176.1

Air Filter/AF20-A to AF40-A **Made to Order**

Please contact SMC for detailed dimensions, specifications, and lead times.




q Long Bowl

Drain capacity is greater than that of standard models.

Applicable Model/Drain Capacity

Model	AF20-A	AF30-A	AF40-A	AF40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4
Drain capacity [cm³]	19	43	8	8

Note) Please consult with SMC for dimensions.



- Semi-standard: Select one each for a to d.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AF30-03B-2R-A-X64

Symbol Description 20	Body size 30	40
	•	
— Rc ●	_	
Thread type NNote 1) NPT		•
F Note 2) G	•	•
+	•	•
01 1/8 ●		_
02 1/4	•	•
3 Port size 03 3/8 —	•	•
04 1/2 —	<u> </u>	•
06 3/4 —	_	•
+		
Option (Mounting) — Without mounting option	•	•
B Note 3) With bracket	•	•
+		
— Polycarbonate bowl	•	•
2 Metal bowl	•	•
a Bowl Note 4) 6 Nylon bowl	•	•
C With bowl guard	_	_
6C With bowl guard (Nylon bowl)	_	
+		
— With drain cock — □	•	•
5 to b Drain port J Note 5 Drain guide 1/8	_	
Lie Drain guide 1/4	•	•
W Note 6) Drain cock with barb fitting (for ø6 x ø4 nylon tube) —		
+		
c Flow direction — Flow direction: Left to right	•	•
Flow direction: Right to left		•
d Pressure unit Name plate and caution plate for bowl in imperial units: MPa Z Note 7) Name plate and caution plate for bowl in imperial units: psi, °F	Note 8)	Note 8)

Note 1) Drain guide is NPT1/8 (applicable to the AF20-A) and NPT1/4 (applicable to the AF30-A to AF40-A). Note 2) Drain guide is G1/8 (applicable to the AF20-A) and G1/4 (applicable to the AF30-A to AF40-A). Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.

Note 4) Refer to Chemical data on page 32 for chemical resistance of the bowl.

Note 5) Without a valve function

Note 6) The combination of metal bowl: 2 is not available.

Note 7) For thread type: NPT.

Note 8) \bigcirc : For thread type: NPT only

Air Filter/AF20-A to AF40-A **Made to Order**




lease contact SMC for detailed dimensions, specifications, and lead times.

w With Element Service Indicator

Clogging status of elements can be checked visually.

Applicable Model

Model	AF20-A	AF30-A	AF40-A	AF40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4



- \bullet Option/Semi-standard: Select one each for \boldsymbol{a} to $\boldsymbol{f}.$
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AF30-03BD-2R-A-X2141

With element service indicator

A special body type is required to mount the element service indicator. It cannot be mounted on a standard body.

	_						•	
		_					0	
				Symbol	Description		Body size	
						20	30	40
				_	Rc	•	•	•
2		Th	nread type	N Note 1)	NPT	•	•	•
				F Note 2)	G	•	•	•
				+				
				01	1/8	•	_	_
				02	1/4	•	•	•
3			Port size	03	3/8	_	•	•
_				04	1/2	_	_	•
				06	3/4	_	_	•
				+				
		а	Mounting		Without mounting option	•	•	•
		a	iviouriting	B Note 3)	With bracket	•	•	•
4	l ioi			+				
4	[] [_	Without auto drain	•	•	•
		b	Float type auto drain	C Note 4)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•
			auto drain	D Note 5)	N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•
			•	+				
				_	Polycarbonate bowl	•	•	•
				2	Metal bowl	•	•	•
		С	Bowl Note 6)	6	Nylon bowl	•	•	•
			DOWI 7	8	Metal bowl with level gauge	_	•	•
				С	With bowl guard	•	Note 7)	Note 7)
				6C	With bowl guard (Nylon bowl)	•	Note 7)	Note 7)
	Semi-standard			+				
	ng			_	With drain cock	•	•	•
5	sta	d	Drain port Note 11)	J Note 8)	Drain guide 1/8	•		_
	<u>=</u>	u	Diam port	J	Drain guide 1/4	_	•	•
	Se			W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_		•
				+				
		е	Flow direction	_	Flow direction: Left to right	•		
			1 low direction	R	Flow direction: Right to left		•	•
				+				
		f	Pressure unit	_	Name plate and caution plate for bowl in imperial units: MPa	•		
		•	i iessure utili	Z Note 9)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 10)	Note 10)	Note 10)
	-1/ D	-			a the AEOO A) and NDT1/4 (applicable to the AEOO A to AEO A)			

Note 1) Drain guide is NPT1/8 (applicable to the AF20-A) and NPT1/4 (applicable to the AF30-A to AF40-A).

The auto drain port comes with ø3/8" One-touch fitting (applicable to the AF30-A to AF40-A). Note 2) Drain guide is G1/8 (applicable to the AF20-A) and G1/4 (applicable to the AF30-A to AF40-A).

Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.

Note 4) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.

Note 5) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.

Note 6) Refer to Chemical data on page 32 for chemical resistance of the bowl.

Note 7) A bowl guard is provided as standard equipment (polycarbonate).

Note 8) Without a valve function

Note 9) For thread type: NPT.

Note 10) \bigcirc : For thread type: NPT only

Note 11) The combination of float type auto drain: C and D is not available.

Note 12) The combination of metal bowl: 2 and 8 is not available.



Mist Separator

Series AFM Nominal filtration rating: 0.3 μm
 Series AFD Nominal filtration rating: 0.01 μm

AFM20-A to AFM40-A Micro Mist Separator

AFD20-A to AFD40-A



Symbol Mist Separator






AFM40-A

- Micro Mist Separator
- 1 2





How to Order



Option/Semi-standard: Select one each for a to f.
 Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) AFM30-03BD-R-A

Made to Order

(Refer to pages 45 and 46 for details.)

_					(Helef to pages 4			
	\	_					0	
				Symbol	Description		Body size	
						20	30	40
				_	Rc	•	•	•
2		Th	nread type	N Note 1)	NPT	•	•	•
				F Note 2)	G	•	•	•
				+				
				01	1/8	•	_	_
				02	1/4	•	•	•
3		- 1	Port size	03	3/8	_	•	•
				04	1/2	_	_	•
				06	3/4	_	_	•
	•			+			•	
			Mounting	_	Without mounting option	•	•	•
		а	Mounting	B Note 3)	With bracket	•	•	•
4	ion			+				
U	l l auto drain			_	Without auto drain	•	•	•
				C Note 4)	N.C. (Normally closed) Drain port is closed when pressure is not applied.	•	•	•
		D Note 5)			N.O. (Normally open) Drain port is open when pressure is not applied.	_	•	•
				+				
				_	Polycarbonate bowl	•	•	•
				2	Metal bowl	•	•	
			Bowl Note 6)	6	Nylon bowl	•	•	
		С	DOWI **** s/	8	Metal bowl with level gauge	_	•	•
				С	With bowl guard	•	Note 7)	Note 7)
				6C	With bowl guard (Nylon bowl)	•	Note 7)	Note 7)
	ard			+				
	ınd			_	With drain cock	•	•	•
6	Semi-standard	d	Drain	Note 8)	Drain guide 1/8	•	_	
	ëmi	_	port Note 11)	•	Drain guide 1/4		•	•
	Š			W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•	•
				+			_	
		е	Flow direction		Flow direction: Left to right	•	•	•
				R	Flow direction: Right to left			•
				+	1			
		f	Pressure unit		Name plate and caution plate for bowl in imperial units: MPa	O NUL 10	O No. 103	O N/// 45
				Z Note 9)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 10)	Note 10)	O Note 10)

Note 1) Drain guide is NPT1/8 (applicable to the AFM20-A, AFD20-A) and NPT1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A). The auto drain port comes with ø3/8" One-touch fitting (applicable to the AFM30-A/40-A, AFD30-A/40-A).

Note 2) Drain guide is G1/8 (applicable to the AFM20-A, AFD20-A) and G1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A).

Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws

Note 4) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.

Note 5) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended. Note 6) Refer to Chemical data on page 42 for chemical resistance of the bowl.

Note 7) A bowl guard is provided as standard equipment (polycarbonate).

Note 8) Without a valve function

Note 9) For thread type: NPT.

Note 10) O: For thread type: NPT only

Note 11) The combination of float type auto drain: C and D is not available.

Note 12) The combination of metal bowl: 2 and 8 is not available.



Mist Separator Series AFM20-A to AFM40-A Micro Mist Separator Series AFD20-A to AFD40-A

Standard Specifications

Model		AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A			
Port size		1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4			
Fluid		, , , , ,	•	ir	<u> </u>			
Ambient and fluid temperature	е		− 5 to 60°C (w	ith no freezing)				
Proof pressure			1.5	MPa				
Maximum operating pressure			1.0	MPa				
Minimum operating pressure			0.05	MPa				
Nominal filtration rating	AFM20-A to AFM40-06-A	0.3 μm (99.9% filtered particle size)						
Nominal intration rating	AFD20-A to AFD40-06-A	515 1 p (5515 / 5 p 1515 5)						
Outlet side oil mist	AFM20-A to AFM40-06-A	, , , , , , , , , , , , , , , , , , ,						
concentration	AFD20-A to AFD40-06-A	MAX 0.1 mg/m³ (ANR) (Before saturated with oil 0.01 mg/m³ (ANR) or less ≈ 0.008 ppm) Note 2) Note 3)						
Rated flow [L/min (ANR)] Note 1)	AFM20-A to AFM40-06-A	200	450	11	00			
nated flow [L/fillif (ANN)]	AFD20-A to AFD40-06-A	120	240	6	00			
Drain capacity [cm³]		8	25	4	5			
Bowl material		Polycarbonate						
Bowl guard		Semi-standard (Steel)	St	Standard (Polycarbonate)				
Weight [kg]		0.09	0.19	0.38	0.43			

Note 1) Conditions: Inlet pressure: 0.7 MPa; The rated flow varies depending on the inlet pressure. Keep the air flow within the rated flow to prevent an outflow of lubricant to the outlet side.

Options/Part No.

		Model						
Optional specifications		AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A			
Bracket assembly Note 1)		AF22P-050AS	AF32P-050AS	AF42P-050AS	AF42P-070AS			
Floor to the state of the Note 2) Note 3)	N.C.	AD27-A	AD37-A	AD4	17-A			
Float type auto drain Note 2) Note 3)		_	AD38-A	AD ₂	18-A			

Semi-standard/Bowl Assembly Part No.

S	emi-star	ndard spe	ecification	s			Mo	del		
Bowl material	Float	e 2) Note 3) t type drain N.O.	With drain guide	With barb fitting	With bowl guard	AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A	
	_	_	_	_		C2SF-C-A	_	_		
	•	_	_	_	•	AD27-C-A	_	-	_	
Polycarbonate bowl	_	_	•	_	_	C2SF-J-A	C3SF-J-A	C4SI	-J-A	
DOWI	_	_	_	•	_	_	C3SF-W-A	C4SF	-W-A	
	_	_	•	_	•	C2SF-CJ-A	_	-	_	
	_	_	_	_	_	C2SF-6-A	C3SF-6-A	C4SF-6-A		
	_	_	_	_	•	C2SF-6C-A	_	_		
	•	_	_	_	_	AD27-6-A	AD37-6-A	AD47	7-6-A	
Nylon bowl	_	•	_	_	_	_	AD38-6-A	AD48	3-6-A	
INVIORI DOWI	•	_	_	_	•	AD27-6C-A	_	<u> </u>		
	_	_	•	_	_	C2SF-6J-A	C3SF-6J-A	C4SF-6J-A		
	_	_	_	•	_	_	C3SF-6W-A	C4SF	-6W-A	
	_	_	•	_	•	C2SF-6CJ-A	_	_	_	
	_	_	_	_	_	C2SF-2-A	C3SF-2-A	C4SF	2-A	
Metal bowl	•	_	_	_	_	AD27-2-A	AD37-2-A	AD47	7-2-A	
ivietai DOWI	_	•	_	_	_	_	AD38-2-A	AD48	3-2-A	
	_	_	•	_	_	C2SF-2J-A	C3SF-2J-A	C4SF	-2J-A	
	_	_	_	_	_	_	C3LF-8-A	C4LF	-8-A	
Metal bowl	•	_	_		_		AD37-8-A	AD47	7-8-A	
with level gauge	_		_		_		AD38-8-A	AD48	3-8-A	
	_	_	•		_	_	C3LF-8J-A	C4LF	-8J-A	

Note 1) Assembly of a bracket and 2 mounting screws



Note 2) When the compressor oil mist discharge concentration is 30 mg/m³ (ANR).

Note 3) Bowl O-ring and other O-rings are slightly lubricated.

Note 2) Minimum operating pressure: N.O. type-0.1 MPa; N.C. type-0.1 MPa (AD27-A) and 0.15 MPa (AD37-A/47-A).

Please consult with SMC separately for psi and $^{\circ}\text{F}$ unit display specifications.

Note 3) Please consult with SMC for details on drain piping to fit NPT or G port sizes.


Note 4) The bowl assembly includes the bowl O-ring.


Series AFM20-A to AFM40-A Series AFD20-A to AFD40-A


Flow-rate Characteristics (Representative values)


When saturated with oil


--- Initial state














Mist Separator Series AFM20-A to AFM40-A Micro Mist Separator Series AFD20-A to AFD40-A

Specific Product Precautions

Be sure to read before handling. Refer to back cover for Safety Instructions, "Handling Precautions for SMC I Products" (M-E03-3) and the Operation Manual for F.R.L. Precautions.

Design/Selection

⚠ Warning

1. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

				rence)
Туре	Chemical name	Application examples	Mate Polycar- bonate	Nylon
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0
Inorganic salts	Sodium sulfide Sulfate of potash Sulfate of soda	_	×	Δ
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×
Oil	Gasoline Kerosene	_	×	0
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ

When the above factors are present, or there is some doubt, use a metal bowl for safety

Air Supply

∕!\ Caution

- 1. Install an air filter (Series AF) as a pre-filter on the inlet side of the mist separator to prevent premature clogging.
- 2. Install a mist separator (Series AFM) as a pre-filter on the inlet side of the micro mist separator to prevent premature clogging.
- 3. Do not install on the inlet side of the dryer as this can cause premature clogging of the element.

Maintenance

∕∖\ Warning

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

Mounting/Adjustment

♠ Caution

1. When the bowl is installed on the mist separator, or micro mist separator, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.



Design

∕∖∖ Caution

1. Design the system so that the mist separator is installed in a pulsation-free location. The difference between internal and external pressure inside the element should be kept within 0.1 MPa, as exceeding this value could cause damage.

Selection


∕∖\ Caution

- 1. Do not allow air flow that exceeds the rated flow. If the air flow is allowed outside the range of the rated flow even momentarily, drainage and lubricant may splash at the outlet side or cause damage to the component.
- 2. Do not use in a low pressure application (such as a blower). F.R.L. unit has its own minimum operating pressure depending on the equipment and is designed specifically to function with compressed air. If used below the minimum operating pressure, a loss of performance and malfunction can occur. Please contact SMC if an application under such conditions cannot be avoided.

Series AFM20-A to AFM40-A Series AFD20-A to AFD40-A

Construction


AFM20-A AFD20-A




Float type auto drain (N.C.)



AFM30-A to AFM40-06-A AFD30-A to AFD40-06-A





Component Parts

No.	Description	Material	Model	Colour
1	Body	Aluminium die-cast	AFM20-A to AFM40-06-A AFD20-A to AFD40-06-A	White

Replacement Parts

				Part no.						
No.	Description	on	Material	AFM20-A AFD20-A	AFM30-A AFD30-A	AFM40-A AFD40-A	AFM40-06-A AFD40-06-A			
2	0 Flament accombine	AFM20 to 40	_	AFM20P-060AS	AFM30P-060AS	AFM40P-060AS				
	Element assembly	AFD20 to 40	_	AFD20P-060AS	AFD30P-060AS	AFD40P-060AS				
3	Bowl seal		NBR	C2SFP-260S	C32FP-260S	C42FP-260S				
4	Bowl assembly Note)		Polycarbonate	C2SF-A	C3SF-A	C45	SF-A			


Note) Bowl seal is included. Please contact SMC regarding the bowl assembly supply for psi and °F unit specifications.




Mist Separator Series AFM20-A to AFM40-A Micro Mist Separator Series AFD20-A to AFD40-A


Dimensions





AFM30-A to AFM40-06-A AFD30-A to AFD40-06-A







			Ctanda	rd on oo	ification	2						Optio	nal spe	cificatio	ns		
Model	Model Standard specifications						Bracket mount							With auto drain			
	Р	Α	В	С	D	Е	G	J	M	N	Q	R	S	Т	U	٧	В
AFM20-A/AFD20-A	1/8, 1/4	40	87.6	9.8	20	_	40	20	30	27	22	5.4	8.4	40	2.3	28	104.9
AFM30-A/AFD30-A	1/4, 3/8	53	115.1	14	26.7	30	50	26.7	41	40	23	6.5	8	53	2.3	30	156.8
AFM40-A/AFD40-A	1/4, 3/8, 1/2	70	147.1	18	35.5	38.4	75	35.5	50	54	26	8.5	10.5	70	2.3	35	186.9
AFM40-06-A/AFD40-06-A	3/4	75	149.1	20	35.5	38.4	75	35.5	50	54	25	8.5	10.5	70	2.3	34	188.9

				Semi-standard specification	ations		
Model	With barb fitting With drain guide		Metal bowl Metal bowl with drain guide		Metal bowl with level gauge	Metal bowl with level gauge, with drain guide	
	В	В	В	В	В	В	
AFM20-A/AFD20-A	_	91.4	87.4	93.9	_	_	
AFM30-A/AFD30-A	123.6	121.9	117.6	122.1	137.6	142.1	
AFM40-A/AFD40-A	155.6	153.9	149.6	154.1	169.6	174.1	
AFM40-06-A/AFD40-06-A	157.6	155.9	151.6	156.1	171.6	176.1	

Mist Separator/AFM20-A to AFM40-A Micro Mist Separator/AFD20-A to AFD40-A Made to Order



Please contact SMC for detailed dimensions, specifications, and lead times.


Long Bowl

Drain capacity is greater than that of standard models.

Applicable Model/Drain Capacity

Model	AFM20-A, AFD20-A	AFM30-A, AFD30-A	AFM40-A, AFD40-A	AFM40-06-A, AFD40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4
Drain capacity (cm ³)	19	43		88

Note) Please consult with SMC for dimensions



- Semi-standard: Select one each for a to d.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AFM30-03B-2R-A-X64

	_	_					0	
				Symbol	Description		Body size	
						20	30	40
				_	Rc	•	•	•
2		T	hread type	N Note 1)	NPT	•	•	•
				F Note 2)	G	•	•	•
				+				
				01	1/8	•	_	_
				02	1/4	•	•	•
3		Port size 03			3/8	_	•	•
			04	1/2	_	_	•	
				06	3/4	_	_	•
				+				,
4	١,	Ontid	on (Mounting)	_	Without mounting option	•	•	•
		Орис	on (wounting)	B Note 3)	With bracket	•	•	
				+				
					Polycarbonate bowl	•	•	•
			Bowl Note 4)	2	Metal bowl	•	•	•
		а		6	Nylon bowl	•	•	•
				С	With bowl guard	•	_	_
				6C	With bowl guard (Nylon bowl)	•	_	_
	ō			+				
	ıdaı				With drain cock	•	•	•
6	stan	b	Drain port	J Note 5)	Drain guide 1/8	•	_	_
	Semi-standard				Drain guide 1/4		•	•
	Ser			W Note 6)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)			
				+				
		С	Flow direction	_	Flow direction: Left to right		•	
				R	Flow direction: Right to left	•	•	
				+	N			
		d	Pressure unit	- Note 7)	Name plate and caution plate for bowl in imperial units: MPa	Note 8)	Note 8)	Note 8)
	d		Z Note 7)	Name plate and caution plate for bowl in imperial units: psi, °F	O Note o)	O Note of	O NOTE O)	

Note 1) Drain guide is NPT1/8 (applicable to the AFM20-A, AFD20-A) and NPT1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A).

Note 2) Drain guide is G1/8 (applicable to the AFM20-A, AFD20-A) and G1/4 (applicable to the AFM30-A/40-A, AFD30-A/40-A). Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.

Note 4) Refer to Chemical data on page 42 for chemical resistance of the bowl.

Note 5) Without a valve function

Note 6) The combination of metal bowl: 2 is not available

Note 7) For thread type: NPT

Note 8) O: For thread type: NPT only



AW+AL AF+AR+AL

AF+AR

Attachment | AW+AFM | AF+AFM+AR

Mist Separator/*AFM20-A to AFM40-A*Micro Mist Separator/*AFD20-A to AFD40-A* **Made to Order**




Please contact SMC for detailed dimensions, specifications, and lead times.

2 With Element Service Indicator

Clogging status of elements can be checked visually.

Applicable Model

Model	AFM20-A, AFD20-A	AFM30-A, AFD30-A	AFM40-A, AFD40-A	AFM40-06-A, AFD40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4



- Option/Semi-standard: Select one each for a to f.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
- Example) AFM30-03BD-R-A-X2141

	\					0	
			Symbol	Description		Body size	
					20	30	40
			_	Rc	•	•	•
	TI	nread type	N Note 1)	NPT			
			F Note 2)	G	•	•	•
			+				
			01	1/8		_	_
			02	1/4		•	•
		Port size	03	3/8	_	•	•
			04	1/2	_	_	•
			06	3/4	_	_	•
			+				
	_	Manustina	_	Without mounting option	•		•
	а	Mounting	B Note 3)	With bracket	•	•	•
Option			+				
		F1	_	Without auto drain			•
O	b	Float type	C Note 4)	N.C. (Normally closed) Drain port is closed when pressure is not applied.			
		auto drain	D Note 5)	N.O. (Normally open) Drain port is open when pressure is not applied.			
			+	- (
			_	Polycarbonate bowl			
			2	Metal bowl			
		D I Noto 6)	6	Nylon bowl	•		•
	С	Bowl Note 6)	8	Metal bowl with level gauge	_		•
			С	With bowl guard		Note 7)	Note 7)
			6C	With bowl guard (Nylon bowl)	•	Note 7)	Note 7)
ard			+				
nd				With drain cock	•		
sta	d	Drain port Note 11)	■ Note 8)	Drain guide 1/8	•		
<u>-</u>	u	Dialii poit		Drain guide 1/4	_	•	•
Semi-standard			W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_		
0,			+				
	е	Flow direction	_	Flow direction: Left to right			
	_	I low direction	R	Flow direction: Right to left		•	
			+				
	f	Pressure unit	_	Name plate and caution plate for bowl in imperial units: MPa	•	•	
		i icooure utili	Z Note 9)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 10)	Note 10)	O Note 10)

- (applicable to the AFM30-A/40-A, AFD30-A/40-A). The auto drain port comes with ø3/8" One-touch fitting (applicable to the
- AFM30-A/40-A, AFD30-A/40-A). Note 2) Drain guide is G1/8 (applicable to the AFM20-A, AFD20-A) and G1/4
- (applicable to the AFM30-A/40-A, AFD30-A/40-A).

 Note 3) A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws
- Note 4) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.
- Note 6) Refer to Chemical data on page 42 for chemical resistance of the bowl.
- Note 7) A bowl guard is provided as standard equipment (polycarbonate).
- Note 8) Without a valve function
- Note 9) For thread type: NPT.
- Note 10) O: For thread type: NPT only Note 11) The combination of float type auto drain: C and D is not available.
- Note 12) The combination of metal bowl: 2 and 8 is not available.



Modular Type Regulators

Series AR

Regulator Series AR	Model	Port size	Options
Will State Size:	AR20-A	1/8, 1/4	
	AR25-A	1/4, 3/8	Bracket
04 06 06 00 00 00 00 00 00 00 00 00 00 00	AR30-A	1/4, 5/0	Round type pressure gauge
MPA STATE OF	AR40-A	1/4, 3/8, 1/2	With set nut (for panel mount)*
P.49 to 55	AR40-06-A	3/4	* Not interchangeable with existing AR series

Regulator

AR20-A to AR40-A

Symbol






AR20-A



. to Ouden

How to Order



- Option/Semi-standard: Select one each for a to g.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AR30-03BG-1N-A

Made to Order

(Refer to page 55 for details.)

	\								
				Symbol	Description		Body	/ size	
						20	25	30	40
				_	Rc	•	•	•	•
2		Tł	read type	N	NPT		•	•	•
				F	G		•	•	•
	•			+			•		
				01	1/8		_	_	_
				02	1/4		•	•	•
3		- 1	Port size	03	3/8	_	•	•	•
				04	1/2	_	_	_	•
				06	3/4	_	_	_	•
				+			1		
				_	Without mounting option				
	=	а	Mounting	B Note 2)	With bracket	•	•	•	•
	lote 1			Н	With set nut (for panel mount) Note 3)	•	•	•	•
4	اج			+			•		
	Option Note 1)		D	_	Without pressure gauge		•	•	
		b	Pressure gauge Note 4)	G	Round type pressure gauge (with limit indicator)		•	•	•
			gauge	M	Round type pressure gauge (with colour zone)		•	•	•
				+					
			Set	_	0.05 to 0.7 MPa setting		•	•	
		С	pressure Note 5)	1	0.02 to 0.2 MPa setting		•	•	•
				+					
		d	Exhaust	_	Relieving type				
	-	u	mechanism	N	Non-relieving type				
	dar			+					
A	lanc	е	Flow direction	_	Flow direction: Left to right				
6	i-st	-	riow direction	R	Flow direction: Right to left				
	Semi-standard			+					
	0)	f	Knob	_	Downward	•			
		•	KIIOD	Υ	Upward				
				+		1			
		g	Pressure unit	_	Name plate and pressure gauge in imperial units: MPa				
		9	i 1033ule uill	Z Note 6)	Name plate and pressure gauge in imperial units: psi	Note 7)	Note 7)	Note 7)	Note 7)
	- 4\ 0		D O II M		and a supplied to a speaking time of altimospace				

Note 1) Option B, G, H, M are not assembled and supplied loose at the time of shipment.

Note 2) Assembly of a bracket and set nuts

Note 3) Only for the AR20-A to 40-A

Note 4) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.

Note 5) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.

Note 6) For thread type: NPT

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 7) O: For thread type: NPT only



Model	AR20-A	AR25-A	AR30-A	AR40-A	AR40-06-A							
Port size	1/8, 1/4	1/4, 3/8, 1/2	/2 3/4									
Pressure gauge port size	1/8											
Fluid		Air										
Ambient and fluid temperature		- 5	to 60°C (with no free	zing)								
Proof pressure			1.5 MPa									
Maximum operating pressure			1.0 MPa									
Set pressure range			0.05 to 0.7 MPa									
Construction			Relieving type									
Weight [kg]	0.17	0.19	0.34	0.58	0.60							

Options/Part No.

	Ontional	posifications			Model				
	Optional s	specifications	AR20-A	AR25-A	AR40-A	AR40-06-A			
Bracke	t assemb	ly Note 1)	AR22P-270AS	AR27P-270AS	AR32P-270AS	AR42P-270AS AR42P-270A			
Set nut	t		AR22P-260S	AR22P-260S	AR42P-260S	AR42P-260S			
	Round	Standard		G36-10-□01		G46-10-□01			
Pressure	type	0.02 to 0.2 MPa setting		G36-4-□01		G46-4-	□01		
gauge	Round type	Standard		G36-10-□01-L		G46-10-□01-L			
		0.02 to 0.2 MPa setting		G36-4-□01-L		G46-4-□01-L			

Note 1) Assembly of a bracket and set nuts

Note 2) in part numbers for a round pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for psi unit specifications.

⚠ Specific Product Precautions

Be sure to read before handling. Refer to back cover for Safety Instructions, "Handling Precautions for SMC I Products" (M-E03-3) and the Operation Manual for F.R.L. Precautions.

Selection

Warning

1. Although exhaust of the residual pressure to the inlet side is possible when eliminating the inlet pressure, exhaust is not possible when the set pressure is 0.15 MPa or less. Use the regulator with backflow function.

Maintenance

🗥 Warning

1. When using the regulator between a solenoid valve and an actuator, check the pressure gauge periodically. Sudden pressure fluctuations may shorten the durability of the pressure gauge. A digital pressure gauge is recommended for such situation or as deemed necessary.

Mounting/Adjustment

🗥 Warning

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

∖ Caution


- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
 - Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
 - Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disap-
- 2. Pulsation will be generated when the difference between the inlet and the outlet pressure is large. In this case, reduce the pressure difference between the inlet and the outlet. Please consult with SMC if the pulsation problem is not resolved.





Series AR20-A to AR40-A


Flow-rate Characteristics (Representative values)


Condition: Inlet pressure 0.7 MPa














Pressure Characteristics (Representative values)

Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min (ANR)








Inlet pressure [MPa]

0.1

0.2


0.3 0.4 0.5 0.6 0.7 0.8 0.9 1 1.1



Series AR20-A to AR40-A

Construction

AR20-A to 40-06-A



Component Parts

No.	Description	Material	Colour
1	Body	Aluminium die-cast	White
2	Bonnet	Polyacetal	White


Replacement Parts


No.	Description	Material	Part no.										
INO.	Description	Material	AR20-A	AR40-A	AR40-06-A								
3	Valve assembly	Stainless steel, HNBR	AR22P	-060AS	AR32P-060AS	R32P-060AS AR42P-							
4	Diaphragm assembly	Weatherable NBR	AR22P	-150AS	AR32P-150AS	AR42P	-150AS						
5	Valve guide assembly	Polyacetal	AR22P	-050AS	AR32P-050AS	AR42P	-050AS						



Dimensions

AR20-A to AR40-06-A





Panel fitting dimension




Plate thickness AR20-A to AR25-A : MAX.4 AR30-A to AR40-06-A: MAX.8

									Optional specifications														
Model			Star	ndard sp	pecifica	itions			Round type Round type pressure pressure gauge gauge (with colour zone)		Bracket mount						Panel mount						
	P ₁	P ₂	Α	B ^{Note)}	С	D	F	J	Н	J	Н	J	М	N	Q	R	S	Т	U	٧	W	Υ	Z
AR20-A	1/8, 1/4	1/8	40	67.4	23.5	22	M36 x 1.5	22	ø37.5	58.5	ø37.5	59.5	30	34	43.9	5.4	15.4	55	2.3	27.3	36.5	17.5	6
AR25-A	1/4, 3/8	1/8	53	70.4	23.5	22	M36 x 1.5	22	ø37.5	58.5	ø37.5	59.5	30	34	44.3	5.4	15.4	55	2.3	30.3	36.5	17.5	6
AR30-A	1/4, 3/8	1/8	53	83.5	27	28.5	M45 x 1.5	28.5	ø37.5	65	ø37.5	66	41	36	46	6.5	24	65	2.3	32.5	45.5	22.5	7
AR40-A	1/4, 3/8, 1/2	1/8	70	100	33.5	34.5	M52 x 1.5	34.5	ø42.5	72	ø42.5	72	50	38	54	8.5	26.5	70	2.3	38.4	52.5	26	7
AR40-06-A	3/4	1/8	75	101.5	33.5	34.5	M52 x 1.5	34.5	ø42.5	72	ø42.5	72	50	38	55.5	8.5	26.5	70	2.3	39.9	52.5	26	7

Note) The total length of B dimension is the length when the filter regulator knob is unlocked.



AF+AR AW+AL AF+AR+AL

AF+AFM+AR

Regulator/AR20-A to AR40-A Made to Order



Please contact SMC for detailed dimensions, specifications, and lead times.

1 0.4 MPa Setting


The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.7 MPa.

Specifications

Proof pressure	1.5 MPa
Maximum operating pressure	1.0 MPa
Nominal filtration rating	0.05 to 0.4 MPa

Applicable Model

Model	AR20-A	AR25-A	AR30-A	AR40-A	AR40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8	1/4, 3/8, 1/2	3/4



- Option/Semi-standard: Select one each for a to f.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
 Example) AR30-03BG-NR-A-X406

	_	_					(
				Symbol	Description		Body		
						20	25	30	40
				_	Rc	•	•	•	
2		Thread type			NPT	•	•	•	•
				F	G	•	•	•	•
				+					
				01	1/8	•	_	_	_
	3			02	1/4	•	•	•	•
3			Port size 03		3/8	_	•	•	•
				04	1/2	_		_	•
				06	3/4	_	_	_	•
				+					
				_	Without mounting option	•			
	=	а	Mounting	B Note 2)	With bracket	•	•	•	•
	Note .			Н	With set nut (for panel mount) Note 3)	•	•	•	•
4	Option Note 1)			+					
	pti			_	Without pressure gauge	•			
		b	Pressure gauge	G	Round type pressure gauge (with limit indicator)				•
				M	Round type pressure gauge (with colour zone)				
				+					
		С	Exhaust mechanism	_	Relieving type				
			Landust moonamism	N	Non-relieving type				
				+					
	ard	d	Flow direction	_	Flow direction: Left to right				
_	ng		1 low direction	R	Flow direction: Right to left				
5	Semi-standard			+					
] Ä	е	Knob	_	Downward			•	
	Š		11102	Υ	Upward				
				+					
		f	Pressure unit		Name plate and caution plate for bowl in imperial units: MPa		•		
				Z Note 4)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 5)	Note 5)	Note 5)	Note 5)

Note 1) Option B, G, H, M are not assembled and supplied loose at the time of shipment.

Note 2) Assembly of a bracket and set nuts

Note 3) Only for the AR20-A to 40-A

Note 4) For thread type: NPT

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 5) O: For thread type: NPT only



AL

AB

Modular Type Lubricators

Series AL

Lubricator Series AL	Model	Port size	Option
	AL20-A	1/8, 1/4	
regr	AL30-A	1/4, 3/8	Dunalent
Ook B	AL40-A	1/4, 3/8, 1/2	Bracket
P.57 to 61	AL40-06-A	3/4	

Lubricator

AL20-A to AL40-A


Symbol





AL20-A AL40-A

How to Order



- Option/Semi-standard: Select one each for a to d.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AL30-03B-3RW-A

		_					0	
				Symbol	Description		Body size	
						20	30	40
		Thread type		_	Rc	•	•	•
2				N	NPT	•	•	•
				F	G	•	•	•
				+				
				01	1/8	•	_	_
				02	1/4	•	•	•
3		Port size		03	3/8	_	•	•
				04	1/2	_	_	•
				06	3/4	_	_	•
				+				
		Ontion (Mounting)		_	Without mounting option	•	•	•
4	4 Option (Mounting)		B Note 1)	With bracket	•	•	•	
				+			_	
			Bowl Note 5)	_	Polycarbonate bowl	•	•	•
				2	Metal bowl	•	•	•
				6	Nylon bowl	•	•	•
		а	DOWI ******	8	Metal bowl with level gauge	<u> </u>	•	•
				С	With bowl guard	•	Note 2)	Note 2)
	ا ح			6C	With bowl guard (Nylon bowl)	•	Note 2)	Note 2)
	dar			+				
6	tan		Lubricant	_	Without drain cock	•	•	•
•	Ji-S	b	exhaust port	3	With drain cock	•	•	•
	Semi-standard		Oxflador port	3W	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	<u> </u>	•	
	0,			+				
		С	Flow direction	_	Flow direction: Left to right	•	•	•
			1 low direction	R	Flow direction: Right to left	•	•	
				+				,
		d	Pressure unit	_	Name plate and caution plate for bowl in imperial units: MPa	•	•	•
		u Flessure unit		Z Note 3)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 4)	O Note 4)	Note 4)

Note 1) Option B is not assembled and supplied loose at the time of shipment.

Note 2) A bowl guard is provided as standard equipment (polycarbonate). Note 3) For thread type: NPT.

Note 4) O: For thread type: NPT only

Note 5) Refer to Chemical data on page 59 for chemical resistance of the bowl.



Lubricator Series AL20-A to AL40-A

Standard Specifications

Model	AL20-A	AL30-A	AL40-A	AL40-06-A						
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4						
Fluid	Air									
Proof pressure		1.5	5 MРа							
Maximum operating pressure		1.0 MPa								
Ambient and fluid temperature	- 5 to 60°C (with no freezing)									
Minimum dripping flow rate [L/min (ANR)] Note)	15	1/4: 30 3/8: 40	1/4: 30 3/8: 40 1/2: 50	50						
Oil capacity [cm³]	25	55	13	5						
Recommended lubricant		Class 1 turbin	e oil (ISO VG32)							
Bowl material		Polyca	arbonate							
Bowl guard	Semi-standard (Steel)		Standard (Polycarbonate)							
Weight [kg]	0.10	0.20	0.38	0.43						

Note) • The flow rate is 5 drops or greater/min under the following conditions: Inlet pressure of 0.5 MPa; Class 1 turbine oil (ISO VG32); Temperature at 20°C; Oil adjustment valve fully opened.

• Use air consumption flow rate for minimum dripping flow rate.

Option/Part No.

Optional specifications	Model							
Optional specifications	AL20-A	AL20-A AL30-A AL40-A						
Bracket assembly Note)	AF22P-050AS	AF32P-050AS	AF42P-050AS	AF42P-070AS				

Note) Assembly of a bracket and 2 mounting screws

Semi-standard/Bowl Assembly Part No.


Semi-stan	dard spe	cification	ıs		Мо	del				
Bowl material	With drain cock	With barb fitting	With bowl guard	AL20-A	AL30-A	AL40-A	AL40-06-A			
	•	_	_	C2SL-3-A	C3SL-3-A	C4SL-3-A				
Polycarbonate	_	_	•	C2SL-C-A	_	_				
bowl		_		C2SL-3C-A	_	_				
	•	•	_	_	C3SL-3W-A	C4SL-	-3W-A			
	_	_	_	C2SL-6-A	C3SL-6-A	C4SI	6-A			
	•	_	_	C2SL-36-A	C3SL-36-A	C4SL	-36-A			
Nylon bowl	_	_		C2SL-6C-A	_	_				
	•	_		C2SL-36C-A	_	_	_			
	•	•	_	_	C3SL-36W-A	C4SL-	36W-A			
Metal bowl	_	_	_	C2SL-2-A	C3SL-2-A	C4SI	2-A			
ivietai DOWI	•	_	_	C2SL-23-A	C3SL-23-A	C4SL	-23-A			
Metal bowl	_	_	_	_	C3LL-8-A	C4LI	8-A			
with level gauge	•	_	_	_	C3LL-38-A	C4LL-38-A				


Note) • The bowl assembly includes the bowl O-ring.


[•] Please consult with SMC separately for psi and °F unit display specifications.


Series AL20-A to AL40-A

Flow-rate Characteristics (Representative values)









⚠ Specific Product Precautions

Be sure to read before handling. Refer to back cover for Safety Instructions, "Handling Precautions for SMC Products" (M-E03-3) and the Operation Manual for F.R.L. Precautions.

Selection

△Warning

- **1.** Do not introduce air from the outlet side as this can damage the bumper.
- The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

Type	Chemical	Application	Mat	erial
Type	name	examples	Polycarbonate	Nylon
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×
Alkaline	Sodium hydroxide (Causfic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0
Inorganic salts	Sodium sulfide Sulfate of potash Sulfate of soda	_	×	Δ
Chlorine solvents	Officionin	Cleansing liquid for metals Printing ink Dilution	×	Δ
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×
Oil	Gasoline Kerosene	-	×	0
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ
O: Esse	entially safe. \triangle : Some	effects may occur. ×	: Effects v	vill occur.

When the above factors are present, or there is some doubt, use a metal bowl for safety.

∆ Caution

 Use a check valve (Series AKM) to prevent back flow of the lubricant when redirecting the air flow before the lubricator

Maintenance

∆Warning

- For the AL20-A type, replenish the lubricant after releasing the inlet pressure. Lubrication cannot take place under a pressurised condition.
- 2. Adjustment of the oil regulating valve for models from the AL20-A to AL40-A should be carried out manually. Turning it counterclockwise increases the dripping amount, and turning it clockwise reduces the dripping amount. The use of tools etc. can result in damage to the unit. From the fully closed position, three rotations will bring it to the fully open position. Please do not rotate it any further than this. Note that the numbered scale markings are guidelines for adjusting the position, and not indicators of the dripping amount.

∧Caution

 Check the dripping amount once a day.
 Drip failure can cause damage to the components that need lubrication.

Mounting/Adjustment

^Caution


 When the bowl is installed, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the bowl.







Construction


AL20-A





AL30-A, AL40-A





Component Parts

No.	Description	Material	Model	Colour		
1	Body	Aluminium die-cast	AL20-A to AL40-A	White		

Replacement Parts

No.	Description	Matarial	Part no.								
	Description	Material	AL20-A	AL30-A	AL40-A	AL40-06-A					
2	Sight dome assembly	Polycarbonate		AL20P-	080AS						
3	Lubrication plug assembly	_	AL22P-060AS	AL32P-060AS	AL42P-060AS						
4	Bumper retainer assembly	_	AL20P-030AS	AL30P-030AS	AL40P-030AS						
5	Bumper (assembly)	Synthetic resin	AL20P-040S	AL30P-040S	AL40F	P-040S					
6	Bowl seal	NBR	C2SFP-260S	C32FP-260S	C42FP-260S						
7	Bowl assembly Note)	Polycarbonate	C2SL-A	C3SL-A	C4SL-A						

Note) Bowl seal is included. Please contact SMC regarding the bowl assembly supply for psi and °F unit specifications.

AW+AL

AC

AF+AR

Attachment | AW+AFM | AF+AFM+AR





Series AL20-A to AL40-A

Dimensions

AL20-A

AL30-A to AL40-06-A





Applicable model		AL20-A								
Optional/Semi-standard specifications	With drain cock	Metal bowl	Metal bowl with drain cock	Metal bowl						
Dimensions	8	B	B	B						

Applicable model		AL30-A to AL40-06-A											
Optional/Semi-standard specifications	With drain cock	Metal bowl with level gauge	Metal bowl with drain cock	Metal bowl with level gauge, with drain cock	Drain cock with barb fitting								
Dimensions			B	B	Barb fitting Applicable tubing: T0604								

		Standard specifications									Optional specifications						
Model			Stant	uaru spec	ilications				Bracket mount								
	Р	Α	В	С	D	E	G	J	M	N	Q	R	S	Т	U		
AL20-A	1/8, 1/4	40	79.3	35.9	20	_	60	20	30	27	22	5.4	8.4	40	2.3		
AL30-A	1/4, 3/8	53	104.1	38.1	26.7	30	80	26.7	41	40	23	6.5	8	53	2.3		
AL40-A	1/4, 3/8, 1/2	70	136.1	39.8	35.5	38.4	110	35.5	50	54	26	8.5	10.5	70	2.3		
AL40-06-A	3/4	75	138.1	37.8	35.5	38.4	110	35.5	50	54	25	8.5	10.5	70	2.3		

	Semi-standard specifications											
Model	With drain cock With barb fitting		Metal bowl	Metal bowl with drain cock	Metal bowl with level gauge	Metal bowl with level gauge, with drain cock						
	В	В	В	В	В	В						
AL20-A	87.7	_	84.5	87.5	_	_						
AL30-A	115.1	123.6	104.1	117.6	124.1	137.6						
AL40-A	147.1	155.6	136.1	149.6	156.1	169.6						
AL40-06-A	149.1	157.6	138.1	151.6	158.1	171.6						



Modular Type Filter Regulators


Series AW

Filter Regulator Series AW	Model	Port size	Options
	AW20-A	1/8, 1/4	Bracket
	AW30-A	1/4, 3/8	Float type auto drain Round type
4	AW40-A	1/4, 3/8, 1/2	pressure gauge With set nut (for panel mount)*
P.63 to 72	AW40-0	6-A 3/4	* Mounting pitch is different from existing AW series.

Filter Regulator


AW20-A to AW40-A

Symbol Filter Regulator



• Integrated filter and regulator units save space and require less piping.

How to Order



- Option/Semi-standard: Select one each for a to i.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

 Example) AW30-03BG-1N-A

■ Made to Order

(Refer to page 71 for details.)

			0					
Symbol	Symbol Description							
		20	30	40				
	Rc	•	•	•				
Thread type N Note 1)	NPT	•	•	•				
F Note 2)	G	•	•	•				
+								
01	1/8	•	_	_				
02	1/4	•	•	•				
3 Port size 03	3/8	_	•	•				
04	1/2	_	_	•				
06	3/4		_	•				
— Witho	ut mounting option	•	•	•				
a Mounting B Note 4) With b	racket	•	•	•				
H With s	et nut (for panel mount)	•	•	•				
+								
₩ Witho	ut auto drain		•	•				
b Float type auto drain	ormally closed) Drain port is closed when pressure is not applied.							
4 Float type auto drain Witho C Note 5) N.C. (ND Note 6) N.O. (N	ormally open) Drain port is open when pressure is not applied.	_						
+								
	ut pressure gauge		•	•				
gauge Note 7) G Round	type pressure gauge (with limit indicator)	•	•	•				
IVI Round	type pressure gauge (with colour zone)			•				
+		1						
	0.7 MPa setting			•				
pressure 100 of 1 0.02 t	0.2 MPa setting			•				
a + +		1						
Polyca	arbonate bowl		•	•				
S S S S S S S S S S			•	•				
e Bowl Note 9) 6 Nylon			•	•				
	bowl with level gauge		•	•				
	owl guard		Note 10)	Note 10)				
6C With b	owl guard (Nylon bowl)		Note 10)	Note 10)				



Filter Regulator Series AW20-A to AW40-A



AW20-A

AW40-A

	_	_					0			
				Symbol	Description	Body size				
						20	30	40		
					With drain cock	•	•	•		
		f	Drain	. ■ Note 11)	Drain guide 1/8	•	_	_		
		port Note 14)	J	Drain guide 1/4		•	•			
				W Note 15)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_	•	•		
	ard			+						
	standard		Exhaust	_	Relieving type	•	•	•		
6	sta	g	mechanism	N	Non-relieving type	•	•	•		
	Semi			+						
	Se	h	Flow direction	_	Flow direction: Left to right	•	•	•		
		"	Flow direction	R	Flow direction: Right to left	•	•	•		
				+						
			Proceuro unit	_	Name plate, caution plate for bowl, and pressure gauge in imperial units: MPa	•	•	•		
	i Pressure u		riessure unit	Z Note 12)	Name plate, caution plate for bowl, and pressure gauge in imperial units: psi, °F	O Note 13)	O Note 13)	O Note 13)		

- Note 1) Drain guide is NPT1/8 (applicable to the AW20-A) and NPT1/4 (applicable to the AW30-A to AW40-A). The auto drain port comes with ø3/8" One-touch fitting (applicable to the AW30-A to AW40-A).
- Note 2) Drain guide is G1/8 (applicable to the AW20-A) and G1/4 (applicable to the AW30-A to AW40-A).
- Note 3) Option B, G, H, M are not assembled and supplied loose at the time of shipment.
- Note 4) Assembly of a bracket and set nuts Note 5) When pressure is not applied, condensate which does not start the auto drain
 - mechanism will be left in the bowl. Releasing the residual condensate before ending operations for the day is recommended.
- Note 6) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations.

N.C. type is recommended.

- Note 7) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.
- Note 8) Pressure can be set higher than the specification pressure in some cases, but use pressure within the specification range.
- Note 9) Refer to Chemical data on page 66 for chemical resistance of the bowl.
- Note 10) A bowl guard is provided as standard equipment (polycarbonate).

Note 11) Without a valve function

Note 12) For thread type: NPT.

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 13) O: For thread type: NPT only

Note 14) The combination of float type auto drain: C and D is not available.

Note 15) The combination of metal bowl: 2 and 8 is not available.

Standard Specifications

Model	AW20-A	AW30-A	AW40-A	AW40-06-A					
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4					
Pressure gauge port size			1/8	•					
Fluid		Air							
Ambient and fluid temperature		−5 to 60°C (with no freezing)							
Proof pressure		1.5 MPa							
Maximum operating pressure		1.0 MPa							
Set pressure range		0.05 to	0.7 MPa						
Nominal filtration rating		5	μm						
Drain capacity [cm³]	8	25	4	15					
Bowl material		Polyca	arbonate						
Bowl guard	Semi-standard (Steel)		Standard (Polycarbonate	e)					
Construction		Reliev	ring type						
Weight [kg]	0.21	0.41	0.75	0.81					

Series AW20-A to AW40-A

Options/Part No.

	Ontional anacific	actions		Mod	del		
	Optional specific	alions	AW20-A	AW30-A	AW40-A	AW40-06-A	
Bracket	assembly Note 1)		AR22P-270AS	AR32P-270AS	AR42P	-270AS	
Set nut			AR22P-260S	AR32P-260S	AR42F	P-260S	
	Round type Note 2)	Standard	G36-1	0-□01	G46-10-□01		
Pressure		0.02 to 0.2 MPa setting	G36-4	I-□01	G46-4-□01		
gauge	Round type Note 2)	Standard	G36-10	-□01-L	-□01-L		
	(with colour zone)	0.02 to 0.2 MPa setting	G36-4-	.□01-L	G46-4-□01-L		
	Note 3) Note 4)	N.C.	AD27-A	AD37-A	AD47-A		
Float typ	e auto drain	N.O.		AD38-A	AD4	18-A	

Semi-standard/Bowl Assembly Part No.

S	emi-stan	dard spe	cification	S			Mod	del							
Bowl material	Float type auto drain		Float type		Float type auto drain		Float type auto drain		Note 4) With drain guide	With barb fitting	With bowl guard	AW20-A	AW30-A	AW40-A	AW40-06-A
	N.C.	N.O.	_		•	0005.0.4									
-					_	C2SF-C-A	_		_						
Polycarbonate	•	_	_		•	AD27-C-A		_							
bowl		_	•	_	_	C2SF-J-A	C3SF-J-A	C4SF-J-A							
		_	_	•	_	_	C3SF-W-A	C4SF-W-A							
		_				C2SF-CJ-A	_		_						
	_	_	_	_	_	C2SF-6-A	C3SF-6-A	C4SI	=-6-A						
	_	_	_			C2SF-6C-A	_	_	_						
		_	_	_	_	AD27-6-A	AD37-6-A	AD47	7-6-A						
	_	•	_	_	_	_	AD38-6-A	AD48	3-6-A						
Nylon bowl	•	_				AD27-6C-A —		_							
	_	_	•	_	_	C2SF-6J-A	C3SF-6J-A	C4SF	-6J-A						
	_	_	_	•		_	C3SF-6W-A	C4SF	-6W-A						
	_	_		_		C2SF-6CJ-A	_	_	_						
	_	_	_	_	_	C2SF-2-A	C3SF-2-A	C4SI	2-A						
[•	_	_		_	AD27-2-A	AD37-2-A	AD47	7-2-A						
Metal bowl	_		_	_	_	_	AD38-2-A	AD48	3-2-A						
	_	_	•	_	_	C2SF-2J-A	C3SF-2J-A	C4SF	-2J-A						
	_	_	_	_	_	_	C3LF-8-A	C4LF	-8-A						
Metal bowl	•	_	_	_	_	— AD37-8-A		AD47	7-8-A						
with level gauge			_	_		_	AD38-8-A	AD48							
		_		_	_	_	C3LF-8J-A	C4LF-8J-A							

Note 1) Assembly of a bracket and set nuts



Note 2) \square in part numbers for a round pressure gauge indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. Please contact SMC regarding the connection thread NPT and pressure gauge supply for psi unit specifications.

Note 3) Minimum operating pressure: N.O. type-0.1 MPa; N.C. type-0.1 MPa (AD27-A) and 0.15 MPa (AD37-A/47-A).

Please consult with SMC separately for psi and °F unit display specifications.

Note 4) Please consult with SMC for details on drain piping to fit NPT or G port sizes.

The bowl assembly includes the bowl O-ring.

Be sure to read before handling. Refer to back cover for Safety Instructions, "Handling Precautions for SMC I Products" (M-E03-3) and the Operation Manual for F.R.L. Precautions.

Design/Selection

∕**∿ Warnin**a

- 1. Although exhaust of the residual pressure to the inlet side is possible when eliminating the inlet pressure, exhaust is not possible when the set pressure is 0.15 MPa or less. Use the regulator with backflow function.
- 2. The standard bowl for the air filter, filter regulator, and lubricator, as well as the sight dome for the lubricator are made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Effects of atmosphere of organic solvents and chemicals, and where these elements are likely to adhere to the equipment. Chemical data for substances causing degradation (Reference)

Typo	Chemical name	Application examples	Material		
Туре	Chemical name	Application examples	Polycarbonate	Nylon	
Acid	Hydrochloric acid Sulfuric acid, Phosphoric acid Chromic acid	Acid washing liquid for metals	Δ	×	
Alkaline	Sodium hydroxide (Caustic soda) Potash Calcium hydroxide (Slack lime) Ammonia water Carbonate of soda	Degreasing of metals Industrial salts Water-soluble cutting oil	×	0	
Inorganic salts	Sodium sulfide Sulfate of potash Sulfate of soda		×	Δ	
Chlorine solvents	Carbon tetrachloride Chloroform Ethylene chloride Methylene chloride	Cleansing liquid for metals Printing ink Dilution	×	Δ	
Aromatic series	Benzene Toluene Paint thinner	Coatings Dry cleaning	×	Δ	
Ketone	Acetone Methyl ethyl ketone Cyclohexane	Photographic film Dry cleaning Textile industries	×	×	
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×	
Oil	Gasoline Kerosene	_	×	0	
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0	
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0	
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×	
Others	Thread-lock fluid Seawater Leak tester	_	×	Δ	

When the above factors are present, or there is some doubt, use a metal bowl for safety.

Maintenance

∕!\ Warning

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

Mounting/Adjustment

∕**!\ Warnin**g

- 1. Set the regulator while verifying the displayed values of the inlet and outlet pressure gauges. Turning the regulator knob excessively can cause damage to the internal parts.
- 2. Do not use tools on the pressure regulator knob as this may cause damage. It must be operated manually.

Mounting/Adjustment

∖ Caution

- 1. Be sure to unlock the knob before adjusting the pressure and lock it after setting the pressure. Failure to follow this procedure can cause damage to the knob and the outlet pressure may fluctuate.
 - · Pull the pressure regulator knob to unlock. (You can visually verify this with the "orange mark" that appears in the gap.)
 - · Push the pressure regulator knob to lock. When the knob is not easily locked, turn it left and right a little and then push it (when the knob is locked, the "orange mark", i.e., the gap will disappear).
- 2. Pulsation will be generated when the difference between the inlet and the outlet pressure is large. In this case, reduce the pressure difference between the inlet and the outlet. Please consult with SMC if the pulsation problem is not resolved.
- 3. When the bowl is installed, install them so that the lock button lines up to the groove of the front (or the back) of the body to avoid drop or damage of the howl





AF+AR+AL AW+AL

AF+AR


AF+AFM+AR


Attachment | AW+AFM


Series AW20-A to AW40-A

Flow-rate Characteristics (Representative values)

Condition: Inlet pressure 0.7 MPa










Pressure Characteristics (Representative values)

Conditions: Inlet pressure 0.7 MPa, Outlet pressure 0.2 MPa, Flow rate 20 L/min [ANR]









Filter Regulator Series AW20-A to AW40-A

Construction

AW20-A



AW30-A to AW40-06-A



Component Parts

No.	Description	Material	Colour		
1	Body	Aluminium die-cast	White		
2	Bonnet	Polyacetal	White		

Replacement Parts


No	No. Description	Material	Part no.								
INO.		Material	AW20-A	AW30-A	AW40-A	AW40-06-A					
3	Valve assembly	Stainless steel, HNBR	AW22P-060AS	AW32P-060AS	AW42P-060AS						
4	Filter element	Non-woven fabric	AF20P-060S	AF30P-060S	AF40P-060S						
5	Diaphragm assembly	Weatherable NBR	AR22P-150AS	AR32P-150AS	AR42P	-150AS					
6	Bowl seal	NBR	C2SFP-260S	C32FP-260S	C42FP-260S						
7	Bowl assembly Note)	Polycarbonate	C2SF-A	C3SF-A	C4SF-A						


Note) Bowl seal is included. Please contact SMC regarding the bowl assembly supply for psi and $^{\circ}F$ unit specifications.

Series AW20-A to AW40-A

Dimensions

AW20-A





Bracket (Option) т D J U N S œ ď OUT Pressure gauge В (Option) 2 x **P**1 (Port size) Ε Clearance for maintenance Drain G Panel fitting dimension 2 x **P**2 (Pressure gauge OUT port size)

Panel fitting dimension





Plate thickness AW20-A: Max.4

Plate thickness AW30-A to AW40-06-A: MAX.8

AW30-A to AW40-06-A

Applicable model		AW2	20-A		AW30-A to AW40-06-A		
Optional/Semi-standard specifications	With auto drain (N.C.)	With drain guide	Metal bowl	Metal bowl with drain guide	With auto drain (N.O./N.C.)		
Dimensions	M5 x 0.8	1/8 Width across flats 14	a a	Width across flats 14	N.O.: Black N.C.: Grey Thread type/Rc,G: ø10 One-touch fitting Thread type/NPT: ø3/8" One-touch fitting		



Model		Standard specifications									Optional specifications Round type pressure gauge (with colour zone)			
	P1	P2	Α	В	CNote)	D	Е	F	G	J	Н	J	Н	J
AW20-A	1/8, 1/4	1/8	40	87.6	67.4	22	_	M36 x 1.5	25	22	ø37.5	58.5	ø37.5	59.5
AW30-A	1/4, 3/8	1/8	53	115.1	83.5	28.5	30	M45 x 1.5	35	28.5	ø37.5	65	ø37.5	66
AW40-A	1/4, 3/8, 1/2	1/8	70	147.1	100	34.5	38.4	M52 x 1.5	40	34.5	ø42.5	72	ø42.5	72
AW40-06-A	3/4	1/8	75	149.1	101.5	34.5	38.4	M52 x 1.5	40	34.5	ø42.5	72	ø42.5	72

	Optional specifications											Semi-standard specifications						
Model			Brac	ket m	ount				Panel	moun	t	With auto drain	With barb fitting	With drain guide	Metal bowl	Metal bowl with drain guide	Metal bowl with level gauge	Metal bowl with level gauge, with drain guide
	M	N	Q	R	S	Т	U	٧	W	Υ	Z	В	В	В	В	В	В	В
AW20-A	30	34	43.9	5.4	15.4	55	2.3	27.3	36.5	17.5	6	104.9	_	91.4	87.4	93.9	_	_
AW30-A	41	36	46	6.5	24	65	2.3	32.5	45.5	22.5	7	156.8	123.6	121.9	117.6	122.1	137.6	142.1
AW40-A	50	38	54	8.5	26.5	70	2.3	38.4	52.5	26	7	186.9	155.6	153.9	149.6	154.1	169.6	174.1
AW40-06-A	50	38	55.5	8.5	26.5	70	2.3	39.9	52.5	26	7	188.9	157.6	155.9	151.6	156.1	171.6	176.1





Filter Regulator/AW20-A to AW40-A Made to Order



Please contact SMC for detailed dimensions, specifications, and lead times.

1 0.4 MPa Setting

The maximum set pressure is 0.4 MPa. When a pressure gauge is included, the display will show a range from 0 to 0.7 MPa.

Specifications

Proof pressure	1.5 MPa
Maximum operating pressure	1.0 MPa
Set pressure range	0.05 to 0.4 MPa

Applicable Model

Model	AW20-A	AW30-A	AW40-A	AW40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4

2 Long Bowl


Drain capacity is greater than that of standard models.

Applicable Model/Drain Capacity

Model	AW20-A	AW30-A	AW40-A	AW40-06-A
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4
Drain capacity (cm ³)	19	43	8	88

Note) Please consult with SMC for dimensions.

How to Order



Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) AW30-03BG-2N-A-X406						MPa Set	ting	Long Bowl			
	Symbol					0		Body size			
				Description		Body size					
					20	30 40		20	30	40	
			_	Rc	•	•	•		•	•	
2	Thread type		N Note 1)	NPT	•	•	•		•	•	
		F Note 2)	G	•	•	•		•	•		
			+								
			01	1/8		_	_		_	_	
	Port size		02	1/4							
3			03	3/8	_		•	_			
			04	1/2	_	_		_	_		
			06	3/4	_	_			_	•	
			+								
			_	Without mounting option		•					
	а	Mounting	B Note 4)	With bracket		•				•	
			Н	With set nut (for panel mount)	•					•	
			+					,			
ote 3)		Float type	_	Without auto drain	•	•		_	_	_	
ع 4	b	auto drain	C Note 5)	r loat typo dato drain (14.0.)	•			_	_	_	
4 Option Note			D Note 6)	Float type auto drain (N.O.)						_	
0	"		+								
				Without pressure gauge	•	•			•	•	
	С	Pressure gauge	G	Round type pressure gauge (with limit indicator)	•	•		Note 7)	Note 7)	Note	
			M	Round type pressure gauge (with colour zone)				Note 7)	Note 7)	Note	

Note 1) Drain guide is NPT1/8 (applicable to the AW20-A) and NPT1/4 (applicable to the AW30-A to AW40-A).

The auto drain port comes with ø3/8" One-touch fitting (applicable to the AW30-A to AW40-A).

Note 2) Drain guide is G1/8 (applicable to the AW20-A) and G1/4 (applicable to the AW30-A to AW40-A).

Note 3) Option B, G, H, M are not assembled and supplied loose at the time of shipment. Note 4) Assembly of a bracket and set nuts

Note 5) When pressure is not applied, condensate which does not start the auto drain mechanism will be left in the bowl.

Releasing the residual condensate before ending operations for the day is recommended.

Note 6) If the compressor is small (0.75 kW, discharge flow is less than 100 L/min[ANR]), air leakage from the drain cock may occur during start of operations. N.C. type is recommended.

Note 7) When the pressure gauge is attached, a 1.0 MPa pressure gauge will be fitted for standard (0.7 MPa) type. 0.4 MPa pressure gauge for 0.2 MPa type.



Filter Regulator Series AW20-A to AW40-A

					0.4	MPa Set	tting	L	ong Bo	wl
Si		Symbol	Description		0		0			
			Symbol	Description	Body size 20 30		40	20	Body size 20 30	
		Set	_	0.05 to 0.7 MPa setting	_	_	_		•	
	d	pressure Note 8)	1	0.02 to 0.2 MPa setting	_	_	_	•	•	•
			+							
		Bowl Note 9)	_	Polycarbonate bowl		•	•	•	•	•
			2	Metal bowl	•	•	•	•	•	•
			6	Nylon bowl	•	•	•	•	•	•
	е		8	Metal bowl with level gauge	_	•	•	_	_	_
			С	With bowl guard		_	_		_	_
			6C	With bowl guard (Nylon bowl)		_	_		_	_
p			+							
lg			—	With drain cock						
Semi-standard	f	Note 10) Drain port	. Note 11)	Drain guide 1/8		_	_		_	_
Ë	•	Diaili port	J	Drain guide 1/4	_			_		•
Se			W Note 12)	Drain cock with barb fitting (for ø6 x ø4 nylon tube)	_			_		•
			+							
	g	Exhaust	_	Relieving type						•
	9	mechanism	N	Non-relieving type						•
			+							
	h	Flow direction		Flow direction: Left to right		•			•	•
	•••	1 low direction	R	Flow direction: Right to left						
	_		+							
	i	Pressure unit		Name plate and caution plate for bowl in imperial units: MPa		•			•	•
		- 1000uic uiil	Z Note 13)	Name plate and caution plate for bowl in imperial units: psi, °F	Note 14)	Note 14)	Note 14)	Note 14)	O Note 14)	Note

Note 9) Refer to Chemical data on page 66 for chemical resistance of the bowl.

Note 10) The combination of float type auto drain: C and D is not available. Note 11) Without a valve function

Note 12) The combination of metal bowl: 2 and 8 is not available.

Note 13) For thread type: NPT.

Cannot be used with M: Round pressure gauge (with colour zone). Available by request for special.

Note 14) \bigcirc : For thread type: NPT only

⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk Caution: which, if not avoided, could result in minor or moderate injury.

Warning indicates a hazard with a medium level of Warning: risk which, if not avoided, could result in death or serious injury.

⚠ Danger :

Danger indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

*1) ISO 4414: Pneumatic fluid power - General rules relating to systems. ISO 4413: Hydraulic fluid power – General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements)

ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered.*2)
 - Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
 - *2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

☎+43 (0)2262622800 www.smc.at Austria office@smc.at Belaium www.smcpneumatics.be info@smconeumatics.be Bulgaria **2** +359 (0)2807670 office@smc.bg www.smc.bg Croatia *****+385 (0)13707288 office@smc.hr www.smc.hr Czech Republic **2** +420 541424611 www.smc.cz office@smc.cz Denmark ★+45 70252900 www.smcdk.com smc@smcdk.com smc@smcpneumatics.ee Estonia ***** +372 6510370 www.smcpneumatics.ee Finland **2** +358 207513513 www.smc.fi smcfi@smc.fi France **1** +33 (0)164761000 www.smc-france.fr promotion@smc-france.fr Germany **2** +49 (0)61034020 www.smc-pneumatik.de info@smc-pneumatik.de Greece **2** +30 210 2717265 www.smchellas.gr sales@smchellas.gr Hungary ***** +36 23511390 www.smc.hu office@smc.hu Ireland **2** +353 (0)14039000 www.smcpneumatics.ie sales@smcpneumatics.ie Turkey Italy **☎**+39 0292711 mailbox@smcitalia.it www.smcitalia.it UK Latvia **2**+371 67817700 www.smclv.lv info@smclv.lv

Lithuania **2** +370 5 2308118 Netherlands Norway **2** +47 67129020 Poland **Portugal** Romania Russia Slovakia Slovenia Spain Sweden Switzerland

2 +31 (0)205318888 **2** +48 (0)222119616 **2**+351 226166570 **2** +40 213205111 **2** +7 8127185445 2 +421 (0)413213212 www.smc.sk ***** +386 (0)73885412 ***** +34 902184100 **2** +46 (0)86031200 www.smc.nu **2** +41 (0)523963131 www.smc.ch **2** +90 212 489 0 440 www.smcpnomatik.com.tr ****** +44 (0)845 121 5122 www.smcpneumatics.co.uk sales@smcpneumatics.co.uk

www.smclt.lt www.smcpneumatics.nl www.smc-norge.no www.smc.nl www.smc.eu www.smcromania.ro www.smc-pneumatik.ru www.smc.si www.smc.eu

info@smclt.lt info@smcpneumatics.nl post@smc-norge.no office@smc.pl postpt@smc.smces.es smcromania@smcromania.ro info@smc-pneumatik.ru office@smc.sk office@smc.si post@smc.smces.es nost@smc.nu info@smc.ch

info@smcpnomatik.com.tr

SMC CORPORATION Akihabara UDX 15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN Phone: 03-5207-8249 FAX: 03-5298-5362