





Manufacturer data sheet: V1.074

Monitoring relay - current monitoring 1-phase

Status: Available Data sheet created: 01.07.2025

Item Number: 1340203 - Serie: Enya - EAN: 9008662014220



~	Monitoring relay series ENYA
~	Current monitoring 1-phase
~	Multifunction
~	Measuring range 1A
~	Measuring voltage = supply voltage
~	Supply voltage 230V AC
~	1 changeover contact
~	width 17.5mm
~	Installation type

Description

AC current monitoring in 1-phase mains with adjustable thresholds, adjustable hysteresis, adjustable tripping delay.

General information Short description Current monitoring 1-phase, 1A, multifunction, 1 changeover contact, 230V AC Item Number 1340203 EAN 9008662014220 Main category Monitoring Relays Series Enya E1IM1AACL10 230V AC Туре Design Installation design Supply 230V AC 17.5 x 87 x 65 mm Dimensions

MONITORING RELAYS


 ϵ


Manufacturer data sheet: V1.074


Functions and measurands

Amount of functions

3







Overcurrent monitoring (OVER, OVER+Latch)

When the supply voltage U is applied, the output relay R switches into on-position, if the measured current is below the Max-value. When the measured current exceeds the Max-value, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired. OVER: The output relay R switches into on-position again, if the current falls below the Min-value. OVER+Latch: The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage, provided that the measured current is below the Max-value.

Window function (WIN, WIN+Latch)

When the supply voltage U is applied, the output relay R switches into on-position, if the measured current is within the adjusted window. When the measured current leaves the window between Min and Max, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired. WIN: The output relay R switches into on-position again, if the current re-enter the adjusted window. WIN+Latch: The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage, provided that the measured current is within the threshold values.

Untercurrent monitoring (UNDER, UNDER+Latch)

When the supply voltage U is applied, the output relay R switches into on-position, if the measured current is beyond the Min-value. When the measured current falls below the Min-value, the output relay R switches into off-position after the interval of the tripping delay (Delay) has expired. UNDER: The output relay R switches into on-position again, if the current exceeds the Max-value. UNDER+Latch: The output relay R switches only into on-position again by interrupting and re-applying of the supply voltage, provided that the measured current is beyond the Min-value.

Time ranges		
Number Of Areas	1	
	Setting range	
Time ranges	Start-up delay (Start)	-
	Shutter delay (Delay)	0,1 10s

Indicators	
Supply/time lapse 1	Green LED U ON: Supply voltage applied
Relay state	Yellow LED ON/OFF: output relay position
Error / monitoring function	Red LED ON/OFF: Display error for corresponding threshold
Error / monitoring function	Red LED flashes: Indication of tripping delay for corresponding threshold



 ϵ

Manufacturer data sheet: V1.074

ousing material	made of self-extinguishing plastic
	0 0,
lousing - protection degree	IP40
lounting	top hat rail TH 35 7,5-15 according to IEC 60715:2017 / EN 60715:2017
erminals/connections	Touch-proof clamping yoke terminals according to DGUV 3 (Screwdriver PZ1 required)
erminals - protection degree	IP20
Nounting position	any
lax. Tightening Torque	1 Nm
	1 x 0.5 to 2.5mm² with/without ferrule
	• 1 x 4mm² without wire end ferrule
erminal capacity	• 2 x 0.5 to 1.5mm ² with/without end sleeves
	• 2 x 2.5mm² flexible without ferrules

Supply circuit	
Terminals/connections	Li-N
Supply voltage a.c.	230 V
Supply voltage tolerance a.c.	-15% +15% Un
Rated frequency [Hz]	a.c. 48 63 Hz
Rated consumption a.c.	0,8 W / 5 VA
Duty cycle	100 %
Recovery time	500 ms
Drop-out voltage	>20% of the nominal voltage
Overvoltage category	III (IEC 60664-1)
Rated surge voltage	4 kV
Rated impulse withstand voltage	300 V

Output curcuit	
Туре	Relay
Contact 1	1 changeover contact
Terminals 1	15-16-18
Rated voltage	250 V a.c.
Switching Capacity 1	1250 VA (5 A/250 V a.c.)
Fuse Protection	5 A quick
Mechanical life	15 x 10 ⁶ Switching cycles
Electrical life	1×10^{5} Switching cycles at 5A, 250V a.c. (according to EN 61810-1)
Electrical life 2	1×10^{5} at 5 A, 240 V a.c. (according to UL 508)
Switching frequency	max. 6/min at 1250 VA
Rated surge voltage	4 kV
Overvoltage category	III (according to IEC 60664-1)

 ϵ

Manufacturer data sheet: V1.074

Measurand	Current - one phase
Measuring range	1 A a.c.
Terminals/connections	Li-Lk
Overload capacity	2 A
Pulse load	1 s 10 A, 3 s 5 A
Input resistance	47 m ⁻
Frequency - sinusoidal	48 63 Hz
Switching threshold minimum	5% 95% of In
Switching threshold maximum	10% 100% of In
Rated surge voltage	4 kV
Overvoltage category	III (nach IEC 60664-1)

Λ			2	
\neg	u	.u	ıa	LV.
				-

Base accuracy	≤5 %
Adjustment accuracy	±5 %
Repetition accuracy	≤2 %
Temperature influence	≤0.1 % / °C

Ambient conditions and general specifications

Ambient temperature IEC	-25 +55 °C
Storage temperature	-25 +70 °C
Transport temperature	-25 +70 °C
Relative humidity	15% 85% (in accordance with IEC 60721-3-3 class 3K3)
Pollution degree	2, pollution level can be increased by installation in suitable enclosures (according to IEC 60664-1)

Logistics

Minimum Quantity	1
Tariff Number	85364900
EAN	9008662014220
Country of Origin	AT
Product Weight (g)	72

Available declarations / conformities

EAC	✓
CE	✓
REACH	Open document
WEEE	Open document
TSCA	Open document
RoHs	Open document
CMRT	<u>Open document</u>

CAD Files

STEP_E1_en.STEP Download file





(E


Manufacturer data sheet: V1.074

Media & drawings









Dimensions

Tele Haase Steuergeräte Ges.m.b.H Vorarlberger Allee 38

1230 Vienna Austria

CALL US



+43 / 1 / 614 74 - 0





? support@tele-haase.at

Changes and errors excepted

